

InteliLite 9

Controller for single gen-set applications

SW version 1.1.0

1 Document information	6
2 System overview	11
3 Applications overview	16
4 Installation and wiring	18
5 Controller setup	45
6 Communication	111
7 Technical data	137
8 Appendix	139

Table of contents

1 Document information	6
1.1 Clarification of notation	6
1.2 About this Global Guide	6
1.3 Legal notice	6
1.4 General warnings	8
1.4.1 Remote control and programing	8
1.4.2 SW and HW versions compatibility	8
1.4.3 Dangerous voltage	8
1.4.4 Adjust the setpoints	8
1.5 Certifications and standards	9
1.6 Document history	9
1.7 Symbols in this manual	10
2 System overview	11
2.1 General description	11
2.1.1 The key features of IntelliLite 9	11
2.2 True RMS measurement	11
2.3 Configurability and monitoring	11
2.3.1 Supported configuration and monitoring tools	12
2.3.2 Configuration parts	12
2.4 PC Tools	13
2.4.1 IntelliConfig	13
2.4.2 WinScope	13
2.5 Plug-in Modules	14
2.5.1 CM-Ethernet	14
2.5.2 CM-4G-GPS	14
2.5.3 CM-GPRS	15
2.5.4 CM-RS232-485	15
2.5.5 EM-BIO8-EFCP	15
3 Applications overview	16
3.1 AMF - Automatic Mains Failure Start	16
3.2 MRS - Manual Remote Start	16
4 Installation and wiring	18
4.1 Package content	18
4.2 Controller installation	18
4.2.1 Dimensions	18

4.2.2 Mounting	19
4.3 Terminal Diagram	20
4.4 Recommended wiring	21
4.4.1 General	22
4.4.2 Grounding	22
4.4.3 Power supply	22
4.4.4 Measurement wiring	23
4.4.5 Magnetic pick-up	30
4.4.6 Binary inputs	32
4.4.7 Binary Outputs	33
4.4.8 E-Stop	34
4.4.9 Analog inputs	34
4.4.10 CAN bus	38
4.4.11 USB	40
4.4.12 Example of AMF Wiring	41
4.4.13 Example of MRS Wiring	42
4.5 Plug-in module installation	43
4.5.1 Installation	43
5 Controller setup	45
5.1 Default configuration	45
5.1.1 Binary inputs AMF	45
5.1.2 Binary outputs AMF	45
5.1.3 Binary inputs MRS	45
5.1.4 Binary outputs MRS	46
5.1.5 Analog inputs	46
5.2 Controller configuration and PC tools connection	46
5.2.1 USB	46
5.2.2 RS232/RS485	47
5.2.3 Ethernet	49
5.3 Operator Guide	50
5.3.1 Front panel elements	51
5.3.2 Display screens and pages structure	52
5.3.3 Browsing alarms	65
5.3.4 Password	66
5.3.5 Information screen	72
5.3.6 Language selection	73
5.3.7 Display contrast adjustment	74
5.4 Functions	74
5.4.1 Start-stop sequence	75

5.4.2 AMF sequence	77
5.4.3 Operating Modes	78
5.4.4 Engine start	79
5.4.5 Stabilization	81
5.4.6 Connecting to load	81
5.4.7 MRS operation	81
5.4.8 AMF operation	81
5.4.9 Engine cool down and stop	82
5.4.10 Alarm management	83
5.4.11 History log	89
5.4.12 Breaker control	90
5.4.13 Exercise timer	93
5.4.14 Service timers	99
5.4.15 Flowchart	101
5.4.16 Additional running engine indications	102
5.4.17 Voltage phase sequence detection	102
5.4.18 Gen-set operation states	102
5.4.19 Sensor curves	105
5.4.20 Tier 4 Final	105
5.4.21 Alternate configuration	108
5.4.22 E-Stop	109
5.4.23 ECU Frequency selection	110
6 Communication	111
6.1 PC	111
6.1.1 Direct communication	111
6.1.2 Remote communication	113
6.2 Connection to 3rd party systems	124
6.2.1 MODBUS-RTU, MODBUS/TCP	124
7 Technical data	137
8 Appendix	139
8.1 Controller objects	140
8.1.1 Setpoints	141
8.1.2 Values	258
8.1.3 Logical binary inputs	293
8.1.4 Logical binary outputs	314
8.1.5 Logical analog inputs	348
8.2 Alarms	356

8.2.1 Alarms level 1	356
8.2.2 Alarms level 2	372
8.2.3 Fail sensor and other types	385
8.3 Modules	388
8.3.1 Plug-In modules	389

1 Document information

1.1 Clarification of notation	6
1.2 About this Global Guide	6
1.3 Legal notice	6
1.4 General warnings	8
1.5 Certifications and standards	9
1.6 Document history	9
1.7 Symbols in this manual	10

 [back to Table of contents](#)

1.1 Clarification of notation

Note: This type of paragraph calls readers attention to a notice or related theme.

IMPORTANT: This type of paragraph highlights a procedure, adjustment etc., which can cause a damage or improper function of the equipment if not performed correctly and may not be clear at first sight.

Example: This type of paragraph contains information that is used to illustrate how a specific function works.

1.2 About this Global Guide

This manual contains important instructions for IntelliLite 9 controllers family that shall be followed during installation and maintenance of the controllers.

This manual provides general information how to install and operate IntelliLite 9 controllers.

This manual is dedicated for:

- ▶ Operators of gen-sets
- ▶ Gen-set control panel builders
- ▶ For everybody who is concerned with installation, operation and maintenance of the gen-set

1.3 Legal notice

This End User's Guide/Manual as part of the Documentation is an inseparable part of ComAp's Product and may be used exclusively according to the conditions defined in the "END USER or Distributor LICENSE AGREEMENT CONDITIONS – COMAP CONTROL SYSTEMS SOFTWARE" (License Agreement) and/or in the "ComAp a.s. Global terms and conditions for sale of Products and provision of Services" (Terms) and/or in the "Standardní podmínky projektů komplexního řešení ke smlouvě o dílo, Standard Conditions for Supply of Complete Solutions" (Conditions) as applicable.

ComAp's License Agreement is governed by the Czech Civil Code 89/2012 Col., by the Authorship Act 121/2000 Col., by international treaties and by other relevant legal documents regulating protection of the intellectual properties (TRIPS).

The End User and/or ComAp's Distributor shall only be permitted to use this End User's Guide/Manual with ComAp Control System Registered Products. The Documentation is not intended and applicable for any other purpose.

Official version of the ComAp's End User's Guide/Manual is the version published in English. ComAp reserves the right to update this End User's Guide/Manual at any time. ComAp does not assume any responsibility for its use outside of the scope of the Terms or the Conditions and the License Agreement.

Licensed End User is entitled to make only necessary number of copies of the End User's Guide/Manual. Any translation of this End User's Guide/Manual without the prior written consent of ComAp is expressly prohibited!

Even if the prior written consent from ComAp is acquired, ComAp does not take any responsibility for the content, trustworthiness and quality of any such translation. ComAp will deem a translation equal to this End User's Guide/Manual only if it agrees to verify such translation. The terms and conditions of such verification must be agreed in the written form and in advance.

For more details relating to the Ownership, Extent of Permitted Reproductions Term of Use of the Documentation and to the Confidentiality rules please review and comply with the ComAp's License Agreement, Terms and Conditions available on www.comap-control.com.

Security Risk Disclaimer

Pay attention to the following recommendations and measures to increase the level of security of ComAp products and services.

Please note that possible cyber-attacks cannot be fully avoided by the below mentioned recommendations and set of measures already performed by ComAp, but by following them the cyber-attacks can be considerably reduced and thereby to reduce the risk of damage. ComAp does not take any responsibility for the actions of persons responsible for cyber-attacks, nor for any damage caused by the cyber-attack. However, ComAp is prepared to provide technical support to resolve problems arising from such actions, including but not limited to restoring settings prior to the cyber-attacks, backing up data, recommending other preventive measures against any further attacks.

Warning: Some forms of technical support may be provided against payment. There is no legal or factual entitlement for technical services provided in connection to resolving problems arising from cyber-attack or other unauthorized accesses to ComAp's Products or Services.

General security recommendations and set of measures

1. AccessCode

- Change the AccessCode BEFORE the device is connected to a network.
- Use a secure AccessCode – ideally a random string of 8 characters containing lowercase, uppercase letters and digits.
- For each device use a different AccessCode.

2. Password

- Change the password BEFORE the device enters a regular operation.
- Do not leave displays or PC tools unattended if an user, especially administrator, is logged in.

3. Controller Web interface

- The controller web interface at port TCP/80 is based on http, not https, and thus it is intended to be used only in closed private network infrastructures.
- Avoid exposing the port TCP/80 to the public Internet.

4. MODBUS/TCP

- The MODBUS/TCP protocol (port TCP/502) is an instrumentation protocol designed to exchange data between locally connected devices like sensors, I/O modules, controllers etc. From it's nature it does not

contain any kind of security – neither encryption nor authentication. Thus it is intended to be used only in closed private network infrastructures.

- Avoid exposing the port TCP/502 to the public Internet.

5. SNMP

- The SNMP protocol (port UDP/161) version 1,2 is not encrypted. Thus it is intended to be used only in closed private network infrastructures.
- Avoid exposing the port UDP/161 to the public Internet.

Used Open Source Software: mBed-TLS

<https://www.mbed.com/en/development/software/mbed-tls/>

<http://www.apache.org/licenses/LICENSE-2.0>

1.4 General warnings

1.4.1 Remote control and programming

Controller can be remotely controlled. In the event that maintenance of gen-set has to be done, or controller has to be programmed, check the following points to ensure that the engine cannot be started or any other parts of the system cannot be effected.

To be sure:

- ▶ Disconnect remote control
- ▶ Disconnected binary outputs

1.4.2 SW and HW versions compatibility

Be aware to use proper combination of SW and HW versions.

1.4.3 Dangerous voltage

In no case touch the terminals for voltage and current measurement!

Always connect grounding terminals!

In any case do not disconnect controller CT terminals!



1.4.4 Adjust the setpoints

All parameters are adjusted to their typical values. However the setpoints has to be checked and adjusted to their real values before the first starting of the gen-set.


IMPORTANT: Wrong adjustment of setpoints can destroy the gen-set.

***Note:** The controller contains a large number of configurable setpoints, because of this it is impossible to describe all of its functions. Some functions can be changed or have different behavior in different SW versions. Always check the Global guide and New feature list for SW version which is used in controller. This manual only describes the product and is not guaranteed to be set for your application.*

IMPORTANT: Be aware that the binary outputs can change state during and after software reprogramming (before the controller is used again ensure that the proper configuration and setpoint settings are set in the controller).

The following instructions are for qualified personnel only. To avoid personal injury do not perform any action not specified in related guides for product.

1.5 Certifications and standards

<ul style="list-style-type: none"> ▶ EN 61000-6-2 ▶ EN 61000-6-4 ▶ EN 61010-1 ▶ EN 60068-2-1 (-20 °C/16 h for std, -40 °C/16 h for LT version) ▶ EN 60068-2-2 (70 °C/16 h) ▶ EN 60068-2-6 (2÷25 Hz / ±1,6 mm; 25÷100 Hz / 4,0 g) ▶ EN 60068-2-27 (a=500 m/s²; T=6 ms) ▶ EN 60068-2-30:2005 25/55°C, RH 95%, 48hours ▶ EN 60529 (front panel IP65, back side IP20) 	
---	--

1.6 Document history

Revision number	Related sw. version	Date	Author
2	1.1.0	12.9.2018	Michal Slavata
1	1.0.0	2.11.2017	Daniel Švanda

1.7 Symbols in this manual

	3 x Phases		Connector - male		Grounding		Resistor adjustable
	Active current sensor		Contact		GSM		Resistive sensor RPTC
	AirGate		Contactor		GSM modem		RS 232 male
	Alternating current		Controller simplified		IG-AVRi		RS 232 female
	Analog modem		Module simplified		IG-AVRi TRANS		Starter
	Battery		Current measuring		Jumper		Switch - manually operated
	Binary output		Current measuring		Load		Transformer
	Breaker contact		Diode		Mains		USB type B male
	Breaker contact		Ethernet male		Mains		USB type B female
	Breaker		Ethernet female		Mobile provider		Voltage measuring
	Breaker		Fuel solenoid		Passive current sensor		Wifi / WAN / LAN
	Capacitor		Fuse		Pick - up		back to Document information
	Coil		Fuse switch		Relay coil		
	Connector - female		Generator		Relay coil of slow-operating		
			Generator schematic		Resistor		

2 System overview

2.1 General description	11
2.2 True RMS measurement	11
2.3 Configurability and monitoring	11
2.4 PC Tools	13
2.5 Plug-in Modules	14

[◀ back to Table of contents](#)

2.1 General description

InteliLite 9 Family controllers are comprehensive gen-set controllers for single gen-sets operating in stand-by (MRS) or back-up (AMF) applications. A modular construction allows upgrades to different levels of complexity in order to provide the best solution for various customer applications. The controllers are equipped with a powerful graphic display showing icons, symbols and bar graphs for intuitive operation, which, together with its high level of functionality, sets new standards in Gen-set controls.

2.1.1 The key features of InteliLite 9

- ▶ Easy-to-use operation and installation. The factory default configuration covers most applications
- ▶ Various customizations are possible thanks to its configurability
- ▶ Excellent remote communication capabilities
- ▶ High level of support for EFI engines (most world producers)
- ▶ High reliability

2.2 True RMS measurement

This controller measures AC values based on True RMS principle. This principle corresponds exactly to the physical definition of alternating voltage effective values. Under normal circumstances the mains voltage should have a pure sinusoidal waveform. However some nonlinear elements connected to the mains produce harmonic waveforms with frequencies of multiples of the basic mains frequency and this may result in deformation of the voltage waveforms. The True RMS measurement gives accurate readings of effective values not only for pure sinusoidal waveforms, but also for deformed waveforms.

Note: *The harmonic deformation causes that the Power Factor of a generator working parallel with the mains cannot reach values in a certain range around the PF 1.00. The higher the deformation, the wider the power factor dead range. If the requested power factor is adjusted inside the dead range, the controller cannot reach the requested value because of this fact.*

2.3 Configurability and monitoring

One of the key features of the controller is the system's high level of adaptability to the needs of each individual application and wide possibilities for monitoring. This can be achieved by configuring and using the powerful PC/mobile tools.

2.3.1 Supported configuration and monitoring tools

- ▶ IntelliConfig - complete configuration and single gen-set monitoring
- ▶ WinScope - special graphical monitoring software

Note: Use the IntelliConfig PC software to read, view and modify configuration from the controller or disk and write the new configuration to the controller or disk.

The firmware of controller contains a large number of binary inputs and outputs needed for all necessary functions available. However, not all functions are required at the same time on the same gen-set and also the controller hardware does not have so many input and output terminals. One of the main tasks of the configuration is mapping of “logical” firmware inputs and outputs to the “physical” hardware inputs and outputs.

2.3.2 Configuration parts

- ▶ Mapping of logical binary inputs (functions) or assigning alarms to physical binary input terminals
- ▶ Mapping of logical binary outputs (functions) to physical binary output terminals
- ▶ Assigning sensor characteristics (curves) and alarms to analog inputs
- ▶ Selection of peripheral modules, which are connected to the controller, and doing the same (as mentioned above) for them
- ▶ Selection of ECU type, if an ECU is connected
- ▶ Changing the language of the controller interface




Image 2.1 Principle of binary inputs and outputs configuration

The controller is shipped with a default configuration, which should be suitable for most standard applications. This default configuration can be changed only by using a PC with the IntelliConfig software. See IntelliConfig documentation for details.

Once the configuration is modified, it can be saved to a file for later usage with another controller or for backup purposes. The file is called archive and has the file extension .ail3. An archive contains a full image of the controller at the time of saving (if the controller is online for the PC) except the firmware. Besides configuration it also contains current adjustment of all setpoints, all measured values, a copy of the history log and a copy of the alarm list.

The archive can be simply used for cloning controllers, i.e. preparing controllers with identical configuration and settings.


2.4 PC Tools

2.4.1 IntelliConfig

Configuration and monitoring tool for IntelliLite controllers. See more in IntelliConfig Reference Guide.

This tool provides the following functions:

- ▶ Direct or internet communication with the controller
- ▶ Offline or online controller configuration
- ▶ Controller firmware upgrade
- ▶ Reading/writing/adjustment of setpoints
- ▶ Reading of measured values
- ▶ Browsing of controller history records
- ▶ Exporting data into a XLS file
- ▶ Controller language translation




2.4.2 WinScope

Special graphical controller monitoring software used mainly for commissioning and gen-set troubleshooting. See more in the WinScope Reference guide.

This tool provides the following functions:

- ▶ Monitoring and archiving of ComAp controller's parameters and values
- ▶ View of actual / historical trends in controller
- ▶ On-line change of controllers' parameters for easy regulator setup




2.5 Plug-in Modules

2.5.1 CM-Ethernet

Internet/Ethernet module including web server.

- ▶ 10/100 Mbit ethernet interface in RJ45 socket
- ▶ Web interface for monitoring and adjustment of the controller
- ▶ Direct IP connection for remote access from InteliConfig
- ▶ MODBUS/TCP and SNMP protocols for integration of the controller into building management systems or other remote monitoring purposes
- ▶ Sending of active emails



2.5.2 CM-4G-GPS

GSM/4G Internet module and GPS locator

- ▶ Wireless integrated solution
- ▶ Quick and easy installation
- ▶ Support of WebSupervisor
- ▶ Instant alarm SMS notification
- ▶ System control over SMS
- ▶ Quad Band GPRS/EDGE modem, 850/900/1800/1900 MHz, FDD LTE: Band 1, Band 2, Band 3, Band 4, Band 5, Band 7, Band 8, Band 20, all bands with diversity, WCDMA/HSDPA/HSUPA/HSPA+: Band 1, Band 2, Band 5, Band 8, all bands with diversity
- ▶ GPRS multi-slot class 10
- ▶ TCP/IP communication over GPRS



2.5.3 CM-GPRS

GSM/GPRS Internet module


- ▶ Wireless integrated solution
- ▶ Quick and easy installation
- ▶ Instant alarm SMS notification
- ▶ System control over SMS
- ▶ Quad Band GPRS/EDGE modem, 850/900/1800/1900 MHz
- ▶ GPRS multi-slot class 10



2.5.4 CM-RS232-485

Communication module with two communication ports.

- ▶ RS232 and RS485 interface
- ▶ MODBUS
- ▶ Serial connection to IntelliConfig



2.5.5 EM-BIO8-EFCP

Hybrid current input and binary input/output extension module.

- ▶ Up to 8 additional configurable binary inputs or outputs



[◀ back to System overview](#)

3 Applications overview

3.1 AMF - Automatic Mains Failure Start 16
 3.2 MRS - Manual Remote Start 16

 [back to Table of contents](#)

3.1 AMF - Automatic Mains Failure Start

The typical scheme of Automatic Mains Failure Start application is shown below. The controller controls two breakers – a mains breaker and a generator breaker. Feedback from both breakers isn't necessary. IntelliLite controllers can also work without breaker feedbacks.




Image 3.1 AMF application overview

3.2 MRS - Manual Remote Start

The typical scheme of Manual Remote Start application is shown below. The controller controls one breaker – a generator breaker. Feedback from breaker isn't necessary. IntelliLite controllers can also work without breaker feedback.




Image 3.2 MRS application overview

[back to Applications overview](#)

4 Installation and wiring

- 4.1 Package content 18
- 4.2 Controller installation 18
- 4.3 Terminal Diagram 20
- 4.4 Recommended wiring 21
- 4.5 Plug-in module installation 43

[back to Table of contents](#)

4.1 Package content


The package contains:

- ▶ Controller
- ▶ Mounting holders
- ▶ Terminal blocks

Note: The package does not contain a communication or extension modules. The required modules should be ordered separately.


4.2 Controller installation

4.2.1 Dimensions



Note: Dimension x depends on plug-in module


Note: Dimensions are in millimeters



4.2.2 Mounting

The controller is to be mounted onto the switchboard door. Requested cutout size is 172 x 112 mm. Use the screw holders delivered with the controller to fix the controller into the door as described on pictures below. Recommended torque for holders is 0.15 N·m.

Panel door mounting



Note: Enclosure Type rating with mounting instruction - For use on a Flat surface of a type 1 enclosure.

4.3 Terminal Diagram

① POWER SUPPLY, D+		② BINARY OUTPUTS		③ BINARY INPUTS		④ CAN	
T01	BATT-	T09	E-STOP	T20	RPM GND	T36	CAN L
T02	D+	T10	BOUT1	T21	RPM IN	T37	CAN COM
T03	BATT+	T11	BOUT2	T22	BIN1	T38	CAN H
		T12	BOUT3	T23	BIN2		
		T13	BOUT4	T24	BIN3		
		T14	BOUT5	T25	BIN4		
		T15	BOUT6	T26	BIN5		
				T27	BIN6		





Image 4.1 Terminal diagram for IntelliLite 9 9

⑤ ANALOG INPUTS		⑥ GENERATOR CURRENT MEASUREMENT		⑦ GENERATOR VOLTAGE MEASUREMENT		⑧ MAINS VOLTAGE MEASUREMENT	
T39	AIN COM	T48	COM	T53	N	T61	N
T40	AIN1	T49	L1	T55	L1	T63	L1
T41	AIN2	T50	L2	T57	L2	T65	L2
T42	AIN3	T51	L3	T59	L3	T67	L3

4.4 Recommended wiring




1	Power supply	"+", D, "-"	Power supply (page 22)
2	Binary outputs	09 - 15	Binary Outputs (page 33)
3	Binary inputs	22 - 27	Binary inputs (page 32)
4	CAN bus	H, COM, L	CAN bus (page 38) CAN bus (page 38)
5	Analog inputs	39 - 42	Analog inputs (page 34)
6	Current inputs	48 - 51	Current measurement wiring (page 24)
7	Generator voltage inputs	53 - 59	Voltage measurement AMF wiring (page 26) Voltage measurement MRS wiring (page 28)
8	Mains voltage inputs	61 - 67	Voltage measurement AMF wiring (page 26)
9	USB		USB (page 40)

Note: Wiring terminal markings to included tightening torque: 0,5 N-m (4,5 lb-in)., and wire size: 2 mm² (12-26AWG).

4.4.1 General

To ensure proper function:

- ▶ Use grounding terminals.
- ▶ Wiring for binary inputs and analog inputs must not be run with power cables.
- ▶ Analog and binary inputs should use shielded cables, especially when the length is more than 3 m.

Tightening torque, allowable wire size and type, for the Field-Wiring Terminals:	
Example of used connectors:	
For Mains and Generator Voltage, and for Current terminals:	Use only diameter 2.0–0.5 mm (AWG 12–26) conductor, rated for 90 °C minimum.
For other controller field wiring terminals:	Use only diameter 2.0–0.5 mm (AWG 12–26) conductor, rated for 75 °C minimum.
Specified tightening torque is 0.56 N·m (5.0 In-lb).	
Use copper conductors only.	

4.4.2 Grounding

The shortest possible length of wire should be used for controller grounding. Use cable min 2.5 mm².

The negative " - " battery terminal must be properly grounded.

Switchboard and engine must be grounded at common point. Use as short cable as possible to the grounding point.

4.4.3 Power supply

To ensure proper function:


- ▶ Use power supply cable min. 1.5 mm²

Maximum continuous DC power supply voltage is 36 V DC. The controller's power supply terminals are protected against large pulse power disturbances. When there is a potential risk of the controller being subjected to conditions outside its capabilities, an outside protection device should be used.

It is necessary to ensure that potential difference between generator current COM terminal and battery " - " terminal is maximally ± 2 V. Therefore is strongly recommended to interconnect these two terminals together.

Note: The controller should be grounded properly in order to protect against lightning strikes. The maximum allowable current through the controller's negative terminal is 4 A (this is dependent on binary output load).

For the connections with 12 V DC power supply, the controller includes internal capacitors that allow the controller to continue in operation during cranking if the batter voltage dip occurs. If the voltage dip goes during cranking to 0 V and after 50 ms it recovers to 4 V, the controller continues operating. This cycle can repeat several times. During this voltage dip the controller screen backlight can turn off.



Note: Recommended fusing is 3 A fuse.

Note: In case of the dip to 0 V the high-side binary outputs will be temporarily switched off and after recovering to 4 V back on.

IMPORTANT: When the controller is power up only by USB and the USB is disconnected then the actual statistics can be lost.


Note: Suitable conductor protection shall be provided in accordance with NFPA 70, Article 240.

Note: Low voltage circuits (35 volts or less) shall be supplied from the engine starting battery or an isolated secondary circuit.

Note: It is also possible to further support the controller by connecting the external capacitor and separating diode. The capacitor size depends on required time. It shall be approximately thousands of μF . The capacitor size should be 5 000 μF to withstand 150 ms voltage dip under following conditions: Voltage before dip is 12 V, after 150 ms the voltage recovers to min. allowed voltage, i.e. 8 V.

Power supply fusing

A 3 A fuse should be connected in-line with the battery positive terminal to the controller and modules. These items should never be connected directly to the starting battery. Fuse value and type depends on number of connected devices and wire length. Recommended fuse (not fast) type - T3 A. Not fast due to internal capacitors charging during power up.



Note: Recommended fusing is 3 A fuse.

4.4.4 Measurement wiring

Use 1.5 mm² cables for voltage connection and 2.5 mm² for current transformers connection. Adjust **Connection type** (page 147), **Nominal Voltage Ph-N** (page 149), **Nominal Voltage Ph-Ph** (page 149), **Nominal Current** (page 146), **PT Ratio** (page 149), **Vm PT Ratio** (page 150) and **CT Ratio** (page 147) by appropriate setpoints in the Basic Settings group.

IMPORTANT: Risk of personal injury due to electric shock when manipulating voltage terminals under voltage. Be sure the terminals are not under voltage before touching them.
Do not open the secondary circuit of current transformers when the primary circuit is closed. Open the primary circuit first.

CT Location




Image 4.2 CT Location

There are two options of CT location.

- a) Load
- b) Gen-Set

Note: The current measurement protections are active only when the Gen-set is running.
If the CT Location is set to Load the Short Circuit BOC (page 193) protection is enabled only when GCB is closed.

Current measurement wiring

The number of CT's is automatically selected based on selected value of setpoint Connection type (page 147) [3Ph4Wire / High Leg D / 3Ph3Wire / Split Ph / Mono Ph].

Generator currents and power measurement is suppressed if current level is below <1 % of CT range.

To ensure proper function:

- ▶ Use cables of 2.5 mm²
- ▶ Use transformers to 5 A
- ▶ Connect CT according to following drawings:

3 phase application:




Image 4.3 3 phase application

It is necessary to ensure that potential difference between current COM terminal and battery “-” terminal is maximally $\pm 2\text{ V}$. Therefore is strongly recommended to interconnect these two terminals together.

Split phase application:




Image 4.4 Split phase application

IMPORTANT: The second phase of split phase connection is connected to the terminal, where is normally connected the third phase.

Mono phase application:

Connect CT according to following drawings. Terminals phase 2 and phase 3 are opened.




Image 4.5 Mono phase application

Voltage measurement AMF wiring

There are 4 voltage measurement Connection Type (setpoint **Connection type** (page 147) [3Ph4Wire /3Ph3Wire / Split Ph / Mono Ph]) options, every type matches to corresponding generator connection type.

Note: For fusing of voltage measurement input use T1A or T2A fuse.

The generator protections are evaluated from different voltages based on **Connection type** (page 147) setting:

- ▶ 3Ph 4W – Ph-Ph voltage, Ph-N voltage
- ▶ 3Ph 3W – Ph-Ph voltage
- ▶ Split Ph – Ph-N voltage
- ▶ Mono Ph – Ph-N voltage

ConnectionType: 3 Phase 4 Wires




Image 4.6 3 phase application with neutral

ConnectionType: 3 Phase 3 Wires




Image 4.7 3 phase application without neutral

ConnectionType: Split Phase




Image 4.8 Split phase application

IMPORTANT: The second phase of split phase connection is connected to the terminal, where is normally connected the third phase.

ConnectionType: Mono Phase




Image 4.9 Mono phase application

Voltage measurement MRS wiring

There are 4 voltage measurement Connection Type (setpoint Connection type (page 147) [3Ph4Wire /3Ph3Wire / Split Ph / Mono Ph]) options, every type matches to corresponding generator connection type.

Note: For fusing of voltage measurement input use T1A or T2A fuse.

The generator protections are evaluated from different voltages based on Connection type (page 147) setting:

- ▶ 3Ph 4W – Ph-Ph voltage, Ph-N voltage
- ▶ 3Ph 3W – Ph-Ph voltage

- ▶ Split Ph – Ph-N voltage
- ▶ Mono Ph – Ph-N voltage

ConnectionType: 3 Phase 4 Wires




Image 4.10 3 phase application with neutral

ConnectionType: 3 Phase 3 Wires




Image 4.11 3 phase application without neutral

ConnectionType: Split Phase




Image 4.12 Split phase application

IMPORTANT: The second phase of split phase connection is connected to the terminal, where is normally connected the third phase.

ConnectionType: Mono Phase





Image 4.13 Mono phase application

4.4.5 Magnetic pick-up

A magnetic speed sensor (pickup) is the most common method of engine speed measurement. To use this method, mount the pickup opposite to the engine flywheel, connect the cable to the controller as shown on the

picture below and adjust the setpoint Gear Teeth (page 151) according to the number of teeth on the flywheel.
 For the details about the pick-up input parameters see **Technical data on page 137**

IMPORTANT: To ensure proper function use a shielded cable.



If engine will not start:

- ▶ Check ground connection from pick-up to controllers, eventually disconnect ground connection to one of them.

Note: In some cases the controller will measure a RPM value even though the gen-set is not running: RPM is measured from the generator voltage (Gear Teeth = 0). Controller is measuring some voltage value on input terminals due to open fusing. If $RPM > 0$ the controller will be put into a Not ready state and the engine will not be allowed to start.

4.4.6 Binary inputs

Use minimally 1 mm² cables for wiring of Binary inputs.





Image 4.14 Wiring binary inputs

Note: The name and function or alarm type for each binary input have to be assigned during the configuration.

4.4.7 Binary Outputs

Use min. 1 mm² cables for wiring of binary outputs. Use external relays as indicated on the schematic below for all outputs except those where low-current loads are connected (signalization etc...).


IMPORTANT: Use suppression diodes on all relays and other inductive loads!



Note: Every single low current binary output can provide up to 0,5 A of steady current.

Note: Binary output 1 (terminal 4) and binary output 2 (terminal 5) are high current outputs (5 A for long term).

IMPORTANT: When operating temperature is higher than 60 °C it is strongly recommended to limit output current of high current binary outputs (terminal 4 and terminal 5) to 4 A (each).



4.4.8 E-Stop

E stop has dedicated terminal T09. Power supply of binary output 1 and binary output 2 (terminals 4 and 5) is internally connected (in controller) to E-Stop terminal. It means higher security and faster disconnection of these outputs. More information about E-Stop functions **see E-Stop on page 109**.

Note: This function has the same behavior as binary input *EMERGENCY STOP* (PAGE 305).




Image 4.15 E-Stop wiring

Note: Recommended fusing is 12 A fuse.

Note: Grey dashed line symbolizes internal connection between E-Stop and binary outputs 1 and 2.

Note: For proper functionality of E-Stop, the terminal T09 must be always wired. Terminal can be connected to battery+ or to terminal T03 (BATT+)

IMPORTANT: Suppression diodes are not indicated, but required.

4.4.9 Analog inputs

The analog inputs are designed for resistive automotive type sensors like VDO or DATCON. The sensors are connected either by one wire (the second pole is the sensor body) or by two wires.

- ▶ In the case of grounded sensors, connect the AI COM terminal to the engine body as near to the sensors as possible.
- ▶ In the case of isolated sensors, connect the AI COM terminal to the negative power supply terminal of the controller as well as one pole of each sensor.

Analog inputs are typically used for: Oil Pressure, Coolant Temperature and Fuel Level. All of these parameters are connected with relevant protections.




Image 4.16 Grounded sensors




Image 4.17 Isolated sensors

Note: Schemes show only analog input connection overview, not actual wiring.

Note: The name, sensor characteristic and alarm types for each analog input have to be assigned during configuration.

Analog inputs with voltage & current sensors

On each analog input, there is a possibility to connect voltage or current output sensor instead of resistive one. Recommended wiring connection for these measurements and recommended curves are bellow.

Voltage sensors

Sensor's output range (V)	R1 (Ω)	R2 (Ω)
0 - 10	390	100
0 - 30	1500	100
0 - 70	3300	100




Image 4.18 Wiring of analog input with voltage sensor

0 - 10 V											
V	0	1	2	3	4	5	6	7	8	9	10
Ω	81	145	219	306	409	539	685	887	1125	1458	1933

0 - 30 V									
V	0	2	4	6	8	10	12	14	
Ω	95	134	177	223	274	330	395	465	
V	16	18	20	22	24	26	28	30	
Ω	543	633	735	853	993	1154	1350	1589	

0 - 70 V												
V	0	2	4	6	8	10	12	14	16	18	20	22
Ω	99	117	137	155	175	196	219	242	266	291	318	346
V	24	26	28	30	32	34	36	38	40	42	44	46
Ω	375	406	439	473	510	549	589	633	679	729	781	838
V	48	50	52	54	56	58	60	62	64	66	68	70
Ω	873	963	1033	1110	1193	1283	1383	1492	1612	1748	1896	2065

Note: This is a conversion of voltage from voltage sensor to appropriate resistance value. Use resistance values in IntelliConfig to create your specific curve. These values should be used in "Ohm" column.

Current sensors

Sensor's output range (mA)	R (Ω)
0-20	100




Image 4.19 Wiring of analog input with current sensor

0 - 22 mA												
mA	0	1	2	3	4	5	6	7	8	9	10	11
Ω	100	133	167	202	241	283	328	375	431	489	553	625
mA	12	13	14	15	16	17	18	19	20	21	22	
Ω	707	793	894	1007	1136	1287	1460	1666	1914	2222	2596	

Note: This is a conversion of current from current sensor to appropriate resistance value. Use resistance values in IntelliConfig to create your specific curve. These values should be used in "Ohm" column.

Analog as binary or tristate inputs

Analog inputs can be used also as binary or tri-state, i.e. for contact sensors without or with circuit check. The threshold level is 750Ω. In the case of tri-state, values lower than 10Ω and values over 2400Ω are evaluated as sensor failure (short or open circuit).




Image 4.20 Analog inputs as tristate




Image 4.21 Analog inputs as binary

Note: The name, sensor characteristic and alarm types for each analog input have to be assigned during configuration.

Note: Tristate and binary sensors are not suitable for Analog Switch functions.

4.4.10 CAN bus

CAN bus wiring

The wiring of the CAN bus should be provided in such a way that the following rules are observed:

- ▶ The maximum length of the CAN bus depends on the communication speed. For a speed of 250 kbps, which is used on the CAN1 bus (extension modules, ECU) and CAN2 bus if it is switched to 32C mode, the maximum length is 200 m. If the CAN2 bus is switched to 8C mode the speed is 50 kbps and the maximum length is 800 m.
- ▶ The bus must be wired in linear form with termination resistors at both ends. No nodes are allowed except on the controller terminals.
- ▶ Shielded cable¹ has to be used, shielding has to be connected to the terminal T01 (BATT -).
- ▶ External units can be connected on the CAN bus line in any order, but keeping line arrangement (no tails, no star) is necessary.
- ▶ The CAN bus has to be terminated by 120 Ohm resistors at both ends use a cable with following parameters:

¹Recommended data cables: BELDEN (<http://www.belden.com>) - for shorter distances: 3105A Paired - EIA Industrial RS-485 PLTC/CM (1x2 conductors); for longer distances: 3106A Paired - EIA Industrial RS-485 PLTC/CM (1x2+1 conductors)

Cable type	Shielded twisted pair
Impedance	120 Ω
Propagation velocity	$\geq 75\%$ (delay $\leq 4,4$ ns/m)
Wire crosscut	$\geq 0,25$ mm ²
Attenuation (@1MHz)	≤ 2 dB/100 m

Note: Communication circuits shall be connected to communication circuits of Listed equipment.

Note: A termination resistor at the CAN (120 Ω) is already implemented on the PCB. For connecting, close the jumper near the appropriate CAN terminal.




Image 4.22 CAN bus topology

► For shorter distances (connection within one building)




Image 4.23 CAN bus wiring for shorter distances

- ▶ For longer distances or in case of surge hazard (connection out of building, in case of storm etc.)




Image 4.24 CAN bus wiring for longer distances

- ① Recommended PT5-HF-12DC-ST¹

4.4.11 USB

This is required for computer connection. Use the shielded USB A-B cable.





Image 4.25 USB connection

Controller can be also powered by USB (only for service purpose like a uploading firmware, change of configuration etc.).


IMPORTANT: Power supply by USB is only for service purpose. Binary inputs and outputs are in logical 0. Also plug-in modules are not working.

¹Protections recommended: Phoenix Contact (<http://www.phoenixcontact.com>): PT 5-HF-12DC-ST with PT2x2-BE (base element) or Saltek (<http://www.saltek.cz>): DM-012/2 R DJ

4.4.12 Example of AMF Wiring




4.4.13 Example of MRS Wiring




4.5 Plug-in module installation

4.5.1 Installation


Remove the back cover. To do this, press four holders which are located in corners.



After removing back cover insert the plug-in module. Plug-in module has to be inserted under holders. Start with holders marked by symbol 1. On the controller are also arrows for better navigation. After inserting plug-in module under holders 1 press it down to holders marked by symbol 2 which locks the module.



After locking the plug-in module into holders, place back the back cover (small cover for connectors has to be removed from back cover). Finally insert the small cover for connectors. Small covers are unique for each plug-in module.



[◀ back to Installation and wiring](#)

5 Controller setup

5.1 Default configuration	45
5.2 Controller configuration and PC tools connection	46
5.3 Operator Guide	50
5.4 Functions	74

[🔍 back to Table of contents](#)

5.1 Default configuration

5.1.1 Binary inputs AMF

Number	Description	Configured function
BIN1	Generator circuit breaker feedback	GCB FEEDBACK (PAGE 307)
BIN2	Mains circuit breaker feedback	MCB FEEDBACK (PAGE 309)
BIN3	Switch controller to OFF mode	REMOTE OFF (PAGE 311)
BIN4	Switch controller to TEST mode	REMOTE TEST (PAGE 313)
BIN5	Suppression of alarms	SD OVERRIDE (PAGE 313)
BIN6	Binary input function used as alarm	BIN PROTECTION 1 (PAGE 296)

5.1.2 Binary outputs AMF

Number	Description	Function
BOUT1	Starter motor control	STARTER (PAGE 344)
BOUT2	Fuel solenoid valve	FUEL SOLENOID (PAGE 326)
BOUT3	Generator circuit breaker control	GCB CLOSE/OPEN (PAGE 327)
BOUT4	Mains circuit breaker control	MCB CLOSE/OPEN (PAGE 335)
BOUT5	Activation of any devices before start	PRESTART (PAGE 341)
BOUT6	Indication of unconfirmed alarm	ALARM (PAGE 322)

5.1.3 Binary inputs MRS

Number	Description	Function
BOUT1	Start and stop the gen-set in AUTO mode.	REMOTE START/STOP (PAGE 312)
BOUT2	Generator circuit breaker feedback	GCB FEEDBACK (PAGE 307)
BOUT3	Switch controller to OFF mode	REMOTE OFF (PAGE 311)
BOUT4	Switch controller to AUTO mode	REMOTE AUTO (PAGE 310)
BOUT5	Suppression of alarms	SD OVERRIDE (PAGE 313)
BOUT6	Binary input function used as alarm	BIN PROTECTION 1 (PAGE 296)

5.1.4 Binary outputs MRS

Number	Description	Function
BOUT1	Starter motor control	STARTER (PAGE 344)
BOUT2	Fuel solenoid valve	FUEL SOLENOID (PAGE 326)
BOUT3	Generator circuit breaker control	GCB CLOSE/OPEN (PAGE 327)
BOUT4	Activation of any devices before start	PRESTART (PAGE 341)
BOUT5	Gen-set can be connected to load	READY TO LOAD (PAGE 343)
BOUT6	Indication of unconfirmed alarm	ALARM (PAGE 322)

5.1.5 Analog inputs

Number	Configured sensor	Function
AIN1	VDO 10 Bar	OIL PRESSURE (PAGE 355)
AIN2	VDO40-120°C	COOLANT TEMP (PAGE 353)
AIN3	VDOLevel %	FUEL LEVEL (PAGE 354)

5.2 Controller configuration and PC tools connection

5.2.1 USB	46
5.2.2 RS232/RS485	47
5.2.3 Ethernet	49

back to Controller setup

This chapter contains brief introduction into the specifics of firmware and archive upload and connection of various PC tools to the controller. If you require detailed information on each PC tool please use the included Help in those PC tools or download their Reference Guides.

5.2.1 USB

You may connect to the controller using the USB port. In this case standard USB A to B cable should be used.

Connection using IntelliConfig




Image 5.1 First screen of IntelliConfig - select connect to controller



Image 5.2 Second screen of IntelliConfig - select detected controllers

Connection using WinScope




Image 5.3 WinScope screen - select direct connection

5.2.2 RS232/RS485

It is possible to connect to the controller using RS232 or RS485 direct connection (serial port or USB to RS232/RS485 converter may be used). The following settings need to be checked in the controller:

- ▶ **COM1 Mode (page 221) = Direct**
- ▶ **Controller Address (page 154) has to be set to the same value as in the PC tool**

Connection using IntelliConfig




Image 5.4 First screen of IntelliConfig - select connect to controller




Image 5.5 Second screen of IntelliConfig - select Serial link

Connection using WinScope




Image 5.6 WinScope screen - select direct connection

Note: Winscope supports only 19200, 38400, 57600 speeds.

5.2.3 Ethernet

It is possible to connect to the controller using ethernet port.

Direct connection

When you use direct connection the controller needs to be reachable directly from the PC you use (i.e. one LAN or WAN without any firewalls and other points that may not allow the connection). The following settings need to be checked in the controller:

- ▶ **Controller Address** (page 154) has to be set to the same value as in the PC tool
- ▶ **IP Address Mode** (page 235) can be set to AUTOMATIC when there is DHCP service is available. Otherwise it needs to be set to FIXED
- ▶ **IP Address** (page 236) is either set automatically or it can be adjusted to a specific requested value
- ▶ **Subnet Mask** (page 236) is either set automatically or it can be adjusted to a specific requested
- ▶ **Gateway IP** (page 237) can be set here when it is used

Connection using IntelliConfig




Image 5.7 First screen of IntelliConfig - select connect to controller




Image 5.8 Second screen of IntelIconfig - select Internet/Ethernet

Connection using WinScope




Image 5.9 WinScope screen

5.3 Operator Guide

5.3.1 Front panel elements	51
5.3.2 Display screens and pages structure	52
5.3.3 Browsing alarms	65
5.3.4 Password	66

5.3.5 Information screen 72
 5.3.6 Language selection 73
 5.3.7 Display contrast adjustment 74

5.3.1 Front panel elements
















Image 5.10 Operator interface of Intelilite 9

Control buttons		
Position	Picture	Description
1		<p>LEFT button. Use this button to move left or to change the mode. The button can change the mode only if the main screen with the indicator of currently selected mode is displayed.</p> <p><i>Note: This button will not change the mode if the controller mode is forced by one of binary inputs listed in the Reference Guide – “Operating modes” chapter.</i></p>
2		<p>RIGHT button. Use this button to move right or to change the mode. The button can change the mode only if the main screen with the indicator of currently selected mode is displayed.</p> <p><i>Note: This button will not change the mode if the controller mode is forced by one of binary inputs listed in the Reference Guide – “Operating modes” chapter.</i></p>
3		<p>HORN RESET button. Use this button to deactivate the horn output without acknowledging the alarms.</p>

4		FAULT RESET button. Use this button to acknowledge alarms and deactivate the horn output. Inactive alarms will disappear immediately and status of active alarms will be changed to "confirmed" so they will disappear as soon as their reasons dismiss.
5		UP button. Use this button to move up or increase value.
6		PAGE button. Use this button to switch over display pages.
7		DOWN button. Use this button to move down or decrease value.
8		ENTER button. Use this button to finish editing a setpoint or moving right in the history page.
9		START button. Works in MAN mode only. Press this button to initiate the start sequence of the engine.
10		STOP button. Works in MAN mode only. Press this button to initiate the stop sequence of the gen-set. Repeated pressing of button will cancel current phase of stop sequence (like cooling) and next phase will continue.
11		GCB button. Works in MAN and TEST modes only. Press this button to open or close the GCB.
12		MCB button. Works in MAN and TEST modes only. Press this button to open or close the MCB.

Indicators and others

Position	Description
13	GENERATOR status indicator. There are two states - Gen-set OK (indicator is green) and Gen-set failure (indicator is red). Green LED is on if the generator voltage is present and within limits. Red LED starts flashing when gen-set failure occurs. After FAULT RESET button is pressed, goes to steady light (if an alarm is still active) or is off (if no alarm is active).
14	MAINS status indicator. There are two states - Mains OK (indicator is green) and Mains failure (indicator is red). Green LED is on, if mains is present and within limits. Red LED starts blinking when the mains failure is detected and after the gen-set has started and connected to the load it lights permanently until the mains failure disappears.
15	Graphic B/W display, 132x64 pixels.
16	GCB ON . Green LED is on if GCB is closed. It is driven by GCB CLOSE/OPEN output or by GCB feedback signal.
17	MCB ON . Green LED is on if MCB is closed. It is driven by MCB CLOSE/OPEN output or by MCB feedback signal.

5.3.2 Display screens and pages structure

The displayed information is structured into "pages" and "screens". Use PAGE button to switch over the pages.

- ▶ The page Measurement consists of screens which display measured values like voltages, current, oil pressure etc., computed values like i.e. gen-set power, statistic data and the alarm list on the last screen.
- ▶ The page Setpoints contains all setpoints organized to groups and also a special group for entering password.
- ▶ The page History log shows the history log in the order that the last record is displayed first.


Main Screen



Symbols


- ▶ Padlock - active when LBI ACCESS LOCK is active
- ▶ R - active when there is active remote connection to controller
- ▶ Exclamation mark - active when there is any alarm in alarmlist

Measurement Screens




Note: Use Up and Down button to move between measurement pages.

Generator			
L1N	230V	L1L2	400V
L2N	230V	L2L3	400V
L3N	230V	L3L1	400V
Generator Freq			50.0Hz



Note: Use Up and Down button to move between measurement pages.

Generator Current	
L1	130A
L2	130A
L3	130A



Note: Use Up and Down button to move between measurement pages.

Mains			
L1N	230V	L1L2	400V
L2N	230V	L2L3	400V
L3N	230V	L3L1	400V
Mains Frequency			50.0Hz



Note: Use Up and Down button to move between measurement pages.

Analog Inputs 1/2	
Oil Pressure	#####Bar
Coolant Temp	##### °C
Fuel Level	#####%




Note: Use Up and Down button to move between measurement pages.

```

Analog Inputs 2/2
Not Used
-----
BatteryVoltage 23.8V
-----

```




Note: Use Up and Down button to move between measurement pages.

```

Binary Inputs 1/2
000000
1 Input 0
2 Input 0
3 Input 0
4 Input 0
5 Input 0

```



Note: Use Up and Down button to move between measurement pages.

```

Binary Inputs 2/2
000000
6 Input 0
E-STOP 1

```



Note: Use Up and Down button to move between measurement pages.

```


Binary Outputs 1/2
000000
1 Output 0
2 Output 0
3 Output 0
4 Output 0
5 Output 0

```



Note: Use Up and Down button to move between measurement pages.

Binary Outputs 2/2	
	000000
6 Output	0



Note: Use Up and Down button to move between measurement pages.

EM-BIOS-EFCP 1/2	
	10101010
IN: Input	1
Not Used	0
OUT: Output	1
IN: Input	0
OUT: Output	1



Note: Use Up and Down button to move between measurement pages.

EM-BIOS-EFCP 2/2	
	00101010
OUT: Output	0
OUT: Output	1
OUT: Output	0




Note: Use Up and Down button to move between measurement pages.

Gen-Set Power			
	kW	PF	kVA
L1	0	0.000	0
L2	0	0.000	0
L3	0	0.000	0
Σ	0	0.000	0



Note: Use Up and Down button to move between measurement pages.

ECU Values	
Fuel Rate	#####l/h
CoolantTemp	##### °C
IntakeTemp	##### °C
Oil Press	#####bar
Boost Press	#####bar
Load	#####%



Note: Use Up and Down button to move between measurement pages.

Statistics 1/2	
Genset kWh	0
Genset kVArh	0
Mains kWh	0
Mains kVArh	0
Running Hours	0
Num Starts	0



Note: Use Up and Down button to move between measurement pages.

Statistics 2/2	
Num E-Stops	0
Shutdowns	0
Maintenance 1	0
Maintenance 2	0
Maintenance 3	0



Note: Use Up and Down button to move between measurement pages.


CM-4G-GPS 1/2	
Cell Signal Lev	93%
Cell ErrorRate	12%
Cell Status	/
Cell Diag Code	12
Operator	T-Mobile CZ
Connection Type	4G



Note: Use Up and Down button to move between measurement pages.


```

CM-4G-GPS  2/2
Latitude   0.1234
Longitude  0.1234
Altitude   123m
HomePosDist 123km
Satelites  1
    
```



Note: Use Up and Down button to move between measurement pages.

```

CM-GPRS
Cell Signal Lev  93%
Cell ErrorRate   12%
Cell Status      /
Cell Diag Code   12
Operator         T-Mobile CZ
    
```



Note: Use Up and Down button to move between measurement pages.

```









CM-Ethernet
Current IP Address
      123.123.123.123
ETH Interface Status
      Connected
    
```



Note: Use Up and Down button to move between measurement pages.



```

Aftertreatment
    
```


			
			



Note: Use Up and Down button to move between measurement pages.



Note: Use Up and Down button to move between measurement pages.




Note: Use Up and Down button to move between measurement pages.

Note: From all of these pages it is possible to switch seamlessly to the setpoint group page by pressing Page button.

Note: There can be some additional screens and also some screens can be hidden. Screen's visibility depends on actual configuration (usage of extension or communication modules, ECU, etc.).

Setpoint Screens




Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.



Note: Use Up and Down button to select required setpoint group.




Note: Use Enter button to enter selected setpoint group.



Note: Use Left and Right button to select required setpoint.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to set required value of selected setpoint.




Note: Use Enter button to confirm adjusted value of setpoint.



Note: Use Page button to discard changes, to set setpoint to previous value and to return to the list of setpoints of selected group.

IMPORTANT: Cannot change setpoint? Setpoints marked with an padlock are password protected. Enter password as described in the chapter Password (page 66).

History Log



Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.




Note: From setpoint group page we can fluently go to the history log pages by pressing Page button.



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

RPM	Pwr	Q
1500	15.0	15.0
0	0.0	0.0
0	0.0	0.0
1500	15.0	15.0
1500	15.0	15.0
-002 MCB Opened		



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

PF	LChr	GFra
0.75	C	50.0
0.00	C	0.0
0.00	C	0.0
0.73	C	50.0
0.74	C	50.0
-002 MCB Opened		



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

Ug1	Ug2	Ug3
230	230	230
0	0	0
0	0	0
230	230	230
230	230	230
-002 MCB Opened		



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

Ug12	Ug23	Ug31
230	230	230
0	0	0
0	0	0
230	230	230
230	230	230
-002 MCB Opened		



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

IL1	IL2	IL3
30	30	30
0	0	0
0	0	0
30	30	30
30	30	30

-002 MCB Opened



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

Um1	Um2	Um3
230	230	230
0	0	0
0	0	0
230	230	230
230	230	230

-002 MCB Opened



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

Um12	Um23	Um31
230	230	230
0	0	0
0	0	0
230	230	230
230	230	230

-002 MCB Opened



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

FC	FMI
0	0
0	0
0	0
0	0
0	0

-002 MCB Opened



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

MFrq	UBat	OilP
50.0	23.2	3.2
0.0	0.0	0.0
0.0	23.2	0.0
50.0	23.3	3.2
50.0	23.3	3.2



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

EngT	FLvl
30.0	50
22.0	20
23.0	30
23.0	30
23.0	50



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

Ein	Bout
011010	110000
110010	010010
010101	010101
110100	011010
110000	010101



Note: Use Up and Down button to select required alarm reason.



Note: Use Enter button to move to the next page of history log.

Mode
MAN
MAN
MAN
MAN
MAN



Note: Use Up and Down button to select required alarm reason.




Note: Use Enter button to move to the first page of history log.


IMPORTANT: The records are numbered in reverse order, i.e. the latest (newest) record is "0" and older records have "-1", "-2" etc.

Note: This is only basic history record. There can be some additional screens in case that in controller is extension module or ECU is configured. Also it depends on connection type.

5.3.3 Browsing alarms



Note: Use Up button to move to alarmlist from main measurement screen.




- ▶ Active alarms are displayed as white text on black background. It means the alarm is still active, i.e. the appropriate alarm conditions are still present.
- ▶ Inactive alarms are displayed as black text on white background. It means the alarm is no more active, i.e. the appropriate alarm conditions are gone.
- ▶ Not confirmed alarms are displayed with an asterisk. It means the alarm is still not acknowledged (confirmed).
- ▶ ECU alarms: SPN/FMI/OC/SC
 - SPN - Suspect parameter number
 - FMI - type of protection
 - OC - number of errors
 - SC - source of error




5.3.4 Password

Enter password




Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.



Note: Use Up and Down button to select setpoint group Password.



Note: Use Enter button to enter setpoint group Password.



Note: Use Up and Down button to select Enter Password.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to set required value of selected setpoint.



Note: Use Left and Right button to move between digits.




Note: Use Enter button to confirm the password or Page button to cancel entering the password.




Note: In case that invalid password is entered, the controller shows Invalid password screen. Use Page button to go back to menu.

Change password



Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.



Note: Use Up and Down button to select setpoint group Password.




Note: Use Enter button to enter setpoint group Password.



Note: Use Up and Down button to select Change Password.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to select required level of password.



Note: Use Enter button to enter selected setpoint.



Note: Use Up and Down button to set required value of password.




Note: Use Left and Right button to move between digits.



Note: After setting new password use Enter button to confirm adjusted password.



Note: Use Up and Down button to set required value of password again.



Note: Use Left and Right button to move between digits.




Note: After setting new password again use Enter button to confirm adjusted password or Page button to discard changes and to cancel changing password.




Note: Before changing the password controller has to be unlocked. In case that controller is locked, the controller shows Password required screen. In that case the password has to be entered before changing the password.

Log out from controller




Note: From all measurement pages we can fluently go to the setpoint group page by pressing Page button.



Note: Use Up and Down button to select setpoint group Password.



Note: Use Enter button to enter setpoint group Password.



Note: Use Up and Down button to select Enter Password.




Note: Use Enter button to enter selected setpoint.



Note: Use Left and Right button to move between digits.

Note: Enter invalid password to log out from controller.



Note: In case that invalid password is entered, the controller shows Invalid password screen. Use Page button to go back to menu.

Lost Password


IMPORTANT: Display the information screen containing the serial number and password decode number as described in the chapter Information screen (page 72) and send them to your local distributor.

Password break protection

The controller password is protected against breaking by brute force. The protection works at every controller interface separately.

1. When an invalid password is entered 5 times after each other, independently on the time period elapsed between the attempts, the controller will be blocked after the 5th unsuccessful attempt for 1 minute at the particular interface.
2. While the controller is blocked it refuses any further attempts to enter password.
3. When unblocked again the controller accepts one attempt to enter password. If the password is incorrect again the controller will be blocked for 2 minutes.
4. Each further attempt to enter invalid password will double the blocking time, but maximum blocking time is 20 minutes.
5. When incorrect password is entered 100-times after each other the controller is blocked forever and the password reset procedure is required to unblock it.

5.3.5 Information screen




Note: On Main measurement screen press Enter and Page button together. Enter button has to be pressed first.



Note: Use Page button to move to the next page.




Note: Use Page button to move to the next page.




Note: Use Up button to move back to main measurement screen.

5.3.6 Language selection




Note: On Main measurement screen press Enter and Page button together. Enter button has to be pressed first.




Note: Use Page button to move to the next page.



Note: Use Page button to move to the next page.



Note: Use Page button to move to the next page.




Note: Use Up and down button to select required language.



Note: Use Enter button to confirm selected language.

5.3.7 Display contrast adjustment



Note: On any measurement screen press Enter and Down button together for lower contrast.

Note: On any measurement screen press Enter and Up button together for higher contrast.



Note: After setting a contrast, no another action is needed.

 back to Controller setup

5.4 Functions

5.4.1 Start-stop sequence	75
5.4.2 AMF sequence	77
5.4.3 Operating Modes	78
5.4.4 Engine start	79
5.4.5 Stabilization	81
5.4.6 Connecting to load	81

5.4.7 MRS operation	81
5.4.8 AMF operation	81
5.4.9 Engine cool down and stop	82
5.4.10 Alarm management	83
5.4.11 History log	89
5.4.12 Breaker control	90
5.4.13 Exercise timer	93
5.4.14 Service timers	99
5.4.15 Flowchart	101
5.4.16 Additional running engine indications	102
5.4.17 Voltage phase sequence detection	102
5.4.18 Gen-set operation states	102
5.4.19 Sensor curves	105
5.4.20 Tier 4 Final	105
5.4.21 Alternate configuration	108
5.4.22 E-Stop	109
5.4.23 ECU Frequency selection	110

 **back to Controller setup**

5.4.1 Start-stop sequence

State	Condition of the transition	Action	Next state
Ready	Start request	PRESTART (PAGE 341) on Prestart Time (page 161) counter started	Prestart
	RPM > 2 or Oil pressure > Starting Oil Pressure (page 162) or Generator voltage > 10V or D+ voltage is higher than D+ Treshold (page 170)		Stop (Stop fail)
	OFF Mode selected or Shutdown alarm active		Not Ready
Not Ready	RPM < 2, Oil pressure not detected, Generator voltage < 10V, D+ not Active no shutdown alarm active, other than OFF Mode selected		Ready
Prestart	Prestart time elapsed	FUEL SOLENOID (PAGE 326) on, STARTER (PAGE 344) on, Maximum Cranking Time (page 160) counter started	Cranking
Cranking	RPM > Starting RPM	STARTER (PAGE 344) off, PRESTART (PAGE 341) off	Starting
	D+ input activated or oil pressure detected or Generator voltage >	STARTER (PAGE 344) off, PRESTART (PAGE 341) off	Cranking

	25% Nominal voltage		
	Maximum Cranking Time (page 160), 1st attempt	STARTER (PAGE 344) off, FUEL SOLENOID (PAGE 326) off, STOP SOLENOID (PAGE 345) on, Cranking Fail Pause (page 160) timer started	Crank pause
	Maximum Cranking Time (page 160) elapsed, last attempt	STARTER (PAGE 344) off, PRESTART (PAGE 341) off	Shutdown (Start fail)
Crank pause	Cranking Fail Pause (page 160) elapsed	STARTER (PAGE 344) on, FUEL SOLENOID (PAGE 326) on, STOP SOLENOID (PAGE 345) off, Maximum Cranking Time (page 160) counter started	Cranking
Starting	Idle Time (page 172) elapsed	Minimal Stabilization Time (page 174) and Maximal Stabilization Time (page 175) counter started	Running
	any shutdown condition	FUEL SOLENOID (PAGE 326) off, STOP SOLENOID (PAGE 345) on	Shutdown
	all cranking attempts elapsed	FUEL SOLENOID (PAGE 326) off, STOP SOLENOID (PAGE 345) on	Shutdown (Start fail)
Running	Stop request	READY TO LOAD (PAGE 343) off, Cooling Time (page 176) counter started	Cooling
	RPM = 0 or any other shutdown condition	READY TO LOAD (PAGE 343) off, FUEL SOLENOID (PAGE 326) off	Shutdown
	GCB CLOSE/OPEN (PAGE 327) closed		Loaded
Loaded	GCB CLOSE/OPEN (PAGE 327) opened		Running
	RPM = 0 or any other shutdown condition	FUEL SOLENOID (PAGE 326) off, STOP SOLENOID (PAGE 345) on, READY TO LOAD (PAGE 343) off,	Shutdown
Cooling	Cooling Time (page 176) elapsed	FUEL SOLENOID (PAGE 326) off, STOP SOLENOID (PAGE 345) on	Stop
	RPM = 0 or any other shutdown condition	FUEL SOLENOID (PAGE 326) off, STOP SOLENOID (PAGE 345) on	Shutdown
	Start request	READY TO LOAD (PAGE 343) on	Running
Stop	RPM = 0, Oil pressure not detected, Generator voltage < 10V, D+ not active		Ready
	If at least one of engine running indication is detected when Stop Time (page 176) elapsed.		Stop (Stop fail)

Note: If all generator parameters are OK and Minimal Stabilization Time (page 174) elapsed, indicates that GCB is possible to close. In AUTO Mode GCB is closed in this moment automatically.

Note: The start-up sequence can be interrupted in any time by stop request

5.4.2 AMF sequence


State	Condition of the transition	Action	Next state
Mains operation	Mains failed or MCB FEEDBACK (PAGE 309) dropout, MCB Opens On (page 207) = Mains Fail	MCB CLOSE/OPEN (PAGE 335) off, Emergency Start Delay (page 200) timer started	Mains failure
	Mains failed or MCB FEEDBACK (PAGE 309) dropout, MCB Opens On (page 207) = Gen Run	Emergency Start Delay (page 200) timer started	Mains failure
Mains failure	Mains voltage and frequency OK, MCB Opens On (page 207) = Mains Fail	After elapsing MCB Close Delay (page 202) MCB CLOSE/OPEN (PAGE 335) on	Mains operation
	Mains voltage and frequency OK, MCB Opens On (page 207) = Gen Run	None	Mains operation
	Emergency Start Delay (page 200) elapsed, MCB Opens On (page 207) = Mains Fail	Engine start sequence performed, then GCB CLOSE/OPEN (PAGE 327) on	Island operation
	Emergency Start Delay (page 200) elapsed, MCB Opens On (page 207) = Gen Run	Engine start sequence performed, then MCB CLOSE/OPEN (PAGE 335) off, time delay Transfer Delay (page 201) performed and GCB CLOSE/OPEN (PAGE 327) on	Island operation
Island operation	Mains voltage and frequency OK	Mains Return Delay (page 200) timer started	Mains return
Mains return	Mains failed		Island operation
	Mains Return Delay (page 200) elapsed	GCB CLOSE/OPEN (PAGE 327) off, then after Transfer Delay (page 201) MCB CLOSE/OPEN (PAGE 335) on and then engine stop sequence performed	Mains operation

Note: Mains failed means mains over/under -voltage, over/under -frequency, voltage asymmetry (preset delay must elapse)

Note: If during start-up sequence mains returns, then MCB is reclosed with delay **MCB Close Delay (page 202)**(if opened, depending on **MCB Opens On (page 207)** setpoint) and start-up sequence is interrupted.

Note: If mains fails during stop procedure (cooling) again, stop sequence is interrupted, MCB opened and GCB re-closed with **Transfer Delay (page 201)**.

5.4.3 Operating Modes

Selecting the operating mode is done through Left  and Right  buttons on the front panel or by changing the **Controller mode (page 152)** setpoint (from the front panel or remotely).

Note: *If this setpoint is configured as password-protected, the correct password must be entered prior to attempting to change the mode.*





Note: *The mode cannot be changed if Access Lock input is active.*

The following binary inputs can be used to force one respective operating mode independent of the mode setpoint selection:

- ▶ **Remote OFF (page 311)**
- ▶ **Remote TEST (page 313)**
- ▶ **Remote MAN (page 311)**
- ▶ **Remote AUTO (page 310)**



If the respective input is active the controller will change the mode to the respective position according to the active input. If multiple inputs are active, the mode will be changed according to priorities of the inputs. The priorities match the order in the list above. If all inputs are deactivated, the mode will return to the original position given by the setpoint.

OFF

No start of the gen-set is possible. Controller stays in Not ready status and cannot be started any way. The MCB is closed permanently (**MCB Opens On (page 207) = GENRUN**) or is open or closed according to whether the mains is present or not (**MCB Opens On (page 207) = MAINSFAIL**). No AMF function will be performed. The buttons MCB , GCB , Start  and Stop  including the appropriate binary inputs for external buttons are not active.

IMPORTANT: When engine is running, it is not possible to switch gen-set to OFF mode.

MAN

The engine can be started and stopped manually using the Start  and Stop  buttons (or external buttons wired to the appropriate binary inputs) in MAN mode. When the engine is running, GCB can be closed. Also MCB can be closed and opened manually using the MCB button, regardless of whether the mains are present or not. No auto start is performed.

Note: *The controller provides interlock between GCB and MCB, it means it is never possible to close both CB together.*

AUTO

The controller does not respond to buttons Start , Stop , MCB ON/OFF  and GCB ON/OFF . Engine start/stop request is evaluated from Mains failure/return.

Note: *When the AMF function will start the engine than the engine will be running at least for the time which is defined in **Mains Return Delay (page 200)** setpoint, even if the mains would return in the meantime.*

TEST

The gen-set will be started when the controller is put to TEST mode and will remain running unloaded. If a mains failure occurs, the MCB will be opened and after **Transfer Delay (page 201)** the GCB will be closed and the gen-set will supply the load. After the mains have recovered, the delay **Mains Return Delay (page 200)** will count down and if it elapses and the mains is still ok, the controller will transfer the load back to the mains after **Transfer Delay (page 201)** and the gen-set will remain running unloaded again until the mode is changed.

Remote test on load

When binary input is closed, the controller automatically transfers load from the mains to the gen-set. See **LBI REM TEST ON LOAD (PAGE 312)**.

5.4.4 Engine start

Diesel engine

- ▶ After the command for start is issued (pressing Start button in MAN mode, auto start condition is fulfilled in AUTO mode or controller is switched to TEST mode), outputs **PRESTART (PAGE 341)** and **GLOW PLUGS (PAGE 332)** are energized for time period given by the setpoints **Prestart Time (page 161)** and **Glow Plugs Time (page 162)**.
- ▶ After **Prestart Time (page 161)** and **Glow Plugs Time (page 162)**, the output **FUEL SOLENOID (PAGE 326)** is energized and after **Fuel Solenoid Lead (page 172)** the starter of motor is activated by energizing the output **STARTER (PAGE 344)**.
- ▶ When one or more of following conditions are met, the starter output is de-energized:
 - The engine speed exceeds the value of **Starting RPM (page 161)**, or
 - One of **Additional running engine indications (page 102)** signals becomes active.
- ▶ The controller remains in the Starting phase until the engine speed exceeds the value of **Starting RPM (page 161)**, after that it is considered as started and the Idle period will follow.
- ▶ The maximum duration that the output **STARTER (PAGE 344)** is energized is determined by the setpoint **Maximum Cranking Time (page 160)**. If the engine does not start within this period, the output **STARTER (PAGE 344)** is de-energized and a pause with length determined by **Cranking Fail Pause (page 160)** will follow. **PRESTART (PAGE 341)** and **GLOW PLUGS (PAGE 332)** outputs are active during the pause. After the pause has elapsed, the next start attempt is executed. The number of start attempts is given by the setpoint **Cranking Attempts (page 160)**.
- ▶ Once the engine is started, the Idle period follows. The binary output **IDLE/NOMINAL (PAGE 335)** remains inactive (as it was during the start). The idle period duration is adjusted by the setpoint **Idle Time (page 172)**.
- ▶ After the idle period has finished, the output **IDLE/NOMINAL (PAGE 335)** is activated and the start-up sequence is finished. The **Stabilization (page 81)** phase follows.




Image 5.11 Flowchart of start of diesel engine

5.4.5 Stabilization

When the **Engine start (page 79)** sequence is finished, the gen-set goes into the stabilization phase. There are two timers (setpoints) in this phase:

- ▶ **Minimal Stabilization Time (page 174)** starts to count down just after the idle period has finished. Generator voltage and frequency are not checked (respective protections are not evaluated) and the GCB cannot be closed even if the generator voltage and frequency are within limits.
- ▶ **Maximal Stabilization Time (page 175)** starts to count down just after the idle period has finished. Generator voltage and frequency are not checked (respective protections are not evaluated) but, opposite to the previous timer, the GCB can be closed if generator voltage and frequency are within limits.

In situations where the GCB is closed automatically (AUTO, TEST modes), the closing of GCB will occur in the first moment when the generator voltage and frequency will get into limits and the **Minimal Stabilization Time (page 174)** has already elapsed.

In the event that the generator voltage or frequency are not within limits within the **Maximal Stabilization Time (page 175)** period, the appropriate protection(s) will be activated and the gen-set will be cooled down and stopped.

Note: The limits for the generator voltage and frequency are given by setpoints in the **Group: Generator settings (page 192)**.

Note: The value of the **Minimal Stabilization Time (page 174)** setpoint has to be lower than the value of **Maximal Stabilization Time (page 175)** setpoint.

5.4.6 Connecting to load

When the **Stabilization (page 81)** phase is finished, the gen-set can be connected to the load.

The command for connecting the gen-set to the load is issued either automatically (AUTO, TEST modes) or manually by pressing the GCB button. The following conditions must be valid:

- ▶ The gen-set is running and the **Minimal Stabilization Time (page 174)** timer has elapsed.
- ▶ The gen-set voltage and frequency are within limits.

5.4.7 MRS operation

The "MRS function" represents manual or remote start of gen-set. It is ideal for prime power applications.

The MRS procedure

When the start command is detected, the following steps are performed:

- ▶ The gen-set is started.
- ▶ GCB is closed and the gen-set begins to supply the load (in AUTO mode, otherwise GCB button has to be pressed)

When the stop command is detected, the following steps are performed:

- ▶ GCB is opened and the gen-set stops supply the load.
- ▶ After GCB is opened, the gen-set cools down and a stop.

5.4.8 AMF operation

The "AMF function" represents the automatic start in the event that the mains have failed and stop after the mains have been restored. The automatic start can be enabled or disabled by binary inputs **AMF START BLOCK**

(PAGE 295) or MAINS FAIL BLOCK (PAGE 308).

Note: The AMF function works only in AUTO mode.

Mains failure detection

The mains are considered as faulty when one or more of the following conditions are valid:

- ▶ The mains voltage is out of the limits given by the setpoints Mains Undervoltage (page 203) and Mains Overvoltage (page 202) for a time period longer than Mains < > Voltage Delay (page 203).
- ▶ The mains frequency is out of the limits given by the setpoints Mains Underfrequency (page 204) and Mains Overfrequency (page 203) for a time period longer than Mains < > Frequency Delay (page 204).
- ▶ The MCB close command was not successful and the alarm **Wrn MCB Fail** (page 366) was not reset.
- ▶ Phase rotation is incorrect.

Healthy mains detection

The mains are considered to be healthy when all of following conditions are valid:

- ▶ The mains voltage is within the limits given by the setpoints Mains Undervoltage (page 203) and Mains Overvoltage (page 202).
- ▶ The mains frequency is within the limits given by the setpoints Mains Underfrequency (page 204) and Mains Overfrequency (page 203).
- ▶ The alarm **Wrn MCB Fail** (page 366) is not active (if MCB feedback is active). This condition is not required if MCB is open (MCB feedback is inactive).
- ▶ Phase rotation is correct.

The AMF procedure

When the mains failure is detected, the following steps are performed:

- ▶ If the setpoint MCB Opens On (page 207) is set to Mains Fail, the MCB is opened
- ▶ The timer for automatic start of the gen-set Emergency Start Delay (page 200) begins to count down.
- ▶ After the timer has elapsed, the gen-set is started.

Note: The automatic start of the gen-set due to AMF function can be disabled by the binary inputs **AMF START BLOCK** (PAGE 295) or **MAINS FAIL BLOCK** (PAGE 308).

- ▶ If the setpoint MCB Opens On (page 207) is set to Gen Run, the MCB is opened once the generator voltage is within limits (after Minimal Stabilization Time (page 174) elapses).

Note: If the mains are restored to health and the gen-set is still not connected to the load, the controller interrupts the startup process and closes back the MCB.

- ▶ After Transfer Delay (page 201) elapses, the GCB is closed and the gen-set begins to supply the load.
- ▶ After the mains restored to normal, the timer Mains Return Delay (page 200) begins to count down.
- ▶ Maximum time between closing of MCB and opening GCB is given by the setpoint Transfer Delay (page 201). After GCB is opened, the gen-set cools down and a stop.

IMPORTANT: Controller has this behavior only in AUTO mode!

5.4.9 Engine cool down and stop

The cool down phase follows after the stop command has been issued and the GCB has been opened.

- ▶ Duration of the cool down phase is determined by the setpoint **Cooling Time** (page 176).
- ▶ Cooling is performed either at nominal speed (generator voltage and frequency protections are evaluated) or at idle speed (generator voltage and frequency protections are not evaluated). Selection of the speed is done by the setpoint **Cooling Speed** (page 176).
- ▶ The cool down can be finished manually in MAN mode by pressing the STOP button.
- ▶ If a new start request comes, the cool down will be interrupted and the gen-set will go back to the stabilization phase. If the cooling was at nominal speed, the stabilization timers will not count down again so the GCB is ready to be closed (after 2 seconds delay).

When the cool down is finished, the output **FUEL SOLENOID** (PAGE 326) is de-energized and **STOP SOLENOID** (PAGE 345) is energized. The engine will stop within the time period determined by the setpoint **Stop Time** (page 176). If the engine does not stop within this time, the alarm **Wrn Stop Fail** (page 368) will be issued.

The output **STOP SOLENOID** (PAGE 345) is energized until the engine is stopped, but at least for the duration of **Stop Time** (page 176). If the **Stop Time** (page 176) has elapsed and the engine has still not stopped, the **STOP SOLENOID** (PAGE 345) is de-energized for 5 s and then energized again for **Stop Time** (page 176) and this repeats until the engine is stopped.

Stopped gen-set evaluation

The gen-set is considered as stopped when all of following conditions are valid:

- ▶ The engine speed is lower than 2 RPM.
- ▶ The generator voltage in all phases is lower than 10 V.
- ▶ None of **Additional running engine indications** (page 102) signals is active.

5.4.10 Alarm management

The controller evaluates two levels of alarms. Level 1 – yellow alarm – is a pre-critical alarm that is only informative and does not take any action regarding gen-set control. Level 2 – red alarm – represents a critical situation, where an action must be taken to prevent damage of the gen-set or technology.

- ▶ One alarm of any type can be assigned to each binary input.
- ▶ Two alarms (one yellow and one red type) can be assigned to each analog input.
- ▶ There are also **Built-in alarms** (page 87) with fixed alarm types.
- ▶ Each alarm is written to the **Alarmlist** (page 87).
- ▶ Each alarm causes a record to be written into the history log.
- ▶ Each alarm activates the Alarm and Horn output.
- ▶ Each alarm can cause sending of a SMS message or an email.




Image 5.12 Analog input alarm evaluation principle

Alarm handling

There are three different alarm categories regarding the period when the alarms are evaluated. The category is selectable for alarms assigned to binary/analog inputs and fixed for built-in alarms. The categories are the following:

- ▶ The alarm is evaluated all the time when the controller is switched on.
- ▶ The alarm is evaluated only when the engine is running. This type should be used for e.g. oil pressure. These alarms begin to be evaluated after the engine has been started with the delay given by the setpoint **Protection Hold Off (page 175)**.
- ▶ The alarm is evaluated only when the generator is excited. These alarms begin to be evaluated after the engine has been started and **Maximal Stabilization Time (page 175)** has elapsed or the GCB has been closed. They remain evaluated until cooling has finished. Only Generator under/overvoltage and Generator under/overfrequency belong to this category. This category is not configurable to binary and analog input alarms.

If an alarm is being evaluated and the appropriate alarm condition is fulfilled, the delay of evaluation will start to run. The delay is adjustable by a setpoint (in the case of built-in alarms, analog input alarms) or is adjusted via configuration window in IntelliConfig (in the case of binary input alarms). If the conditions persist, the alarm will activate. The alarm will not activate if the condition is dismissed while the delay is still running.

After pressing the Fault reset button or activating the binary input **FAULT RESET BUTTON (PAGE 305)**, all active alarms change to confirmed state. Confirmed alarms will disappear from the Alarmlist as soon as the respective condition dismisses. If the condition is dismissed before acknowledging the alarm, the alarm will remain in the Alarmlist as Inactive.

Note: The input **SD OVERRIDE (PAGE 313)** can be used for temporary disabling of red alarms to shutdown the engine. This input may be used in situations where providing the power is extremely important – e.g. if the gen-set drives pumps for fire extinguishers (sprinklers).

Alarm states

An alarm can have following states:

- ▶ Active alarm: the alarm condition persists, alarm delay has elapsed.
- ▶ Inactive alarm: the alarm condition has disappeared, but the alarm has not been confirmed.
- ▶ Confirmed alarm: the alarm condition persists, but the alarm has already been confirmed.



Image 5.13 Alarm List

Alarm types - Level 1

The level 1 alarm indicates that a value or parameter is out of normal limits, but has still not reached critical level. This alarm does not cause any actions regarding the gen-set control.

Warning (Wrn)

The alarm appears in the Alarmlist and is recorded into the history log. Activates the output **AL COMMON WRN** (PAGE 318) as well as the standard alarm outputs (**HORN** (PAGE 334) and **ALARM** (PAGE 322)).

Alarm indication only

The alarm indication only alarm does not perform any actions regarding gen-set control. Alarm is only displayed in alarmlist.

History record only (HistRecOnl)

The event is recorded into the history. Standard alarm outputs (**HORN** (PAGE 334) and **ALARM** (PAGE 322)) are not activated.

Alarm types - Level 2

The level 2 level alarm indicates that a critical level of the respective value or parameter has been reached.

Note: It is not possible to start the engine if any red level protection is active or not confirmed.

IMPORTANT: The gen-set can start by itself after acknowledging the alarms if there is no longer an active red alarm and the controller is in **AUTO** or **TEST** mode!

Shutdown (Sd)

The alarm appears in the alarmlist and is recorded into the history log. It causes immediate stop of the Gen-set without cooling phase. Also GCB breaker is open. The gen-set cannot be started again while there is a shutdown alarm in the alarmlist. Activates the output **AL COMMON SD** (PAGE 318) as well as the standard alarm outputs (**HORN** (PAGE 334) and **ALARM** (PAGE 322)).

Breaker open and cool down (BOC)

The event appears in the alarmlist and is recorded into the history log. It causes immediate opening of the GCB and then the standard stop sequence with cooling follows. The gen-set cannot be started again while there is a BOC alarm in the alarmlist. Activates the output **AL COMMON BOC** (PAGE 318) as well as the standard alarm outputs (**HORN** (PAGE 334) and **ALARM** (PAGE 322)).

Sensor fail detection (FLS)

If the measured resistance on an analog input exceeds the valid range, a sensor fail will be detected and a sensor fail message will appear in the **Alarmlist** (page 87). The valid range is defined by the most-left (RL) and most-right (RH) points of the sensor characteristic $\pm 12.5\%$ from RH-RL.

Note: Sometimes there can be problem with lower limit of valid range which can be counted as negative number. In this case the lower limit is set as one half of the RL point of the sensor curve characteristic.




Image 5.14 Sensor fail detection principle

Remote alarm messaging

If communication plug-in module is connected to the controller, the controller can send SMS messages and emails at the moment when a new alarm appears in the **Alarmlist** (page 87) or new event is written in **History log** (page 89). The message will contain a copy of the **Alarmlist** (page 87) or reasons from **History log** (page 89). To enable this function, adjust setpoints **Event Message** (page 232), **Wrn Message** (page 233), **BOC Message** (page 233) and **Sd Messages** (page 233) to ON. Also enter a valid GSM phone number or email address to the setpoints **Telephone Number 1** (page 230), **Email Address 1** (page 231).

The list of all supported terminals shows the table below:

Terminal	Event SMS	Warning SMS	BOC SMS	Shutdown SMS	Event email	Warning email	BOC email	Shutdown email
CM-RS232-485	no	no	no	no	no	no	no	no
CM-Ethernet	no	no	no	no	yes	yes	yes	yes
CM-GPRS	yes	yes	yes	yes	no	no	no	no
CM-4G-GPS	yes	yes	yes	yes	no	no	no	noyes*

Alarmlist

Alarmlist is a container of active and inactive alarms. It will appear automatically on the controller display, if a new alarm occurs, or can be displayed manually from the display menu.

Active alarms are shown as inverted, not yet confirmed alarms are marked with asterisk before them.

Alarmlist contains three types of alarms:

- ▶ Controller built-in alarms
- ▶ User configured alarms on binary or analog inputs
- ▶ ECU alarms

Controller built-in alarms

An alarm message in the alarmlist begins with a prefix, which represents the alarm type (e.g. Wrm, Sd, BOC, MP, MPR). Then the alarm name follows. In some cases the prefix can be omitted.

User configured alarms

An alarm message in the alarmlist begins with a prefix, which represents the alarm type (e.g. Wrm, Sd, BOC). Alarm type is selected by user during the configuration of binary or analog input as alarm. Then the alarm name follows. Name is adjusted by user during the configuration of binary or analog input as alarm.

ECU alarms

The ECU alarms are received from the ECU. The alarms are represented by the Diagnostic Trouble Code, which contains information about the subsystem where the alarm occurred, the alarm type and the alarm occurrence counter.

The most common fault codes are translated into text form. Other fault codes are displayed as a numeric code and the engine fault codes list must be used to determine the reason.

Built-in alarms

Events specification	Protection type	Description
Analog Input 1 Wrm	WRN	Value measured on analog input 1 is </> than Analog Protection 1 Wrm (page 207) setpoint.
Analog Input 1 Sd	SD	Value measured on analog input 1 is </> than Analog Protection 1 Sd (page 208) setpoint.
Analog Input 2 Wrm	WRN	Value measured on analog input 2 is </> than Analog Protection 2 Wrm (page 209) setpoint.
Analog Input 2 Sd	SD	Value measured on analog input 2 is </> than Analog Protection 2 Sd

Events specification	Protection type	Description
		(page 209) setpoint.
Analog Input 3 Wrn	WRN	Value measured on analog input 3 is \neq than Analog Protection 3 Wrn (page 210) setpoint.
Analog Input 3 Sd	SD	Value measured on analog input 3 is \neq than Analog Protection 3 Sd (page 211) setpoint.
Wrn Battery Voltage	WRN	Battery voltage is out of limits given by Battery Undervoltage (page 188) and Battery Overvoltage (page 188) setpoints.
Binary input		Configurable Warning/BOC/Shutdown alarms on the binary inputs.
Sd Battery Flat	SD	If the controller switches off during starting sequence (STARTER (PAGE 344) output is active) it doesn't try to start again and activates this protection (controller assumes bad battery condition).
Sd Start Fail	SD	Gen-set start failed. All crank attempts were tried without success.
Parameters Fail	NONE	Wrong check-sum of parameters. Happens typically after downloading new firmware or changing of the parameter. The controller stays in INIT mode. Check all parameters, change value of at least one parameter.
Sd Gen Lx $>V$ BOC Gen Lx $<V$ (where x=1,2,3)	SD BOC	The generator voltage is out of limits given by Gen $<V$ BOC and Gen $>V$ Sd setpoints.
BOC Gen $>$, $<$ Frequency	BOC	The generator frequency is out of limits given by Generator Overfrequency BOC (page 195) and Generator Underfrequency BOC (page 196) setpoints.
BOC Overload	BOC	The load is greater than the value given by Overload BOC (page 192) setpoint.
Sd Overspeed	SD	The protection comes active if the speed is greater than Overspeed Sd (page 178) setpoint.
Sd Underspeed	SD	During starting of the engine when the RPM reach the value of Starting RPM (page 161) setpoint the starter is switched off and the speed of the engine can drop under Starting RPM (page 161) again. Then the Underspeed protection becomes active. Protection evaluation starts 5 seconds after reaching Starting RPM (page 161) .
Emergency Stop	SD	If the input Emergency Stop is opened shutdown is immediately activated.
GCB Fail	SD	Failure of generator circuit breaker.
MCB Fail	WRN	Failure of mains circuit breaker.
Sd RPM Measurement Fail	SD	Failure of magnetic pick-up sensor for speed measurement. This alarm appears, if starter was disengaged for other reason than overcrossing Starting RPM (page 161) (like oil pressure or D+) and at the end of timer Maximum Cranking Time (page 160) there are no RPMs $>$ Starting RPM (page 161) detected.
Wrn Stop Fail	WRN	Gen-set stop failed. See description at Gen-set Operation States

Events specification	Protection type	Description
		chapter.
Wm Maintenance 1	WRN	The period for servicing is set by the Maintenance Timer 1 (page 187) setpoint. The protection comes if counter reaches zero.
Wm Maintenance 2	WRN	The period for servicing is set by the Maintenance Timer 2 (page 187) setpoint. The protection comes if counter reaches zero.
Wm Maintenance 3	WRN	The period for servicing is set by the Maintenance Timer 3 (page 188) setpoint. The protection comes if counter reaches zero.
Charge Alternator Fail	WRN	Failure of alternator for charging the battery.
Sd Override	WRN	The protection is active if the output Sd Override is closed.
Mains CCW Rot	WRN	Mains voltage phases are not wired correctly. MCB closing is prohibited by chontroller.
Generator CCW Rot	WRN	Genset voltage phases are not wired correctly. GCB closing is prohibited by chontroller.

Note: This table does not contain all alarms in controller. It is only list of the most common alarms.

5.4.11 History log

The history log is an area in the controller’s non-volatile memory that records “snapshots” of the system at moments when important events occur. The history log is important especially for diagnostics of failures and problems. When the history file is full, the oldest records are removed.

Each record has the same structure and contains:

- The event which caused the record (e.g. “Overspeed alarm” or “GCB closed”)
- The date and time when it was recorded
- All important data values like RPM, kW, voltages, etc. from the moment that the event occurred.

Record structure

Name	Abbreviation	Description
Number	No.	Row number (0 corresponds to the last record, -1 to the previous one, etc.)
Reason	Reason	Reason for history record (any event or alarm related to the gen-set)
Time	Time	Time
Date	Date	Date
RPM	RPM	Engine rotations per minute
Power	Pwr	Generator active power
Reactive power	Q	Generator reactive power
Power Factor	PF	Generator power factor
Load Character	LChr	Generator load character
Generator	Gfrq	Generator Frequency

Frequency		
Generator Voltage	Vg1	Generator voltage Ph1
Generator Voltage	Vg2	Generator voltage Ph2
Generator Voltage	Vg3	Generator voltage Ph3
Generator Voltage	Vg12	Generator voltage Ph12
Generator Voltage	Vg23	Generator voltage Ph23
Generator Voltage	Vg31	Generator voltage Ph31
Generator Current	Ig1	Generator current Ph1
Generator Current	Ig2	Generator current Ph2
Generator Current	Ig3	Generator current Ph3
Mains Voltage	Vm1	Mains voltage Ph1
Mains Voltage	Vm2	Mains voltage Ph2
Mains Voltage	Vm3	Mains voltage Ph3
Mains Voltage	Vm12	Mains voltage Ph12
Mains Voltage	Vm23	Mains voltage Ph23
Mains Voltage	Vm31	Mains voltage Ph31
Mains Frequency	Mfrq	Mains Frequency
Voltage Battery	VBat	Voltage of battery
Analog Input 1	Ain1	Analog input 1
Analog Input 2	Ain2	Analog input 2
Analog Input 3	Ain3	Analog input 3
Analog Input 4	Ain4	Analog input 4
Binary Inputs	BIN	Controller binary inputs
Binary Outputs	BOUT	Controller binary outputs
Controller Mode	Mode	Controller mode

Note: When some setpoint is changed, in history log is written its number of communication object.

5.4.12 Breaker control

The following power switches are controlled by the controller:

- ▶ The generator circuit breaker or contactor – GCB
- ▶ The Mains circuit breaker or contactor – MCB

It is possible to use either a motorized circuit breaker or contactor. Below is a list of available control outputs that should fit all types of contactors or breakers. The following rules must be kept to when designing the wiring of power switches:

- ▶ The control outputs must be configured and wiring of the power switches must be provided in such a way, that the controller has full control over the breakers – i.e. the controller can open and close the breaker at any time.
- ▶ The breaker must respond within max. 5 seconds to a close and open command. Special attention should be paid to opening of motorized circuit breakers, as it could take more than 5 seconds on some types. In such cases it is necessary to use an undervoltage coil for fast opening.

- ▶ After opening the breaker, there is internal delay for another closing of breaker. Delay is 6 seconds - 5 seconds for OFF coil and 1 second for UV coil. After these 6 seconds, breaker can be closed again. For opening of breaker there is no delay.

Breaker control outputs

Close/Open	An output for control of a contactor. Its state represents the breaker position requested by the controller. The breaker must react within 2 seconds to a close or open command, otherwise an alarm is issued.
ON coil	An output giving a 2 second pulse in the moment the breaker has to be closed. The output is intended for control of close coils of circuit breakers.
OFF coil	An output giving a pulse in the moment the breaker has to be opened. The pulse lasts until the feedback deactivates, but at least for 2 seconds. The output is intended for control of open coils of circuit breakers.
UV coil	The GCB UV coil output is active the whole time the gen-set is running (not in idle or cooling). The MCB UV coil output is active when the controller is switched on. The output is deactivated for at least 2 seconds in the moment the breaker has to be switched off. The output is intended for control of undervoltage coils of circuit breakers.




Image 5.15 Breaker control outputs

MCB special requirements

- ▶ If a contactor is used on the MCB position, it is recommended that the wiring be provided in such a way that the contactor will be normally closed and will open if the logical binary output **MCB CLOSE/OPEN** (PAGE 335) closes. This behavior is called “negative logic” and can be adjusted by the setpoint **MCB Logic** (page 205). The negative logic will prevent accidental opening of the MCB when the controller is switched off.
- ▶ If a contactor is used on the MCB position, it will open itself immediately after the mains have failed, because it will lose power for the coil. That is why the following adjustment is necessary to prevent triggering

the **Wrn MCB Fail (page 366)** alarm: MCB Opens On (page 207) = Mains Fail, Mains < > Voltage Delay (page 203) ≤ 1.

- ▶ If a 230 V motor driven circuit breaker is used on the MCB position and an undervoltage coil is not fitted, it is not possible to open the breaker after the mains have failed, because there is no power for the motor drive until the gen-set is started and providing voltage. Adjusting the setpoint MCB Opens On (page 207) = Gen Run will prevent triggering the **Wrn MCB Fail (page 366)** alarm.

Breaker fail detection

Breaker fail detection is based on binary output breaker close/open comparing with binary input breaker feedback.

IMPORTANT: It is necessary to configure breaker feedback to use this function.

IMPORTANT: Also it is possible to use breakers without feedbacks. In this case there is no check of breaker real state.

There are three different time delays for breaker fail detection – see following diagrams.

When binary output breaker close/open is in steady state and breaker feedback is changed the breaker fail is detected immediately (no delay).




Image 5.16 Breaker fail - breaker close/open in steady position - open




Image 5.17 Breaker fail - breaker close/open in steady position - close

When binary output breaker close/open opens there is 2 sec delay for breaker fail detection.




Image 5.18 Breaker fail - breaker close/open opens

When binary output breaker close/open closes there is 2 sec delay for breaker fail detection.




Image 5.19 Breaker fail - breaker close/open closes

5.4.13 Exercise timer

The exercise (general-purpose) timer in controller is intended for scheduling of any operations such as e.g. periodic tests of the gen-set, scheduled transfer of the load to the gen-set prior to an expected disconnection of the mains etc.

Related setpoints for timer 1 are:

- ▶ **Timer 1 Function (page 214)**
- ▶ **Timer 1 Day (page 219)**
- ▶ **Timer 1 Repetition (page 215)**
- ▶ **Timer 1 Repeated Day In Week (page 220)**
- ▶ **Timer 1 First Occur. Date (page 216)**
- ▶ **Timer 1 Repeat Day In Month (page 220)**
- ▶ **Timer 1 First Occur. Time (page 216)**
- ▶ **Timer 1 Repeat Week In Month (page 221)**
- ▶ **Timer 1 Duration (page 216)**
- ▶ **Timer 1 Refresh Period (page 218)**
- ▶ **Timer 1 Repeated (page 217)**
- ▶ **Timer 1 Weekends (page 219)**
- ▶ **Timer 1 Repeat Day (page 220)**

Available modes of timer:

Once	This is a single shot mode. The timer will be activated only once at preset date/time for preset duration.
Daily	The timer is activated every "x-th" day. The day period "x" is adjustable. Weekends can be excluded. E.g. the timer can be adjusted to every 2nd day excluding Saturdays and Sundays.
Weekly	The timer is activated every "x-th" week on selected weekdays. The week period "x" is adjustable. E.g. the timer can be adjusted to every 2nd week on Monday and Friday.
Monthly	The timer is activated every "x-th" month on the selected day. The requested day can be selected either as "y-th" day in the month or as "y-th" weekday in the month. E.g. the timer can be adjusted to every 1st month on 1st Tuesday.
Short period	The timer is repeated with adjusted period (hh:mm). The timer duration is included in the period.

Once mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 214).




Image 5.20 Once mode - IntelliConfig

In timer mode select Once. In timer settings adjust date and time of occurrence of timer. Also adjust the duration of timer.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via *Timer 1 Function* (page 214) setpoint. Than go to *Timer 1 Setup* and press enter button. In *Timer 1 Repetition* (page 215) setpoint select Once

mode. Then adjust Timer 1 First Occur. Date (page 216), Timer 1 First Occur. Time (page 216) and Timer 1 Duration (page 216).

Note: Use left and right buttons to move between timer setpoints.

Daily mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 214).




Image 5.21 Daily mode - IntelliConfig

In timer mode select Repeat. In repetition type select Daily. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Then select the x-th day of repetition (*Timer 1 Refresh Period* (page 218)) and behavior of timer on weekends (*Timer 1 Weekends* (page 219)).

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 3rd day at 12:00 for 1 hour including weekends.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via *Timer 1 Function* (page 214) setpoint. Then go to *Timer 1 Setup* and press enter button. In *Timer 1 Repetition* (page 215) setpoint select Repeated mode. Then adjust *Timer 1 First Occur. Date* (page 216), *Timer 1 First Occur. Time* (page 216) and *Timer 1 Duration* (page 216). In setpoint *Timer 1 Repeated* (page 217) select Daily and adjust *Timer 1 Refresh Period* (page 218) (x-th day of repetition) and *Timer 1 Weekends* (page 219) (behavior of timer on weekends).

Note: Use left and right buttons to move between timer setpoints.

Weekly mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 214).




Image 5.22 Weekly mode - IntelliConfig

In timer mode select Repeat. In repetition type select Weekly. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Then select the x-th week of repetition (*Timer 1 Refresh Period* (page 218)) and days when timer should be active (*Timer 1 Day* (page 219)).

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 2nd week on Monday, Wednesday and Friday at 12:00 for 1 hour.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via *Timer 1 Function* (page 214) setpoint. Then go to *Timer 1 Setup* and press enter button. In *Timer 1 Repetition* (page 215) setpoint select Repeated mode. Then adjust *Timer 1 First Occur. Date* (page 216), *Timer 1 First Occur. Time* (page 216) and *Timer 1 Duration* (page 216). In setpoint *Timer 1 Repeated* (page 217) select Weekly and adjust *Timer 1 Day* (page 219) (days when timer should be active) and *Timer 1 Refresh Period* (page 218) (x-th week of repetition).

Note: Use left and right buttons to move between timer setpoints.

Monthly mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 214).

There are two types of monthly repetition. First of them is based on repeating one day in month.




Image 5.23 Monthly mode - IntelConfig

In timer mode select Repeat. In repetition type select Monthly. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Than select the type of monthly repetition and the x-th day of repetition (Timer 1 Repeat Day In Month (page 220)). Than select the x-th month of repetition.

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 2nd day in 2nd month at 12:00 for 1 hour.

Second type of monthly repetition is based on repeating days in week in month.




Image 5.24 Monthly mode - Intelliconfig

In timer mode select Repeat. In repetition type select Monthly. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Then select the type of monthly repetition, the x-th week of repetition and days in week. Then select the x-th month of repetition.

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 2nd week in 2nd month on Monday, Wednesday and Friday at 12:00 for 1 hour.

Set-up via controller interface

There are two types of monthly repetition. First of them is based on repeating one day in month.

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function (page 214)** setpoint. Then go to **Timer 1 Setup** and press enter button. In **Timer 1 Repetition (page 215)** setpoint select Repeated mode. Then adjust **Timer 1 First Occur. Date (page 216)**, **Timer 1 First Occur. Time (page 216)** and **Timer 1 Duration (page 216)**. In setpoint **Timer 1 Repeated (page 217)** select Monthly and adjust type of monthly repetition via **Timer 1 Repeat Day (page 220)**, **Timer 1 Refresh Period (page 218)** (x-th month of repetition) and **Timer 1 Repeat Day In Month (page 220)** (concrete day in repeated months).

Second type of monthly repetition is based on repeating days in week in month.

In controller go to the Scheduler setpoint group. Select the function of timer via **Timer 1 Function (page 214)** setpoint. Then go to **Timer 1 Setup** and press enter button. In **Timer 1 Repetition (page 215)** setpoint select Repeated mode. Then adjust **Timer 1 First Occur. Date (page 216)**, **Timer 1 First Occur. Time (page 216)** and **Timer 1 Duration (page 216)**. In setpoint **Timer 1 Repeated (page 217)** select Monthly and adjust type of monthly repetition via **Timer 1 Repeat Day (page 220)**, **Timer 1 Refresh Period (page 218)** (x-th month of repetition), **Timer 1 Repeated Day In Week (page 220)** (days in week when timer is active) and **Timer 1 Repeat Week In Month (page 221)** (concrete week in repeated months).

Note: Use left and right buttons to move between timer setpoints.

Short period mode

Set-up via IntelliConfig

To set-up timer via IntelliConfig go to the setpoint ribbon, setpoint group scheduler and setpoint *Timer 1 Setup*.

Note: First of all function of timer has to be adjusted via setpoint *Timer 1 Function* (page 214).




Image 5.25 Short period mode - IntelliConfig

In timer mode select Repeat. In repetition type select Short period. In timer settings adjust date and time of first occurrence of timer. Also adjust the duration of each occurrence of timer. Then select the interval of repetition (shorter than 1 day).

Example: On image example first start of timer will be 1/1/2016 at 12:00. Duration will be 1 hour. Timer will be again activated every 4th hour for 1 hour.

Set-up via controller interface

In controller go to the Scheduler setpoint group. Select the function of timer via *Timer 1 Function* (page 214) setpoint. Then go to *Timer 1 Setup* and press enter button. In *Timer 1 Repetition* (page 215) setpoint select Repeated mode. Then adjust *Timer 1 First Occur. Date* (page 216), *Timer 1 First Occur. Time* (page 216) and *Timer 1 Duration* (page 216). In setpoint *Timer 1 Repeated* (page 217) select Short Period and adjust *Timer 1 Refresh Period* (page 218) (interval of repetition).

Note: Use left and right buttons to move between timer setpoints.

5.4.14 Service timers

Service timers are used as maintenance interval counters. Counters can be set by setpoints - *Maintenance Timer 1* (page 187), *Maintenance Timer 2* (page 187) and *Maintenance Timer 3* (page 188). All of them work the same way - their values are decremented every hour when the gen-set is running.

Actual value of counters is located either as the same setpoints **Maintenance Timer 1 (page 187)**, **Maintenance Timer 2 (page 187)** and **Maintenance Timer 3 (page 188)** or as values **Maintenance 1 (page 277)**, **Maintenance 2 (page 278)** and **Maintenance 3 (page 278)**.

When the value of counter reaches 0, the alarm **Wrn Maintenance 1 (page 365)** or **Wrn Maintenance 2 (page 366)** or **Wrn Maintenance 3 (page 366)** is active until the respective counter is readjusted back to nonzero value.

Unused timer has to be adjusted to maximal value 10000 (OFF).

5.4.15 Flowchart




Image 5.26 Basic flowchart of controller sequences

5.4.16 Additional running engine indications

It is helpful to have information other than speed (RPM), whether the engine is rotating or not, especially if RPM is measured from the generator frequency instead of magnetic pickup. The generator frequency measurement can be unreliable at very low speeds and/or may have a delayed reaction to sudden and big changes (i.e. in the moment that the engine has just started...).

The following conditions are evaluated as additional running engine indication:

- ▶ Voltage on the D+ input is higher than **D+ Threshold (page 170)** of battery voltage. Connect this input to the D+ (L) terminal of the charging alternator and enable the D+ function by the setpoint D+ Function. If D+ terminal is not available, leave the input unconnected and disable the function.
- ▶ The pickup is not used and frequency is not detected on the pickup input. Connect the pickup input to the W terminal of the charging alternator if you do not use pickup and the W terminal is available. If not, leave the input unconnected.
- ▶ Oil pressure > **Starting Oil Pressure (page 162)** setpoint. The oil pressure is evaluated from the analog input or from the ECU if an ECU is configured.
- ▶ At least one phase of generator voltage is >25% of nominal voltage.

These signals are used during start for powering down the starter motor even if still no RPM is measured and also during stop in order to evaluate if the engine is really stopped.

5.4.17 Voltage phase sequence detection

Controller detects phase sequence voltage terminals. This protection is important after controller installation to avoid wrong voltage phase connection. There is fix defined phase sequence in controller L1, L2, L3. When the phases are connected in different order (e.g. L1,L3,L2 or L2,L1,L3) following alarms are detected:

- ▶ **Generator CCW Rotation (page 369)**
- ▶ **Mains CCW Rotation (page 370)**

5.4.18 Gen-set operation states

Engine state machine

Init	Autotest during controller power on. <i>Note: Sometimes controller stays in Init mode after FW upgrade. It means that there are new parameters which should be checked by user. It is possible to disable this control via IntelliConfig.</i>
Not ready	Gen-set is not ready to start. ■ Example: When shutdown alarm is active or unit is in OFF mode.
Prestart	Prestart sequence in process, PRESTART (PAGE 341) output is closed. ■ Example: Usually used for preheating or processes executed prior gen-set start.
Cranking	Engine is cranking, STARTER (PAGE 344) output is closed
Pause	Pause between start attempts.
Starting	Starting speed is reached and the Idle timer is running.
Running	Gen-set is running at nominal speed.
Loaded	Gen-set is running at nominal speed and GCB CLOSE/OPEN (PAGE 327) is closed.

Stop	Stop. Example: Automatic or manual stop command was issued, engine is stopping.
Shutdown	Shut-down alarm activated.
Ready	Gen-set is ready to run.
Cooling	Gen-set is cooling before stop.

Engine started conditions

- ▶ Engine speed (RPM) > Starting RPM (page 161) or
- ▶ Oil pressure > Starting Oil Pressure (page 162) or
- ▶ D+ terminal active (reached D+ Treshold (page 170) of supply voltage) for minimum 1 s or
- ▶ Generator voltage > 25% of Nominal Voltage Ph-N (page 149) or Nominal Voltage Ph-Ph (page 149) (any phase)

Note: Any of these condition will disconnect starter of the engine, however for transition to next state RPM needs to be higher than Starting RPM (page 161).

Engine running conditions

- ▶ Engine speed (RPM) > Starting RPM (page 161) or
- ▶ Oil pressure > Starting Oil Pressure (page 162) or
- ▶ Generator voltage > 25% of Nominal Voltage Ph-N (page 149)

Still engine conditions

- ▶ Engine speed (RPM) < Starting RPM (page 161) or
- ▶ Oil pressure < Starting Oil Pressure (page 162) or
- ▶ Generator voltage < 50 V (any phase)

Note: When the engine was running before and all above conditions are fulfilled, additional 2 s delay is necessary to confirm “still engine”.

When any engine running conditions are appeared on still engine than the **Wrn Stop Fail (page 368)** is activated with following delay:

- ▶ for generator voltage from 10 V to < 50 % of nominal voltage, Wrn Stop Fail has delay 1 s
- ▶ for generator voltage > 50 % of nominal voltage, Wrn Stop Fail has delay 200 ms
- ▶ Oil pressure > Starting Oil Pressure (page 162), Wrn Stop Fail has delay 1 s
- ▶ for detected RPM, there is no delay.

Stop engine conditions

If no engine running conditions are validated than the controller will wait extra 12 s before leaving the Machine state Stop and than it will release the **STOP SOLENOID (PAGE 345)** output.




Image 5.27 Engine stops in **Stop Time** (page 176)

When the total time of stopping will exceed setpoint **Stop Time** (page 176) than the **Wrrn Stop Fail** (page 368) and binary outputs are activated. The controller will continuously try to stop the engine.




Image 5.28 Engine stops after first **Stop Time** (page 176)

Electric state machine

MainsOper	Mains is present and all its values are within limits. ■ Example: MCB is closed, GCB is opened
MainsFlt	Mains fails
IslOper	Island operation ■ Example: MCB is opened, GCB is closed
MainsRet	Mains recover
BrksOff	GCB, MCB opened

5.4.19 Sensor curves

Default sensor curves

There are 16 default resistive curves available. The following table provides information on minimum/maximum values of respective sensors. Actual values especially of temperature curves may differ. Meaning is to prolong curve to the lower temperature values, so the cold engine will not raise alarm fail sensor.

Curve	Min [Ohm]	Max [Ohm]	Units
VDO 10 Bar 0-2400ohm	0	2400	Bar
VDO40-120°C0-2400ohm	0	2400	°C
VDOLevel%0-2400ohm	0	2400	%
General line 1	0	1000	ohm
General line 2	0	1000	ohm
General line 3	0	1000	ohm
General line 4	0	1000	ohm
General line 5	0	1000	ohm
General line 6	0	1000	ohm
General line 7	0	1000	ohm
General line 8	0	1000	ohm
General line 9	0	1000	ohm
General line 10	0	1000	ohm
General line 11	0	1000	ohm
General line 12	0	1000	ohm
General line 13	0	1000	ohm

Note: Curves can be modified via *InteliConfig*. In *InteliConfig* are also prepared some standard curves.

IMPORTANT: For right behavior of function, curve for this analog input has to be in percentage.

5.4.20 Tier 4 Final

Tier 4 Final support generally provides monitoring and control of after-treatment system installed on generators engine. The requirements are defined as:

- ▶ Providing After-Treatment status information by
 - displaying universal lamps (icons)
 - displaying analog and binary values
- ▶ Control of After-Treatment regeneration function by
 - transmitting commands to the ECU

Providing After-Treatment status information

After-Treatment screen

This screen is shown with configured ECU which supports Tier 4 Final. After-Treatment screen is automatically shown, once any of selected lamps gets active or change status. Deactivating of the lamp will not trigger showing the screen. The screen is then shown until operator switch it to another one. Alarmlist screen has lower priority so even new alarm appears, After-treatment screen is still displayed. To avoid displaying blank screen, inactive lamps are represented by "dotted" icons. For no active lamp the screen shows all dotted icons. Please see examples below:




Image 5.29 Example of active Tier 4 Final screen




Image 5.30 Example of inactive Tier 4 Final screen











Universal lamps (icons)







Universal lamp icons are shown on the After-Treatment screen. Based on specific value read in specific frame with specific SPN is every lamp icon either:

- ▶ shown
- ▶ hidden

- ▶ blinking slow (1 Hz)
- ▶ blinking fast (2 Hz)

Note: Lamp icon blinking is defined as displaying active lamp icon and inverse colored active lamp icon in required frequency.

Lamp name	Active icon	Inactive icon	Notes
Amber warning lamp			Note: This value can light or blink on both frequencies.
Red stop lamp			Note: This value can light or blink on both frequencies.
Engine wait to start lamp			
DPF/SCR lamp command			Note: DPF = Diesel Particulate Filter; SCR = Selective Catalytic Reduction. This lamp also activates alarm After-Treatment (page 368).
Exhaust system high temperature lamp command			Note: This lamp also activates alarm After-Treatment (page 368).

Lamp name	Active icon	Inactive icon	Notes
Malfunction indicator lamp			<i>Note: This value can light or blink on both frequencies. This lamp also activates alarm After-Treatment (page 368).</i>
Fluid tank low level indicator			<i>Note: This lamp also activates alarm After-Treatment (page 368).</i>
DPF regeneration inhibited			<i>Note: Indicates the state of diesel particulate filter active regeneration inhibition. This lamp also activates alarm After-Treatment (page 368).</i>

Analog values

Supported analog values:

- ▶ DPF Ash Load (page 261)
- ▶ DPF Soot Load (page 261)
- ▶ DEF Level (page 261)

Control of After-Treatment regeneration function

User can force or inhibit regeneration process by activating appropriate binary inputs of the controller. Please see the list of binary inputs below:

- ▶ FORCE REGENERATION (PAGE 305)
- ▶ REGENERATION INHIBIT (PAGE 310)

5.4.21 Alternate configuration

In controller are 3 sets of configuration.

Configuration set 1	Configuration set 2	Configuration set 3
Nominal Power Split Phase 1 (page 241)	Nominal Power Split Phase 2 (page 245)	Nominal Power Split Phase 3 (page 249)
Nominal Power 1 (page 241)	Nominal Power 2 (page 245)	Nominal Power 3 (page 249)
Nominal RPM 1 (page 239)	Nominal RPM 2 (page 243)	Nominal RPM 3 (page 247)
Nominal Frequency 1 (page 239)	Nominal Frequency 2 (page 244)	Nominal Frequency 3 (page 248)
Nominal Voltage Ph-N 1 (page 240)	Nominal Voltage Ph-N 2 (page 244)	Nominal Voltage Ph-N 3 (page 248)
Nominal Voltage Ph-Ph 1 (page 240)	Nominal Voltage Ph-Ph 2 (page 244)	Nominal Voltage Ph-Ph 3 (page 248)
Nominal Current 1 (page 242)	Nominal Current 2 (page 246)	Nominal Current 3 (page 250)
Connection Type 1 (page 242)	Connection type 2 (page 246)	Connection type 3 (page 250)
ECU Speed Adjustment 1 (page 253)	ECU Speed Adjustment 2 (page 255)	ECU Speed Adjustment 3 (page 257)

Configuration sets can be changed via logical binary inputs **ALTERNATE CONFIG 2 (PAGE 295)** and **ALTERNATE CONFIG 3 (PAGE 295)**. Configuration set 1 is active when there is no input activated. In case that inputs **ALTERNATE CONFIG 2 (PAGE 295)** and **ALTERNATE CONFIG 3 (PAGE 295)** are active at the same time, the configuration set 3 is taken into account.

ALTERNATE CONFIG 2 (PAGE 295)	ALTERNATE CONFIG 3 (PAGE 295)	Active configuration set
0	0	1
1	0	2
0	1	3
1	1	3

5.4.22 E-Stop

Binary outputs for the control of some essential functions are internally wired as "safe", it means, that their deactivation is directly bind with the dedicated Input E-STOP (not evaluated as the LBI in the controller). This BO are fully configurable and are used e.g. for the Starter and Fuel control.

- ▶ The emergency stop circuit must be secured.
- ▶ No accidental activation on the PCB, circuit must disable the operation of the emergency stop.
- ▶ The power supply of the associated binary outputs (BIN1 and BIN2) is supplied by the E-STOP input, not by the + battery voltage.

Note: There is no difference in the way of configuration of all binary outputs. Binary outputs BO1 (Starter), BO2 (Fuel Solenoid) are intended for these functions (not dedicated).

There is a measuring of E-STOP input voltage analogically and setting the binary value (representing emergency stop input level) based on comparison of the measured voltage to two analog levels, which are derived from the controller supply voltage (battery voltage) perceptually.




Image 5.31 SW principle of E-STOP

- ▶ If the input voltage of E-stop is higher than high comparison level (for ex. higher than 80% of the supply voltage), then E-stop is not activated.
- ▶ If the input voltage of E-stop is lower than low comparison level (for ex. lower than 60% of the supply voltage), then E-stop is activated.

If the input voltage of E-stop is located somewhere between low and high comparison levels (for ex. between 60 and 80 % of the supply voltage), then E-stop binary value will stay on its previous state (means E-stop binary value will not change).

Visualization on CU screen

- ▶ 1 - E-STOP has voltage - state is OK
- ▶ 0 - E-STOP has no voltage - protection is active

More information about connection **see E-Stop on page 34.**

5.4.23 ECU Frequency selection

Setpoint *ECU Freq Select* is no longer in use. However *ECU Frequency Select* (page 264) value was kept and the value can be calculated from *Nominal Frequency* (page 150) setpoint. Sequence for frequency change is executed automatically (engine must be in still condition and ECU is powered on – ECU Power Relay is not configured) in following 9 steps:

1. Starting of the engine is blocked (state: Not Ready)
2. Wait 100 ms
3. *ECU Stop Pulse* is set for 1000 ms (standard Stop Pulse duration)
4. Wait 3000 ms
5. Frequency selection is changed to a new value
6. Wait 2000 ms
7. *ECU Stop Pulse* is set for 1000 ms (standard Stop Pulse duration)
8. Wait 2000 ms
9. Come back from start blocking state

This sequence does not control LBO **ECU POWER RELAY** (PAGE 324) anyhow.

Note: If LBO **ECU POWER RELAY** (PAGE 324) is used, this change can be make only in prestart phase. So prestart has to be set up for enough long time.

 **back to Functions**

6 Communication

6.1 PC 111
 6.2 Connection to 3rd party systems 124

 [back to Table of contents](#)

6.1 PC

6.1.1 Direct communication 111
 6.1.2 Remote communication 113

6.1.1 Direct communication

A RS232, USB, RS485 or ethernet interface can be used for direct cable connection to a PC.

Connection via RS232

A plug-in communication module CM-RS232-485 is necessary for communication via RS232 connection. The module is plugged into the slot located on the rear side of the controller. To find more information about installation of the modules **see Plug-in module installation on page 43**.

RS232 interface uses **COM1 Mode (page 221)** port of the controller. Use a cross-wired serial communication cable with DB9 female connectors and signals Rx, Tx, GND.

Note: Also USB-RS232 convertor can be used.




Image 6.1 Cross-wired RS232 cable is used




Image 6.2 Cross-wired RS232 cable and USB is used

Connection via RS485

A plug-in communication module CM-RS232-485 is necessary for communication via RS485 connection.

The module is plugged into the slot located on the rear side of the controller. To find more information about installation of the modules **see Plug-in module installation on page 43.**

RS485 interface uses **COM2 Mode (page 223)** port of the controller. Use a cross-wired serial communication cable with DB9 female connectors and signals Rx, Tx, GND.

Note: Also USB-RS485 convertor can be used.




Image 6.3 RS485 cable is used

Connection via Ethernet

A plug-in communication module CM-Ethernet is necessary for ethernet connection.

The module is plugged into the slot located on the rear side of the controller. To find more information about installation of the modules **see Plug-in module installation on page 43.**

This connection type is used for communication with the controller from InteliConfig or any other PC tool. . Only three remote clients can be connected at the same time.

To connect your PC tool to the controller use the INTERNET connection type and just put the CM-Ethernet IP address into the gen-set address box in the PC tool.




Image 6.4 Ethernet cable is used

Connection via USB

USB interface uses HID profile.




Image 6.5 Shielded USB type A cable is used

 **back to Communication**

6.1.2 Remote communication

A PC can be connected to the controller also remotely via CM-GPRS or CM-Ethernet plug-in module.

IMPORTANT: Factory default password and access code are "0". It is highly recommended to change these parameters.

Ethernet LAN connection

Direct IP LAN connection is intended to be used if the CM-Ethernet module is reachable from the client computer by specifying the IP address at which the module can be contacted.

- ▶ If direct IP connection is to be used within a local network the CM-Ethernet must have static IP address in the respective local network.




Image 6.6 Ethernet LAN connection

Setting-up static IP address

There are two basic ways to get the static IP address.

First way is to switch the CM-Ethernet to manual IP address mode. Adjust the setpoint **IP Address Mode** (page 235) to **FIXED**. In that case all setpoints of IP settings (**IP Address** (page 236), **Subnet Mask** (page 236), **Gateway IP** (page 237), **DNS IP Address 1** (page 237)) have to be adjusted manually. If this method is used several basic rules should be kept to avoid conflicts with the remaining network infrastructure:

- ▶ The static IP used in the controller must be selected in accordance with the local network in which CM-Ethernet is connected.
- ▶ The static IP used in the controller must be excluded from the pool of addresses which is assigned by DHCP server, which is in charge of the respective local network.
- ▶ The local infrastructure must generally allow using devices with manually assigned IP addresses.
- ▶ There must not be any other device using the same static IP address. This can be tested from a computer connected to the same network using "ping <required_ip_address>" command issued from the command line. The IP address is not occupied if there is not any response to the ping command.

Note: The list above contains only basic rules. Other specific restrictions/rules may take place depending on the local network security policy, technology used, topology etc.

Next way is to switch the CM-Ethernet to automatic IP address mode. Adjust the setpoint **IP Address Mode** (page 235) to **AUTOMATIC**. In that case all IP settings are assigned by DHCP server. Then configure the


DHCP server to assign always the same IP address (i.e. static IP address) to the particular CM-Ethernet according to its MAC address.

Internet connection

Public static IP

If public static IP connection is to be used from the Internet, the IP address, which is entered into the client computer, must be static and public in scope of the Internet.

- ▶ If CM-Ethernet is connected to Internet via a local ethernet network then in most cases port forwarding must be created from the public IP address of the network gateway to the local IP address of CM-Ethernet at the port specified for ComAp protocol. Different port numbers can be used to create multiple port forwarding rules in the same local network.



SMS

Event SMS

The IntelliLite 9 controller equipped with the CM-GPRS or CM-4G-GPS communication module is able to send Event SMS according to the setting of setpoint:

- ▶ **Event Message (page 232)**

Note: Firstly setpoint Telephone Number 1 (page 230) has to be adjusted.

The following events can be received by mobile phone:

- ▶ Engine Start/Stop
 - Manual Start/Stop
 - Remote Start/Stop
 - AMF Start/Stop (as Automatic Mains Failure Start/Stop)
 - Test Start/Stop Gen-set
- ▶ Mains Fail
- ▶ Mains Returned
- ▶ Load on Mains
- ▶ Load on Gen-set
- ▶ Test On Load

Message structure:

- ▶ Genset Name (hh:mm:ss dd.mm.yyyy)
- ▶ hh:mm:ss Mains Fail
- ▶ hh:mm:ss AMF Start
- ▶ hh:mm:ss Load on Genset
- ▶ hh:mm:ss Mains Returned
- ▶ hh:mm:ss Load on Mains
- ▶ hh:mm:ss AMF Stop

Alarm SMS

The IntelliLite 9 controller equipped with the CM-GPRS or CM-4G-GPS communication module is able to send Alarm SMS according to the setting of setpoints:

- ▶ Wrn Message (page 233)
- ▶ BOC Message (page 233)
- ▶ Sd Messages (page 233)

Note: Firstly setpoint Telephone Number 1 (page 230) has to be adjusted.

Message structure:

- ▶ Gen-set Name
- ▶ AL=(Alarm 1, Alarm 2, Alarm x)

Note: Asterisk means that alarm is unconfirmed and exclamation mark means that alarm is active.

SMS commands

To control the gen-set equipped with IntelliLite 9 controller and CM-GPRS or CM-4G-GPS communication module (or modem) via SMS requests, send an SMS in the structure of:

xxxx, yyyy, zzzz, etc.

SMS send to the telephone number of the SIM card in your CM-GPRS module (or modem). Where the “#” mark means the controller access code, “xxxx” means the Command 1, “yyyy” is Command 2, “zzzz” is Command 3, etc.

Note: Access code is set up via IntelliConfig.

IMPORTANT: If wrong controller access code is set, then only help command is working.

start	Start the engine in MAN mode.
stop	Stop the engine in MAN mode.
fault reset	Acknowledging alarms and deactivating the horn output.
gcb close	Closing GCB in MAN and TEST mode.
gcb open	Opening GCB in MAN and TEST mode.
mcb close	Closing MCB in MAN and TEST mode
mcb open	Opening MCB in MAN and TEST mode
off	Switching to OFF mode.
man	Switching to MAN mode.
auto	Switching to AUTO mode.
test	Switching to TEST mode.
status	Get status information from controller unit.
help	Get a list of available SMS requests.

Note: Between commands are internal delays adjusted due to system requirements.

Example: When the controller, in AUTO mode, with a controller name of “InteliLite 9-Test”, with the CM-GPRS module and access code “0” receives the SMS:

0 man, start, gcb close, gcb open, stop, auto

Controller mode will be changed to MANUAL mode. The engine will be started and GCB will close. Then GCB will open, the engine will stop and it will go into AUTO mode again.

The controller will send back the SMS (controller will respond to SMS after every command has been finished, not sooner.):

#InteliLite 9-Test: <OK>, <OK>, <OK>, <OK>, <OK>, <OK>

The value <OK> or <ERROR> means if the command has been performed successfully or not.

Emails

Event Email

The InteliLite 9 controller equipped with the CM-Ethernet communication module is able to send Event Email according to the setting of setpoint:

▶ [Event Message \(page 232\)](#)

Note: Firstly setpoints *Email Address 1 (page 231)* and *SMTP Sender Address (page 235)* (for CM-Ethernet) have to be adjusted.

Note: *#Summer Time Mode (page 213)* and *Time Zone (page 232)* have to be adjusted for correct time in emails.

Message structure:

Controller

Name: XXX

Serial number: XXX

SW branch: XXX

SW version: XXX

Application: XXX

Appl. version: XXX

Date: dd/mm/yyyy

Time: hh:mm:ss

Alarm list

Alarm 1

Alarm 2

Alarm 3

Events

hh:mm:ss Event 1

hh:mm:ss Event 2

hh:mm:ss Event 3

Alarm Email

The IntelliLite 9 controller equipped with the CM-Ethernet communication module is able to send Alarm Emails according to the setting of setpoints:

- ▶ **Wrn Message (page 233)**
- ▶ **BOC Message (page 233)**
- ▶ **Sd Messages (page 233)**

Note: Firstly setpoints Email Address 1 (page 231) and SMTP Sender Address (page 235) (for CM-Ethernet) have to be adjusted.

Note: #Summer Time Mode (page 213) and Time Zone (page 232) have to be adjusted for correct time in emails.

Message structure:

Controller

Name: XXX

Serial number: XXX

SW branch: XXX

SW version: XXX

Application: XXX

Appl. version: XXX

Date: dd/mm/yyyy

Time: hh:mm:ss

Alarm list

Alarm 1

Alarm 2

Alarm 3

History events

0 dd/mm/yyyy hh:mm:ss.0 Event 1

-1 dd/mm/yyyy hh:mm:ss.0 Event 2

-2 dd/mm/yyyy hh:mm:ss.0 Event 3

Note: Asterisk means that alarm is unconfirmed and exclamation mark means that alarm is active.

Web Server

IMPORTANT: The web interface is based on HTTP protocol and is intended to be used only in private networks. It is not recommended to expose the web interface to the public Internet.

The Web Server is designed for basic monitoring and adjustment of the controller using a web browser. Just put the controller IP address into the browser to display the main controller web page like <http://192.168.1.254>. You will be asked for the controller access code prior to entering the web pages.

IMPORTANT: Do not use the browser navigation buttons as "Back", "Forward" or "Reload". Use the links and the reload button located in the toolbar instead.

Note: Only two remote clients can be connected to the Web Server at one moment. If you close your web browser without disconnecting from the CM-Ethernet ("Exit" button at the web pages), the connection will be blocked for next 5 minutes.




Image 6.7 Web Server main screen

Scada

Click to the SCADA link in the toolbar to display the scada page. The scada page is also the main page which is displayed by default if you just put the CM-Ethernet address into the browser (after entering the right access code).




Image 6.8 Web Server - Scada screen

Measurement

Click to the MEASUREMENT link in the toolbar to display the measurement page. Then click to the required group name in the left box to display values of the group in the right box.

Note: The measurement page is automatically refreshed every 60 seconds (this time cannot be changed).




Image 6.9 Web Server - measurement screen

Setpoints

Click to the SETPOINTS link in the toolbar to display the setpoints page.

Click to the required group name in the left box to display setpoints of the group in the right box.

Click to the required setpoint name or value to change the value. If the respective setpoint is protected by password, which is indicated by a lock icon by the setpoint name, you have to click on the "Controller password" icon located in the toolbar and then enter valid password.




Image 6.10 Web Server - Setpoints screen

History

Click to the HISTORY link in the toolbar to display the history page.

Use the control buttons to move within the history file.

Note: The history page is automatically refreshed every 60 seconds. If a new record appears in the controller, the web page will not show it immediately as e.g. IntelliConfig.




Image 6.11 Web Server - History screen

Web Server Adjustment

Click to the "Web Server settings" icon in the toolbar to display the settings page.

Select the controller language the web pages will appear in.

Select the rate of automatic refresh of the scada page.




Image 6.12 Web Server - Adjustment screen

[back to Communication](#)

6.2 Connection to 3rd party systems

6.2.1 MODBUS-RTU, MODBUS/TCP 124

[back to Communication](#)

6.2.1 MODBUS-RTU, MODBUS/TCP

MODBUS protocol is used for integration of the controller into a building management system or for remote monitoring via 3rd party monitoring tools.

- ▶ MODBUS-RTU can be used on serial interfaces (CM-RS232-485 module is required). The MODBUS-RTU server must be activated by switching the setpoint **COM1 Mode** (page 221) or **COM2 Mode** (page 223) into the Modbus position. The serial speed for MODBUS-RTU communication is to be adjusted by the setpoint **COM1 MODBUS Communication Speed** (page 222) or **COM2 MODBUS Communication Speed** (page 224).

- ▶ MODBUS/TCP can be used on the ethernet interface (CM-Ethernet module is required). Up to 2 clients can be connected simultaneously. The MODBUS/TCP server must be activated by the setpoint **MODBUS Server** (page 238).

MODBUS, MODBUS/TCP protocol can be used simultaneously with Web connection and direct ethernet connection.

The MODBUS, MODBUS/TCP protocol is enabled alternatively with the SNMP protocol, so both protocols can not be active simultaneously.

IMPORTANT: Do not write setpoint repeatedly (e.g. power control form a PLC repeated writing of baseload setpoint via Modbus). The setpoints are stored in EEPROM memory. which can be overwritten up to 10⁵ times without risk of damage or data loss, but may become damaged, when the allowed number of writing cycles is exceeded!

Address space

The object address space is separated into several areas as described in the table below. The actual mapping of specific controller data objects to specific MODBUS addresses, which depends on configuration, can be exported into a text file from the appropriate controller archive using IntelliConfig. There are several special registers with fixed meaning (reserved registers) which are listed in a separate table in this chapter.

MODBUS address	Meaning	Access	MODICON object type	MODBUS function
0000 .. 0999	Binary objects	Read only	Discrete Inputs	Read: 01, 02
1000 .. 2999	Values	Read only	Input Registers	Read: 03, 04
3000 .. 3999	Setpoints	Read/Write	Holding Registers	Read: 03, 04 Write: 06, 16
4200 .. 7167	Reserved registers	Read/Write, depends on each specific register	Input Registers Holding Registers	Read: 03, 04 Write: 06, 16

Mapping data types to registers

As there are multiple data types in the controller but only one data type in MODBUS (the register, which is 2 byte long), a mapping table is necessary to compose and decompose the MODBUS messages correctly.

Data type	Meaning	Number of registers	Data mapping
Integer8	1-byte signed integer	1	MSB = sign extension LSB = value
Unsigned8	1-byte unsigned integer	1	MSB = 0 LSB = value
Integer16	2-byte signed integer	1	MSB = value, MSB LSB = value, LSB
Unsigned16	2-byte unsigned integer	1	MSB = value, MSB LSB = value, LSB
Integer32	4-byte signed integer	2	MSB1 = value, byte 3 (MSB)

Data type	Meaning	Number of registers	Data mapping
			LSB1 = value, byte 2 MSB2 = value, byte 1 LSB2 = value, byte 0 (LSB)
Unsigned32	4-byte unsigned integer	2	MSB1 = value, byte 3 (MSB) LSB1 = value, byte 2 MSB2 = value, byte 1 LSB2 = value, byte 0 (LSB)
Binary8	8-bit binary value	1	MSB = 0 LSB = value, bits 0-7
Binary16	16-bit binary value	1	MSB = value, bits 8-15 LSB = value, bits 0-7
Binary32	32-bit binary value	2	MSB1 = value, bits 24-31 LSB1 = value, bits 16-23 MSB2 = value, bits 8-15 LSB2 = value, bits 0-7
Char	1-byte ASCII character	1	MSB = 0 LSB = ASCII value of the character
StrList	Index into a list of strings	1	MSB = 0 LSB = index into the list
ShortStr	Zero-terminated string of max 15 ASCII characters.	8	MSB1 = ASCII value of the 1. character LSB1 = ASCII value of the 2. character MSB2 = ASCII value of the 3. character LSB2 = ASCII value of the 4. character ...
LongStr	Zero-terminated string of max 31 ASCII characters.	16	MSB1 = ASCII value of the 1. character LSB1 = ASCII value of the 2. character MSB2 = ASCII value of the 3. character LSB2 = ASCII value of the 4. character ...

Data type	Meaning	Number of registers	Data mapping
Date	Date (dd-mm-yy)	2	MSB1 = BCD (dd) LSB1 = BCD (mm) MSB2 = BCD (yy) LSB2 = 0
Time	Time (hh-mm-ss)	2	MSB1 = BCD (hh) LSB1 = BCD (mm) MSB2 = BCD (ss) LSB2 = 0
Alarm	An item of the Alarmlist	27	MSB1 = reserved for future use LSB1 = reserved for future use MSB2 = Alarm level *) LSB2 = Alarm status **) MSB3 = alarm string ***) LSB3 = alarm string MSB4 = alarm string LSB5 = alarm string ...

*) 1 .. level 1 (yellow), 2 .. level 2 (red), 3 .. sensor fail

**) Bit0 – alarm is active, Bit1 – alarm is confirmed

***) String encoding is UTF-8

Error codes (exception codes)

Exception code is returned by the controller (server) if the query sent from the client could not be completed successfully.

The controller responds with the error codes in as follows:

- ▶ 01 – illegal function is returned if an incompatible type of operation is applied for a specific object, e.g. if function 03 is applied to a binary object.
- ▶ 02 – illegal address is returned if the client tries to perform an operation with a object address that is not related to any existing object or that is located inside an object which is composed by multiple addresses (registers).
- ▶ 04 – device error is returned in all other erroneous situations. More detailed specification of the problem can be consequently obtained by reading the registers 4205 – 4206.

Reserved registers

There are several registers with specific meaning. These registers are available in all controllers regardless of the configuration.

Register addresses	Number of registers	Access	Data type	Meaning
4200 - 4201	2	read/write	Time	RTC Time in BCD code
4202 - 4203	2	read/write	Date	RTC Date in BCD code
4204	1	read/write	Unsigned8	Index of the language that is used for text data provided by MODBUS (e.g. alarmlist messages).
4205 - 4206	2	read	Unsigned32	Last application error. To be read after the device returns the exception code 04. It contains specific information about the error.
4207 - 4208	2	read/write	Unsigned32	Writing: command argument Reading: command return value
4209	1	write	Unsigned16	Command code
4010	1	-	-	Not implemented
4211	1	write	Unsigned16	Password
4212 - 4213	2	read	Unsigned32	Communication status
4214	1	read	Unsigned8	Number of items in the Alarmlist
4215 - 4241	27	read	Alarm	1. record in alarm list
4242 - 4268	27	read	Alarm	2. record in alarm list
4269 - 4295	27	read	Alarm	3. record in alarm list
4296 - 4322	27	read	Alarm	4. record in alarm list
4323 - 4349	27	read	Alarm	5. record in alarm list
4350 - 4376	27	read	Alarm	6. record in alarm list
4377 - 4403	27	read	Alarm	7. record in alarm list
4404 - 4430	27	read	Alarm	8. record in alarm list
4431 - 4457	27	read	Alarm	9. record in alarm list
4458 - 4484	27	read	Alarm	10. record in alarm list
4485 - 4511	27	read	Alarm	11. record in alarm list
4512 - 4538	27	read	Alarm	12. record in alarm list
4539 - 4565	27	read	Alarm	13. record in alarm list
4566 - 4592	27	read	Alarm	14. record in alarm list
4593 - 4619	27	read	Alarm	15. record in alarm list
4620 - 4646	27	read	Alarm	16. record in alarm list

List of commands and arguments

"Commands" are used to invoke a specific action in the controller via the communication channel. The list of available actions is in the table below. The general procedure of writing a command via MODBUS is as follows:

- (Optional) Write required level of password into the register 44212 (register address 4211). Use function 6. If the password is required or not depends on configuration of access rules. It can be adjusted/modified by IntelliConfig.

2. Write the command argument into the registers 44208-44209 (register addresses 4207-4208). Use function 16.
3. Write the command code into the register 44210 (register address 4209). Use function 6.
4. (Optional) Read the command return value from the registers 44208-44209 (register addresses 4207-4208). Use function 3.
5. If the command was executed the return value is as listed in the table. If the command was accepted but there was an error during execution the return value indicates the reason:
 - a. 0x00000001 – invalid argument
 - b. 0x00000002 – command refused (e.g. controller not in MAN, breaker can not be closed in the specific situation etc.)

Action	Command code	Argument	Return value
Engine start *)	0x01	0x01FE0000	0x000001FF
Engine stop *)	0x01	0x02FD0000	0x000002FE
Fault reset *)	0x01	0x08F70000	0x000008F8
Horn reset *)	0x01	0x04FB0000	0x000004FC
GCB toggle *)	0x02	0x11EE0000	0x000011EF
GCB on	0x02	0x11EF0000	0x000011F0
GCB off	0x02	0x11F00000	0x000011F1
MCB toggle *)	0x02	0x12ED0000	0x000012EE
MCB on	0x02	0x12EE0000	0x000012EF
MCB off	0x02	0x12EF0000	0x000012F0

*) This action is an equivalent of pressing the front panel button

MODBUS examples

Modbus RTU examples

- ▶ Reading of Battery voltage
 - Export table of values from IntelliConfig

Table: Values									
Allowed MODBUS functions: 03, 04									
Register(s)	Com.Obj.	Name	Dimension	Type	Len	Dec	Min	Max	Group
01053	8213	BatteryVoltage	V	Integer	2	1	0	400	Controller I/O

Request: (Numbers in Hex)									
01	03	04	1D	00	01	15	3C		
Controller address	Modbus function	Register address 041D _{hex} = 1053 _{dec}		Number of registers			CRC		

Response: (Numbers in Hex)									
01	03	02	00	F0	B8	00			
Controller address	Modbus function	Length of data 02 _{hex} = 2 bytes read	Data 00F0 _{hex} = 240 _{dec}			CRC			

We read value 240 from register 01053. From table of modbus registers we get dimension of read value and "Dec". Dec=1 means shift one decimal place to the right. So battery voltage is **24.0 V**.

- ▶ Reading Nominal power
 - Export table of values from IntelliConfig

Table: Values									
Allowed MODBUS functions: 03, 04									
Register(s)	Com.Obj.	Name	Dimension	Type	Len	Dec	Min	Max	Group
01228	9018	Nominal Power	kW	Integer	2	0	0	32767	Generator

Request: (Numbers in Hex)									
01	03	04	CC	00	01	45	05		
Controller address	Modbus function	Register address 04CC _{hex} = 1228 _{dec}		Number of registers			CRC		

Response: (Numbers in Hex)									
01	03	02	00	C8	B9	D2			
Controller address	Modbus function	Length of data 02 _{hex} = 2 bytes read	Data 00C8 _{hex} = 200 _{dec}			CRC			

Read nominal power is 200 kW.

► Reading all binary inputs as modbus register

Table: Values									
Allowed MODBUS functions: 03, 04									
Register(s)	Com.Obj.	Name	Dimension	Type	Len	Dec	Min	Max	Group
01068	8235	Binary Inputs		Binary#2	2	0	-	-	Controller I/O

Request: (Numbers in Hex)							
01	03	04	2C	00	01	44	F3
Controller address	Modbus function	Register address 042C _{hex} = 1068 _{dec}		Number of registers		CRC	

Response: (Numbers in Hex)							
01	03	02	00	12	38	49	
Controller address	Modbus function	Length of data 02 _{hex} = 2 bytes read	Data 0012 _{hex} = 00010010 _{bin}		CRC		

Binary inputs is 00010010. It means Binary input 2 and binary input 5 are active.

Note: You can use modbus function 4 insted of 3, rest of data remain same (CRC differs).

► Reading binary inputs as coil status.

Table: Binaries						
Allowed MODBUS functions: 01, 02						
Addresses Modbus Addr. Prot. Addr.	Source = Value = State	C.O.# State #	Name of Value Name of State	Bit #	Bit Name Activated by protection(s):	Group
00000	Value	8235	Binary Inputs	1	GCB Feedback	Controller I/O
00001	Value	8235	Binary Inputs	2	MCB Feedback	Controller I/O
00002	Value	8235	Binary Inputs	3	Emergency Stop	Controller I/O

We will read state of MCB Feedback binary input.

Request: (Numbers in Hex)							
01	01	00	01	00	01	AC	0A
Controller address	Modbus function	Register address $0001_{\text{hex}} = 0001_{\text{dec}}$		Number of registers		CRC	

Response: (Numbers in Hex)					
01	01	01	01	90	48
Controller address	Modbus function	Length of data $01_{\text{hex}} = 1 \text{ byte read}$		Data $01_{\text{hex}} = \text{active}$	
				CRC	

The readed data is 01, it means this binary input is active.

Note: You can use modbus function 2 insted of 1, rest of data remains same (CRC differs).

▶ Starting the engine

Before starting engine you may need to write password. Depends on your settings in controller.

Table Reserved registers (page 127)

Register addresses	Number of registers	Access	Data type	Meaning
4207 - 4208	2	read/write	Unsigned32	Writing: command argument Reading: command return value
4209	1	write	Unsigned16	Command code

Table List of commands and arguments (page 128)

Action	Command code	Argument	Return value
Engine start	0x01	0x01FE0000	0x000001FF
Engine stop	0x01	0x02FD0000	0x000002FE

Request 1/2: (Numbers in Hex)

01	10	10	6F	00	03	06
Controller address	Modbus function $10_{\text{hex}} = 16_{\text{dec}}$	Register address $106F_{\text{hex}} = 4207_{\text{dec}}$	Number of registers		Data length in bytes	

Request 2/2: (Numbers in Hex)

01	FE	00	00	00	01	68	0B
Argument				Command code		CRC	

Note: Command and argument may be written as one "packet" (function 16) or you can split it and write argument (function 16) and after that write command code (function 6).

► Password

This password is the same as in IntelliConfig or directly in controller.

Table **Reserved registers (page 127)**

Register addresses	Number of registers	Access	Data type	Meaning
4211	1	write	Unsigned16	Password

Note: Default password is "0".

In this example the password is "1234".

Request: (Numbers in Hex)							
01	06	10	73	04	D2	7C	D1
Controller address	Modbus function	Register address 1073 _{hex} = 4211 _{dec}		Password 04D2 _{hex} = 1234 _{dec}		CRC	

Response for success: (Numbers in Hex)							
01	06	10	73	00	00	7C	D1
Controller address	Modbus function	Register address 1073 _{hex} = 4211 _{dec}		Allways zero.		CRC	

Response for bad password: (Numbers in Hex)							
01	86	04			43	A3	
Controller address	Modbus exception for function 6.	04 – device error see Error codes (exception codes) on page 127			CRC		

► Nominal Power – writing

Table: Setpoints									
Allowed MODBUS functions: 03, 04, 06, 16									
Register(s)	Com.Obj.	Name	Dimension	Type	Len	Dec	Min	Max	Group
03008	8276	Nominal Power	kW	Unsigned	2	0	1	5000	Basic Settings

Request: (Numbers in Hex)									
01	06	0B	C0	00	64	8A	39		
Controller address	Modbus function	Register address 0BC0 _{hex} = 3008 _{dec}		Data 0064 _{hex} = 100 _{dec}		CRC			

Response: (Numbers in Hex)									
01	06	0B	C0	00	00	8B	D2		
Controller address	Modbus function	Register address 0BC0 _{hex} = 3008 _{dec}		Allways zero		CRC			

Written setpoint nominal power is 100 kW.

► CRC calculation

The check field allows the receiver to check the validity of the message. The check field value is the Cyclical Redundancy Check (CRC) based on the polynomial $x^{16}+x^{15}+x^2+1$. CRC is counted from all message bytes preceding the check field.

Online CRC calculator: <http://www.lammertbies.nl/comm/info/crc-calculation.html> Use CRC-16 (Modbus)

Write LSB first.

For writing nominal power 100 kW the CRC is calculated from this data: 01060BC00064_{hex}

Modbus TCP examples

▶ Reading of Battery voltage

- Export table of values from IntelliConfig

Table: Values									
Allowed MODBUS functions: 03, 04									
Register(s)	Com.Obj.	Name	Dimension	Type	Len	Dec	Min	Max	Group
01053	8213	BatteryVoltage	V	Integer	2	1	0	400	Controller I/O

Request: (Numbers in Hex)											
00	00	00	00	00	06	01	03	04	1D	00	01
transaction identifier (usually 0)	protocol identifier (usually 0)	Length of data bytes following		Controller address	Modbus function	Register address 041D _{hex} = 1053 _{dec}		Number of registers			

Request: (Numbers in Hex)											
00	00	00	00	00	06	01	03	04	1D	00	01
transaction identifier (usually 0)	protocol identifier (usually 0)	Length of data bytes following		Controller address	Modbus function	Register address 041D _{hex} = 1053 _{dec}		Number of registers			

Response: (Numbers in Hex)											
00	00	00	00	00	05	01	03	02	00	F0	
transaction identifier (usually 0)	protocol identifier (usually 0)	Length of data bytes following		Controller address	Modbus function	Length of data 02 _{hex} = 2 bytes read		Data 00F0 _{hex} = 240 _{dec}			

We read value 240 from register 01053. From table of modbus registers we get dimension of read value and "Dec". Dec=1 means shift one decimal place to the right. So battery voltage is **24.0 V**.

🔍 [back to Connection to 3rd party systems](#)

7 Technical data

Power supply

Power supply range	8-36 VDC
Power consumption	394 mA / 8 VDC
	255 mA / 12 VDC
	140 mA / 24 VDC
	97 mA / 36 VDC
Fusing	Power terminal max. 3 A
	E-Stop max. 12 A
Fusing E-Stop	12 A
Max. Power Dissipation	3,5 W

Operating conditions

Operating temperature	-20 °C to +70 °C
Storage temperature	-30 °C to +70 °C
Protection degree (front panel)	IP 65
Operating humidity	95 % w/o condensation
Vibration	5-25 Hz, ± 1,6 mm
	25-100 Hz, a = 4 g
Shocks	a = 500 m/s ²
Surrounding air temperature rating 70°C	
Suitable for pollution degree 3	

D+ terminal

Max. output current	250 mA / 36 V
Charging fail threshold	Adjustable

Voltage measurement

Measurement inputs	3ph-n Gen voltage , 3ph-n Mains
Measurement range	277 V
Max. allowed voltage	350 V
Accuracy	1 %
Frequency range	40-70 Hz (accuracy 0.1 Hz)
Input impedance	0,72 MΩ ph-ph , 0,36 MΩ ph-n

Current measurement

Measurement inputs	3ph Gen current, 1ph Mains current
Measurement range	5 A
Max. allowed current	10 A
Accuracy	1,5 % for full temperature range (1 % from 0 °C to 50 °C)
Input impedance	< 0,1 Ω

Binary inputs

Number	6, non-isolated
Close/Open indication	0-2 VDC close contact >6 VDC open contact

Binary outputs

Low current	4 low current output, non-isolated 0,5 A switching to positive supply terminal
High current	2 high current output, non-isolated 5 A (60 °C), 4 A (70 °C) switching to positive supply terminal

Analog inputs

Number	3, non-isolated
Resolution	0,1 Ω
Range	0-2500 Ω
Input impedance	800 Ω
Accuracy	±2 % from value in range 0-2500 Ω
	±1,5 kΩ in range 2,5-15 kΩ

Magnetic pickup

Voltage input range	4 Vpk-pk to 50 Vpk-pk in range 4 Hz to 1 kHz 6 Vpk-pk to 50 Vpk-pk in range 1 kHz to 5 kHz 10 Vpk-pk to 50 Vpk-pk in range 5 kHz to 10 kHz
Frequency input range	4 Hz to 10 kHz
Frequency measurement tolerance	0,2 % from range 10 kHz

Communications

USB port	Non-isolated
CAN 1	CAN bus, 250 kbps, max 200 m, 120 Ω termination option, non-isolated

 [back to Table of contents](#)

8 Appendix

8.1 Controller objects	140
8.2 Alarms	356
8.3 Modules	388

 [back to Table of contents](#)

8.1 Controller objects

8.1.1 Setpoints	141
8.1.2 Values	258
8.1.3 Logical binary inputs	293
8.1.4 Logical binary outputs	314
8.1.5 Logical analog inputs	348

8.1.1 Setpoints

What setpoints are:

Setpoints are analog, binary or special data objects which are used for adjusting the controller to the specific environment. Setpoints are organized into groups according to their meaning. Setpoints can be adjusted from the controller front panel, PC, MODBUS, etc.

All setpoints can be protected by a password against unauthorized changes. Password protection can be assigned to the setpoints during the configuration procedure. See the chapter **Password (page 66)** in Operator guide for instructions on how to enter and modify a password.

IMPORTANT: Do not write setpoints repeatedly (e.g. power control from a PLC by repeated writing of baseload setpoint via Modbus). The setpoints are stored in EEPROM memory, which can be overwritten up to 10⁵ times without risk of damage or data loss, but it may become damaged, when the allowed number of writing cycles is exceeded.

List of setpoint groups

Group: Basic settings	145
Group: Engine settings	159
Group: Generator settings	192
Group: Protections	197
Group: AMF settings	200
Group: General Analog Inputs	207
Group: Scheduler	212
Group: Plug-In Modules	221
Group: CM-RS232-485	221
Group: CM-GPRS	224
Group: CM-4G-GPS	227
Group: CM-Ethernet	231
Group: Alternate Config	239

For full list of setpoints go to the chapter **List of setpoints (page 142)**.

Generator Undervoltage BOC	194
Generator Undervoltage Wm	194
Generator <> Voltage Delay	195
Generator Overfrequency BOC	195
Generator Overfrequency Wm	195
Generator Underfrequency BOC	196
Generator Underfrequency Wm	196
Generator <> Frequency Delay	196

Protections

Overload Protection	197
Short Circuit Protection ...	197
Generator <> Voltage Protection	198
Generator Frequency Protection	198
Underspeed Protection ...	199
Overspeed Protection	199

AMF settings

Emergency Start Delay ...	200
Mains Return Delay	200
Transfer Delay	201
MCB Close Delay	202
Mains Overvoltage	202
Mains Undervoltage	203
Mains < > Voltage Delay ...	203
Mains Overfrequency	203
Mains Underfrequency ...	204
Mains < > Frequency Delay	204
Return From Island	204
Return From Test	205
MCB Logic	205

MCB Opens On	207
--------------------	-----

General Analog Inputs

Analog Protection 1 Wm ..	207
Analog Protection 1 Sd ...	208
Analog Protection 1 Delay	208
Analog Protection 2 Wm ..	209
Analog Protection 2 Sd ...	209
Analog Protection 2 Delay	210
Analog Protection 3 Wm ..	210
Analog Protection 3 Sd ...	211
Analog Protection 3 Delay	211

Scheduler

Time	212
Date	212
Time Stamp Period	212
#Summer Time Mode	213
Timer 1 Function	214
Timer 1 Setup	215
Timer 1 Repetition	215
Timer 1 First Occur. Date	216
Timer 1 First Occur. Time	216
Timer 1 Duration	216
Timer 1 Repeated	217
Timer 1 Refresh Period ...	218
Timer 1 Weekends	219
Timer 1 Day	219
Timer 1 Repeat Day	220
Timer 1 Repeated Day In Week	220
Timer 1 Repeat Day In Month	220
Timer 1 Repeat Week In Month	221

Plug-In Modules

Slot A	221
--------------	-----

Communication

Modules

COM1 Mode	221
COM1 Communication Speed	222
COM1 MODBUS Communication Speed ...	222
COM2 Mode	223
COM2 Communication Speed	223
COM2 MODBUS Communication Speed ...	224
Message Language	224
Time Zone	225
Event Message	225
Wm Message	226
BOC Message	226
Sd Messages	226
Telephone Number 1	227
Required Connection Type	227
Message Language	228
Time Zone	228
Event Message	229
Wm Message	229
BOC Message	229
Sd Messages	230
Telephone Number 1	230
Email Address 1	231
Message Language	231
Time Zone	232
Event Message	232
Wm Message	233
BOC Message	233
Sd Messages	233
SMTP UserName	234
SMTP User Password ...	234
SMTP Server Address ...	234
SMTP Sender Address ...	235
IP Address Mode	235
IP Address	236

Subnet Mask 236
 Gateway IP237
 DNS IP Address 1 237
 DNS IP Address 2 238
 MODBUS Server238

Alternate Config

Nominal RPM 1 239
 Nominal Frequency 1 239
 Nominal Voltage Ph-N 1 ..240
 Nominal Voltage Ph-Ph 1 .240
 Nominal Power 1241
 Nominal Power Split
 Phase 1 241
 Nominal Current 1242
 Connection Type 1242
 Nominal RPM 2 243
 Nominal Frequency 2 244
 Nominal Voltage Ph-N 2 ..244
 Nominal Voltage Ph-Ph 2 .244
 Nominal Power 2245
 Nominal Power Split
 Phase 2 245
 Nominal Current 2246
 Connection type 2246
 Nominal RPM 3 247
 Nominal Frequency 3 248
 Nominal Voltage Ph-N 3 ..248
 Nominal Voltage Ph-Ph 3 .248
 Nominal Power 3249
 Nominal Power Split
 Phase 3 249
 Nominal Current 3250
 Connection type 3250
 ECU Frequency Select 1 .252
 ECU Speed Adjustment 1 253
 ECU Frequency Select 2 .254
 ECU Speed Adjustment 2 255
 ECU Frequency Select 3 .256
 ECU Speed Adjustment 3 257

Group: Basic settings

Subgroup: Name

Gen-Set Name

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	0 .. 15 characters [-]		
Default value	InteliLite	Alternative config	NO
Step	[-]		
Comm object	8637	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
User defined name, used for the controller identification at remote phone or mobile connection. Gen-Set Name is maximally 15 characters long and can be entered using IntelliConfig or from controller's configuration menu.			
<p>Note: If the Gen-Set Name is "TurboRunHours", the running hours will be counted faster - 1 minute in real will represent 1 hour.</p>			

[back to List of setpoints](#)

Subgroup: Power settings

Nominal Power Split Phase

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	9977	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type (page 147)		
Description			
Nominal power of the gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</p>			
<p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Power Split Phase 1 (page 241), Nominal Power Split Phase 2 (page 245) and Nominal Power Split Phase 3 (page 249).</p>			

[back to List of setpoints](#)

Nominal Power

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	8276	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal power of the gen-set. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</p>			
<p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Power 1 (page 241), Nominal Power 2 (page 245) and Nominal Power 3 (page 249).</p>			

◀ back to List of setpoints

Subgroup: Current settings

Nominal Current

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 10 000 [A]		
Default value	350 A	Alternative config	YES
Step	1 A		
Comm object	8275	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type (page 147).		
Description			
It is current limit for mains current protections and means maximal continuous mains current. Nominal Current can be different from mains rated current value.			
<p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Current 1 (page 242), Nominal Current 2 (page 246) and Nominal Current 3 (page 250).</p>			

◀ back to List of setpoints

CT Ratio

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [A/5A]		
Default value	2 000 A/5A	Alternative config	NO
Step	1 A/5A		
Comm object	8274	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Gen-set current transformers ratio.			
<i>Note: Generator currents and power measurement is suppressed if current level is below 1% of CT range.</i>			

🔍 back to List of setpoints

CT Location

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Load / Gen-set [-]		
Default value	Gen-set	Alternative config	NO
Step	[-]		
Comm object	11625	Related applications	AMF
Config level	Advanced		
Setpoint visibility	Always		
Description			
Adjustment of location of current measurement.			
Load: Current CT's are physically placed on Load (typically between GCB and MCB).			
Gen-Set: Current CT's are physically placed on GenSet (typically before GCB).			
<i>Note: For more details about this function see chapter CT Location (page 24).</i>			

🔍 back to List of setpoints

Subgroup: Voltage settings

Connection type

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Mono Phase / SplitPhase / 3Ph3Wire / High Leg D / 3Ph4Wire / Autodetect [-]		
Default value	3Ph4Wire	Alternative config	YES
Step	[-]		
Comm object	11628	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			

Generator winding connection system

Mono Phase	Single phase voltage measurement L1-N 1x CT (Current Transformer)																
Split Phase	Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer)																
3Ph3Wire	Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift No neutral is available 3x CT (Current Transformer)																
High Leg D	High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer)																
3Ph4Wire	Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer)																
Autodetect	<table border="0"> <tr> <td>High Leg Delta</td> <td>L1 >=100V; L1 <=140V L2 >=140V L3 >=100V; L3 <=140V</td> </tr> <tr> <td>or</td> <td></td> </tr> <tr> <td>3PH3Wire or 3Ph4Wire</td> <td>L1 >=100V L2 >=100V L3 >=100V</td> </tr> <tr> <td>or</td> <td></td> </tr> <tr> <td>Split Phase</td> <td>L1 >=100V L2 <= 20V L3 >=100V</td> </tr> <tr> <td>or</td> <td></td> </tr> <tr> <td>Mono Phase</td> <td>L1 >=100V L2 <= 20V L3 <= 20V</td> </tr> <tr> <td>or</td> <td></td> </tr> </table> <p>Voltage Autodetect shutdown</p>	High Leg Delta	L1 >=100V; L1 <=140V L2 >=140V L3 >=100V; L3 <=140V	or		3PH3Wire or 3Ph4Wire	L1 >=100V L2 >=100V L3 >=100V	or		Split Phase	L1 >=100V L2 <= 20V L3 >=100V	or		Mono Phase	L1 >=100V L2 <= 20V L3 <= 20V	or	
High Leg Delta	L1 >=100V; L1 <=140V L2 >=140V L3 >=100V; L3 <=140V																
or																	
3PH3Wire or 3Ph4Wire	L1 >=100V L2 >=100V L3 >=100V																
or																	
Split Phase	L1 >=100V L2 <= 20V L3 >=100V																
or																	
Mono Phase	L1 >=100V L2 <= 20V L3 <= 20V																
or																	

Note: To lock this setpoint against editing you also have to lock setpoint Connection Type 1 (page 242), Connection type 2 (page 246) and Connection type 3 (page 250).

 [back to List of setpoints](#)

Nominal Voltage Ph-N

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 20 000 [V]		
Default value	231 V	Alternative config	YES
Step	1 V		
Comm object	8277	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type (page 147).		
Description			
Nominal voltage (phase to neutral).			
<p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Voltage Ph-N 1 (page 240), Nominal Voltage Ph-N 2 (page 244) and Nominal Voltage Ph-N 3 (page 248).</p>			

🔍 back to List of setpoints

Nominal Voltage Ph-Ph

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 40 000 [V]		
Default value	400 V	Alternative config	YES
Step	1 V		
Comm object	11657	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type (page 147).		
Description			
Nominal system voltage (phase to phase).			
<p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Voltage Ph-Ph 1 (page 240), Nominal Voltage Ph-Ph 2 (page 244) and Nominal Voltage Ph-Ph 3 (page 248).</p>			

🔍 back to List of setpoints

PT Ratio

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	0,1 .. 500,0 [V/V]		
Default value	1,0 V/V	Alternative config	NO
Step	0,1 V/V		
Comm object	9579	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Generator voltage potential transformers ratio. If no PTs are used, adjust the setpoint to 1.			

🔍 back to List of setpoints

Vm PT Ratio

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	0,1 .. 500,0 [V/V]		
Default value	1,0 V/V	Alternative config	NO
Step	0,1 V/V		
Comm object	9580	Related applications	AMF
Config level	Advanced		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Mains voltage potential transformers ratio. If no PTs are used, adjust the setpoint to 1.			

[◀ back to List of setpoints](#)

Subgroup: Frequency settings


Nominal Frequency

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	45 .. 65 [Hz]		
Default value	50 Hz	Alternative config	YES
Step	1 Hz		
Comm object	8278	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal system frequency (usually 50 or 60 Hz).			
<p>Note: To lock this setpoint against editing you also have to lock setpoint Nominal Frequency 1 (page 239), Nominal Frequency 2 (page 244) and Nominal Frequency 3 (page 248).</p>			

[◀ back to List of setpoints](#)


Gear Teeth

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	FGen->RPM / 1 .. 500 [-]		
Default value	120	Alternative config	NO
Step	1		
Comm object	8252	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
<p>Number of teeth on the engine flywheel where the pick-up is installed. Set to zero if no pick-up is used and the Engine speed will be counted from the generator frequency.</p> <p><i>Note: If no pickup is used, the D+ or W terminal should be used to prevent possible overcranking, which can occur if at least 25% of nominal generator voltage is not present immediately after exceeding firing speed.</i></p>			

 [back to List of setpoints](#)

Nominal RPM


Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	100 .. 4 000 [RPM]		
Default value	1 500 RPM	Alternative config	YES
Step	1 RPM		
Comm object	8253	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
<p>Nominal engine speed (RPM - revolutions per minute).</p> <p><i>Note: To lock this setpoint against editing you also have to lock setpoint Nominal RPM 1 (page 239), Nominal RPM 2 (page 243) and Nominal RPM 3 (page 247).</i></p>			

 [back to List of setpoints](#)

Subgroup: Controller settings

Controller mode

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	OFF / MAN / AUTO / TEST [-]		
Default value	OFF	Alternative config	NO
Step	[-]		
Comm object	8315	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
<p>This setpoint can be used for changing the Controller mode remotely, e.g. via MODBUS. Use the mode selector on the main screen for changing the mode from the front panel. Use mode selector in the control window for changing the mode from IntelliConfig.</p>			




 [back to List of setpoints](#)

GCB Mode

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Normal / Manual / No Button [-]		
Default value	Normal	Alternative config	NO
Step	[-]		
Comm object	11771	Related applications	MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Mode of Generator Circuit Breaker behavior.			
Normal	In this mode GCB is always controlled by gen-set controller using relevant GCB control binary outputs (GCB CLOSE/OPEN (PAGE 327) , GCB OFF COIL (PAGE 329) , GCB ON COIL (PAGE 330) or GCB UV COIL (PAGE 330)). GCB alarms are issued as usual. In MAN mode GCB is controlled manually by GCB button. In AUT mode GCB is controlled automatically.		
Manual	In this mode, the GCB is always manually operated (by operator not by controller). GCB feedback signal can be wired up to the controller. (However this isn't mandatory.) The GCB button on the controller is inactive.		
No Button	In this mode GCB button is inactive. In MAN mode GCB is operated automatically. It is closed and opened .at the same time and under same conditions as in AUT mode. GCB FEEDBACK (PAGE 307) is evaluated if configured. There is no change in AUT mode compared to Normal GCB mode.		
<p>IMPORTANT: In Manual GCB Mode gen-set can be started with GCB closed (with connected load).</p> <p>IMPORTANT: In Manual GCB mode GCB binary outputs(GCB CLOSE/OPEN, GCB OFF COIL, GCB ON COIL AND GCB UV COIL) are following GCB status (according to GCB feedback input). It is up to operator to ensure these LBOs are not configured or even wired to GCB.</p> <p><i>Note: This setting is available only when separate MRS archive is used. When AMF archive is used GCB behaves according Normal mode.</i></p> <p><i>Note: In Manual GCB mode there isn't any safe way how to disconnect load when electrical parameters of generator aren't within limits. Only immediate gen-set shutdown is applicable in this situation. Built-in generator protections:</i></p> <ul style="list-style-type: none"> ▶ <i>Overload</i> ▶ <i>Short Circuit</i> ▶ <i>Generator Undervoltage</i> ▶ <i>Generator Underfrequency</i> ▶ <i>Generator Overerfrequency</i> <p><i>behave as Shutdown protections.</i></p>			

 [back to List of setpoints](#)

Operation Mode

Setpoint group	Basic settings	Related FW	1.1.0				
Range [units]	AMF / MRS [-]						
Default value	AMF	Alternative config	NO				
Step	[-]						
Comm object	12157	Related applications	AMF				
Config level	Advanced						
Setpoint visibility	Always						
Description							
Based on this setpoint is defined basic controller function.							
<table border="1"> <tr> <td>AMF</td> <td>Normal AMF operation</td> </tr> <tr> <td>MRS</td> <td>When MRS mode is selected the controller will not perform AMF functions anymore. MCB button  will be inactive and also mains measurement and protections will be disabled. The controller will keep TEST mode and the gen-set in AUTO mode will be able to start by REMOTE START/STOP (PAGE 312) binary input.</td> </tr> </table>				AMF	Normal AMF operation	MRS	When MRS mode is selected the controller will not perform AMF functions anymore. MCB button  will be inactive and also mains measurement and protections will be disabled. The controller will keep TEST mode and the gen-set in AUTO mode will be able to start by REMOTE START/STOP (PAGE 312) binary input.
AMF	Normal AMF operation						
MRS	When MRS mode is selected the controller will not perform AMF functions anymore. MCB button  will be inactive and also mains measurement and protections will be disabled. The controller will keep TEST mode and the gen-set in AUTO mode will be able to start by REMOTE START/STOP (PAGE 312) binary input.						

[◀ back to List of setpoints](#)

Controller Address

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 32 [-]		
Default value	1	Alternative config	NO
Step	1		
Comm object	24537	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Controller identification number. It is possible to set controller address different from the default value (1) so that more IL controllers can be interconnected (via RS485) and accessed e.g. from MODBUS terminal.			
<p>Note: When opening connection to the controller it's address has to correspond with the setting in PC tool.</p>			
<p>Note: This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p>			

[◀ back to List of setpoints](#)

Reset To Manual

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Disabled / Enabled [-]		
Default value	Disabled	Alternative config	NO
Step	[-]		
Comm object	9983	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
<p>If this function is enabled, the controller will switch automatically to MAN mode when there is a red alarm in the alarm list and fault reset button is pressed. This is a safety function that prevents the gen-set starting again automatically in specific cases when fault reset button is pressed.</p> <p>Example: Controller is in AUTO mode and there is red inactive unconfirmed alarm and fault reset button is pressed, controller will start automatically.</p>			

[back to List of setpoints](#)

Backlight Timeout

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Disabled / 1 .. 255 [min]		
Default value	Disabled	Alternative config	NO
Step	1 min		
Comm object	10121	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
<p>The display backlight is switched off when this timer exceed. When setpoint is adjusted to disabled then the display will be backlighted all the time.</p>			


[back to List of setpoints](#)

Horn Timeout

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Disabled / 1 .. 599 [s]		
Default value	10 s	Alternative config	NO
Step	1 s		
Comm object	8264	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Setting of horn behavior.			
Disabled	Disabling the Horn sounding function		
1 .. 599 [s]	Timeout for HORN (PAGE 334) binary output. The HORN (PAGE 334) output is opened when this timeout elapsed.		
<p>Note: Horn timeout starts again from the beginning if a new alarm appears before previous Horn timeout has elapsed.</p>			

🔍 back to List of setpoints

Zero Power Mode

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Disabled / 1 - 360 [min]		
Default value	Disabled	Alternative config	NO
Step	1 min		
Comm object	8548	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154) Always		
Description			
The controller is switched to Zero Power Mode when there is no user interaction with the controller for the preset time period. Zero Power Mode is disabled in AMF automatic mode. For the controller wake up press button Start  or activate Binary Input 1. The controller will not switch to Zero Power Mode if generator is running. In Zero Power Mode binary outputs go to high impedance.			
<p>Note: Power consumption of controller in Zero Power Mode is 0 mA. Controller is internally disconnected from power supply.</p>			

🔍 back to List of setpoints

Power On Mode

Setpoint group	Basic settings	Related FW	1.1.0				
Range [units]	Previous / OFF [-]						
Default value	Previous	Alternative config	NO				
Step	[-]						
Comm object	13000	Related applications	AMF, MRS				
Config level	Advanced						
Setpoint visibility	Always						
Description							
This setpoint adjusts controller mode after power on of controller.							
<table border="1"> <tr> <td>Previous</td> <td>When controller is power on, than is switched into last mode before power off.</td> </tr> <tr> <td>OFF</td> <td>When controller is power on, than is switched into OFF mode.</td> </tr> </table>				Previous	When controller is power on, than is switched into last mode before power off.	OFF	When controller is power on, than is switched into OFF mode.
Previous	When controller is power on, than is switched into last mode before power off.						
OFF	When controller is power on, than is switched into OFF mode.						
<p><i>Note: Remote modes - In case that some LBI remote mode is activated during power on of controller than this LBI has higher priority than this setpoint - controller mode is forced into mode selected via LBI. After deactivation of LBI, controller is switched into value selected via setpoint Power On Mode</i></p>							

[back to List of setpoints](#)

RunHoursSource

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	AUTO / ECU / INTERNAL [-]		
Default value	AUTO	Alternative config	NO
Step	[-]		
Comm object	13345	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
By adjusting this setpoint it is possible to select which source of Running Hours (page 278) is used.			
AUTO	In case there is connected ECU sending valid running hours value, this value is used as source. Otherwise value from internal counter is used.		
ECU	Running hours are taken from ECU in case ECU is sending valid data. It is not possible to set and reset Running Hours (page 278) value in statistics.		
INTERNAL	Running Hours (page 278) value is taken from internal counter. It is possible to set and reset this value in statistics.		

[back to List of setpoints](#)

Subgroup: HMI Settings

Main Screen Line 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	RPM/PF/Run Hours/ATT/AIN1 [-]		
Default value	PF	Alternative config	NO
Step	[-]		
Comm object	13346	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
This setpoint adjusts line 1 on Mains screen.			

[back to List of setpoints](#)

Main Screen Line 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	RPM/PF/Run Hours/ATT/AIN1 [-]		
Default value	RPM	Alternative config	NO
Step	[-]		
Comm object	14628	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
This setpoint adjusts line 2 on Mains screen.			

[back to List of setpoints](#)

Screen Filter

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Enable/Disabled [-]		
Default value	Disabled	Alternative config	NO
Step	[-]		
Comm object	15889	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
<p>This setpoint enables/disables filter values on CU screen and PC tools. List of values which are filtered when filter is ON.</p> <ul style="list-style-type: none"> ▶ Generator Voltage L1-L2 ▶ Generator Voltage L2-L3 ▶ Generator Voltage L3-L1 ▶ Generator Voltage L1-N ▶ Generator Voltage L2-N ▶ Generator Voltage L3-N ▶ Generator Frequency ▶ Load kVA ▶ Load kVA L1 ▶ Load kVA L2 ▶ Load kVA L3 ▶ Load kVAr ▶ Load kVAr L1 ▶ Load kVAr L2 ▶ Load kVAr L3 ▶ Load kW ▶ Load kW L1 ▶ Load kW L2 ▶ Load kW L3 			

[⬅ back to List of setpoints](#)

Group: Engine settings

Subgroup: Starting

Cranking Attempts

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	1 .. 10 [-]		
Default value	3	Alternative config	NO
Step	1		
Comm object	8255	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Maximal number of cranking attempts.			

[back to List of setpoints](#)

Cranking Fail Pause

Setpoint group	Engine settings	Related FW	1.1.0
Fixed value	8 s		
Description			
Pause between Cranking Attempts (page 160). PRESTART (PAGE 341) output is active in this pause until Cranking Fail Pause elapses.			
<p>IMPORTANT: This is a fixed parameter, it isn't possible to adjust it in any manner. This parameter isn't visible either in controller or in PC tools.</p>			

[back to List of setpoints](#)

Maximum Cranking Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	1 .. 255 [s]		
Default value	5 s	Alternative config	NO
Step	1 s		
Comm object	8256	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Maximum time limit of cranking time.			
<p>IMPORTANT: There is a protection against broken pinion on starter. In case that there are no RPM after 5 seconds of starting, cranking is interrupted and cranking fail pause follows.</p>			

[back to List of setpoints](#)

Prestart Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 600 [s]		
Default value	2 s	Alternative config	NO
Step	1 s		
Comm object	8394	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		

Description

Time of closing of the **PRESTART (PAGE 341)** output prior to the engine start. Set to zero if you want to leave the output **PRESTART (PAGE 341)** open.




Image 8.1 Prestart Time

🔍 back to List of setpoints

Starting RPM

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	5 .. 50 [%]		
Default value	25%	Alternative config	NO
Step	1 % of Nominal RPM (page 151)		
Comm object	8254	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		

Description

This setpoint defines the “firing” speed level as percent value of the **Nominal RPM (page 151)**. If this level is exceeded the engine is considered as started.

🔍 back to List of setpoints

Starting Oil Pressure

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0,0 .. 10,0 [bar]		
Default value	4,5 bar	Alternative config	NO
Step	0,1 bar		
Comm object	9681	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Oil pressure limit for starting. The controller will stop cranking (STARTER (PAGE 344) goes OFF) if the oil pressure rises above this limit.			
IMPORTANT: Value from analog input has higher priority than value from ECU.			

[back to List of setpoints](#)

Glow Plugs Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. Prestart Time (page 161) [s]		
Default value	0 s	Alternative config	NO
Step	1 s		
Comm object	14412	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
This setpoint defines the time before starting when logical binary output GLOW PLUGS (PAGE 332) will be close.			

[back to List of setpoints](#)

Fuel Pump Off

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Fuel Pump On (page 164) .. 100 [%]		
Default value	90 %	Alternative config	NO
Step	1 %		
Comm object	10101	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if the logical binary output FUEL PUMP (PAGE 327) is configured and logical binary input FUEL PUMP ON/OFF (PAGE 306) isn't configured		

Description

Threshold level for switching the binary output **FUEL PUMP (PAGE 327)** off.




Image 8.2 Fuel Pump Off

IMPORTANT: When binary input **FUEL PUMP ON/OFF (PAGE 306)** is configured then binary output **FUEL PUMP (PAGE 327)** is control by this binary input. Setpoints Fuel Pump On (page 164) and Fuel Pump Off are not evaluated!

Note: Value from analog input has higher priority than ECU.

Note: This setpoint is visible only if the logical binary output **FUEL PUMP (PAGE 327)** is configured.

[back to List of setpoints](#)

Fuel Pump On

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. Fuel Pump Off (page 163) [%]		
Default value	20 %	Alternative config	NO
Step	1 %		
Comm object	10100	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if the logical binary output FUEL PUMP (PAGE 327) is configured and logical binary input FUEL PUMP ON/OFF (PAGE 306) isn't configured		

Description

Threshold level for switching the binary output **FUEL PUMP (PAGE 327)** on.




Image 8.3 Fuel Pump On

IMPORTANT: When binary input **FUEL PUMP ON/OFF (PAGE 306)** is configured then binary output **FUEL PUMP (PAGE 327)** is control by this binary input. Setpoints Fuel Pump On and Fuel Pump Off (page 163) are not evaluated!

Note: Value from analog input has higher priority than ECU.

Note: This setpoint is visible only if the logical binary output **FUEL PUMP (PAGE 327)** is configured.

[back to List of setpoints](#)

Subgroup: Choke

Choke Function

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Disabled /Fixed Time / Temp Based [-]		
Default value	Disabled	Alternative config	NO
Step	[-]		
Comm object	15717	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only when LBO CHOKE (PAGE 322) is configured.		
Description			
This setpoint defines choke function behavior.			
Disabled	Choke function is disabled and logical binary output CHOKE (PAGE 322) is activated under no circumstances.		
Fixed Time	Choke time is fixedly defined by Choke Time (page 165) setpoint.		
Temp Based	Choke time is calculated using actual engine (coolant) temperature. Setpoints Choke Start Temp (page 166) and Choke Increment (page 167) are taken into consideration.		

🔍 back to List of setpoints

Choke Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0–3600 [s]		
Default value	0 s	Alternative config	NO
Step	1 s		
Comm object	13011	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only when LBO CHOKE (PAGE 322) is configured and setpoint Choke Function (page 165) = Fixed Time.		
Description			
Defines time logical binary output CHOKE (PAGE 322) is activated for when fixed time is used. When setpoint Choke Function (page 165) is set to <i>Temp Based</i> value, <i>Choke Time</i> value have no effect.			
<p>Note: If setpoint Choke Lead (page 169) is set to nonzero value, total time the CHOKE output is activated still matches value set by Choke Time setpoint. This mean Choke Timeshould be longer than Choke Leadto ensure expected Choke behavior.</p>			


🔍 back to List of setpoints

Choke Start Temp

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	-20,0 .. 80,0 [°C]		
Default value	0,0 °C	Alternative config	NO
Step	0,1 °C		
Comm object	15716	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only when LBO CHOKE (PAGE 322) is configured and setpoint Choke Function (page 165) = Temp Based.		

Description

This setpoint adjust the base temperature for Choke function. When temperature will be higher than this setpoint, Choke Time will be always 0. When temperature will be lower than this setpoint, Choke Time will be calculated by curve adjusted via setpoint Choke Increment (page 167). When setpoint Choke Function (page 165) is set to *Fixed Time* value, setpoint *Choke Start Temp* has no effect.




[back to List of setpoints](#)

Choke Increment

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0,00 .. 20,00 [s/°C]		
Default value	0,00 s/°C	Alternative config	NO
Step	0,01 s/°C		
Comm object	15715	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only when LBO CHOKE (PAGE 322) is configured and setpoint Choke Function (page 165) = Temp Based.		

Description

This setpoint adjust the maximal time of activation of binary output **CHOKE** (PAGE 322). Calculated time depends on engine (coolant) temperature. Setpoint adjust curve which is used for calculating actual Choke Time. When setpoint Choke Function (page 165) is set to *Fixed Time* value, setpoint *Choke Increment* has no effect.



Note: If setpoint *Choke Lead* (page 169) is set to nonzero value, total time the *CHOKE* output is activated still matches calculated value (based on actual temperature and setpoints *Choke Increment* and *Choke Start Temp* (page 166)) This mean that adjusted parameters should ensure that calculated *Choke Time* will be longer than *Choke Lead* to ensure expected *Choke* behavior.


[back to List of setpoints](#)

Choke Voltage

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Disabled / 1–100 [%]		
Default value	Disabled	Alternative config	NO
Step	1 %		
Comm object	15718	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only when LBO CHOKE (PAGE 322) is configured.		

Description

This setpoint adjust threshold level for deactivation of **CHOKE (PAGE 322)** binary output. When generator voltage is higher than this level, then logical binary output CHOKE is deactivated. In multiphase system it is sufficient to deactivate CHOKE LBO when at least one voltage crosses this threshold. In case setpoint *Choke Voltage* is set to *Disabled* value, no voltage is taken into account and CHOKE LBO isn't deactivated on the voltage basis.



[back to List of setpoints](#)

Choke Lead

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. Prestart Time [s]		
Default value	0 s	Alternative config	NO
Step	1 s		
Comm object	15774	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only when LBO CHOKE (PAGE 322) is configured.		
Description			
This setpoint adjust the lead of logical binary output CHOKE. CHOKE (PAGE 322) is activated before logical binary output STARTER (PAGE 344).			
<p>Note: In case Choke Lead is longer than 8 s (cranking fail pause), Choke Lead will be limited to 8 s (cranking fail pause time). This limitation is applied only for cranking fail pause, Choke Lead in Prestart stays unchanged.</p>			

🔍 back to List of setpoints

Subgroup: D+ Functions

D+ Function

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Enabled / ChargeFail / Disabled [-]		
Default value	Disabled	Alternative config	NO
Step	[-]		
Comm object	9683	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Behavior of D+ terminal.			
Enabled	The D+ terminal is used for both functions – “running engine” detection and charge fail detection.		
ChargeFail	The D+ terminal is used for charge fail detection only		
Disabled	The D+ terminal is not used.		




Image 8.4 D+ Function 1




Image 8.5 D+ Function 2

[back to List of setpoints](#)

D+ Threshold

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0..100 [%]		
Default value	80 %	Alternative config	NO
Step	1 %		
Comm object	14959	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only if setpoint D+ Function (page 169) is not set to <i>Disabled</i> value.		
Description			
This setpoint adjusts threshold level for D+ function.			

[back to List of setpoints](#)

D+ Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	1..255 [s]		
Default value	1 s	Alternative config	NO
Step	1 s		
Comm object	14960	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only if setpoint D+ Function (page 169) is not set to <i>Disabled</i> value.		
Description			
This setpoint adjusts delay for D+ function. This delay is used for: <ul style="list-style-type: none"> ▶ Alarm Charging Alternator Fail. ▶ For engine running condition - disengagement of starter 			

[◀ back to List of setpoints](#)

D+ Alarm Type

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	No Protec/Wrn/Sd [-]		
Default value	Wrn	Alternative config	NO
Step	[-]		
Comm object	15751	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only if setpoint D+ Function (page 169) is not set to <i>Disabled</i> value.		
Description			
This setpoint adjusts type of alarm Charging Alternator Fail.			

[◀ back to List of setpoints](#)

Subgroup: Starting Timers

Fuel Solenoid Lead

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0,0 .. 25,0 [s]		
Default value	0,5 s	Alternative config	NO
Step	0,1 s		
Comm object	10525	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		

Description

Delay between **FUEL SOLENOID (PAGE 326)** and **STARTER (PAGE 344)** logical binary inputs. **FUEL SOLENOID (PAGE 326)** is closed before **STARTER (PAGE 344)**. Lead time is adjusted via this setpoint.




Image 8.6 Fuel Solenoid Lead

Note: LBO PRESTART (PAGE 341) goes to logical zero when Fuel Solenoid Lead goes to logical one.

[back to List of setpoints](#)

Idle Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 600 [s]		
Default value	12 s	Alternative config	NO
Step	1 s		
Comm object	9097	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		

Description

Idle Time delay starts when RPM exceeds **Starting RPM (page 161)**. Start fail is detected when during Idle state RPM decreases below 2 RPM.

The output **IDLE/NOMINAL (PAGE 335)** remains inactive during the idle period. Binary output Idle/Nominal opens during Cooling period again. This output can be used for switching the governor between idle and nominal speed.




Image 8.7 Idle Time 1




Image 8.8 Idle Time 2

[back to List of setpoints](#)

Minimal Stabilization Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	1 .. Maximal Stabilization Time (page 175) [s]		
Default value	2 s	Alternative config	NO
Step	1 s		
Comm object	8259	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		

Description

When the gen-set has been started and the idle timer has elapsed, the controller will wait for a period adjusted by this setpoint before closing GCB, even if the generator voltage and frequency are already in limits.




Image 8.9 Minimal Stabilization Time

[back to List of setpoints](#)

Maximal Stabilization Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Minimal Stabilization Time (page 174) .. 300 [s]		
Default value	10 s	Alternative config	NO
Step	1 s		
Comm object	8313	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		

Description

When the gen-set has been started and the idle timer has elapsed, the generator voltage and frequency must get within limits within this period of time, otherwise an appropriate shutdown alarm (generator voltage and/or frequency) is issued.




Image 8.10 Maximal Stabilization Time

[back to List of setpoints](#)

Protection Hold Off

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0,0 .. 300,0 [s]		
Default value	5,0 s	Alternative config	YES
Step	0,1 s		
Comm object	10023	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		

Description

During the start of the gen-set, some engine protections have to be blocked (e.g. Oil pressure). The protections are unblocked after the Protect Hold Off. The time starts after reaching Starting RPM.

[back to List of setpoints](#)

Subgroup: Stopping

Cooling Speed

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Idle / Nominal [-]		
Default value	Nominal	Alternative config	NO
Step	[-]		
Comm object	10046	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Selects the function of the binary output IDLE/NOMINAL (PAGE 335) during engine cooling state.			
Idle	Cooling is executed at Idle speed and generator protections are switched off.		
Nominal	Cooling is executed at Nominal speed and generator protections are active.		
<i>Note: When ECU is connected the predefined value 900 RPM for Idle speed is requested.</i>			
<i>Note: Binary output IDLE/NOMINAL (PAGE 335) must be configured and connected to speed governor. Engine Idle speed must be adjusted on speed governor.</i>			

[back to List of setpoints](#)

Subgroup: Stopping Timers

Cooling Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 3 600 [s]		
Default value	30 s	Alternative config	NO
Step	1 s		
Comm object	8258	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Runtime of the unloaded gen-set to cool the engine before stop.			

[back to List of setpoints](#)

Stop Time

Setpoint group	Engine settings	Related FW	1.1.0
Fixed value	60 s		
Description			
Under normal conditions the engine must certainly stop within this period after the FUEL SOLENOID (PAGE 326) has been de-energized and the STOP SOLENOID (PAGE 345) energized. The stop solenoid remains energized for the entire stop time period.			




Image 8.11 Stop Time 1




Image 8.12 Stop Time 2

IMPORTANT: This is a fixed parameter, it isn't possible to adjust it in any manner. This parameter isn't visible either in controller or in PC tools.

🔍 back to List of setpoints

After Cooling Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 3 600 [s]		
Default value	180 s	Alternative config	NO
Step	1 s		
Comm object	8662	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Runtime of engine after cooling pump. Binary output Cooling pump is closed when the engine starts and opens AfterCool time delayed after gen-set stops.			

[◀ back to List of setpoints](#)

Subgroup: Engine Protections

Overspeed Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Underspeed Sd (page 178) 50 .. 200 [%]		
Default value	115%	Alternative config	NO
Step	1 % of Nominal RPM (page 151)		
Comm object	8263	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for over speed protection. Relative to the nominal speed.			

[◀ back to List of setpoints](#)

Underspeed Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. Overspeed Sd (page 178) [%]		
Default value	25%	Alternative config	NO
Step	1 % of Nominal RPM (page 151)		
Comm object	8260	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for underspeed protection. Relative to the nominal speed.			

[◀ back to List of setpoints](#)

Overspeed Overshot

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 50 [%]		
Default value	20%	Alternative config	NO
Step	1 % of Nominal RPM (page 151)		
Comm object	14107	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
This setpoint rise the upper limit of overspeed protection for the time which is defined in setpoint Overspeed Overshot Period (page 179). In this time the upper limit of protection is Overspeed Sd (page 178) + Overspeed Overshoot .			

🔍 back to List of setpoints

Overspeed Overshot Period

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 255 [s]		
Default value	5 s	Alternative config	NO
Step	1 s		
Comm object	14108	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Overspeed Overshot (page 179)		
Description			
Time for which is Overspeed Overshot (page 179) active. The timer starts in the same time when starter starts.			
<i>Note: The setpoint is visible only, if Overspeed Overshot (page 179) is greater than 0.</i>			

🔍 back to List of setpoints

Oil Pressure Wrn

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	12895	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input OIL PRESSURE (PAGE 355) is configured		
Description			
Warning or history threshold level for OIL PRESSURE (PAGE 355).			

🔍 back to List of setpoints

Oil Pressure Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	12779	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input OIL PRESSURE (PAGE 355) is configured		
Description			
Shutdown threshold level for OIL PRESSURE (PAGE 355) .			

[back to List of setpoints](#)

Oil Pressure Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	3 s	Alternative config	NO
Step	1 s		
Comm object	14341	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input OIL PRESSURE (PAGE 355) is configured		
Description			
Delay for OIL PRESSURE (PAGE 355) .			

[back to List of setpoints](#)

ECU Oil Pressure Wrn

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by ECU sensor curve		
Default value	the value is defined by ECU sensor curve	Alternative config	YES
Step	the step is defined by ECU sensor curve		
Comm object	14426	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Warning threshold level for Oil pressure which is send from ECU.			

[back to List of setpoints](#)

ECU Oil Pressure Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by ECU sensor curve		
Default value	the value is defined by ECU sensor curve	Alternative config	NO
Step	the step is defined by ECU sensor curve		
Comm object	14425	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Shutdown threshold level for Oil pressure which is send from ECU.			

[back to List of setpoints](#)

ECU Oil Pressure Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	3 s	Alternative config	NO
Step	1 s		
Comm object	14427	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Delay for Oil pressure which is send from ECU.			

[back to List of setpoints](#)

Coolant Temperature Wrn

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	12896	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input COOLANT TEMP (PAGE 353) is configured		
Description			
Warning or history threshold level for COOLANT TEMP (PAGE 353) .			

[back to List of setpoints](#)

Coolant Temperature Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	12780	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input COOLANT TEMP (PAGE 353) is configured		
Description			
Shutdown or BOC threshold level for COOLANT TEMP (PAGE 353) .			

[back to List of setpoints](#)

Coolant Temperature Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	5 s	Alternative config	NO
Step	1 s		
Comm object	14342	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input COOLANT TEMP (PAGE 353) is configured		
Description			
Delay for COOLANT TEMP (PAGE 353) .			

[back to List of setpoints](#)

ECU Coolant Temperature Wrn

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by ECU sensor curve		
Default value	the value is defined by ECU sensor curve	Alternative config	NO
Step	the step is defined by ECU sensor curve		
Comm object	14429	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Warning threshold level for Coolant temperature which is send from ECU.			

[back to List of setpoints](#)

ECU Coolant Temperature Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by ECU sensor curve		
Default value	the value is defined by ECU sensor curve	Alternative config	NO
Step	the step is defined by ECU sensor curve		
Comm object	14428	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Shutdown or BOC threshold level for Coolant temperature which is send from ECU.			

[back to List of setpoints](#)

ECU Coolant Temperature Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	5 s	Alternative config	NO
Step	1 s		
Comm object	14430	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Delay for Coolant temperature which is send from ECU.			

[back to List of setpoints](#)

Coolant Temperature Low Wrn

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	YES
Step	the step is defined by analog sensor curve		
Comm object	9684	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if the logical analog input COOLANT TEMP (PAGE 353) is configured		
Description			
Threshold level for lower limit of COOLANT TEMP (PAGE 353) .			

[back to List of setpoints](#)

Coolant Temperature Low Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	5 s	Alternative config	YES
Step	1 s		
Comm object	10270	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if the logical analog input COOLANT TEMP (PAGE 353) is configured		
Description			
Delay for Coolant Temperature Low Wrn (page 183).			

[back to List of setpoints](#)

Fuel Level Wrn

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	12897	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input FUEL LEVEL (PAGE 354) is configured		
Description			
Warning or history threshold level for FUEL LEVEL (PAGE 354) .			

[back to List of setpoints](#)

Fuel Level Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	12898	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input FUEL LEVEL (PAGE 354) is configured		
Description			
Shutdown or BOC threshold level for FUEL LEVEL (PAGE 354) .			

[back to List of setpoints](#)

Fuel Level Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	10 s	Alternative config	NO
Step	1 s		
Comm object	14343	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input FUEL LEVEL (PAGE 354) is configured		
Description			
Delay for FUEL LEVEL (PAGE 354).			

[back to List of setpoints](#)

ECU Fuel Level Wrn

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by ECU sensor curve		
Default value	the value is defined by ECU sensor curve	Alternative config	NO
Step	the step is defined by ECU sensor curve		
Comm object	14432	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Warning threshold level for Fuel level which is send from ECU.			

[back to List of setpoints](#)

ECU Fuel Level Sd

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	the range is defined by ECU sensor curve		
Default value	the value is defined by ECU sensor curve	Alternative config	NO
Step	the step is defined by ECU sensor curve		
Comm object	14431	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Shutdown or BOC threshold level for Fuel level which is send from ECU.			

[back to List of setpoints](#)

ECU Fuel Level Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	10 s	Alternative config	NO
Step	1 s		
Comm object	14433	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if ECU is configured		
Description			
Delay for Fuel level which is send from ECU.			

[back to List of setpoints](#)

Transfer Wrn Delay

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Disabled / 1 .. 60 [s]		
Default value	30 s	Alternative config	YES
Step	1 s		
Comm object	10685	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if the logical binary output FUEL PUMP (PAGE 327) is configured		
Description			
<p>If the controller does not see the fuel increase during fuel transfer within this time alarm Wrn Fuel Transfer Failed (page 371) will be displayed and the FUEL PUMP (PAGE 327) will be turned off. Alarm Wrn Fuel Transfer Failed (page 371) will be displayed but this alarm becomes immediately inactive and it will be possible to delete this message by the Fault reset button. If the fault is deleted the controller will initiate the transfer again.</p>			

[back to List of setpoints](#)

Subgroup: Maintenance

Maintenance Timer 1

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	-10 000 ... 9 999 [h] / Disabled		
Default value	1 000 h	Alternative config	NO
Step	1 h		
Comm object	11616	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Maintenance timer 1 counts down when engine is running. If reaches zero, an alarm appears, but the timer still counting down into negative values. When the value 10000 is set, than the Maintenance function is disabled and counter does not count. Counter value disappear from controllers statistics.			

[◀ back to List of setpoints](#)

Maintenance Timer 2

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	-10 000 ... 9 999 [h] / Disabled		
Default value	1 000 h	Alternative config	NO
Step	1 h		
Comm object	11617	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Maintenance timer 2 counts down when engine is running. If reaches zero, an alarm appears, but the timer still counting down into negative values. When the value 10000 is set, than the Maintenance function is disabled and counter does not count. Counter value disappear from controllers statistics.			

[◀ back to List of setpoints](#)

Maintenance Timer 3

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	-10 000 ... 9 999 [h] / Disabled		
Default value	1 000 h	Alternative config	NO
Step	1 h		
Comm object	11618	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Maintenance timer 3 counts down when engine is running. If reaches zero, an alarm appears, but the timer still counting down into negative values. When the value 10000 is set, than the Maintenance function is disabled and counter does not count. Counter value disappear from controllers statistics.			

[◀ back to List of setpoints](#)

Subgroup: Battery Protections

Battery Undervoltage

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	8,0 V .. Battery Overvoltage (page 188) [V]		
Default value	18,0 V	Alternative config	NO
Step	0,1 V		
Comm object	8387	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Warning threshold for low battery voltage.			

[◀ back to List of setpoints](#)

Battery Overvoltage

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Battery Undervoltage (page 188) .. 40,0 [V]		
Default value	36,0 V	Alternative config	NO
Step	0,1 V		
Comm object	9587	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Warning threshold for high battery voltage.			

[◀ back to List of setpoints](#)

Battery <> Voltage Delay

Setpoint group	Engine settings	Related FW	1.1.0
Fixed value	5 s		
Description			
Delay for Battery Undervoltage (page 188) and Battery Overvoltage (page 188) protection.			
<p>IMPORTANT: This is a fixed parameter, it isn't possible to adjust it in any manner. This parameter isn't visible either in controller or in PC tools.</p>			

🔍 back to List of setpoints

Low Battery Charging Cycle

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Disabled / 1–240 [min]		
Default value	Disabled	Alternative config	NO
Step	1 min		
Comm object	15766	Related applications	MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
<p>This setpoint enables battery charging and defines the time gen-set is running for to recharge battery. If battery charging is enabled and battery undervoltage is detected for more than 5 minutes, gen-set is started and will run for time defined in setpoint <i>Low Battery Charging Cycle</i>.</p> <p>Battery charging is only initiated in AUT mode when no Shutdown alarm and Fuel Level alarm is active. If there is battery undervoltage detected again after previous Charging Cycle is finished (and undervoltage lasts more than 5 minutes) next Charging Cycle is initiated.</p> <p>If controller is switched to MAN mode during battery charging, gen-set stay running regardless timer (<i>Low Battery Charging Cycle</i> setpoint) elapsing. Gen-set is stopped by STOP button or by any SD alarm event only in this case.</p> <p>If there is <i>Charging Alternator Fail</i> alarm occurred during battery recharging period, current battery recharging continues until time is elapsed. Next gen-set start due to battery undervoltage is blocked until controller is restarted.</p> <p>IMPORTANT: If controller is in MAN mode and the battery voltage is under the limit more than 5 minutes engine is started immediately when controller is switched to AUT mode.</p> <p>Note: Low Battery Charging function is available only when separate MRS archive is used.</p>			

🔍 back to List of setpoints

Subgroup: ECU Settings

ECU Frequency Select

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Primary / Secondary / Default [-]		
Default value	Default	Alternative config	NO
Step	[-]		
Comm object	10266	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		
Description			
<p>This setpoint is used for choosing a frequency of ECU. Values are saved in ECU.</p> <p>VOLVO EMS2 (GE engines)</p> <p>The nominal speed is selected via the VP Status proprietary frame, parameter "Frequency select".</p> <p>SCANIA EMS/S6</p> <p>The nominal speed is selected via parameters "Nominal speed switch 1" and "Nominal speed switch 2" in the DLN1 proprietary frame.</p> <p>Frequency change for Volvo Penta engines with EMS2</p> <p>This description refers to the Volvo Penta Application bulletin 30-0-003. The procedure for changing engine speed on the D9 and D16 engines is different from the D12 engine. There is no system reset on the EMS2 unit; therefore the procedure is changed.</p> <p><u>Procedure if ECU not energized:</u></p> <ol style="list-style-type: none"> 1. Switch the IL controller to MAN Mode. 2. Power up the ECU. 3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter 4. Press the Stop button on the IL controller. <p>Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.</p> <p><u>Procedure with ECU powered on:</u></p> <ol style="list-style-type: none"> 1. Switch the IL controller to MAN Mode. 2. Press the Stop button on the IL controller. 3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter 4. Press the Stop button on the IL controller. <p>Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.</p> <p>Note: To lock this setpoint against editing you also have to lock setpoint ECU Frequency Select 1 (page 252), ECU Frequency Select 2 (page 254) and ECU Frequency Select 3 (page 256).</p>			

 [back to List of setpoints](#)

ECU Speed Adjustment

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 100 [%]		
Default value	50 %	Alternative config	NO
Step	1 %		
Comm object	9948	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		
Description			
<p>Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50%. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands.</p> <p>Note: To lock this setpoint against editing you also have to lock setpoint <i>ECU Speed Adjustment 1 (page 253)</i>, <i>ECU Speed Adjustment 2 (page 255)</i> and <i>ECU Speed Adjustment 3 (page 257)</i>.</p>			

🔍 back to List of setpoints

Subgroup: Ventilation

Ventilation Pulse Time

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0–3600 [s]		
Default value	30 s	Alternative config	NO
Step	1 s		
Comm object	15767	Related applications	MRS. AMF
Config level	Advanced		
Setpoint visibility	Only when logical binary output VENTILATION ON PULSE (PAGE 346) or VENTILATION OFF PULSE (PAGE 347) is configured.		
Description			
<p>This setpoint defines duration of pulse generated on logical binary outputs VENTILATION ON PULSE (PAGE 346) or VENTILATION OFF PULSE (PAGE 347) at the moment when logical binary output VENTILATION (PAGE 346) is activated or deactivated respectively.</p>			

🔍 back to List of setpoints

Group: Generator settings

Subgroup: Overload Protection

Overload BOC

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	Overload Wrn (page 192) .. 200 [%]		
Default value	120 %	Alternative config	NO
Step	1 % of Nominal Power (page 146)		
Comm object	8280	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold level for generator overload (in % of Nominal power) protection. Protection is BOC (Breaker Open and gen-set Cooldown).			
<i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i>			

[back to List of setpoints](#)

Overload Wrn

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	0 .. Overload BOC (page 192) [%]		
Default value	120 %	Alternative config	NO
Step	1 % of Nominal Power (page 146)		
Comm object	9685	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold level for generator overload (in % of Nominal power) protection. This is only warning.			

[back to List of setpoints](#)

Overload Delay

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	0,0 .. 600,0 [s]		
Default value	5,0 s	Alternative config	NO
Step	0,1 s		
Comm object	8281	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Delay for Overload BOC (page 192)Overload BOC (page 192) and Overload Wrn (page 192) protection.			

[back to List of setpoints](#)

Subgroup: Current Protection

Short Circuit BOC

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	100 .. 500 [%]		
Default value	250 %	Alternative config	NO
Step	1 % of Nominal Current (page 146)		
Comm object	8282	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
BOC occurs when generator current reaches this preset threshold.			
<i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i>			

[back to List of setpoints](#)

Short Circuit BOC Delay

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	0,00 .. 10,00 [s]		
Default value	0,04 s	Alternative config	YES
Step	0,01 s		
Comm object	9991	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Delay for Short Circuit BOC (page 193) protection.			

[back to List of setpoints](#)

Subgroup: Voltage Protection

Generator Overvoltage Sd

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	Generator Overvoltage Wrn (page 194) .. 200 [%]		
Default value	110 %	Alternative config	NO
Step	1 % of Nominal Voltage Ph-N (page 149) or Nominal Voltage Ph-Ph (page 149)		
Comm object	8291	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator overvoltage protection. All three phases are checked. Maximum out of three is used.			
<i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i>			

[back to List of setpoints](#)

Generator Overvoltage Wrn

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	Generator Undervoltage Wrn (page 194) .. Generator Overvoltage Sd (page 193) [%]		
Default value	110 %	Alternative config	NO
Step	1 % of Nominal Voltage Ph-N (page 149) or Nominal Voltage Ph-Ph (page 149)		
Comm object	9686	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator overvoltage protection. All three phases are checked. Maximum out of three is used.			
<i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i>			

[back to List of setpoints](#)

Generator Undervoltage BOC

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	0 .. Generator Undervoltage Wrn (page 194) [%]		
Default value	70 %	Alternative config	NO
Step	1 % of Nominal Voltage Ph-N (page 149) or Nominal Voltage Ph-Ph (page 149)		
Comm object	8293	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator undervoltage protection. All three phases are checked. Minimum out of three is used.			
<i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i>			
<i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i>			

[back to List of setpoints](#)

Generator Undervoltage Wrn

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	Generator Undervoltage BOC (page 194) .. Generator Overvoltage Wrn (page 194) [%]		
Default value	70 %	Alternative config	NO
Step	1 % of Nominal Voltage Ph-N (page 149) or Nominal Voltage Ph-Ph (page 149)		
Comm object	9687	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator undervoltage protection. All three phases are checked. Minimum out of three is used.			
<i>Note: Phase to phase and phase to neutral voltages are used for this protection.</i>			

[back to List of setpoints](#)

Generator <> Voltage Delay

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	0,0 .. 600,0 [s]		
Default value	3,0 s	Alternative config	NO
Step	0,1 s		
Comm object	9103	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Delay for Generator Overvoltage Sd (page 193), Generator Overvoltage Wrn (page 194), Generator Undervoltage BOC (page 194) and Generator Undervoltage Wrn (page 194) protection.			

⬅ back to List of setpoints

Subgroup: Frequency Protection

Generator Overfrequency BOC

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	Generator Overfrequency Wrn (page 195) .. 200,0 [%]		
Default value	110,0 %	Alternative config	NO
Step	0,1 % of Nominal Frequency (page 150)		
Comm object	8296	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator phase L1 overfrequency.			
<i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i>			

⬅ back to List of setpoints

Generator Overfrequency Wrn

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	Generator Underfrequency Wrn (page 196) .. Generator Overfrequency BOC (page 195) [%]		
Default value	110,0 %	Alternative config	NO
Step	0,1 % of Nominal Frequency (page 150)		
Comm object	9688	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator phase L1 overfrequency.			

⬅ back to List of setpoints

Generator Underfrequency BOC

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	0,0 .. Generator Underfrequency Wrn (page 196) [%]		
Default value	85,0 %	Alternative config	NO
Step	0,1 % of Nominal Frequency (page 150)		
Comm object	8298	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator phase L1 underfrequency.			
<i>Note: When there is no control of breakers, the type of protection is Sd not BOC.</i>			

[back to List of setpoints](#)

Generator Underfrequency Wrn

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	Generator Underfrequency BOC (page 196) .. Generator Overfrequency Wrn (page 195) [%]		
Default value	85,0 %	Alternative config	NO
Step	0,1 % of Nominal Frequency (page 150)		
Comm object	9689	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Threshold for generator phase L1 underfrequency.			

[back to List of setpoints](#)

Generator <> Frequency Delay

Setpoint group	Generator settings	Related FW	1.1.0
Range [units]	0,0 .. 600,0 [s]		
Default value	3,0 s	Alternative config	NO
Step	0,1 s		
Comm object	8297	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Delay for Generator Overfrequency BOC (page 195), Generator Overfrequency Wrn (page 195), Generator Underfrequency Wrn (page 196) and Generator Underfrequency BOC (page 196) protection.			

[back to List of setpoints](#)

Group: Protections

Subgroup: Overload Protection

Overload Protection

Setpoint group	Protections	Related FW	1.1.0
Range [units]	Enabled/Disabled/By LBI [-]		
Default value	Enabled	Alternative config	NO
Step	[-]		
Comm object	15664	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
This setpoint adjusts the behavior of generator Overload protection.			
Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoints Overload BOC (page 192) , Overload Wrn (page 192) and Overload Delay (page 192) .		
Disabled:	Protection is disabled.		
By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .		

🔍 back to List of setpoints

Subgroup: Current Protection

Short Circuit Protection

Setpoint group	Protections	Related FW	1.1.0
Range [units]	Enabled / Disabled / By LBI [-]		
Default value	Enabled	Alternative config	NO
Step	[-]		
Comm object	15665	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
This setpoint adjusts the behavior of generator Short Circuit protection.			
Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoints Short Circuit BOC (page 193) and Short Circuit BOC Delay (page 193) .		
Disabled:	Protection is disabled.		
By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .		

🔍 back to List of setpoints

Subgroup: Voltage Protection

Generator <> Voltage Protection

Setpoint group	Protections	Related FW	1.1.0
Range [units]	Enabled / Disabled / By LBI [-]		
Default value	Enabled	Alternative config	NO
Step	[-]		
Comm object	15668	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
This setpoint adjusts the behavior of generator Generator <> Voltage protection. GCB closing is blocked, if the protection is disabled!			
Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoints Generator Overvoltage Sd (page 193) , Generator Overvoltage Wrn (page 194) , Generator Undervoltage BOC (page 194) , Generator Undervoltage Wrn (page 194) and Generator <> Voltage Delay (page 195) .		
Disabled:	Protection is disabled.		
By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .		

[back to List of setpoints](#)

Subgroup: Frequency Protection

Generator Frequency Protection

Setpoint group	Protections	Related FW	1.1.0
Range [units]	Enabled / Disabled / By LBI [-]		
Default value	Enabled	Alternative config	NO
Step	[-]		
Comm object	15670	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
This setpoint adjusts the behavior of generator Generator Frequency protection. GCB closing is blocked, if the protection is disabled!.			
Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoints Generator Overfrequency BOC (page 195) , Generator Overfrequency Wrn (page 195) , Generator Underfrequency BOC (page 196) , Generator Underfrequency Wrn (page 196) , and Generator <> Frequency Delay (page 196) .		
Disabled:	Protection is disabled.		
By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .		

[back to List of setpoints](#)

Subgroup: Speed Protection

Underspeed Protection

Setpoint group	Protections	Related FW	1.1.0						
Range [units]	Enabled / Disabled / By LBI [-]								
Default value	Enabled	Alternative config	NO						
Step	[-]								
Comm object	15671	Related applications	AMF, MRS						
Config level	Advanced								
Setpoint visibility	Always								
Description									
This setpoint adjusts the behavior of generator Underspeed protection.									
<table border="1"> <tr> <td>Enabled:</td> <td>Protection is enabled. Behavior of protection is adjusted via setpoint Underspeed Sd (page 178).</td> </tr> <tr> <td>Disabled:</td> <td>Protection is disabled.</td> </tr> <tr> <td>By LBI:</td> <td>Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310).</td> </tr> </table>				Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoint Underspeed Sd (page 178) .	Disabled:	Protection is disabled.	By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .
Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoint Underspeed Sd (page 178) .								
Disabled:	Protection is disabled.								
By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .								

[◀ back to List of setpoints](#)

Overspeed Protection


Setpoint group	Protections	Related FW	1.1.0						
Range [units]	Enabled / Disabled / By LBI [-]								
Default value	Enabled	Alternative config	NO						
Step	[-]								
Comm object	15672	Related applications	AMF, MRS						
Config level	Advanced								
Setpoint visibility	Always								
Description									
This setpoint adjusts the behavior of generator Overspeed protection.									
<table border="1"> <tr> <td>Enabled:</td> <td>Protection is enabled. Behavior of protection is adjusted via setpoint Overspeed Sd (page 178).</td> </tr> <tr> <td>Disabled:</td> <td>Protection is disabled.</td> </tr> <tr> <td>By LBI:</td> <td>Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310).</td> </tr> </table>				Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoint Overspeed Sd (page 178) .	Disabled:	Protection is disabled.	By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .
Enabled:	Protection is enabled. Behavior of protection is adjusted via setpoint Overspeed Sd (page 178) .								
Disabled:	Protection is disabled.								
By LBI:	Protection is enabled or disabled by the state of LBI PROTECTION ENABLE (PAGE 310) .								

[◀ back to List of setpoints](#)

Group: AMF settings

Subgroup: AMF Timers

Emergency Start Delay

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	0 .. 6 000 [s]		
Default value	5 s	Alternative config	NO
Step	1 s		
Comm object	8301	Related applications	AMF
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Delay after the mains failure to the start command of the gen-set.			
			
Image 8.13 Emergency Start Delay			

[back to List of setpoints](#)

Mains Return Delay

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	1 .. 3 600 [s]		
Default value	20 s	Alternative config	NO
Step	1 s		
Comm object	8302	Related applications	AMF
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
This setpoint adjust the delay, how long mains has to be returned after mains fail to start load transfer to mains.			

[back to List of setpoints](#)

Transfer Delay

Setpoint group	AMF settings	Related FW	1.1.0
Fixed value	1.0 s		

Description

Delay after GCB opening to MCB closing during the return procedure. Delay after MCB opening to GCB closing if the setpoint **Description (page 207)** is set to GENRUN.

The time charts below show recommended setting of Transfer Delay setpoint.

If the Transfer Delay setpoint is set shorter than the time required for opening of the circuit breaker, the controller closes **GCB CLOSE/OPEN (PAGE 327)** output straight away (100 ms) after the **MCB FEEDBACK (PAGE 309)** input deactivates.




Image 8.14 Transfer Delay 1

If some delay between **MCB FEEDBACK (PAGE 309)** deactivation and closing of **GCB CLOSE/OPEN (PAGE 327)** output is required, then the Transfer Delay must be set to sum of “MCB opening” + “Delay” time.

Mains Undervoltage

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	50 .. Mains Overvoltage (page 202) [%]		
Default value	60 %	Alternative config	YES
Step	1 % of Nominal Voltage Ph-Ph (page 149)		
Comm object	8307	Related applications	AMF
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Threshold for mains undervoltage. All three phases are checked. Minimum voltage out of three phases is used.			

🔍 back to List of setpoints

Mains <> Voltage Delay

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	0,0 .. 600,0 [s]		
Default value	2,0 s	Alternative config	YES
Step	0,1 s		
Comm object	8306	Related applications	AMF
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Delay for Mains Undervoltage (page 203) and Mains Overvoltage (page 202) protection.			

🔍 back to List of setpoints

Subgroup: AMF Frequency Conditions

Mains Overfrequency

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	Mains Underfrequency (page 204) .. 150 [%]		
Default value	102,0 %	Alternative config	NO
Step	1,0 % of Nominal Frequency (page 150)		
Comm object	8310	Related applications	AMF
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Threshold for mains overfrequency.			

🔍 back to List of setpoints

Mains Underfrequency

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	50 .. Mains Overfrequency (page 203) [%]		
Default value	98,0 %	Alternative config	NO
Step	1,0 % of Nominal Frequency (page 150)		
Comm object	8312	Related applications	AMF
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Threshold for mains underfrequency.			

🔍 back to List of setpoints

Mains < > Frequency Delay

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	0,0 .. 600,0 [s]		
Default value	0,5 s	Alternative config	NO
Step	0,1 s		
Comm object	8311	Related applications	AMF
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Delay for Mains Underfrequency (page 204) and Mains Overfrequency (page 203) protection.			

🔍 back to List of setpoints

Subgroup: AMF Settings

Return From Island

Setpoint group	AMF settings	Related FW	1.1.0
Fixed value	Auto		
Description			
Setpoint adjust the behavior of closing MCB when the mains returns.			
Manual	When Return From Island = MANUAL and there is a Mains Fail, gen-set is started and take the load. After mains return the load have to manually transfer to mains. Also in Alarmlist will be displayed Manual Restore (page 370) alarm.		
	Note: Select MANUAL in case you need to manually control the moment when the load is transferred back to the mains.		
Auto	No automatic mode change is performed.		
IMPORTANT: This is a fixed parameter, it isn't possible to adjust it in any manner. This parameter isn't visible either in controller or in PC tools.			

🔍 back to List of setpoints

Return From Test

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	Manual / Auto [-]		
Default value	Manual	Alternative config	NO
Step	[-]		
Comm object	8618	Related applications	AMF
Config level	Advanced		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Setpoint adjust the behavior of test mode.			
Manual	<ol style="list-style-type: none"> 1. Select TEST mode, gen-set will start and run unloaded 2. To transfer the load from mains to gen-set press MCB button <input type="checkbox"/> I/O or wait for mains fail 3. The gen-set remains running loaded when mains recovers 4. To transfer load back to mains press MCB button or switch controller to AUTO mode (mains has to be healthy) 5. To stop the gen-set switch controller to AUTO (to stop gen-set automatically) or to MAN mode (to stop gen-set manually) 		
Auto	<ol style="list-style-type: none"> 1. Select TEST mode, gen-set will start and run unloaded 2. To transfer load from mains to the gen-set wait for the mains fail. The controller does not response for MCB button <input type="checkbox"/> I/O. 3. When the mains recovers: <ol style="list-style-type: none"> a. After the Mains Return Delay (page 200) the controller opens the GCB b. After the Transfer Delay (page 201) the controller closes the MCB 4. The gen-set remains running unloaded 5. To stop the gen-set switch controller to AUTO (to stop gen-set automatically) or to MAN mode (to stop gen-set manually) 		

[⬅ back to List of setpoints](#)

MCB Logic

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	Close On / Close Off [-]		
Default value	Close Off	Alternative config	NO
Step	[-]		
Comm object	8444	Related applications	AMF
Config level	Advanced		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
The set point influences the behavior of the output MCB CLOSE/OPEN (PAGE 335) .			
Close On When the output MCB CLOSE/OPEN (PAGE 335) is closed – MCB should be closed.			

Close Off When the output **MCB CLOSE/OPEN** (PAGE 335) is closed – MCB should be opened.




Image 8.16 MCB Logic 1





Image 8.17 MCB Logic 2

 [back to List of setpoints](#)

MCB Opens On

Setpoint group	AMF settings	Related FW	1.1.0
Range [units]	Mains Fail / Gen Run [-]		
Default value	Gen Run	Alternative config	NO
Step	[-]		
Comm object	9850	Related applications	AMF
Config level	Advanced		
Setpoint visibility	Conditioned by the setpoint Operation Mode (page 154)		
Description			
Setpoint adjust the behavior of opening MCB in AUTO mode when there is mains fail.			
<p>Mains Fail The command to open the MCB is given immediately after mains fail condition is evaluated. If the mains will return into parameters after MCB was opened and before GCB is closed, timer MCB Close Delay (page 202) is applied before MCB closing.</p> <p>Gen Run MCB will be opened when engine will be running and it will be possible to transfer load from Mains to gen-set (after stabilisation phase).</p>			
<p>Note: This option should be used for MCBs using 230V control and not equipped with the undervoltage coil.</p>			

🔍 back to List of setpoints

Group: General Analog Inputs

General Analog Input 1

Analog Protection 1 Wrn

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	9259	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT01 (PAGE 350) is configured		
Description			
Warning or history threshold level for AIN PROT01 (PAGE 350).			
<p>Note: These setpoints are used only if LAI AIN PROT01 (PAGE 350) is adjusted to required protection type. Otherwise these setpoints are useless.</p>			

🔍 back to List of setpoints

Analog Protection 1 Sd

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	9260	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT01 (PAGE 350) is configured		
Description			
Shutdown or BOC threshold level for AIN PROT01 (PAGE 350).			
<p>Note: These setpoints are used only if LAI AIN PROT01 (PAGE 350) is adjusted to required protection type. Otherwise these setpoints are useless.</p>			

🔍 back to List of setpoints

Analog Protection 1 Delay

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	0 s	Alternative config	NO
Step	1 s		
Comm object	9261	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT01 (PAGE 350) is configured		
Description			
Delay for AIN PROT01 (PAGE 350).			
<p>Note: These setpoints are used only if LAI AIN PROT01 (PAGE 350) is adjusted to required protection type. Otherwise these setpoints are useless.</p>			

🔍 back to List of setpoints

General Analog Input 2

Analog Protection 2 Wrn

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	9262	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT02 (PAGE 351) is configured		
Description			
Warning or history threshold level for AIN PROT02 (PAGE 351) .			
<i>Note: These setpoints are used only if LAI AIN PROT02 (PAGE 351) is adjusted to required protection type. Otherwise these setpoints are useless.</i>			

[back to List of setpoints](#)

Analog Protection 2 Sd

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	9263	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT02 (PAGE 351) is configured		
Description			
Shutdown or BOC threshold level for AIN PROT02 (PAGE 351) .			
<i>Note: These setpoints are used only if LAI AIN PROT02 (PAGE 351) is adjusted to required protection type. Otherwise these setpoints are useless.</i>			

[back to List of setpoints](#)

Analog Protection 2 Delay

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	0 s	Alternative config	NO
Step	1 s		
Comm object	9264	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT02 (PAGE 351) is configured		
Description			
Delay for AIN PROT02 (PAGE 351) .			
<i>Note: These setpoints are used only if LAI AIN PROT02 (PAGE 351) is adjusted to required protection type. Otherwise these setpoints are useless.</i>			

[back to List of setpoints](#)

General Analog Input 3

Analog Protection 3 Wrn

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	9265	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT03 (PAGE 352) is configured		
Description			
Warning or history threshold level for AIN PROT03 (PAGE 352) .			
<i>Note: These setpoints are used only if LAI AIN PROT03 (PAGE 352) is adjusted to required protection type. Otherwise these setpoints are useless.</i>			

[back to List of setpoints](#)

Analog Protection 3 Sd

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	the range is defined by analog sensor curve		
Default value	the value is defined by analog sensor curve	Alternative config	NO
Step	the step is defined by analog sensor curve		
Comm object	9266	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT03 (PAGE 352) is configured		
Description			
Shutdown or BOC threshold level for AIN PROT03 (PAGE 352).			
<i>Note: These setpoints are used only if LAI AIN PROT03 (PAGE 352) is adjusted to required protection type. Otherwise these setpoints are useless.</i>			

🔍 back to List of setpoints

Analog Protection 3 Delay

Setpoint group	General Analog Inputs	Related FW	1.1.0
Range [units]	0 .. 900 [s]		
Default value	0 s	Alternative config	NO
Step	1 s		
Comm object	9267	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Visible only if the logical analog input AIN PROT03 (PAGE 352) is configured		
Description			
Delay for AIN PROT03 (PAGE 352).			
<i>Note: These setpoints are used only if LAI AIN PROT03 (PAGE 352) is adjusted to required protection type. Otherwise these setpoints are useless.</i>			

🔍 back to List of setpoints

Group: Scheduler

Subgroup: Time & Date

Time

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	HH:MM:SS [-]		
Default value	0:0:0	Alternative config	NO
Step	[-]		
Comm object	24554	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Real time clock adjustment.			

[back to List of setpoints](#)

Date

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	DD/MM/YYYY [-]		
Default value	1.1.2015	Alternative config	NO
Step	[-]		
Comm object	24553	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Actual date adjustment.			

[back to List of setpoints](#)

Time Stamp Period

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	0 .. 240 [min]		
Default value	60 min	Alternative config	NO
Step	1 min		
Comm object	8979	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Time interval for periodic history records.			
Note: History record is made only when engine is running.			

[back to List of setpoints](#)

#Summer Time Mode

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Disabled / Winter / Summer / Winter - S / Summer - S [-]		
Default value	Disabled	Alternative config	NO
Step	[-]		
Comm object	8727	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Behavior of switching between winter and summer time.			
Disable	Automatic switching between summer and wintertime is disabled.		
Winter (Summer)	Automatic switching between summer and wintertime is enabled and it is set to winter (summer) season.		
Winter - S (Summer - S)	Modification for southern hemisphere.		

[◀ back to List of setpoints](#)

Subgroup: Timer 1

Timer 1 Function

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Disable / No Func / TEST / Test OnLd / MFail Blk //Auto Run / Mode OFF [-]		
Default value	Disable	Alternative config	NO
Step	[-]		
Comm object	15358	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
<p>It is possible to choose from following timer functions. Binary output EXERCISE TIMER 1 (PAGE 325) is always activated when Timer is active regardless of chosen timer function. Timer functions require controller running in AUTO mode.</p> <p>Controller activates timer whenever it is powered up even in period, where timer should be already running.</p> <p>Disable The Timer is disabled.</p> <p>No Func There is no any other function, only binary output of timer is activated.</p> <p>Auto Run When this option is chosen then the binary output of timer is internally connected to the REMOTE START/STOP (PAGE 312) binary input.</p> <p>TEST When this option is chosen then the binary output of timer is internally connected to the binary input Remote TEST.</p> <p>TEST OnLd When this option is chosen then the binary output of timer is internally connected to the Remote TEST On Load binary input.</p> <p>MFail Blk When this option is chosen then the binary output of timer is internally connected to the Mains Fail Block binary input.</p> <p>Mode OFF When this option is chosen then the binary output of timer is internally connected to the Remote OFF binary input.</p>			

[🔍 back to List of setpoints](#)

Timer 1 Setup

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	[-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	10969	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Related setpoints for timer 1 are:			
▶ Timer 1 Function (page 214)		▶ Timer 1 Day (page 219)	
▶ Timer 1 Repetition (page 215)		▶ Timer 1 Repeated Day In Week (page 220)	
▶ Timer 1 First Occur. Date (page 216)		▶ Timer 1 Repeat Day In Month (page 220)	
▶ Timer 1 First Occur. Time (page 216)		▶ Timer 1 Repeat Week In Month (page 221)	
▶ Timer 1 Duration (page 216)		▶ Timer 1 Refresh Period (page 218)	
▶ Timer 1 Repeated (page 217)		▶ Timer 1 Weekends (page 219)	
▶ Timer 1 Repeat Day (page 220)			

[◀ back to List of setpoints](#)

Timer 1 Repetition

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Off / Once / Repeated [-]		
Default value	Off	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Defines repetition of Timer 1 Function (page 214).			
Off	Timer 1 Function (page 214) will not be activated.		
Once	Timer 1 Function (page 214) will be activated only one time.		
Repeated	Timer 1 Function (page 214) will be repeatedly activated.		

[◀ back to List of setpoints](#)

Timer 1 First Occur. Date

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	[DD/MM/YYYY]		
Default value	01/01/2000	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Date of first occurrence of Timer 1 Function (page 214).			

[back to List of setpoints](#)

Timer 1 First Occur. Time

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	[HH:MM]		
Default value	00:00	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Time of first occurrence of Timer 1 Function (page 214).			

[back to List of setpoints](#)

Timer 1 Duration

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	[HH:MM]		
Default value	00:00	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Timer 1 Function (page 214) duration time.			

[back to List of setpoints](#)

Timer 1 Repeated

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Daily / Weekly / Monthly / Short Period [-]		
Default value	Daily	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Repeated interval of Timer 1 Function (page 214).			
Daily	Timer 1 Function (page 214) is repeated every day.		
Weekly	Timer 1 Function (page 214) is repeated every week in chosen days.		
Monthly	Timer 1 Function (page 214) is repeated in chosen day every month or in chosen days of chosen week of month		
Short Period	Timer 1 Function (page 214) is repeated in adjusted period.		

[◀ back to List of setpoints](#)

Timer 1 Refresh Period

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	[-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Refresh period of Timer 1 Function (page 214). Meaning of this setpoint depends on type of repetition adjusted in Timer 1 Repeated (page 217).			
Daily	<p>Range [units]: 1 .. 1000 [day]. This setpoint adjust that every X day the timer will be activated.</p> <p>Example: If you have daily repetition and you set this setpoint to 2, then every second day from first occurrence of Timer 1 Function (page 214), the Timer 1 Function (page 214) will be activated.</p>		
Weekly	<p>Range [units]: 1 .. 60 [week]. This setpoint adjust that every X week the timer will be activated.</p> <p>Example: If you have weekly repetition and you set this setpoint to 2, then every second week from first occurrence of Timer 1 Function (page 214), the Timer 1 Function (page 214) will be activated in selected days adjusted by Timer 1 Day (page 219).</p>		
Monthly	<p>Range [units]: 1 .. 12 [month]. This setpoint adjust that every X month the timer will be activated.</p> <p>Example: If you have monthly repetition and you set this setpoint to 2, then every second month from first occurrence of Timer 1 Function (page 214), the Timer 1 Function (page 214) will be activated in selected day of month adjusted by Timer 1 Repeat Day In Month (page 220) or in selected days of week of month adjusted by Timer 1 Day (page 219) and Timer 1 Repeat Week In Month (page 221).</p>		
Short Period	<p>Range [units]: [HH:MM]. This setpoint adjust that every X short period the timer will be activated.</p> <p>Example: If you have short period repetition and you set this setpoint to 2, then every second minute from first occurrence of Timer 1 Function (page 214), the Timer 1 Function (page 214) will be activated.</p>		

[◀ back to List of setpoints](#)

Timer 1 Weekends

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Including / Skip / Postpone [-]		
Default value	Including	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Behavior of Timer 1 Function (page 214) on weekends.			
Including	Timer 1 Function (page 214) counter is running on the weekends and Timer 1 Function (page 214) can be active.		
Skip	Timer 1 Function (page 214) counter is running on the weekends but Timer 1 Function (page 214) isn't active.		
Postpone	Timer 1 Function (page 214) counter isn't running on the weekends and Timer 1 Function (page 214) isn't active. If the activation of timer is counted on the weekend, than timer will be activated after weekend. Another activation of timer is counted from original date of first occurrence date.		

[◀ back to List of setpoints](#)

Timer 1 Day

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Monday / Tuesday / Wednesday / Thursday / Friday / Saturday/ Sunday[-]		
Default value	All OFF	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Use this setpoint to include or exclude individual days of week. To select the day use Up and Down buttons. To change the value of day use Enter button.			

[◀ back to List of setpoints](#)

Timer 1 Repeat Day

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Repeated Day / Repeated Day In Week [-]		
Default value	Repeated Day	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Use this setpoint to adjust behavior of monthly repetition of the Timer 1 Function (page 214).			
Repeated Day Chose one day in month when Timer 1 Function (page 214) will be activated.			
Repeated Day In Week Chose days in one week when Timer 1 Function (page 214) will be activated.			

🔍 back to List of setpoints

Timer 1 Repeated Day In Week

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	Monday / Tuesday / Wednesday / Thursday / Friday / Saturday/ Sunday[-]		
Default value	All OFF	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Use this setpoint to select the day of week when timer will be activated.			
<i>Note: More day can be selected. Timer will be activated on the day which happened like the first.</i>			

🔍 List of setpoints (page 142)

Timer 1 Repeat Day In Month

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	1..31 [day]		
Default value	0	Alternative config	NO
Step	[-]		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
Use this setpoint to chose the day in month when the Timer 1 Function (page 214) will be activated.			

🔍 back to List of setpoints

Timer 1 Repeat Week In Month

Setpoint group	Scheduler	Related FW	1.1.0
Range [units]	1 .. 5 [week]		
Default value	1 week	Alternative config	NO
Step	1 week		
Comm object	0	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Timer 1 Function (page 214)		
Description			
This setpoint adjust the week of month in which the Timer 1 Function (page 214) will be activated.			

[back to List of setpoints](#)

Group: Plug-In Modules

Slot A

Setpoint group	Plug-In Modules	Related FW	1.1.0
Range [units]	ENABLED / DISABLED [-]		
Default value	ENABLED	Alternative config	NO
Step	[-]		
Comm object	24280	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
This setpoint enable or disable module in slot A.			

[back to List of setpoints](#)

Group: CM-RS232-485

COM1 Mode

Setpoint group	CM-RS232-485	Related FW	1.1.0
Range [units]	Direct / MODBUS [-]		
Default value	Direct	Alternative config	NO
Step	[-]		
Comm object	24522	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Communication protocol switch for the COM1 channel.			
Direct	InteliConfig communication protocol via serial cable.		
MODBUS	MODBUS protocol.		

[back to List of setpoints](#)

COM1 Communication Speed

Setpoint group	CM-RS232-485	Related FW	1.1.0
Range [units]	9600 / 19200 / 38400 / 57600 / 115200[bps]		
Default value	57600 bps	Alternative config	NO
Step	[-]		
Comm object	24341	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed + conditioned by the setpoint COM1 Mode (page 221)		
Description			
If the direct mode is selected on COM1 channel, the direct communication speed of controller part of line can be adjusted here. Speed of second part of line has to be adjusted to the same value.			
<i>Note: Winscope supports only 19200, 38400, 57600 speeds.</i>			

 [List of setpoints \(page 142\)](#)

COM1 MODBUS Communication Speed

Setpoint group	CM-RS232-485	Related FW	1.1.0
Range [units]	9600 / 19200 / 38400 / 57600 / 115200 [bps]		
Default value	9600 bps	Alternative config	NO
Step	[-]		
Comm object	24477	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed + conditioned by the setpoint COM1 Mode (page 221)		
Description			
If the MODBUS mode is selected on COM1 channel, the MODBUS communication speed can be adjusted here.			

 [List of setpoints \(page 142\)](#)

COM2 Mode

Setpoint group	CM-RS232-485	Related FW	1.1.0
Range [units]	Direct / MODBUS [-]		
Default value	Direct	Alternative config	NO
Step	[-]		
Comm object	24451	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Communication protocol switch for the COM2 channel.			
Direct	InteliConfig communication protocol via serial cable.		
MODBUS	MODBUS protocol.		

🔍 back to List of setpoints

COM2 Communication Speed

Setpoint group	CM-RS232-485	Related FW	1.1.0
Range [units]	9600 / 19200 / 38400 / 57600 / 115200[bps]		
Default value	57600 bps	Alternative config	NO
Step	[-]		
Comm object	24340	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed + conditioned by the setpoint COM2 Mode (page 223)		
Description			
If the direct mode is selected on COM2 channel, the direct communication speed of controller part of line can be adjusted here. Speed of second part of line has to be adjusted to the same value.			
Note: Winscope supports only 19200, 38400, 57600 speeds.			

🔍 List of setpoints (page 142)

COM2 MODBUS Communication Speed

Setpoint group	CM-RS232-485	Related FW	1.1.0
Range [units]	9600 / 19200 / 38400 / 57600 / 115200 [bps]		
Default value	9600 bps	Alternative config	NO
Step	[-]		
Comm object	24420	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed + conditioned by the setpoint COM2 Mode (page 223)		
Description			
If the MODBUS mode is selected on COM2 channel, the MODBUS communication speed can be adjusted here.			

🔍 [List of setpoints \(page 142\)](#)

Group: CM-GPRS

Message Language

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	[-]		
Default value	English	Alternative config	NO
Step	[-]		
Comm object	24299	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Use this setpoint to set the language of SMS and e-mail.			
<p>Note: Numbers correspond with languages in language list. See the chapter for <i>Language selection (page 73)</i> more information.</p>			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

🔍 [back to List of setpoints](#)

Time Zone

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	GMT-12:00 .. GMT+13:00 [hours]		
Default value	GMT+1:00 hour	Alternative config	NO
Step	[-]		
Comm object	24366	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
<p>This setpoint is used to select the time zone where the controller is located. See your computer time zone setting (click on the time indicator located in the rightmost position of the Windows task bar) if you are not sure about your time zone.</p> <p>Note: <i>If the time zone is not selected properly the active e-mails may contain incorrect information about sending time, which may result in confusion when the respective problem actually occurred.</i></p> <p>Note: <i>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</i></p>			

[◀ back to List of setpoints](#)

Event Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	10926	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
<p>This setpoint enables or disables Event Messages.</p> <p>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p>			

[◀ back to List of setpoints](#)

Wrn Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	8482	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables Wrn Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[back to List of setpoints](#)

BOC Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	10566	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables BOC Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[back to List of setpoints](#)

Sd Messages

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	8484	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables Sd Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[back to List of setpoints](#)

Telephone Number 1

Setpoint group	CM-GPRS; CM-4G-GPS	Related FW	1.1.0
Range [units]	0..31 characters [-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	24296	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Enter in this setpoint either a valid GSM phone number where the alarm messages shall be sent. For GSM numbers use either the national format (i.e. the number you would dial if you wanted to make a local call) or the full international format beginning with a “+” character followed by the country prefix.			
IMPORTANT: Telephone number has to be entered without spaces.			

[back to List of setpoints](#)

Group: CM-4G-GPS

Required Connection Type

Setpoint group	CM-4G-GPS	Related FW	1.1.0
Range [units]	2G/3G/4G/Automatic [-]		
Default value	Automatic	Alternative config	NO
Step	[-]		
Comm object	24132	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint adjusts preferred connection type of CM-4G-GPS module.			

[back to List of setpoints](#)

Message Language

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	[-]		
Default value	English	Alternative config	NO
Step	[-]		
Comm object	24299	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Use this setpoint to set the language of SMS and e-mail.			
<p>Note: Numbers correspond with languages in language list. See the chapter for <i>Language selection</i> (page 73) more information.</p>			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[back to List of setpoints](#)

Time Zone

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	GMT-12:00 .. GMT+13:00 [hours]		
Default value	GMT+1:00 hour	Alternative config	NO
Step	[-]		
Comm object	24366	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint is used to select the time zone where the controller is located. See your computer time zone setting (click on the time indicator located in the rightmost position of the Windows task bar) if you are not sure about your time zone.			
<p>Note: If the time zone is not selected properly the active e-mails may contain incorrect information about sending time, which may result in confusion when the respective problem actually occurred.</p>			
<p>Note: This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p>			

[back to List of setpoints](#)

Event Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	10926	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables Event Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[back to List of setpoints](#)

Wrn Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	8482	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables Wrn Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[back to List of setpoints](#)

BOC Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	10566	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables BOC Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[back to List of setpoints](#)

Sd Messages

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	8484	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables Sd Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[◀ back to List of setpoints](#)

Telephone Number 1

Setpoint group	CM-GPRS; CM-4G-GPS	Related FW	1.1.0
Range [units]	0..31 characters [-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	24296	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Enter in this setpoint either a valid GSM phone number where the alarm messages shall be sent. For GSM numbers use either the national format (i.e. the number you would dial if you wanted to make a local call) or the full international format beginning with a “+” character followed by the country prefix.			
IMPORTANT: Telephone number has to be entered without spaces.			

[◀ back to List of setpoints](#)

Group: CM-Ethernet

Email Address 1

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	0..63 characters [-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	24298	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Enter in this setpoint a valid e-mail address where the alarm and event e-mails shall be sent.			
<i>Note: This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</i>			

⬅ back to List of setpoints

Message Language

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	[-]		
Default value	English	Alternative config	NO
Step	[-]		
Comm object	24299	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Use this setpoint to set the language of SMS and e-mail.			
<i>Note: Numbers correspond with languages in language list. See the chapter for Language selection (page 73) more information.</i>			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

⬅ back to List of setpoints

Time Zone

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	GMT-12:00 .. GMT+13:00 [hours]		
Default value	GMT+1:00 hour	Alternative config	NO
Step	[-]		
Comm object	24366	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
<p>This setpoint is used to select the time zone where the controller is located. See your computer time zone setting (click on the time indicator located in the rightmost position of the Windows task bar) if you are not sure about your time zone.</p> <p>Note: If the time zone is not selected properly the active e-mails may contain incorrect information about sending time, which may result in confusion when the respective problem actually occurred.</p> <p>Note: This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p>			

[⬅ back to List of setpoints](#)

Event Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	10926	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
<p>This setpoint enables or disables Event Messages.</p> <p>This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.</p>			

[⬅ back to List of setpoints](#)

Wrn Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	8482	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables Wrn Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[◀ back to List of setpoints](#)

BOC Message

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	10566	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables BOC Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[◀ back to List of setpoints](#)

Sd Messages

Setpoint group	CM-GPRS; CM-4G-GPS; CM-Ethernet	Related FW	1.1.0
Range [units]	ON / OFF [-]		
Default value	ON	Alternative config	NO
Step	[-]		
Comm object	8484	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint enables or disables Sd Messages.			
This setpoint is common for CM-Ethernet, CM-GPRS and CM-4G-GPS modules.			

[◀ back to List of setpoints](#)

SMTP UserName

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	0..31 characters [-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	24370	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Use this setpoint to enter the username for the SMTP server. Leave the setpoint blank if the SMTP server does not require authentication.			

[▲ back to List of setpoints](#)

SMTP User Password

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	0..15 characters [-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	24369	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Use this setpoint to enter the password for the SMTP server. Leave the setpoint blank if the SMTP server does not require authentication.			

[▲ back to List of setpoints](#)

SMTP Server Address

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	0..31 characters [-]		
Default value	airgate.comap.cz:9925	Alternative config	NO
Step	[-]		
Comm object	24368	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
This setpoint is used for entering the domain name (e.g. smtp.yourprovider.com) or IP address (e.g. 74.125.39.109) or number of port (with colon like a first mark) of the SMTP server. Ask your internet provider or IT manager for this information.			

[▲ back to List of setpoints](#)

SMTP Sender Address

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	0..31 characters [-]		
Default value	[-]	Alternative config	NO
Step	[-]		
Comm object	24367	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
Enter an existing email address into this setpoint. This address will be used as sender address in active e-mails that will be sent from the controller.			
<p><i>Note: It is not needed to enter an existing email address, nevertheless valid email format needs to be followed.</i></p>			
<p>IMPORTANT: This item is obligatory when emails are configured.</p>			

🔍 back to List of setpoints

IP Address Mode

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	FIXED / AUTOMATIC [-]		
Default value	AUTOMATIC	Alternative config	NO
Step	[-]		
Comm object	24259	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
The setpoint is used to select the method how the ethernet connection is adjusted.			
DISABLED:	<p>The Ethernet connection is fixed by means of the setpoints <u>IP Addr</u>, <u>NetMask</u>, <u>GateIP</u>, <u>DNS IP Address</u>.</p> <p>This method should be used for a classic Ethernet or internet connection. When this type of connection opens, the controller is specified by its IP address. This means that it would be inconvenient if the IP address were not fixed (static).</p>		
ENABLED:	<p>The Ethernet connection setting is obtained automatically from the DHCP server. The obtained settings are then copied to the related setpoints. If the process of obtaining the settings from the DHCP server is not successful, the value <i>000.000.000.000</i> is copied to the setpoint IP address and the module continues to try to obtain the settings.</p>		

🔍 back to List of setpoints

IP Address

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	Valid IP address [-]		
Default value	192.168.1.254	Alternative config	NO
Step	[-]		
Comm object	24376	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed + conditioned by the setpoint IP Address Mode (page 235)		
Description			
<p>The setpoint is used to select the method how the IP Address is adjusted.</p> <p>If IP Address Mode (page 235) is FIXED this setpoint is used to adjust the IP address of the ethernet interface of the controller. Ask your IT specialist for help with this setting.</p> <p>If IP Address Mode (page 235) is AUTOMATIC this setpoint is inactive. The IP address is assigned by the DHCP server.</p>			

[◀ back to List of setpoints](#)

Subnet Mask

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	Valid IP address [-]		
Default value	255.255.255.0	Alternative config	NO
Step	[-]		
Comm object	24375	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed + conditioned by the setpoint IP Address Mode (page 235)		
Description			
<p>The setpoint is used to select the method how the Subnet Mask is adjusted.</p> <p>If IP Address Mode (page 235) is FIXED this setpoint is used to adjust the Subnet Mask. Ask your IT specialist for help with this setting.</p> <p>If IP Address Mode (page 235) is AUTOMATIC this setpoint is inactive. The Subnet Mask is assigned by the DHCP server.</p>			

[◀ back to List of setpoints](#)

Gateway IP

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	Valid IP address [-]		
Default value	192.168.1.1	Alternative config	NO
Step	[-]		
Comm object	24373	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed + conditioned by the setpoint IP Address Mode (page 235)		
Description			
<p>The setpoint is used to select the method how the Gateway IP is adjusted.</p> <p>If IP Address Mode (page 235) is DISABLE this setpoint is used to adjust the IP address of the gateway of the network segment where the controller is connected.</p> <p>If IP Address Mode (page 235) is ENABLED this setpoint is used to display the gateway IP address which has been assigned by the DHCP server.</p> <p>A gateway is a device which connects the respective segment with the other segments and/or Internet.</p>			

[back to List of setpoints](#)

DNS IP Address 1

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	Valid IP address [-]		
Default value	8.8.8.8	Alternative config	NO
Step	[-]		
Comm object	24362	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
<p>The setpoint is used to select the method how the DNS Address 1 is adjusted.</p> <p>If IP Address Mode (page 235) is FIXED this setpoint is used to adjust the domain name server (DNS), which is needed to translate domain names in email addresses and server names into correct IP addresses.</p> <p>If IP Address Mode (page 235) is AUTOMATIC this setpoint is inactive. The DNS server IP address is assigned by the DHCP server.</p>			

[back to List of setpoints](#)

DNS IP Address 2

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	Valid IP address [-]		
Default value	8.8.8.8	Alternative config	NO
Step	[-]		
Comm object	24331	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
<p>The setpoint is used to select the method how the DNS Address 2 is adjusted.</p> <p>If IP Address Mode (page 235) is FIXED this setpoint is used to adjust the domain name server (DNS), which is needed to translate domain names in email addresses and server names into correct IP addresses.</p> <p>If IP Address Mode (page 235) is AUTOMATIC this setpoint is inactive. The DNS server IP address is assigned by the DHCP server.</p>			

[back to List of setpoints](#)

MODBUS Server

Setpoint group	CM-Ethernet	Related FW	1.1.0
Range [units]	DISABLED / ENABLED [-]		
Default value	Disabled	Alternative config	NO
Step	[-]		
Comm object	24337	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Only if relevant module is installed		
Description			
<p>Enable or disable MODBUS communication via ethernet interface.</p>			

[back to List of setpoints](#)

Group: Alternate Config

Subgroup: Basic settings

Nominal RPM 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	100 .. 4000 [RPM]		
Default value	1 500 RPM	Alternative config	YES
Step	1 RPM		
Comm object	9915	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Nominal engine speed (RPM - revolutions per minute).			
<i>Note: This value is used when any other alternate configuration is not active.</i>			

[back to List of setpoints](#)

Nominal Frequency 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	45 .. 65 [Hz]		
Default value	50 Hz	Alternative config	YES
Step	1 Hz		
Comm object	9913	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal system frequency (usually 50 or 60 Hz).			
<i>Note: This value is used when any other alternate configuration is not active.</i>			

[back to List of setpoints](#)

Nominal Voltage Ph-N 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 20000 [V]		
Default value	231 V	Alternative config	YES
Step	1 V		
Comm object	12052	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection Type 1 (page 242).		
Description			
Nominal system voltage (phase to neutral).			
<i>Note: This value is used when any other alternate configuration is not active.</i>			

[back to List of setpoints](#)

Nominal Voltage Ph-Ph 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 40000 [V]		
Default value	400 V	Alternative config	YES
Step	1 V		
Comm object	12055	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection Type 1 (page 242).		
Description			
Nominal system voltage (phase to phase).			
<i>Note: This value is used when any other alternate configuration is not active.</i>			

[back to List of setpoints](#)

Nominal Power 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	12046	Related applications	AMF, MRS,
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal power of the gen-set. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</p>			
<p>Note: This value is used when any other alternate configuration is not active.</p>			

⬅ back to List of setpoints

Nominal Power Split Phase 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	15771	Related applications	AMF, MRS,
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type (page 147)		
Description			
Nominal power of the gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</p>			
<p>Note: This value is used when any other alternate configuration is not active.</p>			

⬅ back to List of setpoints

Nominal Current 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 10 000 [A]		
Default value	350 A	Alternative config	YES
Step	1 A		
Comm object	12049	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
It is current limit for generator current protections and means maximal continuous generator current. Nominal Current can be different from generator rated current value.			
<i>Note: This value is used when any other alternate configuration is not active.</i>			

[back to List of setpoints](#)

Connection Type 1

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Monophase / Splitphase / 3Ph3Wire / High Leg D / 3Ph4Wire / Autodetect [-]		
Default value	3Ph4Wire	Alternative config	YES
Step	[-]		
Comm object	12058	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Generator winding connection system			
Mono Phase	Single phase voltage measurement L1-N 1x CT (Current Transformer)		
Split Phase	Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer)		
3Ph3Wire	Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift No neutral is available 3x CT (Current Transformer)		
High Leg D	High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer)		

3Ph4Wire	Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer)	
Autodetect	High Leg Delta	L1 >=100V; L1 <=140V L2 >=140V L3 >=100V; L3 <=140V
	or	
	3PH3Wire or 3Ph4Wire	L1 >=100V L2 >=100V L3 >=100V
	or	
	Split Phase	L1 >=100V L2 <= 20V L3 >=100V
	or	
	Mono Phase	L1 >=100V L2 <= 20V L3 <= 20V
	or	
Voltage Autodetect shutdown		
Note: This value is used when any other alternate configuration is not active.		

⬅ back to List of setpoints

Nominal RPM 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	100 .. 4000 [RPM]		
Default value	1 500 RPM	Alternative config	YES
Step	1 RPM		
Comm object	9916	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Nominal engine speed (RPM - revolutions per minute).			
Note: This value is used when binary input ALTERNATE CONFIG 2 (PAGE 295) is active.			

⬅ back to List of setpoints

Nominal Frequency 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	45 .. 65 [Hz]		
Default value	50 Hz	Alternative config	YES
Step	1 Hz		
Comm object	9914	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal system frequency (usually 50 or 60 Hz).			
<i>Note: This value is used when binary input ALTERNATE CONFIG 2 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Nominal Voltage Ph-N 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 20000 [V]		
Default value	231 V	Alternative config	YES
Step	1 V		
Comm object	12053	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type 2 (page 246).		
Description			
Nominal system voltage (phase to neutral).			
<i>Note: This value is used when binary input ALTERNATE CONFIG 2 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Nominal Voltage Ph-Ph 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 40000 [V]		
Default value	400 V	Alternative config	YES
Step	1 V		
Comm object	12056	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type 2 (page 246).		
Description			
Nominal system voltage (phase to phase).			
<i>Note: This value is used when binary input ALTERNATE CONFIG 2 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Nominal Power 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	12047	Related applications	AMF, MRS,
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal power of the gen-set. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</p>			
<p>Note: This value is used when binary input ALTERNATE CONFIG 2 (PAGE 295) is active.</p>			

⬅ back to List of setpoints

Nominal Power Split Phase 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	15772	Related applications	AMF, MRS,
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type (page 147)		
Description			
Nominal power of the gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</p>			
<p>Note: This value is used when binary input ALTERNATE CONFIG 2 (PAGE 295) is active.</p>			

⬅ back to List of setpoints

Nominal Current 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 10000 [A]		
Default value	350 A	Alternative config	YES
Step	1 A		
Comm object	12050	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
It is current limit for generator current protections and means maximal continuous generator current. Nominal Current can be different from generator rated current value.			
<i>Note: This value is used when binary input ALTERNATE CONFIG 2 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Connection type 2

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Monophase / Splitphase / 3Ph3Wire / High Leg D / 3Ph4Wire / Autodetect [-]		
Default value	3Ph4Wire	Alternative config	YES
Step	[-]		
Comm object	12059	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		

Description

Generator winding connection system

Mono Phase	Single phase voltage measurement L1-N 1x CT (Current Transformer)
Split Phase	Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer)
3Ph3Wire	Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift No neutral is available 3x CT (Current Transformer)
High Leg D	High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer)

3Ph4Wire	Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer)	
Autodetect	High Leg Delta	L1 >=100V; L1 <=140V L2 >=140V L3 >=100V; L3 <=140V
	or	
	3PH3Wire or 3Ph4Wire	L1 >=100V L2 >=100V L3 >=100V
	or	
	Split Phase	L1 >=100V L2 <= 20V L3 >=100V
	or	
	Mono Phase	L1 >=100V L2 <= 20V L3 <= 20V
	or	
Voltage Autodetect shutdown		

Note: This value is used when binary input **ALTERNATE CONFIG 2 (PAGE 295)** is active.

⬅ back to List of setpoints

Nominal RPM 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	100 .. 4 000 [RPM]		
Default value	1 500 RPM	Alternative config	YES
Step	1 RPM		
Comm object	15196	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Always		
Description			
Nominal engine speed (RPM - revolutions per minute).			
Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.			

⬅ back to List of setpoints

Nominal Frequency 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	45 .. 65 [Hz]		
Default value	50 Hz	Alternative config	YES
Step	1 Hz		
Comm object	15197	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal system frequency (usually 50 or 60 Hz).			
<i>Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Nominal Voltage Ph-N 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 20 000 [V]		
Default value	231 V	Alternative config	YES
Step	1 V		
Comm object	12054	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type 3 (page 250).		
Description			
Nominal system voltage (phase to neutral).			
<i>Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Nominal Voltage Ph-Ph 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	80 .. 40 000 [V]		
Default value	400 V	Alternative config	YES
Step	1 V		
Comm object	12057	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type 3 (page 250).		
Description			
Nominal system voltage (phase to phase).			
<i>Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Nominal Power 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	12048	Related applications	AMF, MRS,
Config level	Standard		
Setpoint visibility	Always		
Description			
Nominal power of the gen-set. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Monophase or Splitphase or 3Ph3Wire or High Leg D or 3Ph4Wire or when Autodetect detects connection type as 3Ph3Wire or High Leg D or 3Ph4Wire.</p>			
<p>Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.</p>			

⬅ back to List of setpoints

Nominal Power Split Phase 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 5 000 [kW]		
Default value	200 kW	Alternative config	Yes
Step	1 kW		
Comm object	15773	Related applications	AMF, MRS,
Config level	Standard		
Setpoint visibility	Conditioned by the setpoint Connection type (page 147)		
Description			
Nominal power of the gen-set for detected split-phase or mono phase connection. Generator Overload BOC (page 192) protection is based on this setpoint.			
<p>Note: This setpoint is used when setpoint Connection type (page 147) is adjusted to Autodetect and Autodetect detects connection type as Monophase or Splitphase.</p>			
<p>Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.</p>			

⬅ back to List of setpoints

Nominal Current 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	1 .. 10 000 [A]		
Default value	350 A	Alternative config	YES
Step	1 A		
Comm object	12051	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
It is current limit for generator current protections and means maximal continuous generator current. Nominal Current can be different from generator rated current value.			
<i>Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.</i>			

[back to List of setpoints](#)

Connection type 3

Setpoint group	Basic settings	Related FW	1.1.0
Range [units]	Monophase / Splitphase / 3Ph3Wire / High Leg D / 3Ph4Wire / Autodetect [-]		
Default value	3Ph4Wire	Alternative config	YES
Step	[-]		
Comm object	12060	Related applications	AMF, MRS
Config level	Standard		
Setpoint visibility	Always		
Description			
Generator winding connection system			
Mono Phase	Single phase voltage measurement L1-N 1x CT (Current Transformer)		
Split Phase	Double Delta connection Split Phase Two phase voltage measurement L1,L2 with 180° phase shift 2x CT (Current Transformer)		
3Ph3Wire	Ungrounded Delta connection Open Delta Ungrounded Wye Corner-Grounded Delta Split Phase Delta Three phase voltage measurement L1,L2,L3 with 120° phase shift No neutral is available 3x CT (Current Transformer)		
High Leg D	High Leg Delta connection Three phase voltage measurement L1,L2,L3 3x CT (Current Transformer)		

3Ph4Wire	Grounded Star (Grounded Wye) connection – 3PY Three phase voltage measurement L1,L2,L3 with 120° phase shift 3x CT (Current Transformer)																								
Autodetect	<table border="0"> <tr> <td data-bbox="435 331 997 414">High Leg Delta</td> <td data-bbox="997 331 1418 414">L1 >=100V; L1 <=140V</td> </tr> <tr> <td data-bbox="435 414 997 459">or</td> <td data-bbox="997 414 1418 459">L2 >=140V</td> </tr> <tr> <td data-bbox="435 459 997 504"></td> <td data-bbox="997 459 1418 504">L3 >=100V; L3 <=140V</td> </tr> <tr> <td data-bbox="435 504 997 593">3PH3Wire or 3Ph4Wire</td> <td data-bbox="997 504 1418 593">L1 >=100V</td> </tr> <tr> <td data-bbox="435 593 997 638">or</td> <td data-bbox="997 593 1418 638">L2 >=100V</td> </tr> <tr> <td data-bbox="435 638 997 683"></td> <td data-bbox="997 638 1418 683">L3 >=100V</td> </tr> <tr> <td data-bbox="435 683 997 772">Split Phase</td> <td data-bbox="997 683 1418 772">L1 >=100V</td> </tr> <tr> <td data-bbox="435 772 997 817">or</td> <td data-bbox="997 772 1418 817">L2 <= 20V</td> </tr> <tr> <td data-bbox="435 817 997 862"></td> <td data-bbox="997 817 1418 862">L3 >=100V</td> </tr> <tr> <td data-bbox="435 862 997 952">Mono Phase</td> <td data-bbox="997 862 1418 952">L1 >=100V</td> </tr> <tr> <td data-bbox="435 952 997 996">or</td> <td data-bbox="997 952 1418 996">L2 <= 20V</td> </tr> <tr> <td data-bbox="435 996 997 1070"></td> <td data-bbox="997 996 1418 1070">L3 <= 20V</td> </tr> </table> <p data-bbox="435 1019 1418 1070">Voltage Autodetect shutdown</p>	High Leg Delta	L1 >=100V; L1 <=140V	or	L2 >=140V		L3 >=100V; L3 <=140V	3PH3Wire or 3Ph4Wire	L1 >=100V	or	L2 >=100V		L3 >=100V	Split Phase	L1 >=100V	or	L2 <= 20V		L3 >=100V	Mono Phase	L1 >=100V	or	L2 <= 20V		L3 <= 20V
High Leg Delta	L1 >=100V; L1 <=140V																								
or	L2 >=140V																								
	L3 >=100V; L3 <=140V																								
3PH3Wire or 3Ph4Wire	L1 >=100V																								
or	L2 >=100V																								
	L3 >=100V																								
Split Phase	L1 >=100V																								
or	L2 <= 20V																								
	L3 >=100V																								
Mono Phase	L1 >=100V																								
or	L2 <= 20V																								
	L3 <= 20V																								
<p>Note: This value is used when binary input ALTERNATE CONFIG 3 (PAGE 295) is active.</p>																									

[⬅ back to List of setpoints](#)

Subgroup: Engine settings

ECU Frequency Select 1

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Primary / Secondary / Default [-]		
Default value	Default	Alternative config	NO
Step	[-]		
Comm object	14335	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		
Description			
<p>This setpoint is used for choosing a frequency of ECU. Values are saved in ECU.</p> <p>VOLVO EMS2 (GE engines)</p> <p>The nominal speed is selected via the VP Status proprietary frame, parameter "Frequency select".</p> <p>SCANIA EMS/S6</p> <p>The nominal speed is selected via parameters "Nominal speed switch 1" and "Nominal speed switch 2" in the DLN1 proprietary frame.</p> <p>Frequency change for Volvo Penta engines with EMS2</p> <p>This description refers to the Volvo Penta Application bulletin 30-0-003. The procedure for changing engine speed on the D9 and D16 engines is different from the D12 engine. There is no system reset on the EMS2 unit; therefore the procedure is changed.</p> <p><u>Procedure if ECU not energized:</u></p> <ol style="list-style-type: none"> 1. Switch the IL controller to MAN Mode. 2. Power up the ECU. 3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter 4. Press the Stop button on the IL controller. <p>Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.</p> <p><u>Procedure with ECU powered on:</u></p> <ol style="list-style-type: none"> 1. Switch the IL controller to MAN Mode. 2. Press the Stop button on the IL controller. 3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter 4. Press the Stop button on the IL controller. <p>Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.</p> <p>Note: This value is used when any other alternate configuration is not active.</p>			

 [back to List of setpoints](#)

ECU Speed Adjustment 1

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 100 [%]		
Default value	50 %	Alternative config	NO
Step	1 %		
Comm object	14337	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		
Description			
<p>Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50%. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands.</p> <p>Note: <i>This value is used when any other alternate configuration is not active.</i></p>			

[◀ back to List of setpoints](#)

ECU Frequency Select 2

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Primary / Secondary / Default [-]		
Default value	Default	Alternative config	NO
Step	[-]		
Comm object	14336	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		

Description

This setpoint is used for choosing a frequency of ECU. Values are saved in ECU.

VOLVO EMS2 (GE engines)

The nominal speed is selected via the VP Status proprietary frame, parameter "Frequency select".

SCANIA EMS/S6

The nominal speed is selected via parameters "Nominal speed switch 1" and "Nominal speed switch 2" in the DLN1 proprietary frame.

Frequency change for Volvo Penta engines with EMS2

This description refers to the Volvo Penta Application bulletin 30-0-003. The procedure for changing engine speed on the D9 and D16 engines is different from the D12 engine. There is no system reset on the EMS2 unit; therefore the procedure is changed.

Procedure if ECU not energized:

1. Switch the IL controller to MAN Mode.
2. Power up the ECU.
3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter
4. Press the Stop button on the IL controller.

Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.

Procedure with ECU powered on:

1. Switch the IL controller to MAN Mode.
2. Press the Stop button on the IL controller.
3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter
4. Press the Stop button on the IL controller.

Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.

Note: This value is used when binary input **ALTERNATE CONFIG 2 (PAGE 295)** is active.

 [back to List of setpoints](#)

ECU Speed Adjustment 2

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 100 [%]		
Default value	50 %	Alternative config	NO
Step	1 %		
Comm object	14338	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		
Description			
Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50%. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands.			
Note: This value is used when binary input <i>ALTERNATE CONFIG 2 (PAGE 295)</i> is active.			

 [back to List of setpoints](#)

ECU Frequency Select 3

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	Primary / Secondary / Default [-]		
Default value	Default	Alternative config	NO
Step	[-]		
Comm object	15198	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		

Description

This setpoint is used for choosing a frequency of ECU. Values are saved in ECU.

VOLVO EMS2 (GE engines)

The nominal speed is selected via the VP Status proprietary frame, parameter "Frequency select".

SCANIA EMS/S6

The nominal speed is selected via parameters "Nominal speed switch 1" and "Nominal speed switch 2" in the DLN1 proprietary frame.

Frequency change for Volvo Penta engines with EMS2

This description refers to the Volvo Penta Application bulletin 30-0-003. The procedure for changing engine speed on the D9 and D16 engines is different from the D12 engine. There is no system reset on the EMS2 unit; therefore the procedure is changed.

Procedure if ECU not energized:

1. Switch the IL controller to MAN Mode.
2. Power up the ECU.
3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter
4. Press the Stop button on the IL controller.

Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.

Procedure with ECU powered on:

1. Switch the IL controller to MAN Mode.
2. Press the Stop button on the IL controller.
3. Change the setpoint ECU FreqSelect and confirm it by pressing Enter
4. Press the Stop button on the IL controller.

Note: The whole procedure (step 2 to 4) must not exceed 10 seconds.

Note: This value is used when binary input **ALTERNATE CONFIG 3 (PAGE 295)** is active.

 [back to List of setpoints](#)

ECU Speed Adjustment 3

Setpoint group	Engine settings	Related FW	1.1.0
Range [units]	0 .. 100 [%]		
Default value	50 %	Alternative config	NO
Step	1 %		
Comm object	15199	Related applications	AMF, MRS
Config level	Advanced		
Setpoint visibility	Visible only if ECU is configured		
Description			
<p>Enables to adjust engine speed in ECU via CAN bus. Nominal speed corresponds to 50%. This setpoint should be used only for Volvo Penta and Scania engines. It has no effect on other engine brands.</p> <p>Note: This value is used when binary input <i>ALTERNATE CONFIG 3 (PAGE 295)</i> is active.</p>			

[back to List of setpoints](#)

8.1.2 Values

What values are:

Values (or quantities) are analog or binary data objects, measured or computed by the controller, that are intended for reading from the controller screen, PC, MODBUS, etc. Values are organized into groups according to their meaning.

Invalid flag

If valid data is not available for a particular value, the invalid flag is set to it. This situation may be due to the following:

- ▶ The value is not being evaluated in the scope of the current application and configuration.
- ▶ Sensor fail has been detected on an analog input.
- ▶ The configured ECU or extension module does not provide the particular value.
- ▶ The communication with the ECU or extension module is interrupted.

A value containing the invalid flag is displayed as “#####” in IntelliConfig and on the controller screen. If such a value is read out via MODBUS, it will contain the data 32768 in the case of signed values and 65535 in the case of unsigned values.

List of values groups

Group: Engine	261
Group: Generator	265
Group: Load	268
Group: Mains	273
Group: Controller I/O	275
Group: Statistics	276
Group: IL Info	279
Group: Log Bout	281
Group: CM-GPRS	284
Group: CM-4G-GPS	286
Group: CM-Ethernet	289
Group: Date/Time	292
Group: Plug-In I/O	292

For full list of setpoints go to the chapter **List of values (page 259)**.

List of values

Engine

DEF Level	261
DPF Ash Load	261
DPF Soot Load	261
ECU-BIN 1	261
ECU-BIN 2	262
ECU-BIN 3	262
ECU-BIN 4	262
ECU-BIN 5	262
ECU-BIN 6	263
ECU-BIN 7	263
ECU-BIN 8	263
ECU-BIN 9	263
ECU-BIN-EXT-1	264
ECU Frequency Select	264
ECU State	264
RPM	265
Speed Request	265
Speed Required RPM	265

Generator

Generator Frequency	265
Generator Voltage L1-L2	266
Generator Voltage L1-N	266
Generator Voltage L2-L3	266
Generator Voltage L2-N	266
Generator Voltage L3-L1	266
Generator Voltage L3-N	267
Nominal Current	267
Nominal Power	267
Nominal Voltage	267

Load

Load A L1	268
Load A L2	268
Load A L3	268
Load Characteristic	268

Load Characteristic L1	269
Load Characteristic L2	269
Load Characteristic L3	269
Load kVA	269
Load kVA L1	270
Load kVA L2	270
Load kVA L3	270
Load kVAr	270
Load kVAr L1	271
Load kVAr L2	271
Load kVAr L3	271
Load kW	271
Load kW L1	272
Load kW L2	272
Load kW L3	272
Load Power Factor	272
Load Power Factor L1	273
Load Power Factor L2	273
Load Power Factor L3	273

Mains

Mains Frequency	273
Mains Voltage L1-L2	273
Mains Voltage L1-N	274
Mains Voltage L2-L3	274
Mains Voltage L2-N	274
Mains Voltage L3-L1	274
Mains Voltage L3-N	274

Controler I/O

Analog Input 1	275
Analog Input 2	275
Analog Input 3	275
Battery Volts	275
Binary Inputs	275
Binary Outputs	276
D+	276

E-STOP	276
--------	-----

Statistics

Genset kVAh	276
Genset kWh	277
Mains kVAh	277
Mains kWh	277
Maintenance 1	277
Maintenance 2	278
Maintenance 3	278
Num E-Stops	278
Num Starts	278
Running Hours	278
Shutdowns	279

IL Info

Application	279
Breaker State	279
Connection Type	279
Engine State	280
FW Branch	280
FW Version	280
ID String	280
Password Decode	280
SPI Module A	281
Timer Text	281
Timer Value	281

Log Bout

Log Bout 1	281
Log Bout 2	282
Log Bout 3	282
Log Bout 4	282
Log Bout 5	282
Log Bout 6	282
Log Bout 7	283
Log Bout 8	283

Log Bout 9	283
Log Bout 10	283
Log Bout 11	283

CM-GPRS ; CM-4G-GPS

Connection Type	284
Cell Diag Code	284
Cell ErrorRate	285
Cell Signal Lev	286
Cell Status	286
Operator	286
Connection Type	286
Cell Diag Code	287
Cell ErrorRate	288
Cell Signal Lev	288
Cell Status	289
Operator	289

CM-Ethernet

Current DNS	289
ETH Interface Status	289
Current Gateway	290
Current IP Address	290
Last Email Result	291
MAC Address	291
Current Subnet Mask	292

Date/Time

Time	292
Date	292

Plug-In I/O

EM BIO A	292
----------------	-----

Group: Engine

DEF Level

Value group	Engine	Related FW	1.1.0
Units	%		
Comm object	14522	Related applications	AMF, MRS
Description			
The level of diesel exhaust fluid tank.			

[back to List of values](#)

DPF Ash Load

Value group	Engine	Related FW	1.1.0
Units	%		
Comm object	12483	Related applications	AMF, MRS
Description			
The rate of ash in DPF (Diesel particulate filter).			

[back to List of values](#)

DPF Soot Load

Value group	Engine	Related FW	1.1.0
Units	%		
Comm object	12484	Related applications	AMF, MRS
Description			
The rate of soot in DPF (Diesel particulate filter).			

[back to List of values](#)

ECU-BIN 1

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10153	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<p>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</p>			

[back to List of values](#)

ECU-BIN 2

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10154	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[▲ back to List of values](#)

ECU-BIN 3

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10155	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[▲ back to List of values](#)

ECU-BIN 4

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10156	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[▲ back to List of values](#)

ECU-BIN 5

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10157	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[▲ back to List of values](#)

ECU-BIN 6

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10158	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[back to List of values](#)

ECU-BIN 7

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10159	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[back to List of values](#)

ECU-BIN 8

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10160	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[back to List of values](#)

ECU-BIN 9

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10161	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<i>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</i>			

[back to List of values](#)

ECU-BIN-EXT-1

Value group	Engine	Related FW	1.1.0
Units	Depends on ECU value		
Comm object	10173	Related applications	AMF, MRS
Description			
This is one of the inputs, which are defined by ECU. Order of values depends on type of ECU.			
<p>Note: Usually there are engine speed[RPM], fuel rate[L/h], coolant temperature[°C], intake temperature [°C], oil pressure[bar], boost pressure[bar], load[%], oil temperature[°C] etc.</p>			

◀ back to List of values

ECU Frequency Select

Value group	Engine	Related FW	1.1.0
Units	-		
Comm object	12926	Related applications	AMF, MRS
Description			
Shows selected frequency of ECU. The value is calculated from setpoint Nominal Frequency (page 150)			
<ul style="list-style-type: none"> ▶ If is Nominal Frequency (page 150) in range from 45 Hz to 54 Hz, is considered as 50 Hz application. The value is set to 0. ▶ If is Nominal Frequency (page 150) in range from 55 Hz to 65 Hz, is considered as 60 Hz application. The value is set to 1. 			

◀ back to List of values

ECU State

Value group	Engine	Related FW	1.1.0
Units	-		
Comm object	10034	Related applications	AMF, MRS
Description			
Shows binary status (0 or 1) of ECU:			
<ul style="list-style-type: none"> ▶ ECU Yellow Lamp ▶ ECU Red Lamp ▶ Wait To Start 			

◀ back to List of values

RPM

Value group	Engine	Related FW	1.1.0
Units	RPM		
Comm object	10123	Related applications	AMF, MRS
Description			
This value contains the current engine speed. The value is obtained from one of the following sources: <ul style="list-style-type: none"> ▶ ECU, if an ECU is configured ▶ Pickup input ▶ Generator frequency 			

[◀ back to List of values](#)

Speed Request

Value group	Engine	Related FW	1.1.0												
Units	%														
Comm object	10137	Related applications	AMF, MRS												
Description															
Engine speed control via CAN bus.															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Speed request</th> <th>Requested speed</th> <th>Accelerator pedal position</th> </tr> </thead> <tbody> <tr> <td>0%</td> <td>1350 RPM</td> <td>0%</td> </tr> <tr> <td>50%</td> <td>1500 RPM</td> <td>50%</td> </tr> <tr> <td>100%</td> <td>1650 RPM</td> <td>100%</td> </tr> </tbody> </table>				Speed request	Requested speed	Accelerator pedal position	0%	1350 RPM	0%	50%	1500 RPM	50%	100%	1650 RPM	100%
Speed request	Requested speed	Accelerator pedal position													
0%	1350 RPM	0%													
50%	1500 RPM	50%													
100%	1650 RPM	100%													

[◀ back to List of values](#)

Speed Required RPM

Value group	Engine	Related FW	1.1.0
Units	RPM		
Comm object	10006	Related applications	AMF, MRS
Description			
Requested engine speed.			

[◀ back to List of values](#)

Group: Generator

Generator Frequency

Value group	Generator	Related FW	1.1.0
Units	Hz		
Comm object	8210	Related applications	AMF, MRS
Description			
Frequency of generator.			

[◀ back to List of values](#)

Generator Voltage L1-L2

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	9628	Related applications	AMF, MRS
Description			
Generator phase to phase voltage between L1 and L2 phases.			

[back to List of values](#)

Generator Voltage L1-N

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	8192	Related applications	AMF, MRS
Description			
Generator voltage on phase 1.			

[back to List of values](#)

Generator Voltage L2-L3

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	9629	Related applications	AMF, MRS
Description			
Generator phase to phase voltage between L2 and L3 phases.			

[back to List of values](#)

Generator Voltage L2-N

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	8193	Related applications	AMF, MRS
Description			
Generator voltage on phase 2.			

[back to List of values](#)

Generator Voltage L3-L1

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	9630	Related applications	AMF, MRS
Description			
Generator phase to phase voltage between L3 and L1 phases.			

[back to List of values](#)

Generator Voltage L3-N

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	8194	Related applications	AMF, MRS
Description			
Generator voltage on phase 3.			

[back to List of values](#)

Nominal Current

Value group	Generator	Related FW	1.1.0
Units	A		
Comm object	9978	Related applications	AMF, MRS
Description			
Generator nominal current.			

[back to List of values](#)

Nominal Power

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	9018	Related applications	AMF, MRS
Description			
Generator nominal power.			

[back to List of values](#)

Nominal Voltage

Value group	Generator	Related FW	1.1.0
Units	V		
Comm object	9917	Related applications	AMF, MRS
Description			
Generator nominal voltage.			

[back to List of values](#)

Group: Load

Load A L1

Value group	Load	Related FW	1.1.0
Units	A		
Comm object	8198	Related applications	AMF, MRS
Description			
Load current phase L1.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

⬅ back to List of values

Load A L2

Value group	Load	Related FW	1.1.0
Units	A		
Comm object	8199	Related applications	AMF, MRS
Description			
Load current phase L2.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

⬅ back to List of values

Load A L3

Value group	Load	Related FW	1.1.0
Units	A		
Comm object	8200	Related applications	AMF, MRS
Description			
Load current phase L3.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

⬅ back to List of values

Load Characteristic

Value group	Load	Related FW	1.1.0
Units	[-]		
Comm object	8395	Related applications	AMF, MRS
Description			
Character of the load. "L" means inductive load, "C" is capacitive and "R" is resistive load (power factor = 1).			

⬅ back to List of values

Load Characteristic L1

Value group	Load	Related FW	1.1.0
Units	[-]		
Comm object	8626	Related applications	AMF, MRS
Description			
Character of the generator load in the L1 phase. “L” means inductive load, “C” is capacitive and “R” is resistive load (power factor = 1).			

[▲ back to List of values](#)

Load Characteristic L2

Value group	Load	Related FW	1.1.0
Units	[-]		
Comm object	8627	Related applications	AMF, MRS
Description			
Character of the generator load in the L2 phase. “L” means inductive load, “C” is capacitive and “R” is resistive load (power factor = 1).			

[▲ back to List of values](#)

Load Characteristic L3

Value group	Load	Related FW	1.1.0
Units	[-]		
Comm object	8628	Related applications	AMF, MRS
Description			
Character of the generator load in the L3 phase. “L” means inductive load, “C” is capacitive and “R” is resistive load (power factor = 1).			

[▲ back to List of values](#)

Load kVA

Value group	Load	Related FW	1.1.0
Units	kVA		
Comm object	8565	Related applications	AMF, MRS
Description			
Load apparent power.			
<p>Note: This value can be also switch into one decimal power format (via IntelliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[▲ back to List of values](#)

Load kVA L1

Value group	Load	Related FW	1.1.0
Units	kVA		
Comm object	8530	Related applications	AMF, MRS
Description			
Load apparent power L1.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kVA L2

Value group	Load	Related FW	1.1.0
Units	kVA		
Comm object	8531	Related applications	AMF, MRS
Description			
Load apparent power L2.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kVA L3

Value group	Load	Related FW	1.1.0
Units	kVA		
Comm object	8532	Related applications	AMF, MRS
Description			
Load apparent power L3.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kVAr

Value group	Load	Related FW	1.1.0
Units	kVAr		
Comm object	8203	Related applications	AMF, MRS
Description			
Load reactive power.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kVAr L1

Value group	Load	Related FW	1.1.0
Units	kVAr		
Comm object	8527	Related applications	AMF, MRS
Description			
Load reactive power in phase L1.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kVAr L2

Value group	Load	Related FW	1.1.0
Units	kVAr		
Comm object	8528	Related applications	AMF, MRS
Description			
Load reactive power in phase L2.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kVAr L3

Value group	Load	Related FW	1.1.0
Units	kVAr		
Comm object	8529	Related applications	AMF, MRS
Description			
Load reactive power in phase L3.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kW

Value group	Load	Related FW	1.1.0
Units	kW		
Comm object	8202	Related applications	AMF, MRS
Description			
Load active power.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kW L1

Value group	Load	Related FW	1.1.0
Units	kW		
Comm object	8524	Related applications	AMF, MRS
Description			
Load active power in phase L1.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kW L2

Value group	Load	Related FW	1.1.0
Units	kW		
Comm object	8525	Related applications	AMF, MRS
Description			
Load active power in phase L2.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load kW L3

Value group	Load	Related FW	1.1.0
Units	kW		
Comm object	8526	Related applications	AMF, MRS
Description			
Load active power in phase L3.			
<p>Note: This value can be also switch into one decimal power format (via InteliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

[back to List of values](#)

Load Power Factor

Load	Load	Related FW	1.1.0
Units	[-]		
Comm object	8204	Related applications	AMF, MRS
Description			
Generator power factor.			

[back to List of values](#)

Load Power Factor L1

Load	Load	Related FW	1.1.0
Units	[-]		
Comm object	8533	Related applications	AMF, MRS
Description			
Generator power factor in phase L1.			

[back to List of values](#)

Load Power Factor L2

Load	Load	Related FW	1.1.0
Units	[-]		
Comm object	8534	Related applications	AMF, MRS
Description			
Generator power factor in phase L2.			

[back to List of values](#)

Load Power Factor L3

Load	Load	Related FW	1.1.0
Units	[-]		
Comm object	8535	Related applications	AMF, MRS
Description			
Generator power factor in phase L3.			

[back to List of values](#)

Group: Mains

Mains Frequency

Value group	Mains	Related FW	1.1.0
Units	Hz		
Comm object	8211	Related applications	AMF
Description			
Frequency of mains.			

[back to List of values](#)

Mains Voltage L1-L2

Value group	Mains	Related FW	1.1.0
Units	V		
Comm object	9631	Related applications	AMF
Description			
Mains phase to phase voltage between L1 and L2 phases.			

[back to List of values](#)

Mains Voltage L1-N

Value group	Mains	Related FW	1.1.0
Units	V		
Comm object	8195	Related applications	AMF
Description			
Mains voltage on phase 1.			

[back to List of values](#)

Mains Voltage L2-L3

Value group	Mains	Related FW	1.1.0
Units	V		
Comm object	9632	Related applications	AMF
Description			
Mains phase to phase voltage between L2 and L3 phases.			

[back to List of values](#)

Mains Voltage L2-N

Value group	Mains	Related FW	1.1.0
Units	V		
Comm object	8196	Related applications	AMF
Description			
Mains voltage on phase 2.			

[back to List of values](#)

Mains Voltage L3-L1

Value group	Mains	Related FW	1.1.0
Units	V		
Comm object	9633	Related applications	AMF
Description			
Mains phase to phase voltage between L3 and L1 phases.			

[back to List of values](#)

Mains Voltage L3-N

Value group	Mains	Related FW	1.1.0
Units	V		
Comm object	8197	Related applications	AMF
Description			
Mains voltage on phase 3.			

[back to List of values](#)

Group: Controller I/O

Analog Input 1

Value group	Controller I/O	Related FW	1.1.0
Units	Configurable		
Comm object	9151	Related applications	AMF, MRS
Description			
This is the value of the analog input 1 of the controller.			

[back to List of values](#)

Analog Input 2

Value group	Controller I/O	Related FW	1.1.0
Units	Configurable		
Comm object	9152	Related applications	AMF, MRS
Description			
This is the value of the analog input 2 of the controller.			

[back to List of values](#)

Analog Input 3

Value group	Controller I/O	Related FW	1.1.0
Units	Configurable		
Comm object	9153	Related applications	AMF, MRS
Description			
This is the value of the analog input 3 of the controller.			

[back to List of values](#)

Battery Volts

Value group	Controller I/O	Related FW	1.1.0
Units	V		
Comm object	8213	Related applications	AMF, MRS
Description			
Controller supply voltage.			

[back to List of values](#)

Binary Inputs

Value group	Controller I/O	Related FW	1.1.0
Units	[-]		
Comm object	8235	Related applications	AMF, MRS
Description			
State of the binary inputs of the controller.			

[back to List of values](#)

Binary Outputs

Value group	Controler I/O	Related FW	1.1.0
Units	[-]		
Comm object	8239	Related applications	AMF, MRS
Description			
State of the binary outputs of the controller.			

⬅ back to List of values

D+

Value group	Controler I/O	Related FW	1.1.0
Units	V		
Comm object	10603	Related applications	AMF, MRS
Description			
D+ terminal voltage.			

⬅ back to List of values

E-STOP

Value group	Controler I/O	Related FW	1.1.0
Units	[-]		
Comm object	15780	Related applications	AMF, MRS
Description			
Shows number of E-STOP input - the same principle of visualization like binary inputs. Principle of value (principle of normally close binary input):			
<ul style="list-style-type: none"> ▶ 1 - E-STOP has voltage - state is OK ▶ 0 - E-STOP has no voltage - protection is active 			

⬅ back to List of values

Group: Statistics

Genset kVArh

Value group	Statistics	Related FW	1.1.0
Units	kVArh		
Comm object	8539	Related applications	AMF, MRS
Description			
Counter of gen-set reactive power.			
<p>Note: This value can be also switch into one decimal power format (via IntelliConfig PC tool). In this case the range of value is decrease 10 times.</p>			

⬅ back to List of values

Genset kWh

Value group	Statistics	Related FW	1.1.0
Units	kWh		
Comm object	8205	Related applications	AMF, MRS
Description			
Counter of gen-set active power.			
<i>Note: This value can be also switch into one decimal power format (via IntelliConfig PC tool). In this case the range of value is decrease 10 times.</i>			

[back to List of values](#)

Mains kVArh

Value group	Statistics	Related FW	1.1.0
Units	kVArh		
Comm object	11026	Related applications	AMF
Description			
Counter of mains reactive power.			
<i>Note: This value can be also switch into one decimal power format (via IntelliConfig PC tool). In this case the range of value is decrease 10 times.</i>			

[back to List of values](#)

Mains kWh

Value group	Statistics	Related FW	1.1.0
Units	kWh		
Comm object	11025	Related applications	AMF
Description			
Counter of mains active power.			
<i>Note: This value can be also switch into one decimal power format (via IntelliConfig PC tool). In this case the range of value is decrease 10 times.</i>			

[back to List of values](#)

Maintenance 1

Value group	Statistics	Related FW	1.1.0
Units	hours		
Comm object	11616	Related applications	AMF, MRS
Description			
Countdown until next maintenance 1. Initial value can be set in Maintenance Timer 1 (page 187).			

[back to List of values](#)

Maintenance 2

Value group	Statistics	Related FW	1.1.0
Units	hours		
Comm object	11617	Related applications	AMF, MRS
Description			
Countdown until next maintenance 2. Initial value can be set in Maintenance Timer 2 (page 187) .			

[back to List of values](#)

Maintenance 3

Value group	Statistics	Related FW	1.1.0
Units	hours		
Comm object	11618	Related applications	AMF, MRS
Description			
Countdown until next maintenance 3. Initial value can be set in Maintenance Timer 3 (page 188) .			

[back to List of values](#)

Num E-Stops

Value group	Statistics	Related FW	1.1.0
Units	[-]		
Comm object	11195	Related applications	AMF, MRS
Description			
Emergency stop alarms counter.			

[back to List of values](#)

Num Starts

Value group	Statistics	Related FW	1.1.0
Units	[-]		
Comm object	8207	Related applications	AMF, MRS
Description			
Engine start commands counter. The counter is increased by 1 even if the particular start command will take more than one attempt.			

[back to List of values](#)

Running Hours

Value group	Statistics	Related FW	1.1.0
Units	hours		
Comm object	8206	Related applications	AMF, MRS
Description			
Engine operation hours counter. The engine hours are incremented in the controller while the engine is running.			

[back to List of values](#)

Shutdowns

Value group	Statistics	Related FW	1.1.0
Units	[-]		
Comm object	11196	Related applications	AMF, MRS
Description			
Shutdown alarms counter. This counter counts all occurrences of a shutdown alarm, not only real shutdowns of the gen-set, i.e. the counter is increased by 2 if two shutdown alarms appear simultaneously.			

[▲ back to List of values](#)

Group: IL Info

Application

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	8480	Related applications	AMF, MRS
Description			
The value contains actual application in controller.			

[▲ back to List of values](#)

Breaker State

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	9245	Related applications	AMF, MRS
Description			
The value contains actual "breaker state" message which is shown on the main screen of the controller.			

[▲ back to List of values](#)

Connection Type

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	12944	Related applications	AMF, MRS
Description			
The text of this value represents the connection type which is adjusted in setpoint Connection type (page 147).			

[▲ back to List of values](#)

Engine State

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	9244	Related applications	AMF, MRS
Description			
The value contains actual "engine state" message which is shown on the main screen of the controller.			

[back to List of values](#)

FW Branch

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	8707	Related applications	AMF, MRS
Description			
The value contains actual branch of firmware in controller.			

[back to List of values](#)

FW Version

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	24339	Related applications	AMF, MRS
Description			
Major and minor firmware version number.			

[back to List of values](#)

ID String

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	24501	Related applications	AMF, MRS
Description			
Name of controller which is used in IntelliConfig in command bar.			

[back to List of values](#)

Password Decode

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	24202	Related applications	AMF, MRS
Description			
This value contains a number which can be used for retrieving a lost password. Send this number together with the controller serial number to your distributor if you have lost your password.			

[back to List of values](#)

SPI Module A

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	14447	Related applications	AMF, MRS
Description			
The name of plug-in module which is inserted in slot A.			

[back to List of values](#)

Timer Text

Value group	IL Info	Related FW	1.1.0
Units	[-]		
Comm object	10040	Related applications	AMF, MRS
Description			
The value contains the numeric code of the "Current process timer" text which is shown on the main screen of the controller.			
The assignment of texts to the codes can be obtained using InteliConfig. Open any connection (also offline with a previously saved archive) and go to the Tools ribbon -> Generate CFG image (all). The resulting file will contain the assignment of texts to the codes.			

[back to List of values](#)

Timer Value

Value group	IL Info	Related FW	1.1.0
Units	[HH:MM:SS]		
Comm object	14147	Related applications	AMF, MRS
Description			
The value contains the "Current process timer" value which is shown on the main screen of the controller.			

[back to List of values](#)

Group: Log Bout

Log Bout 1

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9143	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 2

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9144	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 3

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9145	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 4

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9146	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 5

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9147	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 6

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9148	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 7

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9149	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 8

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	9150	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 9

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	11896	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 10

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	11897	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Log Bout 11

Value group	Log Bout	Related FW	1.1.0
Units	[-]		
Comm object	11898	Related applications	AMF, MRS
Description			
State of binary outputs.			

[back to List of values](#)

Group: CM-GPRS

Connection Type

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24146	Related applications	AMF, MRS
Description			
The type of data connection.			

⬅ back to List of values

Cell Diag Code

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24288	Related applications	AMF, MRS
Description			
Diagnostic code for the CM-GPRS or CM-4G-GPS module.			

GSM Diag Code – Common list of diagnostic codes for cellular modules

Code	Description
0	OK. No error.
1	Not possible to hang up.
2	Modul is switched off
3	Module is switched on
4	Module – error in initialization
5	Module – not possible to set the APN
6	Module – not possible to connect to GPRS network
7	Module – not possible to retrieve IP address
8	Module – not accepted DNS IP address
9	Error in modem detection
10	Error in initialization of analog modem
11	SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking
12	No GSM signal
13	Not possible to read the SIM card parameters
14	GSM modem did not accepted particular initialization command, possibly caused by locked SIM card
15	Unknown modem
16	Bad answer to complement initialization string
17	Not possible to read GSM signal strength

18	CDMA modem not detected
19	No CDMA network
20	Unsuccessful registration to CDMA network
21	SIMCom/ME909s: can't read FW version
22	SIMCom: GSM signal not found
23	SIMCom: can't detect module speed
24	SIMCom: HW reset issued
25	PUK is required
26	Error of SIM card detected
27	ME909s: can't set module bps
28	ME909s: can't set link configuration
29	ME909s: can't do power-off
30	ME909s: can't do power-on
31	ME909s: can't do hardware reset
32	ME909s: ME909s not started
33	ME909s: switch off issued
34	ME909s: switch on issued
35	ME909s: HW reset issued
36	ME909s: can't switch echo off
37	ME909s: can't find out state of registration
38	ME909s: GSM signal not found
39	ME909s: no SIM memory for SMS
40	ME909s: waiting for registration
41	Can't read operator name
42	ME909s: can't set flow control
43	APN not typed
255	Only running communication is needed to indicate

[▲ back to List of values](#)

Cell ErrorRate

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	%		
Comm object	24300	Related applications	AMF, MRS
Description			
This value contains information about relative quality of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. The lower value means higher quality of signal.			

[▲ back to List of values](#)

Cell Signal Lev

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	%		
Comm object	24302	Related applications	AMF, MRS
Description			
This value contains information about relative strength of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. It is a relative value helping to find the best signal and for troubleshooting cases.			

[back to List of values](#)

Cell Status

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24290	Related applications	AMF, MRS
Description			
The text of this value represents the status of the GSM modem.			

[back to List of values](#)

Operator

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24147	Related applications	AMF, MRS
Description			
The name of operator which to SIM card is connected.			
<i>Note: If roaming service is used then prefix "R" is added before the name of operator.</i>			

[back to List of values](#)

Group: CM-4G-GPS

Connection Type

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24146	Related applications	AMF, MRS
Description			
The type of data connection.			

[back to List of values](#)

Cell Diag Code

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24288	Related applications	AMF, MRS

Description

Diagnostic code for the CM-GPRS or CM-4G-GPS module.

GSM Diag Code – Common list of diagnostic codes for cellular modules

Code	Description
0	OK. No error.
1	Not possible to hang up.
2	Modul is switched off
3	Module is switched on
4	Module – error in initialization
5	Module – not possible to set the APN
6	Module – not possible to connect to GPRS network
7	Module – not possible to retrieve IP address
8	Module – not accepted DNS IP address
9	Error in modem detection
10	Error in initialization of analog modem
11	SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking
12	No GSM signal
13	Not possible to read the SIM card parameters
14	GSM modem did not accepted particular initialization command, possibly caused by locked SIM card
15	Unknown modem
16	Bad answer to complement initialization string
17	Not possible to read GSM signal strength
18	CDMA modem not detected
19	No CDMA network
20	Unsuccessful registration to CDMA network
21	SIMCom/ME909s: can't read FW version
22	SIMCom: GSM signal not found
23	SIMCom: can't detect module speed
24	SIMCom: HW reset issued
25	PUK is required
26	Error of SIM card detected

27	ME909s: can't set module bps
28	ME909s: can't set link configuration
29	ME909s: can't do power-off
30	ME909s: can't do power-on
31	ME909s: can't do hardware reset
32	ME909s: ME909s not started
33	ME909s: switch off issued
34	ME909s: switch on issued
35	ME909s: HW reset issued
36	ME909s: can't switch echo off
37	ME909s: can't find out state of registration
38	ME909s: GSM signal not found
39	ME909s: no SIM memory for SMS
40	ME909s: waiting for registration
41	Can't read operator name
42	ME909s: can't set flow control
43	APN not typed
255	Only running communication is needed to indicate

[back to List of values](#)

Cell ErrorRate

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	%		
Comm object	24300	Related applications	AMF, MRS
Description			
This value contains information about relative quality of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. The lower value means higher quality of signal.			

[back to List of values](#)

Cell Signal Lev

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	%		
Comm object	24302	Related applications	AMF, MRS
Description			
This value contains information about relative strength of the cellular signal received by the CM-GPRS module or by CM-4G-GPS module. It is a relative value helping to find the best signal and for troubleshooting cases.			

[back to List of values](#)

Cell Status

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24290	Related applications	AMF, MRS
Description			
The text of this value represents the status of the GSM modem.			

[back to List of values](#)

Operator

Value group	CM-GPRS; CM-4G-GPS (4G part)	Related FW	1.1.0
Units	[-]		
Comm object	24147	Related applications	AMF, MRS
Description			
The name of operator which to SIM card is connected.			
<i>Note: If roaming service is used then prefix "R" is added before the name of operator.</i>			

[back to List of values](#)

Group: CM-Ethernet

Current DNS

Value group	CM-Ethernet	Related FW	1.1.0
Units	[-]		
Comm object	24181	Related applications	AMF, MRS
Description			
Current domain name server.			

[back to List of values](#)

ETH Interface Status

Value group	CM-Ethernet	Related FW	1.1.0
Units	[-]		
Comm object	24180	Related applications	AMF, MRS
Description			
Current status of ethernet communication.			

[back to List of values](#)

Current Gateway

Value group	CM-Ethernet	Related FW	1.1.0
Units	[-]		
Comm object	24182	Related applications	AMF, MRS
Description			
Current gateway address.			

[◀ back to List of values](#)

Current IP Address

Value group	CM-Ethernet	Related FW	1.1.0
Units	[-]		
Comm object	24184	Related applications	AMF, MRS
Description			
Current IP address of the controller.			

[◀ back to List of values](#)

Last Email Result

Value group	CM-Ethernet	Related FW	1.1.0																																						
Units	[-]																																								
Comm object	24332	Related applications	AMF, MRS																																						
Description																																									
Result of last email, which was sent by controller.																																									
<table border="1"> <thead> <tr> <th>Code</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Email was successfully sent.</td> </tr> <tr> <td>2</td> <td>It is not possible to establish connection with SMTP server.</td> </tr> <tr> <td>3</td> <td>SMTP server is not ready for communication.</td> </tr> <tr> <td>8</td> <td>HELO command was refused.</td> </tr> <tr> <td>9</td> <td>EHLO command was refused.</td> </tr> <tr> <td>11</td> <td>AUTH LOGIN command was refused.</td> </tr> <tr> <td>12</td> <td>Wrong user name.</td> </tr> <tr> <td>13</td> <td>Wrong password.</td> </tr> <tr> <td>14</td> <td>MAIL FROM command was refused.</td> </tr> <tr> <td>15</td> <td>RCPT TO command was refused.</td> </tr> <tr> <td>16</td> <td>DATA command was refused.</td> </tr> <tr> <td>17</td> <td>Sending of email failed.</td> </tr> <tr> <td>20</td> <td>QUIT command was refused.</td> </tr> <tr> <td>25</td> <td>It is impossible to create data for command DATA.</td> </tr> <tr> <td>26</td> <td>It is impossible to read data for command DATA.</td> </tr> <tr> <td>27</td> <td>Email address can't be read.</td> </tr> <tr> <td>30</td> <td>SMTP server address translation error (from DNS server).</td> </tr> <tr> <td>31</td> <td>Error reading email content data (24327).</td> </tr> </tbody> </table>				Code	Description	0	Email was successfully sent.	2	It is not possible to establish connection with SMTP server.	3	SMTP server is not ready for communication.	8	HELO command was refused.	9	EHLO command was refused.	11	AUTH LOGIN command was refused.	12	Wrong user name.	13	Wrong password.	14	MAIL FROM command was refused.	15	RCPT TO command was refused.	16	DATA command was refused.	17	Sending of email failed.	20	QUIT command was refused.	25	It is impossible to create data for command DATA.	26	It is impossible to read data for command DATA.	27	Email address can't be read.	30	SMTP server address translation error (from DNS server).	31	Error reading email content data (24327).
Code	Description																																								
0	Email was successfully sent.																																								
2	It is not possible to establish connection with SMTP server.																																								
3	SMTP server is not ready for communication.																																								
8	HELO command was refused.																																								
9	EHLO command was refused.																																								
11	AUTH LOGIN command was refused.																																								
12	Wrong user name.																																								
13	Wrong password.																																								
14	MAIL FROM command was refused.																																								
15	RCPT TO command was refused.																																								
16	DATA command was refused.																																								
17	Sending of email failed.																																								
20	QUIT command was refused.																																								
25	It is impossible to create data for command DATA.																																								
26	It is impossible to read data for command DATA.																																								
27	Email address can't be read.																																								
30	SMTP server address translation error (from DNS server).																																								
31	Error reading email content data (24327).																																								

[▲ back to List of values](#)

MAC Address

Value group	CM-Ethernet	Related FW	1.1.0
Units	[-]		
Comm object	24333	Related applications	AMF, MRS
Description			
Current MAC address of the controller ethernet interface.			

[▲ back to List of values](#)

Current Subnet Mask

Value group	CM-Ethernet	Related FW	1.1.0
Units	[-]		
Comm object	24183	Related applications	AMF, MRS
Description			
Current subnet mask.			

[◀ back to List of values](#)

Group: Date/Time

Time

Value group	Date/Time	Related FW	1.1.0
Units	HH:MM:SS		
Comm object	24554	Related applications	AMF, MRS
Description			
Shows setup time.			

[◀ back to List of values](#)

Date

Value group	Date/Time	Related FW	1.1.0
Units	DD.MM.YYYY		
Comm object	24553	Related applications	AMF, MRS
Description			
Shows setup date.			

[◀ back to List of values](#)

Group: Plug-In I/O

EM BIO A

Value group	Plug-In I/O	Related FW	1.1.0
Units	[-]		
Comm object	14291	Related applications	AMF, MRS
Description			
Binary inputs from extension module in slot A.			

[◀ back to List of values](#)

8.1.3 Logical binary inputs

What Logical binary inputs are:

Logical binary inputs are inputs for binary values and functions.

Alphabetical groups of Logical binary inputs

LBI: A	295
LBI: B	296
LBI: C	303
LBI: D	304
LBI: E	305
LBI: F	305
LBI: G	307
LBI: H	308
LBI: M	308
LBI: N	310
LBI: R	310
LBI: S	313

For full list of Logical binary inputs go to the chapter **Logical binary inputs alphabetically (page 294)**.

Logical binary inputs alphabetically

Alternate Config 2	295	Rem TEST On Load	312
Alternate Config 3	295	Remote TEST	313
AMF Function	295	Sd Override	313
AMF Start Block	295		
BIN Protection 1	296		
BIN Protection 02	296		
BIN Protection 03	297		
BIN Protection 04	297		
BIN Protection 05	298		
BIN Protection 06	298		
BIN Protection 07	299		
BIN Protection 08	299		
BIN Protection 09	300		
BIN Protection 10	300		
BIN Protection 11	301		
BIN Protection 12	301		
BIN Protection 13	302		
BIN Protection 14	302		
BIN Protection 15	303		
BIN Protection 16	303		
Choke Inhibit	303		
Dark Mode	304		
Emergency Stop	305		
Fault Reset Button	305		
Force Regeneration	305		
Fuel Pump On/Off	306		
GCB Feedback	307		
Horn Reset Button	308		
Mains Fail Block	308		
MCB Feedback	309		
Not Used	310		
Protection Enable	310		
Regeneration Inhibit	310		
Remote AUTO	310		
Remote MAN	311		
Remote OFF	311		
Remote Start/Stop	312		

LBI: A

Alternate Config 2

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	859		
Description			
This binary input can switch between configuration sets. When this binary input is active, setpoints in Alternate Config group are switched to the second set (setpoints with number 2).			

◀ back to Logical binary inputs alphabetically

Alternate Config 3

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	860		
Description			
This binary input can switch between configuration sets. When this binary input is active, setpoints in Alternate Config group are switched to the third set (setpoints with number 3).			

◀ back to Logical binary inputs alphabetically

AMF Function

Related FW	1.1.0	Related applications	AMF
Comm object	692		
Description			
This binary input can switch controller function between AMF and MRS.			
<p>Note: Binary input "AMF function" has higher priority than the setpoint <i>Operation Mode (page 154)</i> in <i>Basic settings</i>.</p>			

◀ back to Logical binary inputs alphabetically

AMF Start Block

Related FW	1.1.0	Related applications	AMF
Comm object	211		
Description			
This binary input can allow or block the AMF start. In case of running gen-set in AUTO mode gen-set goes to cooling procedure and stops.			

◀ back to Logical binary inputs alphabetically

LBI: B

BIN Protection 1

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9999		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wm	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 02

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9998		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wm	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 03

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9997		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 04

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9996		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 05

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9995		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 06

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9994		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 07

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9993		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 08

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9992		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 09

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9991		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 10

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9990		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 11

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9989		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 12

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9988		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 13

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9987		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 14

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9986		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 15

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9985		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		

[◀ back to Logical binary inputs alphabetically](#)

BIN Protection 16

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9984		
Description			
This binary input is for general input function used as alarm.			
Protection types			
Monitoring	Binary input is not used for protection or any other function. Signal is only monitored.		
HistRecOnl	Binary input is not used for protection. Only history record is made if binary input is active.		
AL Indic	Binary input is not used for protection. Only alarmlist record is made if binary input is active.		
Wrn	Binary input is used for warning protection only.		
BOC	Binary input is used for BOC (Breaker Open and Cooling) protection.		
Sd	Binary input is used for shutdown protection.		


[◀ back to Logical binary inputs alphabetically](#)

LBI: C

Choke Inhibit

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	946		
Description			

Logical binary input CHOKE INHIBIT prevent Choke functionality when logical binary output CHOKE (PAGE 322) is activated. If CHOKE INHIBIT is activated when CHOKE LBO is active, CHOKE LBO is deactivated immediately and vice versa if LBI CHOKE INHIBIT is deactivated and LBO CHOKE should be active then is activated.



⬅ back to Logical binary inputs alphabetically

LBI: D

Dark Mode

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	930		
Description			
This binary input activates function of dark mode. It means that backlight of display is turn of (information on controller screens are not affected) and LEDs (Mains, Generator, Load, Breakers, etc.) are turn off (LEDs don't react on normal condition of their activation and deactivation).			
<i>Note: After deactivation of dark mode, backlight of display is turned on and than behaves normally.</i>			
<i>Note: After deactivation of dark mode, Front Face status LEDs are turned on due to current situation of gen-set.</i>			

⬅ back to Logical binary inputs alphabetically

LBI: E


Emergency Stop

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	40		
Description			
The shutdown procedure will start immediately when this input is activated. Input is inverted (NC = normally closed) in default configuration.			
<p>Note: <i>In case of controller hardware or software fail, safe stop of the engine doesn't have to be ensured. To back-up the Emergency Stop function it is recommended to connect separate circuit for disconnection of Fuel Solenoid and Starter signals.</i></p>			
For more detail see chapter recommended wiring.			

⬅ back to Logical binary inputs alphabetically

LBI: F

Fault Reset Button

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	191		
Description			
Binary input has the same function as Fault Reset button  on the IntelliLite 9 front panel.			

⬅ back to Logical binary inputs alphabetically

Force Regeneration

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	680		
Description			
When this binary input is activated, the controller send request for force regeneration of DPF (diesel particulate filter) to ECU.			
<p>Note: <i>ECU with Tier IV support is required for proper functionality.</i></p>			

⬅ back to Logical binary inputs alphabetically

Fuel Pump On/Off

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	694		
Description			
This binary input is used for manual control of binary output FUEL PUMP (PAGE 327) .			
<i>Note: This binary input is basically designed for ON and OFF switch (switch with arrestment in these positions) because controller reacts to rising and falling edge of signal in this input.</i>			
IMPORTANT: When binary input FUEL PUMP ON/OFF (PAGE 306) is configured then binary output FUEL PUMP (PAGE 327) is control by this binary input. Setpoints Fuel Pump On (page 164) and Fuel Pump Off (page 163) are not evaluated!			

◀ back to Logical binary inputs alphabetically

LBI: G

GCB Feedback

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	63		

Description

Use this input for indication whether the generator circuit breaker is open or closed.




Image 8.18 GCB Feedback 1





Image 8.19 GCB Feedback 2

Note: *InteliLite 9 controller can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.*

 **back to Logical binary inputs alphabetically**

LBI: H

Horn Reset Button

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	192		
Description			
Binary input has the same function as Horn reset  button on the IntelliLite 9 front panel.			

🔍 back to Logical binary inputs alphabetically

LBI: M

Mains Fail Block

Related FW	1.1.0	Related applications	AMF
Comm object	622		
Description			
If the input is closed, the automatic start of the gen-set at Mains failure is blocked. In case of running gen-set in AUTO mode, timer Mains Return Delay (page 200) is started and when it elapses GCB is opened, gen-set goes to cooling procedure and stops. When GCB is opened after Transfer Delay (page 201) the MCB is closed.			
Note: <i>This input simulates healthy Mains.</i>			

🔍 back to Logical binary inputs alphabetically

MCB Feedback

Related FW	1.1.0	Related applications	AMF
Comm object	65		

Description

Use this input for indication whether the mains circuit breaker is open or closed.




Image 8.20 MCB Feedback 1




Image 8.21 MCB Feedback 2

Note: IntelliLite 9 controller can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.

[back to Logical binary inputs alphabetically](#)

LBI: N

Not Used

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	184		
Description			
Binary input has no function. Use this configuration when binary input is not used.			

[◀ back to Logical binary inputs alphabetically](#)

LBI: P

Protection Enable

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	920		
Description			
This logic binary input enables or disables protections adjusted as LBI Enable.			

[◀ back to Logical binary inputs alphabetically](#)

LBI: R

Regeneration Inhibit

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	679		
Description			
When this binary input is activated, the controller sends request to inhibit regeneration of DPF (diesel particulate filter) to ECU.			
<i>Note: ECU with Tier IV support is required for proper functionality.</i>			

[◀ back to Logical binary inputs alphabetically](#)

Remote AUTO

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	620		
Description			
The controller is switched to the AUTO mode (there are four modes OFF / MAN / AUTO / TEST) when this binary input is closed. When opens controller is switched back to previous mode.			
This binary input has the lowest priority from Remote OFF / MAN / AUTO / TEST binary inputs			
Remote control priority:			
▶ Remote OFF (Highest priority)			
▶ Remote TEST			
▶ Remote MAN			
▶ Remote AUTO (Lowest Priority)			

[◀ back to Logical binary inputs alphabetically](#)

Remote MAN

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	618		
Description			
<p>The controller is switched to the MAN mode (there are four modes OFF / MAN / AUTO / TEST) when this binary input is closed. When opens controller is switched back to previous mode.</p> <p>Remote control priority:</p> <ul style="list-style-type: none"> ▶ Remote OFF (Highest priority) ▶ Remote TEST ▶ Remote MAN ▶ Remote AUTO (Lowest Priority) 			

[◀ back to Logical binary inputs alphabetically](#)

Remote OFF

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	617		
Description			
<p>The controller is switched to the OFF mode (there are four modes OFF / MAN / AUTO / TEST) when this binary input is closed. When opens controller is switched back to previous mode.</p> <p>Remote control priority:</p> <ul style="list-style-type: none"> ▶ Remote OFF (Highest priority) ▶ Remote TEST ▶ Remote MAN ▶ Remote AUTO (Lowest Priority) 			

[◀ back to Logical binary inputs alphabetically](#)

Remote Start/Stop

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	38		
Description			
Use this input to start and stop the gen-set in AUTO mode.			
<p>Note: If the binary input Remote Start/Stop is active and engine is running and mains failure occurs, the MCB breaker opens, after Transfer Delay (page 201) the GCB breaker is closed. Once the mains is OK, the Mains Return Delay (page 200) elapses and the GCB breaker is opened. Then after Transfer Delay (page 201) is MCB breaker closed. Gen-set remains running as long as binary input Rem Start/Stop is active. For more details see timing diagram below.</p>			
<p>The diagram illustrates the timing sequence for a Remote Start/Stop event. It shows the states of GCB (Generator Circuit Breaker) and MCB (Mains Circuit Breaker) breakers, the Remote Start/Stop input, and the status of the engine and mains. Key delays shown are Transfer Delay and Mains Return Delay.</p>			
Image 8.22 Remote Start/Stop			

⬅ back to Logical binary inputs alphabetically

Rem TEST On Load

Related FW	1.1.0	Related applications	AMF
Comm object	61		
Description			
When input is closed, the controller automatically transfers load from the mains to the gen-set. Load is automatically transferred back to the mains when any gen-set shut down protection activates.			

⬅ back to Logical binary inputs alphabetically

Remote TEST

Related FW	1.1.0	Related applications	AMF
Comm object	621		
Description			
<p>The controller is switched to the TEST mode (there are four modes OFF / MAN / AUTO / TEST) when this binary input is closed. When opens controller is switched back to previous mode.</p> <p>Remote control priority:</p> <ul style="list-style-type: none"> ▶ Remote OFF (Highest priority) ▶ Remote TEST ▶ Remote MAN ▶ Remote AUTO (Lowest Priority) 			

◀ back to Logical binary inputs alphabetically

LBI: S

Sd Override

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	44		
Description			
<p>If this input is active, all alarms except Emergency Stop and Overspeed are suppressed. The suppressed alarms will be displayed in the alarm list, but they will not take effect regarding the gen-set control.</p> <p>Note: <i>Sd Override (page 313)</i> is indicated in the alarm list if Sd Override mode is active to inform the operator that the engine is not protected.</p> <p>IMPORTANT: MISUSE OF THIS INPUT CAN CAUSE DAMAGE TO THE GEN-SET!</p>			

◀ back to Logical binary inputs alphabetically

8.1.4 Logical binary outputs

What Logical binary outputs are:

Logical binary outputs are outputs for binary values and functions.

Alphabetical groups of Logical binary outputs

LBO: A	316
LBO: C	322
LBO: E	323
LBO: F	325
LBO: G	327
LBO: H	334
LBO: I	335
LBO: M	335
LBO: N	340
LBO: P	341
LBO: R	343
LBO: S	344

For full list of Logical binary outputs go to the chapter **Logical binary outputs alphabetically (page 315)**.

Logical binary outputs alphabetically

AL AIN 1 Sd+BOC	316	ECU Yellow Lamp	325
AL AIN 1 Wrm	316	Exercise Timer 1	325
AL AIN 2 Sd+BOC	316	Fault Reset	325
AL AIN 2 Wrm	316	Frequency Select	325
AL AIN 3 Sd+BOC	316	Fuel Solenoid	326
AL AIN 3 Wrm	317	Fuel Pump	327
AL Battery Flat	317	GCB Close/Open	327
AL Battery Overvoltage ..	317	GCB OFF Coil	329
AL Battery Undervoltage .	317	GCB ON Coil	330
AL Battery Voltage	317	GCB UV Coil	330
AL Common BOC	318	Generator Healthy	332
AL Common Fls	318	Glow Plugs	332
AL Common Sd	318	HEST Lamp	334
AL Common Wrm	318	Horn	334
AL CoolantTemp Low	319	Idle/Nominal	335
AL CoolantTemp Sd	319	Mains Healthy	335
AL CoolantTemp Wrm	319	MCB Close/Open	335
AL D+ Fail	319	MCB OFF Coil	337
AL Fuel Level Sd	319	MCB ON Coil	338
AL Fuel Level Wrm	320	MCB UV Coil	339
AL Mains Fail	320	Mode AUTO	340
AL Maintenance 1	320	Mode MAN	340
AL Maintenance 2	320	Mode OFF	340
AL Maintenance 3	320	Mode TEST	340
AL Oil Press Sd	321	Not In AUTO	340
AL Oil Press Wrm	321	Not Used	341
AL Overcurrent	321	Prestart	341
AL Overspeed	321	Ready To AMF	343
AL Underspeed	321	Ready To Load	343
Alarm	322	Ready	343
Cooling Pump	322	RegenerationNeeded	344
Choke	322	Starter	344
ECU Communic Error	323	Stop Pulse	345
ECU Communic OK	323	Stop Solenoid	345
ECU Power Relay	324	Ventilation	346
ECU Red Lamp	324	Ventilation On Pulse	346
ECU Run Stop	325	Ventilation Off Pulse	347

LBO: A

AL AIN 1 Sd+BOC

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1386		
Description			
The output is closed when there is the shutdown or BOC alarm from the analog input 1 of the controller present in the alarmlist or isn't confirmed.			

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 1 Wrn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1382		
Description			
The output is closed when there is the warning alarm from the analog input 1 of the controller present in the alarmlist or isn't confirmed.			

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 2 Sd+BOC

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1387		
Description			
The output is closed when there is the shutdown or BOC alarm from the analog input 2 of the controller present in the alarmlist or isn't confirmed.			

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 2 Wrn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1383		
Description			
The output is closed when there is the warning alarm from the analog input 2 of the controller present in the alarmlist or isn't confirmed.			

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 3 Sd+BOC

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1388		
Description			
The output is closed when there is the shutdown or BOC alarm from the analog input 3 of the controller present in the alarmlist or isn't confirmed.			

[◀ back to Logical binary outputs alphabetically](#)

AL AIN 3 Wrn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1384		
Description			
The output is closed when there is the warning alarm from the analog input 3 of the controller present in the alarmlist or isn't confirmed.			

[◀ back to Logical binary outputs alphabetically](#)

AL Battery Flat

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1292		
Description			
This output is active when the Sd Battery Flat (page 374) or Wrn Battery < Voltage (page 359) alarm is present in the alarmlist or isn't confirm.			

[◀ back to Logical binary outputs alphabetically](#)

AL Battery Overvoltage

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1995		
Description			
This output is active when the Wrn Battery > Voltage (page 359) alarm is present in the alarmlist or isn't confirm.			

[◀ back to Logical binary outputs alphabetically](#)

AL Battery Undervoltage

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1994		
Description			
This output is active when the Wrn Battery < Voltage (page 359) alarm is present in the alarmlist or isn't confirm.			


[◀ back to Logical binary outputs alphabetically](#)

AL Battery Voltage

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1293		
Description			
This output is active when the Wrn Battery > Voltage (page 359) or Wrn Battery < Voltage (page 359) alarm is present in the alarmlist or isn't confirm.			


[◀ back to Logical binary outputs alphabetically](#)

AL Common BOC

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9		
Description			
Output closes when any BOC alarm appears.			
The output opens, if:			
<ul style="list-style-type: none"> ▶ No BOC alarm is active and ▶ Fault reset  button is pressed 			


[◀ back to Logical binary outputs alphabetically](#)

AL Common FIs

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	6		
Description			
Output closes when any sensor fail alarm appears.			
The output opens, if:			
<ul style="list-style-type: none"> ▶ No sensor fail alarm is active and ▶ Fault reset  button is pressed 			


[◀ back to Logical binary outputs alphabetically](#)

AL Common Sd

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	4		
Description			
Output closes when any shutdown alarm appears.			
The output opens, if:			
<ul style="list-style-type: none"> ▶ No shutdown alarm is active and ▶ Fault reset  button is pressed 			

[◀ back to Logical binary outputs alphabetically](#)

AL Common Wrn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	3		
Description			
Output closes when any warning alarm appears.			
The output opens, if:			
<ul style="list-style-type: none"> ▶ No warning alarm is active and ▶ Fault reset  button is pressed 			

[◀ back to Logical binary outputs alphabetically](#)

AL CoolantTemp Low

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1295		
Description			
The output is closed when there is the Wrn Coolant Temperature Low (page 360) alarm from the COOLANT TEMP (PAGE 353) in the alarmlist or isn't confirmed.			

🔍 [Logical binary outputs alphabetically \(page 315\)](#)

AL CoolantTemp Sd

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1421		
Description			
The output is closed when there is the shutdown or BOC alarm from the COOLANT TEMP (PAGE 353) in the alarmlist or isn't confirmed.			

🔍 [Logical binary outputs alphabetically \(page 315\)](#)

AL CoolantTemp Wrn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1420		
Description			
The output is closed when there is the warning alarm from the COOLANT TEMP (PAGE 353) in the alarmlist or isn't confirmed.			
<p><i>Note: Binary output is also active if protection type is set to HistRecOnl and threshold level for history record is reach.</i></p>			

🔍 [back to Logical binary outputs alphabetically](#)

AL D+ Fail

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1260		
Description			
This output is active when the Wrn Charging Alternator Fail (page 359) alarm is present in the alarmlist or isn't confirm.			

🔍 [back to Logical binary outputs alphabetically](#)

AL Fuel Level Sd

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1423		
Description			
The output is closed when there is the shutdown or BOC alarm from the FUEL LEVEL (PAGE 354) in the alarmlist or isn't confirmed.			

🔍 [back to Logical binary outputs alphabetically](#)

AL Fuel Level Wrn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1422		
Description			
The output is closed when there is the warning alarm from the FUEL LEVEL (PAGE 354) in the alarmlist or isn't confirmed.			
<i>Note: Binary output is also active if protection type is set to HistRecOnl and threshold level for history record is reach.</i>			

[◀ back to Logical binary outputs alphabetically](#)

AL Mains Fail

Related FW	1.1.0	Related applications	AMF
Comm object	197		
Description			
Output for signaling Mains Failure. This output is active when at least one mains frequency BOC or Sd alarm or at least one mains voltage BOC or Sd alarm is present in alarmlist or isn't confirmed.			

[◀ back to Logical binary outputs alphabetically](#)

AL Maintenance 1

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1254		
Description			
This output is active when the Alarm Maintenance 1 is present in the alarmlist. It means that counter of maintenance is on zero or the Alarm Maintenance 1 isn't confirm.			

[◀ back to Logical binary outputs alphabetically](#)

AL Maintenance 2

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1255		
Description			
This output is active when the Alarm Maintenance 2 is present in the alarmlist. It means that counter of maintenance is on zero or the Alarm Maintenance 2 isn't confirm.			

[◀ back to Logical binary outputs alphabetically](#)

AL Maintenance 3

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1256		
Description			
This output is active when the Alarm Maintenance 3 is present in the alarmlist. It means that counter of maintenance is on zero or the Alarm Maintenance 3 isn't confirm.			

[◀ back to Logical binary outputs alphabetically](#)

AL Oil Press Sd

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1419		
Description			
The output is closed when there is the shutdown alarm from the OIL PRESSURE (PAGE 355) in the alarmlist or isn't confirmed.			

[⬅ back to Logical binary outputs alphabetically](#)

AL Oil Press Wrn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1418		
Description			
The output is closed when there is the warning alarm from the OIL PRESSURE (PAGE 355) in the alarmlist or isn't confirmed.			
<p><i>Note: Binary output is also active if protection type is set to HistRecOnl and threshold level for history record is reach.</i></p>			

[⬅ back to Logical binary outputs alphabetically](#)

AL Overcurrent

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	109		
Description			
This output is active when the BOC Short Circuit (page 385) alarm is present in alarmlist or isn't confirm.			

[⬅ back to Logical binary outputs alphabetically](#)

AL Overspeed

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	779		
Description			
This output is active when the Sd Overspeed (page 380) alarm is present in the alarmlist or isn't confirm.			

[⬅ back to Logical binary outputs alphabetically](#)

AL Underspeed

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1296		
Description			
This output is active when the Sd Underspeed (page 381) alarm is present in the alarmlist or isn't confirm.			

[⬅ back to Logical binary outputs alphabetically](#)

Alarm

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	2		
Description			
The output is designed to be used as external alarm indication such as a red bulb in the control room etc. The output is active when at least one unconfirmed alarm is present in the alarmlist and remains active until confirmation of alarm.			

◀ back to Logical binary outputs alphabetically

LBO: C

Cooling Pump

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	40		
Description			
This output is dedicated for coolant pump control. It is closed in the moment the gen-set is started and remains closed until the gen-set is stopped and After Cooling Time (page 178) elapses or the cranking pause or the Emergency Stop occurs or the controller is switched to OFF mode.			
Image 8.23 Cooling Pump			

◀ back to Logical binary outputs alphabetically

Choke

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	2091		
Description			
Logical binary output for choke valve control. Output CHOKE is activated every time when logical binary output STARTER (PAGE 344) is activated. Output is deactivated when one of these conditions is fulfilled:			
<ul style="list-style-type: none"> ▶ Choke Time is elapsed ▶ Generator voltage is higher than Choke Voltage ▶ Logical binary input Choke Inhibit is activated 			
Or when some of these situations during start occurs:			
<ul style="list-style-type: none"> ▶ Any second level alarm ▶ Emergency stop ▶ Stop command 			

▶ Cranking pause

◀ back to Logical binary outputs alphabetically

LBO: E

ECU Communic Error

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	348		
Description			
This output is active when an ECU is configured, but the communication with the ECU is not established or has dropped out.			
<p>Note: When <i>ECU POWER RELAY (PAGE 324)</i> is not configured, output is evaluated all the time. If <i>ECU POWER RELAY (PAGE 324)</i> is configured, output is evaluated only when engine is not stop (<i>ECU POWER RELAY (PAGE 324)</i> is active).</p>			

◀ back to Logical binary outputs alphabetically

ECU Communic OK

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	347		
Description			
This output is active when an ECU is configured, connected and the communication with the ECU is established.			
<p>Note: When <i>ECU POWER RELAY (PAGE 324)</i> is not configured, output is evaluated all the time. If <i>ECU POWER RELAY (PAGE 324)</i> is configured, output is evaluated only when engine is not stop (<i>ECU POWER RELAY (PAGE 324)</i> is active).</p>			

◀ back to Logical binary outputs alphabetically

ECU Power Relay

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	116		

Description

This output is to be used for control of “keyswitch” input of an ECU. If the particular ECU does not have keyswitch or a similar input, it can be used for control of DC power for the ECU.

The output closes together with **PRESTART** (PAGE 341) and remains closed for the entire duration that the engine is running. It is opened at the moment that the engine comes to a stop (i.e. together with the **FUEL SOLENOID** (PAGE 326)).




Image 8.24 ECU Power Relay

IMPORTANT: This LBO also affects evaluation of **Sd ECU Communication Fail** (page 374) or **Wrn ECU Communication Fail** (page 360) alarms. With configured LBO ECU Power Relay, these alarms are evaluated only when this LBO is active. Without configured LBO ECU Power Relay, these alarm are evaluated all the time.

⬅ back to Logical binary outputs alphabetically

ECU Red Lamp

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	350		

Description

This output is active when the ECU sends an active “red lamp” flag, i.e. it has detected a critical malfunction and the engine should not be operated until a service check is performed. This flag is taken from the DM1 frame on standard J1939 ECUs. Some ECUs provide this flag in their own proprietary frames and some do not provide the flag at all.

⬅ back to Logical binary outputs alphabetically

ECU Run Stop

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	958		
Description			
Signal for starting and stopping of ECU.			

[◀ back to Logical binary outputs alphabetically](#)

ECU Yellow Lamp

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	349		
Description			
This output is active when the ECU sends an active “yellow lamp” flag, i.e. it has detected a non-critical malfunction. This flag is taken from the DM1 frame on standard J1939 ECUs. Some ECUs provide this flag in their own proprietary frames and some do not provide the flag at all.			

[◀ back to Logical binary outputs alphabetically](#)

Exercise Timer 1

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1250		
Description			
This is an output from the Exercise timer 1. This output makes it easy to make periodic tests of the gen-set and its activation depends on the setpoints in the Subgroup: Timer 1 (page 214) subgroup. This output is active when Timer 1 is active.			

[◀ back to Logical binary outputs alphabetically](#)

LBO: F

Fault Reset

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	592		
Description			
When the Fault Reset button is pressed the output is active for 1 s.			

[◀ back to Logical binary outputs alphabetically](#)

Frequency Select

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1815		
Description			
The Frequency select output is opened when Nominal Frequency (Frequency Settings) is equal to 50Hz and closed when Nominal Frequency (Frequency Settings) is equal to 60Hz.			

[◀ back to Logical binary outputs alphabetically](#)

Fuel Solenoid

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	22		

Description

This output controls the fuel solenoid valve.

The output closes before binary output **STARTER** (PAGE 344). The lead time is adjusted by setpoint **Fuel Solenoid Lead** (page 172).




Image 8.25 Fuel Solenoid 1




Image 8.26 Fuel Solenoid 2

The output opens when:

- ▶ Emergency Stop comes
- ▶ cooled gen-set is stopped
- ▶ in pause between repeated starts

🔍 back to Logical binary outputs alphabetically

Fuel Pump

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1253		

Description

Output closes when the value of Fuel Level lies under the value of Fuel Pump On (page 164) setpoint and opens when value of Fuel Pump Off (page 163) is reached.

This output also can be closed by binary input FUEL PUMP ON/OFF (PAGE 306). In this case the binary output FUEL PUMP ON (PAGE 164) is closed until the binary input FUEL PUMP ON/OFF (PAGE 306) is active or until the value of Fuel Pump Off (page 163) is reached.

Note: Setpoints Fuel Pump On (page 164) and Fuel Pump Off (page 163) are invisible until configuration of this LBO.

🔍 back to Logical binary outputs alphabetically

LBO: G

GCB Close/Open

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	41		

Description

The output controls the generator circuit breaker. Its state represents the breaker position requested by the controller. The breaker must react within 5 seconds to a close or open command, otherwise an alarm is issued.

Note: IntelliLite 9 controllers can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.





Image 8.27 GCB Close command



[back to Logical binary outputs alphabetically](#)

GCB OFF Coil

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	43		

Description

The output is intended for control of open coil of generator circuit breaker. The output gives a pulse in the moment the breaker has to be opened. The pulse lasts until the feedback deactivates, but at least for 5 seconds.




Image 8.30 GCB OFF Coil command

[back to Logical binary outputs alphabetically](#)

GCB ON Coil

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	42		

Description

The output is intended for control of close coil of generator circuit breaker. The output gives at least 5 second pulse in the moment the breaker has to be closed.




Image 8.31 GCB ON Coil close command




Image 8.32 Repeated GCB ON coil close command

[back to Logical binary outputs alphabetically](#)

GCB UV Coil

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	44		

Description

The output is intended for control of undervoltage coil of generator circuit breaker. The output is active the

whole time when the generator is running. The output is deactivated for at least 5 seconds in the moment the breaker has to be switched off.




Image 8.33 GCB UV Coil close command




Image 8.34 GCB UV Coil open command

◀ back to Logical binary outputs alphabetically

Generator Healthy

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	77		
Description			
<p>This output is active when the generator voltage and frequency is within limits. It is deactivated:</p> <ul style="list-style-type: none"> ▶ immediately when the voltage/frequency gets out of limits (when GCB is not closed) or ▶ with an appropriate delay after the voltage/frequency has got out of limits (when GCB is closed) 			

🔍 back to Logical binary outputs alphabetically

Glow Plugs

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1252		
Description			
<p>This output is dedicated for diesel engine only. This output will close for exact time pre-set by setpoint Glow Plugs Time (page 162) before every starting attempt. The output opens in same time as the STARTER (PAGE 344) output closes (100 ms after PRESTART (PAGE 341) output opens).</p>			
<p>The diagram shows the timing sequence for engine starting. The y-axis represents Binary Outputs and the x-axis represents Time. The outputs shown are: Glow Plugs On/Off, Starter On/Off, and Prestart On/Off. The Engine RPM is shown as a shaded area that ramps up from 0 to a steady state. Key time intervals are marked: Prestart Time (from Prestart On to Prestart Off), a 100 ms delay (from Prestart Off to Starter On), Glow Plugs Time (from Glow Plugs On to Glow Plugs Off), and another 100 ms delay (from Starter On to Starter Off). The 'Starting RPM' point is marked on the x-axis, and the 'Engine is running' period begins after the engine has reached its operating speed.</p>			
Image 8.35 Glow Plugs			

When the Glow Plugs Time (page 162) is longer than Cranking Fail Pause (page 160) then the Glow Plugs Time (page 162) in Cranking Fail Pause (page 160) is long as Cranking Fail Pause (page 160).




Image 8.36 Glow Plugs in Cranking Fail Pause 1

When the Glow Plugs Time (page 162) is shorter than Cranking Fail Pause (page 160) then the Glow Plugs Time (page 162) in Cranking Fail Pause (page 160) is long as normal Glow Plugs Time (page 162).




Image 8.37 Glow Plugs in Cranking Fail Pause 2

[back to Logical binary outputs alphabetically](#)



LBO: H

HEST Lamp

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1373		
Description			
This output is closed if ECU send signal HEST Lamp. If ECU stop send HEST LAMP signal binary input will be opened without no matter if alarms in alarmlist are confirmed or not.			

 [back to Logical binary outputs alphabetically](#)

Horn

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1		
Description			
The output designed to be used for acoustic indication of a newly appeared alarm. The output is activated each time a new alarm has appeared and remains active until one of the following events occurs:			
<ul style="list-style-type: none"> ▶ Fault reset  is pressed ▶ Horn reset  is pressed ▶ Horn Timeout (page 156) has elapsed 			

 [back to Logical binary outputs alphabetically](#)

LBO: I

Idle/Nominal

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	39		
Description			
<p>This output is used for switching between idle speed and nominal speed of the engine during the startup phase, if this feature (input) is available on the particular engine. In the case of some EFI engines, the idle/nominal switching is performed over the communication bus.</p> <p>The output Idle/Nominal closes after the timer Idle Time (page 172) elapses. The Idle Time (page 172) starts to countdown when Starting RPM (page 161) reached. The underspeed protection is not evaluated during fixed 5 seconds period after reaching Starting RPM (page 161). A Start Fail protection occurs if the RPM drop below 2RPM during idle.</p>			
<p>The diagram illustrates the engine's operational phases: Starting, Idle Speed, and Nominal Speed. The 'Idle Time' is the duration from reaching 'Starting RPM' to 'Nominal RPM'. The 'Idle/Nominal' output is shown as a signal that transitions from 'Off' to 'On' at the start of the 'Starting' phase and returns to 'Off' at the end of the 'Idle Time' period.</p>			
<p>Note: Connect binary output <i>Idle/Nominal</i> to speed governor to switch the speed: <i>opened = Idle</i> <i>closed = Nominal</i> <i>(for normally open contact type)</i></p>			

Image 8.38 Idle/Nominal

⬅ back to Logical binary outputs alphabetically

LBO: M

Mains Healthy

Related FW	1.1.0	Related applications	AMF
Comm object	78		
Description			
<p>This output is active while mains failure is not detected and mains voltage and frequency is within limits.</p>			

⬅ back to Logical binary outputs alphabetically

MCB Close/Open

Related FW	1.1.0	Related applications	AMF
-------------------	-------	-----------------------------	-----

Comm object 45

Description

The output controls the mains circuit breaker. Its state represents the breaker position requested by the controller. The breaker must react within 5 seconds to a close or open command, otherwise an alarm is issued.

Note: *InteliLite 9 controllers can work even without breaker feedbacks, in this case do not configure the feedback to binary inputs.*




Image 8.39 MCB Close command




Image 8.40 Repeated MCB Close command




Image 8.41 MCB Open command

🔍 back to Logical binary outputs alphabetically

MCB OFF Coil

Related FW	1.1.0	Related applications	AMF
Comm object	47		

Description

The output is intended for control of open coil of mains circuit breaker. The output gives a pulse in the moment the breaker has to be opened. The pulse lasts until the feedback deactivates, but at least for 5 seconds.




Image 8.42 MCB OFF Coil command

[back to Logical binary outputs alphabetically](#)

MCB ON Coil

Related FW	1.1.0	Related applications	AMF
Comm object	46		

Description

The output is intended for control of close coil of mains circuit breaker. The output gives at least 5 second pulse in the moment the breaker has to be closed.




Image 8.43 MCB ON Coil close command




Image 8.44 Repeated MCB ON coil close command

[back to Logical binary outputs alphabetically](#)

MCB UV Coil

Related FW	1.1.0	Related applications	AMF
Comm object	48		

Description

The output is intended for control of undervoltage coil of mains circuit breaker. The output is active the whole time when the controller is switched on. The output is deactivated for at least 5 seconds in the moment the breaker has to be switched off.




Image 8.45 MCB UV Coil close command




Image 8.46 MCB UV Coil open command

🔍 back to Logical binary outputs alphabetically

Mode AUTO

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	19		
Description			
This output is active whenever the controller is in AUTO mode.			

[◀ back to Logical binary outputs alphabetically](#)

Mode MAN

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	18		
Description			
This output is active whenever the controller is in MAN mode.			

[◀ back to Logical binary outputs alphabetically](#)

Mode OFF

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	17		
Description			
This output is active whenever the controller is in OFF mode.			

[◀ back to Logical binary outputs alphabetically](#)

Mode TEST

Related FW	1.1.0	Related applications	AMF
Comm object	20		
Description			
This output is active whenever the controller is in TEST mode.			

[◀ back to Logical binary outputs alphabetically](#)

LBO: N

Not In AUTO

Related FW	1.1.0	Related applications	AMF
Comm object	1248		
Description			
This output is active when controller isn't in AUTO mode.			

[◀ back to Logical binary outputs alphabetically](#)

Not Used

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	286		
Description			
Output has no function.			

◀ back to Logical binary outputs alphabetically

LBO: P

Prestart

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	36		

Description

This output can be used for control of any device, which has to be activated just before start. The output is closed for time period of **Prestart Time** (page 161). The output opens 100 ms before the **STARTER** (PAGE 344) output closes.




Image 8.47 Engine start

When the Prestart Time (page 161) is longer than Cranking Fail Pause (page 160) then the Prestart Time (page 161) in Cranking Fail Pause (page 160) is long as Cranking Fail Pause (page 160) minus 100ms.




Image 8.48 Prestart in Cranking Fail Pause 1

When the Prestart Time (page 161) is shorter than Cranking Fail Pause (page 160) then the Prestart Time (page 161) in Cranking Fail Pause (page 160) is long as normal Prestart Time (page 161).




Image 8.49 Prestart in Cranking Fail Pause 2

[back to Logical binary outputs alphabetically](#)

LBO: R

Ready To AMF

Related FW	1.1.0	Related applications	AMF
Comm object	324		
Description			
<p>The output is closed if the gen-set is ready to start automatically and take the load if the mains fails, i.e.:</p> <ul style="list-style-type: none"> ▶ the controller is in AMF operating mode ▶ the controller is in AUTO controller mode and ▶ no red alarm is present in the alarmlist ▶ when the red alarm is confirmed during Stop Valve and other requirements are fulfilled then the LBO is still inactive until the state ready 			

🔍 back to Logical binary outputs alphabetically

Ready To Load

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	58		
Description			
<p>The output is closed whenever the GCB is closed or can be closed i.e. the stabilization phase is finished, the gen-set is running and the Minimal Stabilization Time (page 174) timer has elapsed. and the gen-set voltage and frequency are within limits.</p> <p>If GCB is open then gen-set voltage and frequency must be in limits.</p> <p>If GCB is close then gen-set voltage and frequency can be out of limits, but protection delay can't be count down. If gen-set voltage and frequency will return into limits until delay is count down then output is still closed.</p>			

🔍 back to Logical binary outputs alphabetically

Ready

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	62		
Description			
<p>The binary output is closed, when the engine is stopped and it is possible to start it i.e. no red alarm is activated or SD OVERRIDE (PAGE 313) is active.</p> <p>The binary output is switch on when the Ready state occurs.</p> <p>The binary output is switch off when the Prestart or the Not Ready or the Stop state occurs i.e. always except Ready state.</p>			

🔍 back to Logical binary outputs alphabetically

RegenerationNeeded

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	1372		
Description			
This output is closed when DPF lamp from ECU is active.			

◀ back to Logical binary outputs alphabetically

LBO: S

Starter

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	24		
Description			

This output is dedicated for starter motor control. The number of cranking attempts is adjusted by setpoint **Cranking Attempts** (page 160) in Engine Settings group. Cranking fail pause is adjusted by setpoint **Cranking Fail Pause** (page 160).




Image 8.50 Starter

The starter output opens when:

- ▶ the “firing” speed is reached
- ▶ maximum time of cranking is exceeded
- ▶ request to stop comes up
- ▶ D+ value is higher than D+ Treshold (page 170)
- ▶ Oil pressure value is higher than Starting Oil Pressure (page 162)
- ▶ Generator voltage > 25% of Nominal Voltage Ph-N (page 149) or Nominal Voltage Ph-Ph (page 149) (any phase)

◀ back to Logical binary outputs alphabetically

Stop Pulse

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	25		
Description			
Output is active for 1 second after STOP SOLENOID (PAGE 345) output activation. This signal is sent to ECU in case of engine stop request.			

Image 8.51 Stop Pulse

🔍 back to Logical binary outputs alphabetically

Stop Solenoid

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	23		
Description			
This output is dedicated to control the stop solenoid (valve). The output closes when an engine stop command is received and remains active until the gen-set is stopped.			

Image 8.52 Stop Solenoid 1




Image 8.53 Stop Solenoid 2

Note: If Additional running engine indications (page 102) are lost during 5s pause than Stop Solenoid is not activated again otherwise stop solenoid is activated again.

🔍 Logical binary outputs alphabetically (page 315)

LBO: V

Ventilation

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	38		
Description			
This logical binary output is activated at the beginning of start procedure together with PRESTART (PAGE 341) LBO. Ventilation output is deactivated when engine stops revolving.			
Ventilation LBO is also deactivated immediately when EMERGENCY STOP (PAGE 305) (or E-Stop) is activated or when controller is switched to OFF mode.			
Note: The output is intended for control of an engine room ventilation fan, engine container ventilation fan, container louvres or similar running gen-set technology.			

🔍 back to Logical binary outputs alphabetically

Ventilation On Pulse

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	2089		
Description			
This logical binary output is activated on rising edge of VENTILATION (PAGE 346) LBO (at the beginning of prestart period). The pulse duration is adjusted by Ventilation Pulse Time (page 191) setpoint.			
Note: The output is intended for control of an engine room ventilation fan, engine container ventilation fan, container louvres or similar running gen-set technology.			

🔍 back to Logical binary outputs alphabetically

Ventilation Off Pulse

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	2090		
Description			
<p>This logical binary output is activated on falling edge of VENTILATION (PAGE 346) LBO (when engine stops). The pulse duration is adjusted by Ventilation Pulse Time (page 191) setpoint.</p> <p>Note: <i>The output is intended for control of an engine room ventilation fan, engine container ventilation fan, container louvres or similar running gen-set technology.</i></p>			

[▲ back to Logical binary outputs alphabetically](#)

8.1.5 Logical analog inputs

What Logical analog inputs are:

Logical analog inputs are inputs for analog values.

Alphabetical groups of Logical analog inputs

LAI: A	350
LAI: C	353
LAI: F	354
LAI: N	355
LAI: O	355

For full list of Logical analog inputs go to the chapter **Logical analog inputs alphabetically (page 349)**.

Logical analog inputs alphabetically

AIN Prot01	350
AIN Prot02	351
AIN Prot03	352
Coolant Temp	353
Fuel Level	354
Not Used	355
Oil Pressure	355

LAI: A

AIN Prot01

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9999		
Description			
<p>Logical analog input designed for general value received from analog sensor. For more information about wiring of analog inputs see Analog inputs on page 34. Limits for this protection are adjusted by setpoints Analog Protection 1 Wrn (page 207) and Analog Protection 1 Sd (page 208). Delay is adjusted by setpoint Analog Protection 1 Delay (page 208).</p>			
Protection types			
Monitoring	Analog value is only measured and displayed on the LCD screen but not used for protection.		
HistRecOnl	Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits.		
AL Indic	Analog value is not used for protection. Only alarmlist record is made if analog value is out of the limits.		
Wrn	Analog value is used for warning protection only.		
Wrn + BOC	Analog value is used for warning and BOC (Breaker Open and Cooling) protection.		
BOC	Analog value is used for BOC (Breaker Open and Cooling) protection.		
Wrn + Sd	Analog value is used for warning and shutdown protection.		
Sd	Analog value is used for shutdown protection.		
Note: This parameter has to be adjusted via <i>InteliConfig</i> .			
Alarm			
Under limit	Alarm is activated when value of analog input is under adjusted limits		
Over limit	Alarm is activated when value of analog input is over adjusted limits		
Under limit + fls	Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.		
Over limit + fls	Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.		
<p>Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.</p>			
Note: This parameter has to be adjusted via <i>InteliConfig</i> .			

🔍 back to Logical analog inputs alphabetically

AIN Prot02

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9998		

Description

Logical analog input designed for general value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 34**. Limits for this protection are adjusted by setpoints **Analog Protection 2 Wrn** (page 209) and **Analog Protection 2 Sd** (page 209). Delay is adjusted by setpoint **Analog Protection 2 Delay** (page 210).

Protection types

Monitoring	Analog value is only measured and displayed on the LCD screen but not used for protection.
HistRecOnl	Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits.
AL Indic	Analog value is not used for protection. Only alarmlist record is made if analog value is out of the limits.
Wrn	Analog value is used for warning protection only.
Wrn + BOC	Analog value is used for warning and BOC (Breaker Open and Cooling) protection.
BOC	Analog value is used for BOC (Breaker Open and Cooling) protection.
Wrn + Sd	Analog value is used for warning and shutdown protection.
Sd	Analog value is used for shutdown protection.

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

Under limit	Alarm is activated when value of analog input is under adjusted limits
Over limit	Alarm is activated when value of analog input is over adjusted limits
Under limit + fls	Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.
Over limit + fls	Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

 [back to Logical analog inputs alphabetically](#)

AIN Prot03

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9997		

Description

Logical analog input designed for general value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 34**. Limits for this protection are adjusted by setpoints **Analog Protection 3 Wrn (page 210)** and **Analog Protection 3 Sd (page 211)**. Delay is adjusted by setpoint **Analog Protection 3 Delay (page 211)**.

Protection types

Monitoring	Analog value is only measured and displayed on the LCD screen but not used for protection.
HistRecOnl	Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits.
AL Indic	Analog value is not used for protection. Only alarmlist record is made if analog value is out of the limits.
Wrn	Analog value is used for warning protection only.
Wrn + BOC	Analog value is used for warning and BOC (Breaker Open and Cooling) protection.
BOC	Analog value is used for BOC (Breaker Open and Cooling) protection.
Wrn + Sd	Analog value is used for warning and shutdown protection.
Sd	Analog value is used for shutdown protection.

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

Under limit	Alarm is activated when value of analog input is under adjusted limits
Over limit	Alarm is activated when value of analog input is over adjusted limits
Under limit + fls	Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.
Over limit + fls	Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

 [back to Logical analog inputs alphabetically](#)

LAI: C

Coolant Temp

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	67		
Description			
<p>Logical analog input designed for coolant temperature value received from analog sensor. For more information about wiring of analog inputs see Analog inputs on page 34. Limits for this protection are adjusted by setpoints Coolant Temperature Wrn (page 181) and Coolant Temperature Sd (page 182). Delay is adjusted by setpoint Coolant Temperature Delay (page 182).</p>			
Protection types			
Monitoring	Analog value is only measured and displayed on the LCD screen but not used for protection.		
HistRecOnl	Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits.		
Wrn	Analog value is used for warning protection only.		
Wrn+Stp	Analog value is used for warning and slow stop protection		
Stp	Analog value is used for slow stop protection		
Wrn + BOC	Analog value is used for warning and BOC (Breaker Open and Cooling) protection.		
BOC	Analog value is used for BOC (Breaker Open and Cooling) protection.		
Wrn + Sd	Analog value is used for warning and shutdown protection.		
Sd	Analog value is used for shutdown protection.		
Note: This parameter has to be adjusted via <i>InteliConfig</i> .			
Alarm			
Under limit	Alarm is activated when value of analog input is under adjusted limits		
Over limit	Alarm is activated when value of analog input is over adjusted limits		
Under limit + fls	Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.		
Over limit + fls	Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.		
<p>Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.</p>			
Note: This parameter has to be adjusted via <i>InteliConfig</i> .			
IMPORTANT: Value from analog input has higher priority than value from ECU.			

 [back to Logical analog inputs alphabetically](#)

LAI: F

Fuel Level

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	78		
Description			
<p>Logical analog input designed for fuel level value received from analog sensor. For more information about wiring of analog inputs see Analog inputs on page 34. Limits for this protection are adjusted by setpoints Fuel Level Wrn (page 184) and Fuel Level Sd (page 184). Delay is adjusted by setpoint Fuel Level Delay (page 185).</p>			
Protection types			
Monitoring	Analog value is only measured and displayed on the LCD screen but not used for protection.		
HistRecOnl	Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits.		
Wrn	Analog value is used for warning protection only.		
Wrn+Stp	Analog value is used for warning and slow stop protection		
Stp	Analog value is used for slow stop protection		
Wrn + BOC	Analog value is used for warning and BOC (Breaker Open and Cooling) protection.		
BOC	Analog value is used for BOC (Breaker Open and Cooling) protection.		
Wrn + Sd	Analog value is used for warning and shutdown protection.		
Sd	Analog value is used for shutdown protection.		
Note: This parameter has to be adjusted via IntelliConfig.			
Alarm			
Under limit	Alarm is activated when value of analog input is under adjusted limits		
Over limit	Alarm is activated when value of analog input is over adjusted limits		
Under limit + fls	Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.		
Over limit + fls	Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.		
<p>Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.</p>			
Note: This parameter has to be adjusted via IntelliConfig.			
IMPORTANT: For right behavior of this function, curve for analog input has to be in percentage.			
IMPORTANT: Value from analog input has higher priority than value from ECU.			

🔍 back to Logical analog inputs alphabetically

LAI: N

Not Used

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	230		
Description			
Input has no function.			

🔍 back to Logical analog inputs alphabetically

LAI: O

Oil Pressure

Related FW	1.1.0	Related applications	AMF, MRS
Comm object	9		
Description			

Logical analog input designed for oil pressure value received from analog sensor. For more information about wiring of analog inputs **see Analog inputs on page 34**. Limits for this protection are adjusted by setpoints **Oil Pressure Wrn (page 179)** and **Oil Pressure Sd (page 180)**. Delay is adjusted by setpoint **Oil Pressure Delay (page 180)**.

Protection types

Monitoring	Analog value is only measured and displayed on the LCD screen but not used for protection.
HistRecOnl	Analog value is only measured and displayed on the LCD screen but not used for protection. History record is made if value is out of the limits.
Wrn	Analog value is used for warning protection only.
Wrn + Sd	Analog value is used for warning and Sd protection.
Sd	Analog value is used for Sd protection.

Note: This parameter has to be adjusted via *InteliConfig*.

Alarm

Under limit	Alarm is activated when value of analog input is under adjusted limits
Over limit	Alarm is activated when value of analog input is over adjusted limits
Under limit + fls	Alarm is activated when value of analog input is under adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.
Over limit + fls	Alarm is activated when value of analog input is over adjusted limits. If sensor fail is detected then the alarm with higher level is activate as well.

Example: Protection type is Wrn + Sd. When sensor fail is detected then Sd alarm will be activated + Sensor fail alarm will be activated.

Note: This parameter has to be adjusted via *InteliConfig*.

IMPORTANT: Value from analog input has higher priority than value from ECU.

🔍 back to Logical analog inputs alphabetically

8.2 Alarms

8.2.1 Alarms level 1	356
8.2.2 Alarms level 2	372
8.2.3 Fail sensor and other types	385

What alarms are:

The controller evaluates two levels of alarms. For more information see **Alarm management on page 83**.

8.2.1 Alarms level 1

Warnings	358
Other type	368

For full list of Alarms level 1 go to **List of alarms level 1 (page 357)**.

What alarms level 1 are:

The level 1 alarm indicates that a value or parameter is out of normal limits, but has still not reached critical level. For more information see **Alarm types - Level 1 on page 85**.

List of alarms level 1

Alarm Email 1 Fail	358	Wrm Generator L3L1 < Voltage	364
Alarm SMS 1 Fail	358	Wrm Generator > Frequency	364
ECU Wait To Start	358	Wrm Generator < Frequency	365
Event Email 1 Fail	358	Wrm Check DPF Status ..	365
Event SMS 1 Fail	359	Wrm Mains Voltage Detected	365
Wrm Battery > Voltage	359	Wrm Maintenance 1	365
Wrm Battery < Voltage	359	Wrm Maintenance 2	366
Wrm Charging Alternator Fail	359	Wrm Maintenance 3	366
Wrm Coolant Temperature Low	360	Wrm MCB Fail	366
Wrm Coolant Temp	360	Wrm Oil Pressure	367
Wrm ECU Communication Fail	360	Wrm Overload	367
Wrm Fuel Level	360	Wrm Override All Sd	368
Wrm AIN Prot	360	Wrm Stop Fail	368
Wrm BIN Protection	361	After-Treatment	368
Wrm Generator L1 > Voltage	361	EM(A) - a message lost ...	369
Wrm Generator L1 < Voltage	361	EM(A) - configuration mistake	369
Wrm Generator L1L2 > Voltage	361	EM(A) - insufficient	369
Wrm Generator L1L2 < Voltage	362	EM(A) - missing or damaged	369
Wrm Generator L2 > Voltage	362	Generator CCW Rotation	369
Wrm Generator L2 < Voltage	362	Mains CCW Rotation	370
Wrm Generator L2L3 > Voltage	363	Manual Restore	370
Wrm Generator L2L3 < Voltage	363	Module(slotA) - comm. outage	370
Wrm Generator L3 > Voltage	363	Module(slotA) - false module	371
Wrm Generator L3 < Voltage	363	Module(slotA) - unexpected	371
Wrm Generator L3L1 > Voltage	364	Module(slotA) - unknown module	371

Warnings

Alarm Email 1 Fail

Alarm Type	Other
Alarmlist message	Alarm Email 1 Fail
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	The alarm indicates that there was a request to send an alarm email to email address which is adjusted in setpoint Email Address 1 (page 231) and email wasn't send.

[⬅ back to List of alarms level 1](#)

Alarm SMS 1 Fail

Alarm Type	Other
Alarmlist message	Alarm SMS 1 Fail
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	The alarm indicates that there was a request to send an alarm SMS to telephone number which is adjusted in setpoint Telephone Number 1 (page 230) and SMS wasn't send.

[⬅ back to List of alarms level 1](#)

ECU Wait To Start

Alarm Type	Warning
Alarmlist message	ECU Wait To Start
Alarm evaluated	Only when ECU is connected
Related applications	AMF, MRS
Description	This alarm is activated when ECU send information that ECU Wait To Start lamp is activated. LBO ALARM (PAGE 322) is not activated, after deactivation of lamp, alarm automatically disappear.

[⬅ back to List of alarms level 1](#)

Event Email 1 Fail

Alarm Type	Other
Alarmlist message	Event Email 1 Fail
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	The alarm indicates that there was a request to send an event email to email address which is adjusted in setpoint Email Address 1 (page 231) and email wasn't send.

[⬅ back to List of alarms level 1](#)

Event SMS 1 Fail

Alarm Type	Other
Alarmlist message	Event SMS 1 Fail
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	The alarm indicates that there was a request to send an event SMS to telephone number which is adjusted in setpoint Telephone Number 1 (page 230) and SMS wasn't send.

🔍 back to List of alarms level 1

Wrn Battery > Voltage

Alarm Type	Warning
Alarmlist message	All the time
Alarm evaluated	Wrn Battery > Voltage
Related applications	AMF, MRS
Description	This alarm informs the operator that the controller supply voltage is too high. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Battery Overvoltage (page 188) ▶ Battery <> Voltage Delay (page 189)

🔍 back to List of alarms level 1

Wrn Battery < Voltage

Alarm Type	Warning
Alarmlist message	Wrn Battery < Voltage
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm informs the operator that the controller supply voltage is too low. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Battery Undervoltage (page 188) ▶ Battery <> Voltage Delay (page 189)

🔍 back to List of alarms level 1

Wrn Charging Alternator Fail

Alarm Type	Warning
Alarmlist message	Wrn Charging Alternator Fail
Alarm evaluated	Engine running only
Related applications	AMF, MRS
Description	This alarm is issued if the engine is running and the voltage on the D+ terminal is lower than D+ Treshold (page 170) of the controller supply voltage. This alarm works similar to the red “battery” alarm indicator on a vehicle dashboard. The setpoint has to be in Charge Fail or Enabled position to enable this alarm.

🔍 back to List of alarms level 1

Wrn Coolant Temperature Low

Alarm Type	Warning
Alarmlist message	Wrn Coolant Temperature Low
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the coolant temperature is lower than the temperature set in Coolant Temperature Low Wrn (page 183) setpoint.

🔍 back to List of alarms level 1

Wrn Coolant Temp

Alarm Type	Warning
Alarmlist message	Wrn Coolant Temp
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the coolant temperature is higher than the temperature set in Coolant Temperature Wrn (page 181) setpoint.

🔍 back to List of alarms level 1

Wrn ECU Communication Fail

Alarm Type	Warning
Alarmlist message	Wrn ECU Communication Fail
Alarm evaluated	With configured LBO ECU POWER RELAY (PAGE 324) - only when this LBO is active Without configured LBO ECU POWER RELAY (PAGE 324) - all the time
Related applications	AMF, MRS
Description	This alarm occurs when an ECU is configured, but the communication with the ECU is not established or has dropped out.

🔍 back to List of alarms level 1

Wrn Fuel Level

Alarm Type	Warning
Alarmlist message	Wrn Fuel Level
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the fuel level is lower than the level set in Fuel Level Wrn (page 184) setpoint.

🔍 back to List of alarms level 1

Wrn AIN Prot

Alarm Type	Warning
Alarmlist message	Wrn + Name of analog input
Alarm evaluated	All the time

Related applications	AMF, MRS
Description	This alarm indicates that value the general analog protection is out of warning protection limit.

🔍 back to List of alarms level 1

Wrn BIN Protection

Alarm Type	Warning
Alarmlist message	Wrn + Name of binary input
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	Binary input also can be adjusted like alarm. In this case message in alarmlist contains prefix - Wrn and binary input name. This alarm occurs, when appropriate binary input is active.

🔍 back to List of alarms level 1

Wrn Generator L1 > Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L1 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	This alarm evaluates the generator phase voltage in phase 1. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Generator Overvoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

🔍 back to List of alarms level 1

Wrn Generator L1 < Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L1 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	This alarm evaluates the generator phase voltage in phase 1. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Generator Undervoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

🔍 back to List of alarms level 1

Wrn Generator L1L2 > Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L1L2 > Voltage
Alarm evaluated	Generator excited only

Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L1L2 < Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L1L2 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L2 > Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L2 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phase 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L2 < Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L2 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phase 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L2L3 > Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L2L3 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L2L3 < Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L2L3 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L3 > Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L3 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phase 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L3 < Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L3 < Voltage
Alarm evaluated	Generator excited only

Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phase 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L3L1 > Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L3L1 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator L3L1 < Voltage

Alarm Type	Warning
Alarmlist message	Wrn Generator L3L1 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage Wrn (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 1

Wrn Generator > Frequency

Alarm Type	Warning
Alarmlist message	Wrn Generator > Frequency
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overfrequency Wrn (page 195) ▶ Generator <> Frequency Delay (page 196)

⬅ back to List of alarms level 1

Wrn Generator < Frequency

Alarm Type	Warning
Alarmlist message	Wrn Generator < Frequency
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Underfrequency Wrn (page 196) ▶ Generator <> Frequency Delay (page 196)

⬅ back to List of alarms level 1

Wrn Check DPF Status

Alarm Type	Warning
Alarmlist message	Wrn Check DPF Status
Alarm evaluated	When ECU is configured
Related applications	AMF, MRS
Description	<p>This alarm occurs when ECU send alarm message about Tier IV protection.</p> <p>Note: Tier IV protection have to be supported by ECU.</p>

⬅ back to List of alarms level 1

Wrn Mains Voltage Detected

Alarm Type	Warning
Alarmlist message	Wrn Mains Voltage Detected
Alarm evaluated	Gen-set is running
Related applications	AMF
Description	<p>This alarm occurs when setpoint Operation Mode (page 154) is adjusted to MRS and voltage is detected on mains.</p>

⬅ back to List of alarms level 1

Wrn Maintenance 1

Alarm Type	Warning
Alarmlist message	Wrn Maintenance 1
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>Adjust the setpoint Maintenance Timer 1 (page 187) to the interval of the next maintenance check. The value of the setpoint will count down while the engine is running and if reaches zero, this alarm will be issued. The alarm message will remain in the alarm list (even if the controller is switched off and on again) until the setpoint is re-adjusted to a positive value.</p>

⬅ back to List of alarms level 1

Wrn Maintenance 2

Alarm Type	Warning
Alarmlist message	Wrn Maintenance 2
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	Adjust the setpoint Maintenance Timer 2 (page 187) to the interval of the next maintenance check. The value of the setpoint will count down while the engine is running and if reaches zero, this alarm will be issued. The alarm message will remain in the alarm list (even if the controller is switched off and on again) until the setpoint is re-adjusted to a positive value.

[◀ back to List of alarms level 1](#)

Wrn Maintenance 3

Alarm Type	Warning
Alarmlist message	Wrn Maintenance 3
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	Adjust the setpoint Maintenance Timer 3 (page 188) to the interval of the next maintenance check. The value of the setpoint will count down while the engine is running and if reaches zero, this alarm will be issued. The alarm message will remain in the alarm list (even if the controller is switched off and on again) until the setpoint is re-adjusted to a positive value.

[◀ back to List of alarms level 1](#)

Wrn MCB Fail

Alarm Type	Warning
Alarmlist message	Wrn MCB Fail
Alarm evaluated	All the time

Related applications	AMF
Description	<p>This alarm will occur when the MCB FEEDBACK (PAGE 309) input does not match the expected position given by the MCB CLOSE/OPEN (PAGE 335) output. It stays active until the mismatch between the output and feedback disappears.</p> <ul style="list-style-type: none"> ▶ If there was no command issued by the controller and the breaker (feedback) changes suddenly the position itself, the alarm will be issued immediately. ▶ Self-opening of the breaker is not considered a fault and if all mains values are within limits, the command to reclose the breaker is issued after delay given by the setpoint Mains Return Delay (page 200) has elapsed. ▶ The alarm will be also issued, if the breaker does not respond to the close command within 2 seconds. After this period has elapsed the output MCB Close/Open is deactivated again and the next attempt to close the breaker will occur first after the alarm is reset. ▶ The alarm will be also issued if the breaker does not respond to the open command within 2 seconds. The output MCB Close/Open will stay deactivated. Closing of GCB is blocked until this alarm becomes inactive.

◀ back to List of alarms level 1

Wrn Oil Pressure

Alarm Type	Warning
Alarmlist message	Wrn Oil Pressure
Alarm evaluated	Gen-set is running
Related applications	AMF, MRS
Description	This alarm indicates that the oil pressure is lower than the pressure set in Oil Pressure Wrn (page 179) setpoint.

◀ back to List of alarms level 1

Wrn Overload

Alarm Type	Warning
Alarmlist message	Wrn Overload
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>The alarm is issued when the gen-set power is over the limit for time period longer than the delay. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Overload Wrn (page 192) adjusts the overload limit. ▶ Overload Delay (page 192) Overload Del adjusts the delay.

◀ back to List of alarms level 1

Wrn Override All Sd

Alarm Type	Warning
Alarmlist message	Override All Sd
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm occurs when binary input Sd OVERRIDE (PAGE 313) is activated.

⬅ back to List of alarms level 1

Wrn Stop Fail

Alarm Type	Warning
Alarmlist message	Wrn Stop Fail
Alarm evaluated	While the engine shall be stopped
Related applications	AMF, MRS

Description
 This alarm occurs if the gen-set shall be stopped, but some symptom indicates that it is not stopped. The period when the gen-set shall be stopped begins after the **FUEL SOLENOID (PAGE 326)** has been switched off and time delay **Stop Time (page 176)** has elapsed and lasts for the entire time the **FUEL SOLENOID (PAGE 326)** or **STARTER (PAGE 344)** are off.




Image 9.1 Stop Fail

Note: Gen-set cannot be started until this alarm is inactive and reset.

⬅ back to List of alarms level 1

Other type

After-Treatment

Alarm Type	Alarm indication
Alarmlist message	After-Treatment
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm occurs when appropriate after-treatment lamp is active.

⬅ back to List of alarms level 1

EM(A) - a message lost

Alarm Type	Other
Alarmlist message	EM(A) - a message lost
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that there is a problem with communication between controller and module in slot.

⬅ back to List of alarms level 1

EM(A) - configuration mistake

Alarm Type	Other
Alarmlist message	EM(A) - configuration mistake
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that there is a problem with configuration of binary input or output of module in slot.

⬅ back to List of alarms level 1

EM(A) - insufficient

Alarm Type	Other
Alarmlist message	EM(A) - insufficient
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	The alarm indicates that there was a request to send an alarm email to email address which is adjusted in setpoint Email Address 1 (page 231) and email wasn't send.

⬅ back to List of alarms level 1

EM(A) - missing or damaged

Alarm Type	Other
Alarmlist message	EM(A) - missing or damaged
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that there is a problem with communication with module in slot (in first 5 second there was no communication and module is configured in slot).

⬅ back to List of alarms level 1

Generator CCW Rotation

Alarm Type	Warning
Alarmlist message	Generator CCW Rotation
Alarm evaluated	All the time

Related applications	AMF, MRS
Description	The controller detects phase sequence on generator voltage terminals. This protection is important after controller installation to avoid wrong voltage phase connection. There is a fixed defined phase sequence in IntelliLite 9 controller: T35 = N, T36 = L1, T37 = L2 and T38 = L3. When the phases are connected in a different order, alarms are detected. This alarm prevent circuit breaker closing.

⬅ back to List of alarms level 1

Mains CCW Rotation

Alarm Type	Alarm indication
Alarmlist message	Mains CCW Rotation
Alarm evaluated	All the time
Related applications	AMF
Description	The controller detects phase sequence on mains voltage terminals. This protection is important after controller installation to avoid wrong voltage phase connection. There is a fixed defined phase sequence in IntelliLite 9 controller: T39 = N, T40 = L1, T41 = L2 and T42 = L3. When the phases are connected in a different order, alarms are detected. This alarm prevent circuit breaker closing.

⬅ back to List of alarms level 1

Manual Restore

Alarm Type	Warning
Alarmlist message	Manual Restore
Alarm evaluated	All the time
Related applications	AMF
Description	Alarm is activated when controller is in AUTO mode, Return From Island (page 204) setpoint is set to manual, load is on gen-set a mains has returned.

⬅ back to List of alarms level 1

Module(slotA) - comm. outage

Alarm Type	Other
Alarmlist message	Module(slotA) - comm. outage
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that there is a problem with communication between controller and module in slot.

⬅ back to List of alarms level 1

Module(slotA) - false module

Alarm Type	Other
Alarmlist message	Module(slotA) - fake module
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that false module is inserted in slot.

[◀ back to List of alarms level 1](#)

Module(slotA) - unexpected

Alarm Type	Other
Alarmlist message	Module(slotA) - unexpected
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that in slot is inserted different module than which is configured or the module is unconfigured and has to be configured for proper function.

[◀ back to List of alarms level 1](#)

Module(slotA) - unknown module

Alarm Type	Other
Alarmlist message	Module(slotA) - unknown module
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that unknown module is inserted in slot.

[◀ back to List of alarms level 1](#)

Wrn Fuel Transfer Failed

Alarm Type	Warning
Alarmlist message	Wrn Fuel Transfer Failed
Alarm evaluated	When FUEL PUMP (PAGE 327) is active
Related applications	AMF, MRS
Description	This alarm will occur when there is no increase of fuel level when FUEL PUMP (PAGE 327) is active.

[◀ back to List of alarms level 1](#)

Wrn Transferring Fuel

Alarm Type	Warning
Alarmlist message	Transferring Fuel
Alarm evaluated	When FUEL PUMP (PAGE 327) is active
Related applications	AMF, MRS
Description	This alarm will occur when FUEL PUMP (PAGE 327) is active.

[◀ back to List of alarms level 1](#)

8.2.2 Alarms level 2

Shutdown	374
Other type	382

For full list of Alarms level 2 go to **List of alarms level 2 (page 373)**.

What alarms level 2 are:

The level 2 level alarm indicates that a critical level of the respective value or parameter has been reached. For more information **see Alarm types - Level 2 on page 85**.

List of alarms level 2

Emergency Stop	374	BOC AIN Prot	382
Sd Battery Flat	374	BOC BIN Protection	382
Sd Coolant Temp	374	BOC Generator L1 < Voltage	383
Sd ECU Communication Fail	374	BOC Generator L1L2 < Voltage	383
Sd Fuel Level	375	BOC Generator L2 < Voltage	383
Sd GCB Fail	375	BOC Generator L2L3 < Voltage	383
Sd AIN Protec	375	BOC Generator L3 < Voltage	384
Sd BIN Protection	375	BOC Generator L3L1 < Voltage	384
Sd Generator L1 > Voltage	376	BOC Generator > Frequency	384
Sd Generator L1 < Voltage	376	BOC Generator < Frequency	385
Sd Generator L1L2 > Voltage	376	BOC Overload	385
Sd Generator L1L2 < Voltage	377	BOC Short Circuit	385
Sd Generator L2 > Voltage	377		
Sd Generator L2 < Voltage	377		
Sd Generator L2L3 > Voltage	377		
Sd Generator L2L3 < Voltage	378		
Sd Generator L3 > Voltage	378		
Sd Generator L3 < Voltage	378		
Sd Generator L3L1 > Voltage	379		
Sd Generator L3L1 < Voltage	379		
Sd Generator > Frequency	379		
Sd Generator < Frequency	379		
Sd Oil Pressure	380		
Sd Overload	380		
Sd Overspeed	380		
Sd RPM Measurement Fail	381		
Sd Short Circuit	381		
Sd Start Fail	381		
Sd Underspeed	381		
BOC Coolant Temp	382		
BOC Fuel Level	382		

Shutdown

Emergency Stop

Alarm Type	Shutdown
Alarmlist message	Emergency Stop
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>Alarm is activated when binary input EMERGENCY STOP (PAGE 305) is activated. The gen-set shuts down in the moment the input is activated and starting is blocked until the input is deactivated and fault reset is pressed.</p> <p>Note: Use red emergency button placed on the switchboard door and connect it to a binary input of the controller. Then configure the function Emergency Stop to this binary input. It is recommended to use NC contact of the button.</p> <p>Note: The MCB control is not affected by this alarm.</p>

⬅ back to List of alarms level 2

Sd Battery Flat

Alarm Type	Shutdown
Alarmlist message	Sd Battery Flat
Alarm evaluated	During cranking
Related applications	AMF, MRS
Description	<p>This alarm will be issued if the controller was reset during cranking of the gen-set. If this situation occurs, the controller supposes the starting battery is so exhausted that its voltage drops so low when starter motor is energized that it causes controller reset.</p>

⬅ back to List of alarms level 2

Sd Coolant Temp

Alarm Type	Shutdown
Alarmlist message	Sd Coolant Temp
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>This alarm indicates that the coolant temperature is higher than the temperature set in Coolant Temperature Sd (page 182) setpoint.</p>

⬅ back to List of alarms level 2

Sd ECU Communication Fail

Alarm Type	Shutdown
Alarmlist message	Sd ECU Communication Fail
Alarm evaluated	<p>With configured LBO ECU POWER RELAY (PAGE 324) - only when this LBO is active</p> <p>Without configured LBO ECU POWER RELAY (PAGE 324) - all the time</p>

Related applications	AMF, MRS
Description	This alarm occurs when an ECU is configured, but the communication with the ECU is not established or has dropped out.

⬅ back to List of alarms level 2

Sd Fuel Level

Alarm Type	Shutdown
Alarmlist message	Sd Fuel Level
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the fuel level is lower than the level set in Fuel Level Sd (page 184) setpoint.

⬅ back to List of alarms level 2

Sd GCB Fail

Alarm Type	Shutdown
Alarmlist message	Sd GCB Fail
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>This alarm will occur when the GCB FEEDBACK (PAGE 307) input does not match the expected position given by the GCB CLOSE/OPEN (PAGE 327) output. It stays active until the mismatch between the output and feedback persists.</p> <ul style="list-style-type: none"> ▶ If there was no command issued by the controller and the breaker (feedback) changes suddenly the position itself, the alarm will be issued immediately. ▶ The alarm will be also issued if the breaker does not respond to an open or close command within 5 seconds.

⬅ back to List of alarms level 2

Sd AIN Protec

Alarm Type	Sd
Alarmlist message	Sd + Name of analog input
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that value the general analog protection is out of shutdown protection limit.

⬅ back to List of alarms level 2

Sd BIN Protection

Alarm Type	Shutdown
Alarmlist message	Sd + Name of binary input
Alarm evaluated	All the time

Related applications	AMF, MRS
Description	Binary input also can be adjusted like alarm. In this case message in alarmlist contains prefix - Sd and binary input name. This alarm occurs, when appropriate binary input is active.

⬅ back to List of alarms level 2

Sd Generator L1 > Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L1 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phase 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Sd (page 193) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L1 < Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L1 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phases 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L1L2 > Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L1L2 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Sd (page 193) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L1L2 < Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L1L2 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L2 > Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L2 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phase 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Sd (page 193) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L2 < Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L2 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phases 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L2L3 > Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L2L3 > Voltage
Alarm evaluated	Generator excited only

Related applications	AMF, MRS
Description	This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Generator Overvoltage Sd (page 193) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L2L3 < Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L2L3 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L3 > Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L3 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	This alarm evaluates the generator phase voltage in phase 3. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Generator Overvoltage Sd (page 193) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L3 < Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L3 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	This alarm evaluates the generator phase voltage in phases 3. The following setpoints are related to it: <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L3L1 > Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L3L1 > Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overvoltage Sd (page 193) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator L3L1 < Voltage

Alarm Type	Shutdown
Alarmlist message	Sd Generator L3L1 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

Sd Generator > Frequency

Alarm Type	Shutdown
Alarmlist message	Sd Generator > Frequency
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overfrequency BOC (page 195) ▶ Generator <> Frequency Delay (page 196)

⬅ back to List of alarms level 2

Sd Generator < Frequency

Alarm Type	Shutdown
Alarmlist message	Sd Generator < Frequency
Alarm evaluated	Generator excited only

Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Underfrequency BOC (page 196) ▶ Generator <> Frequency Delay (page 196)

⬅ back to List of alarms level 2

Sd Oil Pressure

Alarm Type	Shutdown
Alarmlist message	Sd Oil Pressure
Alarm evaluated	Gen-set is running
Related applications	AMF, MRS
Description	<p>This alarm indicates that the oil pressure is lower than the pressure set in Oil Pressure Sd (page 180) setpoint.</p>

⬅ back to List of alarms level 2

Sd Overload

Alarm Type	Shutdown
Alarmlist message	Sd Overload
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>The alarm is issued when the gen-set power is over the limit for time period longer than the delay. The behavior of the overload alarm is adjusted by the following setpoints:</p> <ul style="list-style-type: none"> ▶ Overload BOC (page 192) adjusts the overload limit. ▶ Overload Delay (page 192) adjusts the delay

⬅ back to List of alarms level 2

Sd Overspeed

Alarm Type	Shutdown
Alarmlist message	Sd Overspeed
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>This alarm occurs immediately when the engine speed has exceeded the limit. The behavior of the overspeed alarm is adjusted by the following setpoints:</p> <ul style="list-style-type: none"> ▶ Overspeed Sd (page 178) adjust the overspeed limit ▶ Overspeed Overshot (page 179) adjust the additional overspeed limit ▶ Overspeed Overshot Period (page 179) adjust the time period of additional overspeed limit

⬅ back to List of alarms level 2

Sd RPM Measurement Fail

Alarm Type	Shutdown
Alarmlist message	Sd RPM Measurement Fail
Alarm evaluated	During cranking
Related applications	AMF, MRS
Description	The alarm is issued if the engine speed has not exceeded the Starting RPM (page 161) within the Maximum Cranking Time (page 160) , although some of additional running engine indication sources indicate that the engine has started.

🔍 back to List of alarms level 2

Sd Short Circuit

Alarm Type	Shutdown
Alarmlist message	Sd Short Circuit
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>This is a fast overcurrent protection. The following setpoints are related to this alarm:</p> <ul style="list-style-type: none"> ▶ Short Circuit BOC (page 193) adjusts the short current limit ▶ Short Circuit BOC Delay (page 193) adjusts the delay in fine steps

🔍 back to List of alarms level 2

Sd Start Fail

Alarm Type	Shutdown
Alarmlist message	Sd Start Fail
Alarm evaluated	When the gen-set is being started
Related applications	AMF, MRS
Description	<p>This alarm will be issued after all attempts to start the gen-set have run out but the gen-set did not start. The following setpoints are related to this alarm:</p> <ul style="list-style-type: none"> ▶ Cranking Attempts (page 160) adjust the number of attempts

🔍 back to List of alarms level 2

Sd Underspeed

Alarm Type	Shutdown
Alarmlist message	Sd Underspeed
Alarm evaluated	Engine running only
Related applications	AMF, MRS
Description	<p>This alarm will be issued when the gen-set is running and then stops by itself, i.e. the RPM drops under the value of setpoint Underspeed Sd (page 178).</p> <p>The underspeed alarm starts to be evaluated after successful gen-set start and is being evaluated for the entire time that the fuel solenoid is on.</p>

🔍 back to List of alarms level 2

Other type

BOC Coolant Temp

Alarm Type	BOC
Alarmlist message	BOC Coolant Temperature
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the coolant temperature is higher than the temperature set in Coolant Temperature Sd (page 182) setpoint.

[◀ back to List of alarms level 2](#)

BOC Fuel Level

Alarm Type	BOC
Alarmlist message	BOC Fuel Level
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the fuel level is lower than the level set level in Fuel Level Sd (page 184) setpoint.

[◀ back to List of alarms level 2](#)

BOC AIN Prot

Alarm Type	BOC
Alarmlist message	BOC + Name of analog input
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the value of general analog protection is out of BOC protection limit.

[◀ back to List of alarms level 2](#)

BOC BIN Protection

Alarm Type	BOC
Alarmlist message	BOC + Name of binary input
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	Binary input also can be adjusted like alarm. In this case message in alarmlist contains prefix - BOC and binary input name. This alarm occurs, when appropriate binary input is active.

[◀ back to List of alarms level 2](#)

BOC Generator L1 < Voltage

Alarm Type	BOC
Alarmlist message	BOC Generator L1 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phases 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

BOC Generator L1L2 < Voltage

Alarm Type	BOC
Alarmlist message	BOC Generator L1L2 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 1 and 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

BOC Generator L2 < Voltage

Alarm Type	BOC
Alarmlist message	BOC Generator L2 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phases 2. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

BOC Generator L2L3 < Voltage

Alarm Type	BOC
Alarmlist message	BOC Generator L2L3 < Voltage
Alarm evaluated	Generator excited only

Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 2 and 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

BOC Generator L3 < Voltage

Alarm Type	BOC
Alarmlist message	BOC Generator L3 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase voltage in phases 3. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

BOC Generator L3L1 < Voltage

Alarm Type	BOC
Alarmlist message	BOC Generator L3L1 < Voltage
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator phase to phase voltage between phases 3 and 1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Undervoltage BOC (page 194) ▶ Generator <> Voltage Delay (page 195)

⬅ back to List of alarms level 2

BOC Generator > Frequency

Alarm Type	BOC
Alarmlist message	BOC Generator > Frequency
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Overfrequency BOC (page 195) ▶ Generator <> Frequency Delay (page 196)

⬅ back to List of alarms level 2

BOC Generator < Frequency

Alarm Type	BOC
Alarmlist message	BOC Generator < Frequency
Alarm evaluated	Generator excited only
Related applications	AMF, MRS
Description	<p>This alarm evaluates the generator frequency in the phase L1. The following setpoints are related to it:</p> <ul style="list-style-type: none"> ▶ Generator Underfrequency BOC (page 196) ▶ Generator <> Frequency Delay (page 196)

⬅ back to List of alarms level 2

BOC Overload

Alarm Type	BOC
Alarmlist message	BOC Overload
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>The alarm is issued when the gen-set power is over the limit for time period longer than the delay. The behavior of the overload alarm is adjusted by the following setpoints:</p> <ul style="list-style-type: none"> ▶ Overload BOC (page 192) adjusts the overload limit. ▶ Overload Delay (page 192) adjusts the delay

⬅ back to List of alarms level 2

BOC Short Circuit

Alarm Type	BOC
Alarmlist message	BOC Short Circuit
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	<p>This is a fast overcurrent protection. The following setpoints are related to this alarm:</p> <ul style="list-style-type: none"> ▶ Short Circuit BOC (page 193) adjusts the short current limit ▶ Short Circuit BOC Delay (page 193) adjusts the delay in fine steps

⬅ back to List of alarms level 2

8.2.3 Fail sensor and other types

FIs AIN Prot	388
FIs Coolant Temp	388
FIs Fuel Level	388
FIs Oil Pressure	388

For full list of Fails sensor and other types of alarms go to **List of fail sensor alarms (page 387)**.

What Fail sensor and other types of alarms are

If the measured resistance on an analog input exceeds the valid range, a sensor fail will be detected and a sensor fail message will appear in the Alarmlist. For more information **see Sensor fail detection (FLS) on page 86**.

List of fail sensor alarms

FIs AIN Prot	388
FIs Coolant Temp	388
FIs Fuel Level	388
FIs Oil Pressure	388

Fail sensor

FIs AIN Prot

Alarm Type	FIs
Alarmlist message	FIs + name of analog input 1
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm indicates that the value of general analog protection is out of range or is missing.

[◀ back to List of fail sensor alarms](#)

FIs Coolant Temp

Alarm Type	FIs
Alarmlist message	FIs Coolant Temperature
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm occurs when measurement value of coolant temperature is out of range or is missing.

[◀ back to List of fail sensor alarms](#)

FIs Fuel Level

Alarm Type	FIs
Alarmlist message	FIs Fuel Level
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm occurs when measurement value of fuel level is out of range or is missing.

[▶ List of fail sensor alarms \(page 387\)](#)

FIs Oil Pressure

Alarm Type	FIs
Alarmlist message	FIs Oil Pressure
Alarm evaluated	All the time
Related applications	AMF, MRS
Description	This alarm occurs when measurement value of oil pressure is out of range or is missing.

[◀ back to List of fail sensor alarms](#)

8.3 Modules

8.3.1 Plug-In modules389

8.3.1 Plug-In modules

Communication modules	389
Extension modules	398

IMPORTANT: 2nd generation of IntelliLite 9 controllers does not support new modules and 3rd generation does not support all old modules.

The available communication plug-in modules are:

- ▶ CM-RS232-485 - communication module for connection via RS232 or RS485 line
- ▶ CM-4G-GPS - communication module for connection via 4G
- ▶ CM-GPRS - communication module for connection via GPRS
- ▶ CM-Ethernet - communication module for internet connection via Ethernet

The available extension plug-in modules are:

- ▶ EM-BIO8-EFCP - extension module with 8 binary inputs/outputs

Note: Controller has 1 plug-in module slot.

Communication modules

CM-RS232-485	389
CM-Ethernet	391
CM-GPRS	393
CM-4G-GPS	396

CM-RS232-485

CM-RS232-485 is optional plug-in card to enable IntelliLite 9 the RS232 and RS485 communication. This is required for computer or MODBUS connection. The CM-RS232-485 is a dual port module with RS232 and RS485 interfaces at independent COM channels. The RS232 is connected to COM1 and RS485 to COM2.





Image 9.2 CM-RS232-485 interface

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

RS-232 DB-9 Male Pinout



- PIN 1: Data Carrier Detect**
- PIN 2: Receive Data**
- PIN 3: Transmit Data**
- PIN 4: Data Terminal Ready**
- PIN 5: Signal Ground**
- PIN 6: Data Set Ready**
- PIN 7: Request to Send**
- PIN 8: Clear to Send**
- PIN 9: Ring Indicator**

SERIAL "CROSS-WIRED" CABLE




Image 9.3 Pinout of RS-232 line

RS485 internal wiring




Image 9.4 Pinout of RS-485 line



Image 9.5 Jumpers description

Note: Balancing resistors shall be both closed at only one device in whole RS485 network.

Maximal distance of line is 10m for RS232 line and 1200m for RS485 line.

Terminator 120Ω

Balancing resistor +5V

Technical data

Power consumption	40 mA / 8 VDC
	26 mA / 12 VDC
	14 mA / 24 VDC
	10 mA / 36 VDC
Isolation	Galvanic separation

Firmware upgrade

- ▶ Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- ▶ Instal package to computer or open PSI to instal it into InteliConfig
- ▶ Plug the module into the controller and power the controller on.
- ▶ Open a connection with controller via InteliConfig
- ▶ Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in InteliConfig).
- ▶ Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

CM-Ethernet

CM-Ethernet is a plug-in card with Ethernet 10/100 Mbit interface in RJ45 connector. It provides an interface for connecting a PC with through ethernet/internet network, for sending active e-mails and for integration of the controller into a building management (MODBUS TCP and SNMP protocols). This card also enables to monitor and control the gen-set over web browser from any location with internet access using appropriate security measures.




Image 9.6 CM-Ethernet interface

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

Use an Ethernet UTP cable with a RJ45 connector for linking the module with your Ethernet network. The module can also be connected directly to a PC using cross-wired UTP cable.




Image 9.7 Cross-wired cable

Technical data

Power consumption	120 mA / 8 VDC
	82 mA / 12 VDC
	35 mA / 24 VDC
	25 mA / 36 VDC

Module setup

All settings related to the module are to be adjusted via the controller setpoints. The respective setpoints are located in the setpoint **Group: CM-Ethernet (page 231)**.

All actual operational values like actual IP address etc. are available in controller values in a specific group as well.

On module is also indication LED. Following states are indicated via this LED:

- ▶ bootloader mode with communication with controller - green LED is blinking in period 50ms/50ms
- ▶ bootloader mode without communication with controller - red LED is blinking in period 50ms/50ms
- ▶ operating mode with communication with controller - green LED is blinking in period 500ms/500ms
- ▶ operating mode without communication with controller - red LED is blinking in period 500ms/500ms
- ▶ test mode - green LED is blinking in period 250ms/250ms

Firmware upgrade

- ▶ Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- ▶ Instal package to computer or open PSI to instal it into InteliConfig
- ▶ Plug the module into the controller and power the controller on.
- ▶ Open a connection with controller via InteliConfig
- ▶ Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in InteliConfig).
- ▶ Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

CM-GPRS



Image 9.8 CM-GPRS module

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

Note: GPRS and CSD services must be provided by your GSM/GPRS operator for successful operation.

Note: The GPRS and CSD connection should not be used for the firmware update process.

Technical data

Power consumption	32 mA / 8 VDC
	18 mA / 12 VDC
	10 mA / 24 VDC
	12 mA / 36 VDC

SIM card settings

SIM card to be used in CM-4G-GPS or CM-GPRS modules must be adjusted as follows:

- ▶ SMS service enabled
- ▶ Packet data (Internet access) enabled (when required for the selected mode of operation)
- ▶ PIN code security disabled

How to start using CM-GPRS module

- ▶ You will need a controller, CM-GPRS module, antenna and SIM card with SMS and packet data service.

Make sure that your SIM supports the packet data network type you want to use. I.e. if you want to use the module in GPRS (2,5G) network you have to confirm with the operator that the particular SIM card does support 2,5G network.

- ▶ Make sure SIM card does not require PIN code. Use any mobile phone to switch the SIM PIN security off.
- ▶ Place the SIM card into slot on CM-GPRS card
- ▶ Connect the antenna to Cellular module antenna connector.
- ▶ Switch off the controller.
- ▶ Insert CM-GPRS module into controller
- ▶ Power up the controller.



Image 9.9 Main screen of CM-GPRS module

GSM Diag Code – Diagnostic code for CM-GPRS modem

GSM Diag Code – Common list of diagnostic codes for cellular modules

Code	Description
0	OK. No error.
1	Not possible to hang up.
2	Modul is switched off
3	Module is switched on
4	Module – error in initialization
5	Module – not possible to set the APN
6	Module – not possible to connect to GPRS network
7	Module – not possible to retrieve IP address
8	Module – not accepted DNS IP address
9	Error in modem detection
10	Error in initialization of analog modem
11	SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking
12	No GSM signal
13	Not possible to read the SIM card parameters
14	GSM modem did not accepted particular initialization command, possibly caused by locked SIM card
15	Unknown modem
16	Bad answer to complement initialization string
17	Not possible to read GSM signal strength
18	CDMA modem not detected
19	No CDMA network
20	Unsuccessful registration to CDMA network
21	SIMCom/ME909s: can't read FW version
22	SIMCom: GSM signal not found
23	SIMCom: can't detect module speed

24	SIMCom: HW reset issued
25	PUK is required
26	Error of SIM card detected
27	ME909s: can't set module bps
28	ME909s: can't set link configuration
29	ME909s: can't do power-off
30	ME909s: can't do power-on
31	ME909s: can't do hardware reset
32	ME909s: ME909s not started
33	ME909s: switch off issued
34	ME909s: switch on issued
35	ME909s: HW reset issued
36	ME909s: can't switch echo off
37	ME909s: can't find out state of registration
38	ME909s: GSM signal not found
39	ME909s: no SIM memory for SMS
40	ME909s: waiting for registration
41	Can't read operator name
42	ME909s: can't set flow control
43	APN not typed
255	Only running communication is needed to indicate

Firmware upgrade

- ▶ Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- ▶ Instal package to computer or open PSI to instal it into InteliConfig
- ▶ Plug the module into the controller and power the controller on.
- ▶ Open a connection with controller via InteliConfig
- ▶ Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in InteliConfig).
- ▶ Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

CM-4G-GPS



Image 9.10 CM-4G-GPS module

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.

IMPORTANT: CM-4G-GPS and CM-GPRS modules cant be used in one controller in the same time.

IMPORTANT: Operating temperature of module is from -30°C to +75°C.

Note: Cellular data service must be enabled in your SIM card by your mobile operator for successful operation.

Supported 4G bands are as follows:

- ▶ FDD LTE: Band 1, Band 2, Band 3, Band 4, Band 5, Band 7, Band 8, Band 20, all bands with diversity
- ▶ WCDMA/HSDPA/HSUPA/HSPA+: Band 1, Band 2, Band 5, Band 8, all bands with diversity
- ▶ GSM/GPRS/EDGE: 850 MHz/900 MHz/1800 MHz/1900 MHz

Technical data

Power consumption	55 mA / 8 VDC
	35 mA / 12 VDC
	8 mA / 24 VDC
	5 mA / 36 VDC

SIM card settings

SIM card to be used in CM-4G-GPS or CM-GPRS modules must be adjusted as follows:

- ▶ SMS service enabled
- ▶ Packet data (Internet access) enabled (when required for the selected mode of operation)
- ▶ PIN code security disabled

How to start using CM-4G-GPS module

- ▶ You will need a controller, CM-4G-GPS module, antenna and SIM card with SMS and packet data service.

Note: Make sure that your SIM supports the packet data network type you want to use. - i.e. if you want to use the module in LTE (4G) network you have to confirm with the operator that the particular SIM card supports 4G network.

- ▶ Make sure SIM card does not require PIN code. Use any mobile phone to switch the SIM PIN security off.
- ▶ Place the SIM card into slot on CM-4G-GPS card

- ▶ Connect the antenna to Cellular module antenna connector.
- ▶ Switch off the controller.
- ▶ Insert CM-4G-GPS module into controller
- ▶ Power up the controller.




Image 9.11 Main screen of CM-4G-GPS module

GSM Diag Code – Common list of diagnostic codes for cellular modules

GSM Diag Code – Common list of diagnostic codes for cellular modules

Code	Description
0	OK. No error.
1	Not possible to hang up.
2	Modul is switched off
3	Module is switched on
4	Module – error in initialization
5	Module – not possible to set the APN
6	Module – not possible to connect to GPRS network
7	Module – not possible to retrieve IP address
8	Module – not accepted DNS IP address
9	Error in modem detection
10	Error in initialization of analog modem
11	SIM card is locked (Possibly PIN code required, PIN needs to be deactivated) or unknown status of SIM locking
12	No GSM signal
13	Not possible to read the SIM card parameters
14	GSM modem did not accepted particular initialization command, possibly caused by locked SIM card
15	Unknown modem
16	Bad answer to complement initialization string
17	Not possible to read GSM signal strength
18	CDMA modem not detected

19	No CDMA network
20	Unsuccessful registration to CDMA network
21	SIMCom/ME909s: can't read FW version
22	SIMCom: GSM signal not found
23	SIMCom: can't detect module speed
24	SIMCom: HW reset issued
25	PUK is required
26	Error of SIM card detected
27	ME909s: can't set module bps
28	ME909s: can't set link configuration
29	ME909s: can't do power-off
30	ME909s: can't do power-on
31	ME909s: can't do hardware reset
32	ME909s: ME909s not started
33	ME909s: switch off issued
34	ME909s: switch on issued
35	ME909s: HW reset issued
36	ME909s: can't switch echo off
37	ME909s: can't find out state of registration
38	ME909s: GSM signal not found
39	ME909s: no SIM memory for SMS
40	ME909s: waiting for registration
41	Can't read operator name
42	ME909s: can't set flow control
43	APN not typed
255	Only running communication is needed to indicate

Firmware upgrade

- ▶ Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- ▶ Instal package to computer or open PSI to instal it into InteliConfig
- ▶ Plug the module into the controller and power the controller on.
- ▶ Open a connection with controller via InteliConfig
- ▶ Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in InteliConfig).
- ▶ Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.

Extension modules

EM-BIO8-EFCP	399
--------------------	-----

EM-BIO8-EFCP

EM-BIO8-EFCP is optional plug-in card. Through this card controller can accommodate up to 8 binary inputs or outputs. In IntelConfig PC configuration tool it is possible to easily choose if particular I/O will be binary input or output.




Image 9.12 EM-BIO8-EFCP interface

IMPORTANT: Any manipulation with plug-in module shall be done with disconnected power supply to controller.




Image 9.13 Overview of EM-BIO8-EFCP

Note: Current inputs are supported only in MRS16 and AMF25 controllers.




Image 9.14 EM-BIO8-EFCP wiring

Note: Current inputs are supported only in MRS16 and AMF25 controllers.

EM-BIO8-EFCP technical data

Power supply

Power supply range	8-36 VDC
Power consumption	40 mA / 8 VDC
	27 mA / 12 VDC
	22 mA / 24 VDC
	19 mA / 36 VDC

Binary inputs

Number	Up to 8, non-isolated
Close/Open indication	0-2 VDC close contact >6 VDC open contact

Binary outputs

Number	Up to 8, non-isolated
Max. current	0,5A
Switching to	positive supply terminal

Firmware upgrade

- ▶ Download the newest FW of module from ComAp website (in form of PSI file or installation package)
- ▶ Instal package to computer or open PSI to instal it into IntelliConfig
- ▶ Plug the module into the controller and power the controller on.
- ▶ Open a connection with controller via IntelliConfig
- ▶ Go the menu Tools -> Firmware upgrade, select the Plug-in modules tab and select the appropriate firmware you want to program into the module (in IntelliConfig).
- ▶ Press the OK button to start upgrade of firmware.

The firmware update process may be performed via any kind of connection including connection via the same module in which the firmware is to be updated. The connection is reestablished again automatically when the update process is finished.