

InteliVision 18Touch

18.5" display unit for ComAp controllers

SW version 1.0

| | |
|--|----|
| 1 Document information | 4 |
| 2 System overview | 8 |
| 3 Technical data | 9 |
| 4 Installation and wiring | 10 |
| 5 Display Unit Settings | 20 |
| 6 InteliVision 18Touch connection possibilities | 21 |
| 7 Automatic SCADA start and connecting to the system | 28 |
| 8 Creating a SCADA diagram | 29 |

Table of contents

| | |
|---|-----------|
| 1 Document information | 4 |
| 1.1 Clarification of notation | 4 |
| 1.2 About this guide | 4 |
| 1.3 Legal notice | 4 |
| 1.4 Certifications | 6 |
| 1.5 Document history | 7 |
| 1.6 Related products | 7 |
| 2 System overview | 8 |
| 2.1 General description | 8 |
| 3 Technical data | 9 |
| 4 Installation and wiring | 10 |
| 4.1 Front panel description | 10 |
| 4.2 Rear panel description | 11 |
| 4.2.1 Rear Top | 11 |
| 4.2.2 Rear Bottom | 12 |
| 4.3 Dimensions drawings | 13 |
| 4.4 Mounting | 13 |
| 4.5 Power | 14 |
| 4.6 Ethernet (LAN) Ports | 15 |
| 4.6.1 LAN1 Port | 15 |
| 4.6.2 LAN2 Port | 15 |
| 4.7 COM Ports | 17 |
| 4.7.1 COM1 Port | 17 |
| 4.7.2 COM2 Port | 17 |
| 4.7.3 COM Port Mode | 18 |
| 5 Display Unit Settings | 20 |
| 5.1 Touchscreen settings | 20 |
| 5.2 On-Screen Keyboard (OSK) settings | 20 |
| 6 IntelliVision 18Touch connection possibilities | 21 |
| 6.1 IV18T connection to a Single gen-set | 21 |
| 6.1.1 RS-232 connection | 21 |
| 6.1.2 USB connection | 22 |
| 6.1.3 Ethernet (direct) connection | 22 |

| | |
|--|-----------|
| 6.2 IV18T connection to a Multiple gen-set | 24 |
| 6.2.1 USB / RS-232 connection via I-LB+ | 24 |
| 6.2.2 Multiple Ethernet Connection | 25 |
| 6.2.3 Ethernet (Internet) connection via InternetBridge-NT | 26 |
| 7 Automatic SCADA start and connecting to the system | 28 |
| 8 Creating a SCADA diagram | 29 |
| 8.1 Automatic SCADA generating | 29 |
| 8.2 User-defined SCADA layout | 31 |
| 8.2.1 Preparing SCADA archives | 31 |
| 8.2.2 Creating SCADA on another PC | 32 |

1 Document information

| | |
|-------------------------------------|---|
| 1.1 Clarification of notation | 4 |
| 1.2 About this guide | 4 |
| 1.3 Legal notice | 4 |
| 1.4 Certifications | 6 |
| 1.5 Document history | 7 |
| 1.6 Related products | 7 |
| 6 back to Table of contents | |

1.1 Clarification of notation

Note: This type of paragraph calls readers attention to a notice or related theme.

IMPORTANT: This type of paragraph highlights a procedure, adjustment etc., which can cause a damage or improper function of the equipment if not performed correctly and may not be clear at first sight.

Example: This type of paragraph contains information that is used to illustrate how a specific function works.

1.2 About this guide

This manual contains important instructions about IntelliVision 18Touch display unit that shall be fulfilled during the installation and maintenance.

This manual provides general information how to install and use IntelliVision 18Touch display unit.

1.3 Legal notice

This End User's Guide/Manual as part of the Documentation is an inseparable part of ComAp's Product and may be used exclusively according to the conditions defined in the "END USER or Distributor LICENSE AGREEMENT CONDITIONS – COMAP CONTROL SYSTEMS SOFTWARE" (License Agreement) and/or in the "ComAp a.s. Global terms and conditions for sale of Products and provision of Services" (Terms) and/or in the "Standardní podmínky projektů komplexního řešení ke smlouvě o dílo, Standard Conditions for Supply of Complete Solutions" (Conditions) as applicable.

ComAp's License Agreement is governed by the Czech Civil Code 89/2012 Col., by the Authorship Act 121/2000 Col., by international treaties and by other relevant legal documents regulating protection of the intellectual properties (TRIPS).

The End User and/or ComAp's Distributor shall only be permitted to use this End User's Guide/Manual with ComAp Control System Registered Products. The Documentation is not intended and applicable for any other purpose.

Official version of the ComAp's End User's Guide/Manual is the version published in English. ComAp reserves the right to update this End User's Guide/Manual at any time. ComAp does not assume any responsibility for its use outside of the scope of the Terms or the Conditions and the License Agreement.

Licensed End User is entitled to make only necessary number of copies of the End User's Guide/Manual. Any translation of this End User's Guide/Manual without the prior written consent of ComAp is expressly prohibited! Even if the prior written consent from ComAp is acquired, ComAp does not take any responsibility for the content, trustworthiness and quality of any such translation. ComAp will deem a translation equal to this End User's Guide/Manual only if it agrees to verify such translation. The terms and conditions of such verification must be agreed in the written form and in advance.

For more details relating to the Ownership, Extent of Permitted Reproductions Term of Use of the Documentation and to the Confidentiality rules please review and comply with the ComAp's License Agreement, Terms and Conditions available on www.comap-control.com.

Security Risk Disclaimer

Pay attention to the following recommendations and measures to increase the level of security of ComAp products and services.

Please note that possible cyber-attacks cannot be fully avoided by the below mentioned recommendations and set of measures already performed by ComAp, but by following them the cyber-attacks can be considerably reduced and thereby to reduce the risk of damage. ComAp does not take any responsibility for the actions of persons responsible for cyber-attacks, nor for any damage caused by the cyber-attack. However, ComAp is prepared to provide technical support to resolve problems arising from such actions, including but not limited to restoring settings prior to the cyber-attacks, backing up data, recommending other preventive measures against any further attacks.

Warning: Some forms of technical support may be provided against payment. There is no legal or factual entitlement for technical services provided in connection to resolving problems arising from cyber-attack or other unauthorized accesses to ComAp's Products or Services.

General security recommendations and set of measures

1. AccessCode

- Change the AccessCode BEFORE the device is connected to a network.
- Use a secure AccessCode – ideally a random string of 8 characters containing lowercase, uppercase letters and digits.
- For each device use a different AccessCode.

2. Password

- Change the password BEFORE the device enters a regular operation.
- Do not leave displays or PC tools unattended if an user, especially administrator, is logged in.

3. Controller Web interface

- The controller web interface at port TCP/80 is based on http, not https, and thus it is intended to be used only in closed private network infrastructures.
- Avoid exposing the port TCP/80 to the public Internet.





4. MODBUS/TCP

- The MODBUS/TCP protocol (port TCP/502) is an instrumentation protocol designed to exchange data between locally connected devices like sensors, I/O modules, controllers etc. From it's nature it does not contain any kind of security – neither encryption nor authentication. Thus it is intended to be used only in closed private network infrastructures.
- Avoid exposing the port TCP/502 to the public Internet.

5. SNMP

- The SNMP protocol (port UDP/161) version 1,2 is not encrypted. Thus it is intended to be used only in closed private network infrastructures.
- Avoid exposing the port UDP/161 to the public Internet.

1.4 Certifications

| | |
|---|---|
| Declaration of Conformity | |
| The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques. |  |
| FCC | |
| This equipment has been tested and verified to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense. |  |
| UL | |
| <p>This product is Listed by UL. Representative samples of this product have been evaluated by UL and meet applicable safety standards.</p> <p>1. Battery used only. CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS ATTENTION IL Y A RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UNE BATTERIE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES USAGÉES CONFORMÉMENT AUX INSTRUCTIONS</p> <p>2. Caution for Replaceable batteries and instruction may be forming by a hard copy format, CD-ROM or website</p> <p>3. This product is intended to be supplied by a Listed Power Adapter, rated 12-30Vdc, 5-2A minimum and Tma 60 degree C minimum and LPS, if need further assistance, please contact NEXCOM INTERNATIONAL CO LTD for further information.</p> <p>4. The product intended for vertical use only.</p> |  I.T.E 15CR E465230 |
| RoHS | |
| This device complies with conditions known as “RoHS compliance” and conforms to the requirements of the European Union’s Restrictions on the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (“RoHS”) Directive, 2011/65/EU. RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm. |  |

1.5 Document history

| Revision number | Related sw. version | Date | Author |
|-----------------|---------------------|------------|------------|
| 1 | 1.0 | 11.4. 2018 | ComAp a.s. |

1.6 Related products

| Product | Description | Order code |
|------------------------------------|--|-------------------------------|
| InteliSys Gas | Industrial grade controller for gas gen-set based CHPs and power generation applications | I2GASXXBAB |
| InteliSys ^{NTC} BaseBox | Premium Parallel Gen-set Controller | IS-NTC-BB |
| InteliGen ^{NTC} BaseBox | Complex Parallel Gen-set Controller | IG-NTC-BB |
| InteliMains ^{NTC} BaseBox | Mains Supervision Controller Base Unit | IM-NTC-BB |
| InteliGen ^{NT} | Complex Parallel Gen-set Controller | IG-NT GC |
| InteliSys ^{NTC} Hybrid | Hybrid system controller | IS-NTC HYBRID |
| InteliMains ^{NT} | Mains Supervision Controller | IM-NT GC |
| InteliDrive DCU Marine | Modular Certified Engine Controller for Marine Applications | ID-DCU MARINE |
| InteliGen ^{NT} BaseBox | Complex Parallel Gen-set Controller with Detachable Colour Display | IG-NT-BB |
| InteliLite ^{NT} | Manual Remote Start (MRS) Gen-set Controller | IL-NT MRS15 |
| InteliCompact ^{NT} | Genset Controller for Gensets in Multiple Parallel Applications | IC-NT MINT |
| InteliLite | New generation of the most advanced Auto Mains Failure (AMF) gen-set controller | IL3AMF25BAA |
| InteliGen 200 | New Generation of Parallel Gen-set Controller | IG3200XXBAA |

2 System overview

| | |
|-------------------------------|---|
| 2.1 General description | 8 |
| 6 back to Table of contents | |

2.1 General description

The new IntelliVision 18Touch is the natural successor to the IntelliVision 17Touch. It is designed as an easy-to-use Windows based panel suitable for use with a wide range of ComAp controllers. IntelliVision 18Touch features 18.5" LED backlit projected capacitive touchscreen with a resolution of 1366x768 pixels, extended temperature range and UL certification. Its front protection complies with IP66 and operating temperature extends from -10 °C to +60 °C. Smooth operation is ensured by powerful Intel processor.

The new IntelliVision 18Touch is designed for complete monitoring and control of multiple controllers or complex installation, with large numbers of measured values (CHP - Combined Heat and Power). Optimized for ease of installation, configuration and use, the touchscreen allows users to create touch buttons linked to another screen, with the option of directly controlling gen-sets or breakers. IntelliVision 18Touch communicates over standard interfaces such as RS232/485, Ethernet & USB. IntelliVision 18Touch comes with PC SCADA software enabling users to freely configure their screen with different types of items such as meters, bar graphs, numeric values, control buttons, pictures, etc. The software allows users to check the history of multiple controllers and change setpoints from a single location. IGS-LOG software is also preinstalled at no extra cost for continuous logging of desired parameters. IntelliVision 18Touch is designed to mount on a panel in a power distribution room or optionally on the wall using the VESA standard. IntelliVision 18Touch has an integrated mounting kit.

3 Technical data

Power supply

| | |
|--------------------|-----------|
| Power supply range | 12-30 VDC |
|--------------------|-----------|

Operating conditions

| | |
|-----------------------|---|
| Operating temperature | -10 to 60 °C |
| Storage temperature | -20 to 75 °C |
| Operating humidity | 10%~90% relative humidity (non-condensing) |
| Vibration | IEC 68 2-64 (w/ HDD) 1Grms @ sine, 5~500Hz, 1hr/axis (HDD operating) 2Grms @ sine, 5~500Hz, 1hr/axis (CFast operating) 2.2Grms @ random condition, 5~500Hz, 0.5hr/axis (non-operating) |
| Shock | IEC 68 2-27 HDD: 20G@wall mount, half sine, 11ms |

Mechanical

| | |
|-----------|--------------------------------|
| Housing | IP-66 (front) |
| Mounting | Panel/Wall/Stand/VESA100 |
| Weight | 8.2 kg |
| Dimension | 490.8 mm x 320.6 mm x 62.65 mm |

Interfaces

| | |
|----------|--|
| Rear I/O | 2 x RS232/422/485 2 x USB 2.0 1 x USB 3.0 VGA port: 1 x DB15 Audio port: 1x Line-out |
| Ethernet | 10/100/1000 Base-Tx, 2 x RJ45 |

System

| | |
|----------------|--|
| CPU | Intel® Celeron® quad core J1900 2.0 GHz (2.42 GHz turbo boost) |
| Memory | 4GB RAM |
| Storage Device | 1x 32 GB Solid-state-drive 1x External locked CFast socket |
| Expansion | 2 x mini-PCIe sockets support optional Wi-Fi, 3.5G module or fieldbus card |

LCD specification

| | |
|----------------|-----------------------|
| LCD panel | 18.5" TFT LCD |
| Resolution | 1366 x 768 px |
| Luminance | 300 cd/m ² |
| Contrast Ratio | 1000 |
| Viewing angle | 170°(H), 160°(V) |
| Backlight | LED |

Touchscreen

| | |
|----------------------|---|
| Type | Ten points P-Cap (Projected Capacitive Touch) |
| Light Transmission | 87% |
| Anti-scratch Surface | 7H hardness |

Operating system

| | |
|----|-----------------------------|
| OS | Windows Embedded Standard 7 |
|----|-----------------------------|

[6 back to Table of contents](#)

4 Installation and wiring

- 4.1 Front panel description 10
- 4.2 Rear panel description 11
- 4.3 Dimensions drawings 13
- 4.4 Mounting 13
- 4.5 Power 14
- 4.6 Ethernet (LAN) Ports 15
- 4.7 COM Ports 17

[6 back to Table of contents](#)

4.1 Front panel description




Image 4.1 Front panel overview

4.2 Rear panel description

4.2.1 Rear Top




Image 4.2 Rear bottom panel description

| Title | Description |
|---------------------|---|
| Antenna holes | The 3 external antenna holes are used to mount and connect optional 3.5G/ Wi-Fi antennas. |
| CFast | CFast Card Socket Used to insert a CFast card. |
| Power switch | Press to power-on or power-off the panel PC. |
| Backlight on/off | Press to turn-on or turn-off the display |
| Increase Brightness | Press to increase brightness of the screen. |
| Decrease Brightness | Press to decrease brightness of the screen. |

4.2.2 Rear Bottom




Image 4.3 Rear bottom panel description

| Title | Description |
|------------------|--|
| PS/2 KB/MS | Used to connect a PS/2 keyboard or a PS/2 mouse. |
| Line-out | Used to connect a headphone or a speaker. |
| Remote On/Off | Used to connect a remote to power on/off the system. |
| LAN1 / LAN2 | Used to connect the system to a local area network. LAN1 supports Wake up on LAN. |
| USB 2.0 | Used to connect USB 2.0/1.1 devices. |
| USB 3.0 | USB 3.0 port to connect the system with USB 3.0/2.0 devices. |
| COM1 / COM2 | These COM ports support RS232/422/485 compatible series device through BIOS setting, and have 2.5kV isolated protection. |
| Reset Button | Press this button to restart the system. |
| VGA | Used to connect an analog VGA monitor. |
| 12-30 V DC Input | Used to plug a DC power cord. |

4.3 Dimensions drawings




Image 4.4 Dimensions of the Intelivision 18Touch

4.4 Mounting


IV18T is designed to mount onto the panel. IV18T has an integrated mounting system. The recommended cutout size for panel mounting is 472,4 mm (width) x 302,2 mm (height). Insert IV18T into the cut area and from the rear side install the attached mounting clips and fix them with a screwdriver.

IV18T is a fanless system – no fan cooling system is installed inside the IV18T. For proper operation, install IV18T in a cabinet or rack with enough space around it and away from any strong source of heat. The operating temperature range of the IV18T is from -10 to 60 °C.

IMPORTANT: Do not overtighten the screws to prevent damaging the Panel PC.

4.5 Power

Use the proper power cable. The power supply range is from a 12–30V DC. Use the proper fuse (maximum 5 A) when powered from an onsite DC source. The max input current is 5 A at 12 V. The negative supply voltage pin is connected to the IV18T chassis internally. Ensure correct polarity when connecting the DC power supply.



| PIN | Definition |
|-----|-------------------------------|
| 1 | DC+ (Positive supply voltage) |
| 2 | DC- (Negative supply voltage) |
| 3 | GND (Ground) |

Table 4.1 Description of Power connector

IMPORTANT: Do NOT connect power between pins GND and DC- (IT WILL CAUSE UNREPAIRABLE DAMAGE OF THE DISPLAY UNIT).

Table 4.1 shows the consumption of the IntelIVision 18Touch measured on the two voltage level. The values was measured by the temperature of 20°C.

| Performance (Mode) | +12 V | +30 V |
|--------------------|---------|---------|
| S3 Mode - StandBy | 0,13 A | 0,11 A |
| Total Watts | 1,56 W | 3,30 W |
| Idle Mode | 1,58 A | 0,71 A |
| Total Watts | 18,96 W | 21,30 W |
| Full-Loading Mode | 2,70 A | 1,16 A |
| Total Watts | 32,40 W | 34,80 W |


Table 4.2 Consumption of IV18T

6 back to Installation and wiring

4.6 Ethernet (LAN) Ports

4.6.1 LAN1 Port

- ▶ Support Wake on LAN (WOL)
- ▶ Connector type: RJ45 port with LEDs



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | LAN1M0P | 2 | LAN1M0N |
| 3 | LAN1M1P | 4 | LAN1M2P |
| 5 | LAN1M2N | 6 | LAN1M1N |
| 7 | LAN1M3P | 8 | LAN1M3N |

Table 4.3 Pin description of LAN1 Port on Intelivision 18Touch

| ACT | Status |
|-----------------|---------------|
| Flashing yellow | Data activity |
| Off | No activity |


Table 4.4 ACT / Status description table

| LINK | Status |
|---------------|----------------------|
| Steady Green | 1G network link |
| Steady Orange | 100Mbps network link |
| Off | 10Mbps or no link |

Table 4.5 LINK / Status description table

4.6.2 LAN2 Port

- ▶ Support Wake on LAN (WOL)
- ▶ Connector type: RJ45 port with LEDs



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | LAN1M0P | 2 | LAN1M0N |
| 3 | LAN1M1P | 4 | LAN1M2P |
| 5 | LAN1M2N | 6 | LAN1M1N |
| 7 | LAN1M3P | 8 | LAN1M3N |

Table 4.6 Pin description of LAN1 Port on IntelliVision 18Touch

| ACT | Status |
|-----------------|---------------|
| Flashing yellow | Data activity |
| Off | No activity |

Table 4.7 ACT / Status description table


| LINK | Status |
|---------------|----------------------|
| Steady Green | 1G network link |
| Steady Orange | 100Mbps network link |
| Off | 10Mbps or no link |

Table 4.8 LINK / Status description table

4.7 COM Ports

4.7.1 COM1 Port

- ▶ Connector type: DB-9 port, 9-pin D-Sub




| Pin | RS232 | RS422 | RS485 |
|-----|---------------------------------------|---|---------------------------------------|
| 1 | COM1_DCD | COM1_TXD | COM1_TXD- COM1_RXD- |
| 2 | COM1_RXD | COM1_TXD+ | COM1_TXD+ COM1_RXD+ |
| 3 | COM1_TXD | COM1_RXD+ | Reserve |
| 4 | COM1_DTR | COM1_RXD- | Reserve |
| 5 | COM1_GND | COM1_GND | Reserve |
| 6 | COM1_DSR | COM1_RTS- | Reserve |
| 7 | COM1_RTS | COM1_RTS+ | Reserve |
| 8 | COM1_CTS | COM1_CTS+ | Reserve |
| 9 | COM1_RI (Could be a +5V Power Pin) | COM1_CTS- (Could be a +5V Power Pin) | Reserve (Could be a +5V Power Pin) |

Image 4.5 Pin description of COM1 Port on IntelliVision 18Touch

4.7.2 COM2 Port

- ▶ Connector type: DB-9 port, 9-pin D-Sub



| Pin | RS232 | RS422 | RS485 |
|-----|----------|-----------|------------------------|
| 1 | COM1_DCD | COM1_TXD | COM1_TXD- COM1_RXD- |
| 2 | COM1_RXD | COM1_TXD+ | COM1_TXD+ COM1_RXD+ |
| 3 | COM1_TXD | COM1_RXD+ | Reserve |
| 4 | COM1_DTR | COM1_RXD- | Reserve |

| | | | |
|---|--|--|--|
| 5 | COM1_GND | COM1_GND | Reserve |
| 6 | COM1_DSR | COM1_RTS- | Reserve |
| 7 | COM1_RTS | COM1_RTS+ | Reserve |
| 8 | COM1_CTS | COM1_CTS+ | Reserve |
| 9 | COM1_RI (Could be a +12V Power Pin) | COM1_CTS- (Could be a +12V Power Pin) | Reserve (Could be a +12V Power Pin) |

Image 4.6 Pin description of COM2 Port on IntelliVision 18Touch

4.7.3 COM Port Mode

- ▶ COM port mode can be changed using BIOS setup
 - RS-232
 - RS-422
 - RS-485

About BIOS setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters. These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

How to get to BIOS Setup

At first connect the keyboard to the Panel PC. Powering on the computer and immediately pressing key allows you to enter Setup. Press the key to enter Setup. Navigate to the Serial Port Configuration (see picture bellow) and setup the requested mode and interface parameters. Then exit the BIOS setup with saving the changes.




Image 4.7 Serial Port mode settings using BIOS setup

Serial Port

Enables or disables the serial port.

Onboard Serial Port Mode

Select this to change the serial port mode to RS232, RS422, RS485 or RS485 Auto.

Terminal Resistor

Enables or disables the terminal resistor.

IMPORTANT: Only experniced user should do the BIOS changes.

5 Display Unit Settings

| | |
|---|----|
| 5.1 Touchscreen settings | 20 |
| 5.2 On-Screen Keyboard (OSK) settings | 20 |

6 back to Table of contents

As the operating system Microsoft Windows Embedded Standard 7 is installed on the IV18T, you can use standard settings such as the screensaver (the ComAp Screensaver is preinstalled), power off the display or the whole unit after a set period of time, etc.

Only one user, 'admin', is predefined with no password set. You can restrict users by setting passwords and/or creating new users with limited rights. For more details, use Windows help.

5.1 Touchscreen settings

It is possible to calibrate touch sensor using the standard Microsoft Windows 7 functions.

1. Navigate to Start - Control Panel - Tablet PC Settings - Calibration
2. Perform the calibration
3. Save the calibrate data
4. Done

5.2 On-Screen Keyboard (OSK) settings

The On-Screen Keyboard (OSK) is preinstalled. It can be found on the left side of your desktop. The OSK can be called simply using the gesture tap on the keyboard area.

6 back to Display Unit Settings

6 IntelliVision 18Touch connection possibilities

6.1 IV18T connection to a Single gen-set 21
 6.2 IV18T connection to a Multiple gen-set 24

See chapter related products for more information about compatible ComAp controllers.

6 back to Table of contents

6.1 IV18T connection to a Single gen-set

6.1.1 RS-232 connection




Image 6.1 Point to point RS-232 connection to the IV18T

| IV18T settings | Controller settings |
|---|--|
| 2 x RS-232 serial ports additional settings | Setpoints / Comms settings group RS232 (1) mode = DIRECT additional settings |

Table 6.1 Communication settings for the IV18T and controller

Note: It is also possible to establish a RS-232 connection via I-LB+ or IB-NT

6.1.2 USB connection




Image 6.2 Point to point USB connection

| IV18T settings | Controller settings |
|---|---|
| 3 x USB serial ports (3x rear) No special settings required | No special settings required. Some controllers only via ext. bridge. |

Table 6.2 Communication settings for the IV18T and controller

Note: Direct USB connection is not possible for some controllers. However, USB connection is available for all above-mentioned controllers via I-LB+ or IB-NT (see the chapter Connection via I-LB+ or IB-NT)

6.1.3 Ethernet (direct) connection

Many different kinds of Ethernet topologies exist. A basic point to point Ethernet connection can be made by a direct or cross Ethernet cable. In addition, it is also possible to monitor more than one controller in a site through a switch (TCP/IP protocol-based network). Another possibility is establishing a connection through the internet network, but for this a public IP address is necessary (or AirGate ComAp technology without a need for a public IP address). The physical configuration of such a network can be a small Ethernet LAN or also through the internet.




Image 6.3 Point to point Ethernet connection

| IV18T settings | Controller settings |
|---|--|
| 2 x 10/100/1000 TX ports. IP settings necessary. | Max. 2 clients with IntelliMonitor or max. 2 WebSupervisor clients with Web Interface IP setting necessary |

Table 6.3 Communication settings for the IV18T and controller

Note: Ethernet connection is available for all controllers mentioned in chapter related products via an external Bridge IB-NT (See the chapter Multiple Ethernet connection). You can also use IB-NT without the need for a public IP address (find details on our AirGate technology on our website www.comap-control.com)

► Using a web browser

- An Ethernet connection to the controller allows one to use any web browser for basic monitoring and configuration. Simply enter the IP address of the module into the address bar of your web browser, e.g. `http://192.168.1.254` and then enter the access code. When connecting through a web browser, there is 5-minute timeout period after closing the browser window. After that, the client is automatically logged out.

► Ethernet connection settings

- Settings can be edited via any type of connection (USB, RS-232, RS-485 or Ethernet). Setup is provided via IntelliMonitor. For the Ethernet connection, set the following options in the Comms Settings group:

| | | | | | | | | | | |
|-----------------------|------|-------|-------|-------|-------|-------|-------|-------|--|---------------|
| IP addr mode | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | FIXED ▼ |
| IP address | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 192.168.1.254 |
| Net mask | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 255.255.255.0 |
| Gateway IP | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 192.168.1.1 |
| ComApProtoPort | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 23 |
| AirGate | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | DISABLED ▼ |
| AirGate IP | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | |

Image 6.4 Controller IP settings

Note: The IP addresses of the controllers must be accessible from the IV18T. If the IV18T is connected to another LAN segment than the gen-sets are, there must be a gateway (router) that enables direct traffic between the segments. If the IV18T is connected via the Internet, then the internet gateway of the LAN where the gen-sets are connected must have a public IP address, must allow incoming traffic and must provide port forwarding from the external public IP address to the various internal gen-set IPs according to the port used.

6.2 IV18T connection to a Multiple gen-set

6.2.1 USB / RS-232 connection via I-LB+.




Image 6.5 Connection to the controllers via I-LB+

Note: The I-LB+ module enables monitoring and configuration of up to 32 controllers connected via a CAN(2) intercontroller bus. It is also possible to use I-LB+ for single controller connection. It is recommended to use a USB connection because of the communication bandwidth it provides (rate). It is also possible to use the RS-485 interface on the controllers' side instead of CAN2.

▶ I-LB+ hardware setup

- All jumpers in these positions

| | |
|---------------|---|
| HW/SW control | Does not matter |
| ComAp/ModBus | Open |
| ADDR1/ADDR2 | Selection of CAN address. Open = ADDR1, Close = ADDR2 It is possible to use up to two I-LB+ devices in direct mode on the CAN(2) bus. Leave the jumper open when using one I-LB+ module. The other I-LB+ module has to have this jumper closed. (See I-LB+ module for further details.) |
| DIRECT/MODEM | Open |
| RS485/RS232 | Selection of com port (jumper is in RS232 position) / Does not matter |
| Comm. speed. | Does not matter |
| RS485 120 Ohm | Open = terminator not connected, Closed = terminator connected |
| CAN 120 Ohm | Open = terminator not connected, Closed = terminator connected |
| RS-232 / USB | Open (USB Disable) / Closed (USB enabled) |

Table 6.4 I-LB+ settings

6.2.2 Multiple Ethernet Connection

Many different kinds of Ethernet topology exist. The basic point to point Ethernet connection can be made by a direct or cross Ethernet cable. In addition it is also possible to monitor more than one controller in a site through a switch (TCP/IP protocol-based network). Another possibility is establishing a connection through the internet network, but for this a public IP address is necessary (or AirGate ComAp technology, see our website www.comap-control.com for more information). The physical configuration of such a network can be a small Ethernet LAN or also over the internet.




Image 6.6 Multiple Ethernet connection example

| IV18T settings | Controller settings |
|--|--|
| 2 x 10/100/1000 TX ports IP setting necessary. | Max. 2 clients with IntelliMonitor or max. 2 WebSupervisor clients with Web Interface IP setting necessary (see Image 6.4) |

Table 6.5 Communication settings of IV18T and controller

Note: An Ethernet connection is also available for all above-mentioned controllers via an external Bridge IB-NT (See the chapter Ethernet connection via IB-NT). You can also use IB-NT without the need for a Public IP address (find more information about our AirGate technology on our website www.comap-control.com).

- ▶ Using a web browser
 - An Ethernet connection to the controller allows one to use any web browser for basic monitoring and adjustment of the controller. Simply enter the IP address of the module into the address bar of your web browser, e.g. `http://192.168.1.254` and then enter the access code. When connecting from a web browser, there is a 5-minute timeout after closing the browser window. After that, the client is automatically logged out.
- ▶ Ethernet connection settings
 - Settings can be edited via any type of connection (USB, RS232/422/485, Ethernet). Setup is provided via IntelliMonitor. For an Ethernet connection, set the following options in the Comms Settings group:

| | | | | | | | | | | |
|----------------|------|-------|-------|-------|-------|-------|-------|-------|--|---------------|
| IP addr mode | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | FIXED ▼ |
| IP address | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 192.168.1.254 |
| Net mask | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 255.255.255.0 |
| Gateway IP | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 192.168.1.1 |
| ComApProtoPort | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | 23 |
| AirGate | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | DISABLED ▼ |
| AirGate IP | 0 ON | 1 OFF | 2 OFF | 3 OFF | 4 OFF | 5 OFF | 6 OFF | 7 OFF | | |

Image 6.7 Controller IP settings

Note: IP addresses of the controllers must be accessible from the IV18T. If the IV18T is connected to another LAN segment than the gen-sets are, there must be a gateway (router) that enables direct traffic between the segments. If the IV18T is connected via the Internet, then the internet gateway of the LAN where gen-sets are connected must have public IP address, must allow incoming traffic and must provide port forwarding from the external public IP to the various internal gen-set IPs according to the port used.




Image 6.8 Internet gateway (router) configuration example

6.2.3 Ethernet (Internet) connection via InternetBridge-NT

Up to 32 controllers can be remotely monitored via a single InternetBridge-NT. The response time of a system with this type of connection depends on the number of controllers. The higher the number of controllers, the slower the system response time. It is also possible to interconnect IV18T and controllers locally via InternetBridge-NT as a local bridge from the Ethernet network to the CAN fieldbus or RS-485 interface.




Image 6.9 IB-NT connection example

Note: For more information about setting the InternetBridge-NT, see *IB-NT-1.0-Reference Guide.pdf*, which can be downloaded from our website www.comap-control.com

6 back to IntelliVision 18Touch connection possibilities

7 Automatic SCADA start and connecting to the system

6 back to Table of contents

To automatically start SCADA and connect to the system, use the following settings in IntelliMonitor:

- ▶ Enable (Check) the functions highlighted in the graphic.




Image 7.1 SCADA automatic start example

When the IV18T boots up, IntelliMonitor will automatically start and connect to the predefined site. By enabling the function Fullscreen mode, IntelliMonitor will start in fullscreen mode.



Note: You can easily secure your fullscreen SCADA by setting a password in the SCADA tab. Another setting in the same SCADA tab is Touch panel mode which opens the embedded alphanumeric IntelliMonitor keyboard. For further information please see the IntelliMonitor manual or help.

8 Creating a SCADA diagram

8.1 Automatic SCADA generating 29
 8.2 User-defined SCADA layout 31

6 back to Table of contents

8.1 Automatic SCADA generating

To automatically generate a SCADA, physically connect the IV18T to the system, start IntelliMonitor, select **Open connection**  and create a new Site. Select **Site properties**  and choose the appropriate options for your site topology. Uncheck the box "Disable automatic rendering of single line diagram".




Image 8.1 Site properties

Add all controllers available in the system and their properties.

| Controllers | | | | | | |
|--------------|--------|------|-----|------|------|-------------------------------------|
| Name | Type | Addr | Acc | Pass | User | Ena |
| Controller 1 | IGS-NT | 1 | * | | | <input checked="" type="checkbox"/> |
| Controller 2 | IGS-NT | 2 | * | | | <input checked="" type="checkbox"/> |

Image 8.2 Controllers settings

Choose the connection type used for communication between the system and the IV18T.




Image 8.3 Connection settings

Select **Open connection** Open connection

A site diagram will be generated during the connection process.





Image 8.4 Automatically generated SCADA diagram example

8.2 User-defined SCADA layout

- ▶ It is possible to create a user-defined SCADA which can contain
 - User pictures – static
 - User pictures – dynamically controlled by a binary value
 - Simple graphical objects like lines, circles, rectangles
 - Control buttons
 - Meters
 - Breakers
 - Bar graphs
 - Trends data grids with binary/analog values
 - Link buttons

8.2.1 Preparing SCADA archives

Physically connect the IV18T to the system, start IntelliMonitor, select **Open connection**  and create a new Site. Select **Site properties**  and choose the appropriate options for your site topology. Enable the box “Disable automatic rendering of single line diagram”.





Image 8.5 Site properties

Add all controllers available in the system and their properties.



| Name | Type | Addr | Acc | Pass | User | Ena |
|--------------|--------|------|-----|------|------|-------------------------------------|
| Controller 1 | iGS-NT | 1 | * | | | <input checked="" type="checkbox"/> |
| Controller 2 | iGS-NT | 2 | * | | | <input checked="" type="checkbox"/> |

Image 8.6 Controllers settings

Choose the connection type used for communication between the system and IV18T.







Image 8.7 Connection settings

Select **Open connection** 

Ensure that you can see all controllers on the site. If yes, save archives from all controllers by **Connection – Save all as....** You will need these archives to create your own SCADA schemes.

8.2.2 Creating SCADA on another PC

You can create a SCADA on the IV18T itself or use a more convenient procedure to create a SCADA on any PC or laptop. Use the procedure from the previous chapter to save valid archives. Use the **Export site to file** function  located in the **Open connection** window to create a ZIP archive for the previously created site – highlight it, press  and enter the name and location of the ZIP file (it is best to save it directly to a flash drive). After that, you can disconnect from the system. Use the **Import site from file**  function on your laptop or office PC to get an exact copy of the site structure from the IV18T. You can then work offline with the stored archives.

You can also connect your laptop to the system and save archives from controllers directly to your laptop.

Start IntelliMonitor and without connecting, launch **Tools—Line Diagram Editor**. Click on **Master grid**.




Image 8.8 Structure (Master grid)

In the Properties, change the size to 1366 x 768. This is the native screen resolution of the IV18T. You can also change other properties such as the background color or place your own image as the background. The image will be placed automatically in the top left corner. We suggest using an image file with the same resolution as the IV18T screen.


Now you are ready to place other objects.

Panels

It is possible to use Panels. This object is useful if you need to group multiple objects for one controller. You can set the Panel size, position and background color or user image. If you change the Controller address in the Panel properties, all objects inside this Panel change their controller address to this address.

A limitation is that the Panel is not transparent, which leads to problems when using a user-defined image as the background for the Master grid. It is not obligatory to use Panels.


Objects

You can place other objects in Panels or directly in the Master grid. If the object has properties like Controller address or Communication object, set it. You can enter the Communication object number directly, but it is more convenient to click on the  button to the right and choose the object from the list. You may be asked for an archive with a valid configuration.

If you use images, it is strongly recommended to copy all images used into the root of your site folder.

Do not create any subfolders under your site.

Linked screens


SCADA supports multiple screens, e.g. with detailed information about controllers. The number of screens is limited only by the free space on the HDD. To use them, place an object **Link**  located in the **General** tab. You can set some properties such as text or image. For now, leave the box **Linked scheme** empty. Save this main screen as Default.cwd into the root of your site folder (replace existing one).


From the **File** menu, choose **New drawing** and create a new screen. Do not forget to place a **Link button** to go back to the main (or other) screen. Click **Linked scheme** and choose Default.cwd from the list. Save this scheme with another name with the extension .cwd (e.g. GenSet1.cwd).

From the **File** menu click on **Load drawing from...**, open Default.cwd again, click on **Linked scheme** and from the list choose GenSet1.cwd from the previous example. Save the scheme.

Do not forget to back up your data on a regular basis.

Now you can test it. Switch to IntelliMonitor and open proper .ast as Multi off-line. You can see your SCADA from Default.cwd. If not, right-click on the SCADA icon  and select Refresh Test Link buttons.



Note: When SCADA connects to the system, the screen with the Default.cwd name is automatically displayed if it exists. To display the user screen in SCADA, enable the option **Disable automatic rendering of single line diagram** located in **Open window** in the **Sites** section under the button 





Image 8.9 Site properties

If everything is OK, save all data.

If you have prepared screens offline, close the offline archive on laptop. Click on **Open...** and in the **Open connection** window select your site and click **Export site to file** . Save the ZIP file to the flash disk, insert this flash disk into the IV18T and on the IV18T use **Import site from file** . Select the appropriate Connection type and connect.

6 back to Creating a SCADA diagram