

ComAp Electronic Engines Support

August 2015

ECU List version 6.0

Reference Guide



ComAp a.s.

Kundratka 2359/17, 180 00 Prague 8, Czech Republic
Tel: +420 246 012 111, Fax: +420 266 316 647
E-mail : info@comap.cz, www.comap.cz

Support : support@comap.cz

Copyright © 2004-2015 ComAp a.s.



Table of Contents

TABLE OF CONTENTS.....	2
CLARIFICATION OF NOTATION	5
LEGAL NOTICE	6
PRINCIPLE OF ECU SUPPORT	7
AGCO POWER.....	22
EEM4	22
CATERPILLAR	25
EMCP2 + CCM	25
EMCP2 + PL1000	27
ADEM A4 with EMCP3.x or ADEM A4 with EMCP4.x	28
ADEM	31
CUMMINS	33
CM500.....	33
CM558.....	36
CM570.....	38
CM800.....	41
CM850.....	43
PGI 1.1 interface (CM850 or CM2150 or CM2250).....	46
CM2250 industrial	49
GCS.....	51
DAIMLERCHRYSLER	54
ADM2	54
ADM3	56
DETROIT DIESEL.....	58
DDEC IV or DDEC V.....	58
DEUTZ.....	60
EMR2.....	61
EMR3-E	64
EMR3-S.....	67
EMR4.....	70
TEM Evolution.....	73
FORD	74
E-control	74
GM	76
E-control	76
E-control LCI.....	79
MEFI4B, MEFI5B.....	81
MEFI6.....	83
SECM	85
ISUZU.....	87
ECM.....	87
IVECO	90
EDC or NEF	90
EDC Tier3	94
ADEMIII	97
JCB.....	99
Delphi DCM.....	99
JENBACHER	102
DIA.NE.....	102

JOHN DEERE	105
JDEC	106
MAN	110
Data logger	110
EDC Master, EDC Slave and MFR interface system	112
MTU	116
MDEC	116
ADEC (ECU7) & SAM	118
DDEC10	126
ADEC (ECU7)	130
ECU8 and SMARTConnect	131
PERKINS	136
1100 series	136
1300 series	139
2300, 2500, 2800 series	143
SCANIA	146
S6	146
S8	155
SISU	160
EEM2 or EEM3	160
STEYR	164
M1	164
VM	166
EDC	166
VOLVO	170
EDC3 (EMS1) or EMS2 (singlespeed engines only)	171
EDC3 (EMS1) or EMS2 (allspeed engines only)	175
EDC4 (EMR2)	179
WAUKESHA	180
ESM	180
YANMAR	183
TNV	183
LIST OF TEXTS OF ECU FAULT CODES	186
Agco Power EEM4	186
Caterpillar ADEM A4 with EMCP3.x or ADEM A4 with EMCP4.x	188
Caterpillar ADEM	189
Cummins CM500	190
Cummins CM558	191
Cummins CM570	192
Cummins CM800	193
Cummins CM850	194
Cummins PGI 1.1 interface (CM850 or CM2150 or CM2250)	195
Cummins CM2250 industrial	197
Cummins GCS	198
Daimler Chrysler ADM2	200
Daimler Chrysler ADM3	201
Detroit Diesel Engines DDEC IV/DDEC V	202
Deutz EMR2	203
Deutz EMR3-E and EMR3-S	204
Deutz EMR4	206
Ford e-control	208
GM MEFI4B, MEFI5B	210
GM MEFI6	212
GM SECM	215
GM E-control	216
GM E-control LCI	218

Isuzu ECM	219
Iveco EDC	220
Iveco EDC Tier3	222
Iveco Vector	224
JCB Delphi DCM	225
John Deere JDEC	226
MAN EDC Master, EDC Slave and MFR interface system	227
MTU ADEC (ECU7) & SAM.....	228
MTU ADEC (ECU7) & SAM – P-engines	231
MTU DDEC10	232
MTU ECU8 and SMARTConnect.....	233
Perkins ECM	234
Perkins 1300	235
Scania S6 Single speed	236
Scania S6 Single speed from ver.1794335	237
Scania S6 Allspeed	238
Scania S6 Allspeed from ver.1794335	239
Scania S8 Singlespeed	240
Scania S8 Singlespeed	241
Sisu EEM2/EEM3 Gen-set	242
Sisu EEM2/EEM3 Propulsion.....	244
VM Industrial	246
VM Marine	247
Volvo EDC3 (EMS1) or EMS2 (singlespeed engines only)	248
Volvo EDC3 (EMS1) or EMS2 (allspeed engines only).....	249
Waukesha ESM	251
Yanmar TNV	252
Standard J1939 engine	253
NOTES	254

Clarification of notation

HINT

This type of paragraph points out details to help user installation/configuration.

NOTE:

This type of paragraph calls readers' attention to a notice or related theme.

CAUTION!

This type of paragraph highlights a procedure, adjustment, etc. which may cause damage or improper functioning of the equipment if not carried out correctly and may not be clear at first sight.

WARNING!

This type of paragraph indicates things, procedures, adjustments, etc. which demand a high level of attention, otherwise personal injury or death may occur.

EXAMPLE:

This type of paragraph indicates examples of usage for illustrational purposes.

Legal Notice

This End User's Guide/Manual as part of the Documentation is an inseparable part of ComAp's Product and may be used exclusively according to the conditions defined in the "END USER or Distributor LICENSE AGREEMENT CONDITIONS – COMAP CONTROL SYSTEMS SOFTWARE" (License Agreement) and/or in the "ComAp a.s. Standard terms for sale of Products and provision of Services" (Terms) and/or in the "Standardní podmínky projektů komplexního řešení ke smlouvě o dílo, Standard Conditions for Supply of Complete Solutions" (Conditions) as applicable.

ComAp's License Agreement is governed by the Czech Authorship Act 121/2000 Col., by international treaties and by other relevant legal documents regulating protection of the intellectual properties (TRIPS).

The End User and/or ComAp's Distributor shall only be permitted to use this End User's Guide/Manual with ComAp Control System Registered Products. The Documentation is not intended and applicable for any other purpose. Official version of the ComAp's End User's Guide/Manual is the version published in English. ComAp reserves the right to update this End User's Guide/Manual at any time. ComAp does not assume any responsibility for its use outside of the scope of the Terms or the Conditions and the License Agreement.

Licensed End User is entitled to make only necessary number of copies of the End User's Guide/Manual. Any translation of this End User's Guide/Manual without the prior written consent of ComAp is expressly prohibited!

Even if the prior written consent from ComAp is acquired, ComAp does not take any responsibility for the content, trustworthiness and quality of any such translation. ComAp will deem a translation equal to this End User's Guide/Manual only if it agrees to verify such translation. The terms and conditions of such verification must be agreed in the written form and in advance.

For more details relating to the Ownership, Extent of Permitted Reproductions Term of Use of the Documentation and to the Confidentiality rules please review and comply with the ComAp's License Agreement, Terms and Conditions available on <http://www.comap.cz/>.

Principle of ECU support

Since the engines with electronic fuel injection became commonly used, ComAp has introduced a convenient solution for monitoring and management of such engines based on existing controllers IntelliLite and IntelliGen. These used to be fixed programmed and dedicated to a specific engine type, ECU or communication protocol. A separate module – I-CB (Communication Bridge) – was designed to interface IntelliSys controller and ECU unique for its hardware or software features (e.g. communication speed).

Due to great development on the side of the engine manufacturers regarding electronic equipment and amount of transmitted data from the ECU/engine, ComAp had to react promptly and launched new system of ECU support in the controllers. This new approach described below was started by the IntelliDrive DCU controller. Later on it was adopted by the IntelliLite controller (since version 2.0) and nowadays is integrated into all ComAp controllers.

The new way of ECU support provides above all an easy and fast way how to integrate a new type of ECU. Although the engine manufacturers often declare that the unit provides standard J1939 communication, after deeper analysis many of them appear to use proprietary data frames. Therefore ComAp controllers are simply reconfigurable for such specific units using an external file – Engine Specific Code (ESC) – which contains all necessary information about transmitted values, commands and diagnostic messages. The contents of this file are downloaded to the controller which can afterwards provide complete data monitoring and engine control over the CAN bus.


The above described procedure of implementation of an ECU support ensures easy to use and fast configuration however it doesn't reduce the controller's flexibility. The user should be aware that ComAp provides default configuration and the controller must be adapted and configured to particular application. Providing the most common adjustment doesn't eliminate the need to thoroughly test the functionality of the installed controller in conjunction with the genset and other equipment and advice the end user about the way of its operation.

Due to quick development in this area it is strongly recommended to check up ComAp web pages (www.comap.cz) for software and documentation updates ahead of carrying on with projects comprising electronic engines.

What must be done to support a new ECU?

Lets say about units communicating over CAN bus and using J1939 protocol (we will leave out specific units - using RS232/RS485 or their own CAN bus lines, Modbus). As mentioned above we cannot rely on ECU brief specification which states that the unit supports J1939 protocol but we have to study a comprehensive specification describing all details of data communicated by the unit. Only then it is possible to create an ESC and test it with the engine. So the necessary steps are in brief:

- Study ECU documentation
- If the ECU is fully compatible with SAE J1939-71, an ESC for "Standard J1939 engine" can be used
- If the ECU is sufficiently but not fully consistent with SAE J1939-71, a new ESC has be created in ComAp
- The controller with new ESC has to be tested with the engine/ECU (without testing the functionality is only theoretical – operating conditions of ECUs can vary a lot (for example sequence of activating/deactivating of ECU inputs during starting/stopping of the engine))



What data can be transmitted to/from ECU?

There are generally four types of data communicated between the controller and ECU:

- Values read from the ECU (e.g. Engine coolant temperature, Lube oil pressure)
- Values/parameters written to ECU (e.g. Speed control, Frequency select)
- Commands written to ECU (e.g. Start/Stop, Fault reset)
- Fault codes

What is an ESL file?

ESL (ECU Specification List) file contains list of all supported ECUs and so list of ESC available for a given controller. This list appears in LiteEdit, DriveConfig, GenConfig, NanoEdit, ECUDIag as a list of available engine/ECU types. The ESL file also defines communication/diagnostic protocol used in the ECU.



What is the default ESL setting?

ComAp offers many kinds of controllers for various applications. Almost each of ComAp’s controllers supports electronic engines, but the configuration PC software and its settings are different. Therefore we have various ECU lists designed for each product family. In the table there is a description of recommended ESL across our products family.

	Controller’s Family			
Allspeed.esl	InteliDrive DCU	InteliDrive Lite	InteliDrive Mobile	
Gensets.esl	InteliGen ^{NT}	InteliSys ^{NT}		
InteliLite 2015.esl	InteliLite			
InteliLite.esl	InteliLite ^{NT} *	InteliCompact ^{NT}		
InteliNano.esl	InteliNano ^{NT}			
DriveNano.esl	InteliDrive Nano			

*except InteliLite^{NT} MRS3, MRS10, MRS11 and InteliLite^{NT} AMF8, AMF20

NOTE:

It is possible to use e.g. ECU list – Allspeed for InteliGen^{NT} or InteliSys^{NT} controller family. In that case the default settings and/or some values (fault codes) might be unavailable or different.

How to import ESC - ESL package?

The "ECU list-x.y" package can be downloaded from ComAp website (www.comap.cz) and imported into PC software in the same way as a standard firmware package.

It can also be part of an installation package; in this case it is not necessary to import it separately.

Why ESC and ESL have different versions?

Each ESC has a version which changes with each modification. For example if a new value or diagnostic message is added. An ESL version changes if any of ESC version is changed. It is not possible to issue a new ESC without a new ESL. In practice a whole "ESL-ESC" ("ECU list") package is released and it is distributed separately or included in the installation package of the controller.

The configuration softwares (LiteEdit, DriveConfig, GenConfig, NanoEdit) enable to import this package with IWE/IDC/IGC extension as any other firmware packages.

InteliNano^{NT} configuration,

- Open NanoEdit PC software
- Open controller configuration
- Go to ECU configuration window (Miscellaneous > Engine control unit)
- Choose the ECU from the list
- Write the configuration to the controller

NOTE:

InteliNano^{NT} controller does not provide configurable inputs/outputs for engine values or commands. The values are fixed and can not be changed by the service!

Default values for J1939 ECU				
	Analog from the ECU	Binary from the ECU	Analog to the ECU *	Binary to the ECU *
1	Engine speed		Requested Speed	Start command
2	Coolant Temperature		Accelerator Pedal Position	Stop command
3	Oil Pressure			Idle/Nominal Switch
4	Fuel Level			
5	Total Engine Hours			

* depends on the ECU capability

InteliNano^{NT} speed control,

InteliNano^{NT} is an easy to use AMF or MRS controller with no capability to speed variation. This function is not needed for that kind of application. The requested speed or accelerator pedal position is steady based on the Nominal Frequency setpoint.

Nominal Frequency	Requested Speed	Accelerator Pedal Position
50Hz	1500RPM	50%
60Hz	1800RPM	50%

NOTE:

This function (speed adjust via CAN bus) has to be supported by the engine ECU. Without its support ComAp controllers can not adjust the engine speed.

InteliDrive Nano configuration,

- Open NanoDrive PC software
- Open controller configuration
- Go to ECU configuration window (Miscellaneous > Engine control unit)
- Choose the ECU from the list
- Write the configuration to the controller

NOTE:

InteliDrive Nano controller does not provide configurable inputs/outputs for engine values or commands. The values are fixed and can not be changed by the service!

Default values for J1939 ECU				
	Analog from the ECU	Binary from the ECU	Analog to the ECU *	Binary to the ECU *
1	Engine speed		Requested Speed	Start command
2	Coolant Temperature		Accelerator Pedal Position	Stop command
3	Oil Pressure			Idle/Nominal Switch
4	Fuel Level			
5	Total Engine Hours			

* depends on the ECU capability

InteliDrive Nano speed control,

InteliDrive Nano is an easy to use engine controller with capability to speed variation. The requested speed or accelerator pedal position is based on the configuration and application. Please refer to controller [manual](#) for more information about.

NOTE:

This function (speed adjust via CAN bus) has to be supported by the engine ECU. Without its support ComAp controllers can not adjust the engine speed.

InteliLite^{NT}, InteliCompact^{NT}, InteliDrive Lite configuration,

NOTE:

Controllers InteliLite^{NT} MRS3, InteliLite^{NT} MRS10, InteliLite^{NT} MRS11 and InteliLite^{NT} AMF8, InteliLite^{NT} AMF20 don't support electronic engines (engines equipped with ECU).

- Open LiteEdit PC software
- Open controller configuration
- Enter controller password (controller > enter password)
- Open the modify window (controller > configuration > modify...)
- Click on ECU icon
- Check the "electronic engine is connected" check button
- Choose the ECU from the list below
- Confirm OK
- Write the configuration to the controller

NOTE:

InteliLite^{NT}, InteliCompact^{NT}, InteliDrive Lite controllers do not provide configurable inputs/outputs for engine values or commands. The values are fixed and can not be changed by the service!

Default values for J1939 ECU				
	Analog from the ECU	Binary from the ECU	Analog to the ECU *	Binary to the ECU *
1	Engine speed	Yellow Lamp	Requested Speed	Start command
2	Fuel Rate	Red Lamp	Accelerator Pedal Position	Stop command
3	Coolant Temperature	Wait to Start Lamp		Frequency Selector
4	Intake Temperature			Idle/Nominal Switch
5	Oil Pressure			Tier4 control
6	Percent Load			
7	Boost Pressure			
8	Total Engine Hours			
9	Total Fuel Used			
10	Reserved for future use			

* depends on the ECU capability

InteliLite^{NT}, InteliCompact^{NT} speed adjust and control,

InteliLite^{NT} is an easy to use AMF or MRS gen-set controller with a limited capability to speed variation. The requested speed or accelerator pedal position is calculated from ECU FreqSelect and ECU SpeedAdj setpoints.

InteliCompact^{NT} is an easy to use parallel (SPtM or MINT) controller with a capability to speed variation. The requested speed or accelerator pedal position is calculated from ECU FreqSelect and ECU SpeedAdj setpoints or base on load share or base load demand.

ECU FreqSelect = PRIMARY (DEFAULT)		
ECU SpeedAdj	Requested Speed	Accelerator Pedal Position
0%	1350RPM	0%
50%	1500RPM	50%
100%	1650RPM	100%
ECU FreqSelect = SECONDARY		
ECU SpeedAdj	Requested Speed	Accelerator Pedal Position
0%	1620RPM	0%
50%	1800RPM	50%
100%	1980RPM	100%

NOTE:

This function (speed adjust via CAN bus) has to be supported by the engine ECU. Without its support ComAp controllers can not adjust the engine speed.

InteliLite^{NT}, InteliCompact^{NT}, InteliDrive Lite speed adjust and control,

InteliDrive Lite is an easy to use engine controller with capability to speed variation. The requested speed or accelerator pedal position is calculated base on the configuration. For more information please refer to [controller](#) manual.

ECU FreqSelect = PRIMARY (DEFAULT)		
ECU SpeedAdj	Requested Speed	Accelerator Pedal Position
0%	1350RPM	0%
50%	1500RPM	50%
100%	1650RPM	100%
ECU FreqSelect = SECONDARY		
ECU SpeedAdj	Requested Speed	Accelerator Pedal Position
0%	1620RPM	0%
50%	1800RPM	50%
100%	1980RPM	100%

NOTE:

This function (speed adjust via CAN bus) has to be supported by the engine ECU. Without its support ComAp controllers can not adjust the engine speed.

InteliDrive DCU, InteliDrive Mobile configuration,

- Open DriveConfig PC software
- Open controller configuration
- Add ECU to the configuration (modules card > ECU, check the ECU-1 Used check box)
- Choose the ECU from the list
- Write the configuration to the controller

NOTE:

InteliDrive DCU and InteliDrive Mobile controllers provide configurable inputs/outputs for engine values or commands. The lists of supported values are available in I/O card of DriveConfig. For list of supported values or commands refer to particulate ECU type in this manual.

NOTE:

Some values like Start request, Stop request have red background which means that these ECU values must have assigned a source value from the controller e.g. Starter, Stop pulse. This is checked by DriveConfig Consistency Check function.

InteliDrive DCU, InteliDrive Mobile speed control,

InteliDrive DCU, InteliDrive Mobile are engine controllers with a complex speed control capability. Please refer to [InteliDrive DCU](#) or [InteliDrive Mobile](#) Reference Guide for further information about engine speed control over CAN bus.

Speed Request	Requested Speed	Accelerator Pedal Position
0%	1350RPM	0%
50%	1500RPM	50%
100%	1650RPM	100%

NOTE:

This function (speed adjust via CAN bus) has to be supported by the engine ECU. Without its support ComAp controllers can not adjust the engine speed.

InteliGen^{NT}, InteliSys^{NT} configuration,

- Open GenConfig PC software
- Open controller configuration
- Choose the ECU from the list (modules card > ECU)
- Click on Insert
- Write the configuration to the controller

NOTE:

InteliGen^{NT} and InteliSys^{NT} controllers provide configurable inputs/outputs for engine values or commands. The lists of supported values are available in I/O card of GenConfig. For list of supported values or commands refer to particulate ECU type in this manual.

NOTE:

Some values like Start request, Stop request have red background which means that these ECU values must have assigned a source value from the controller e.g. Starter, Stop pulse. This is checked by GenConfig Consistency Check function.

InteliGen^{NT}, InteliSys^{NT} speed control,

InteliGen^{NT}, InteliSys^{NT} are paralleling gen-set controllers with an essential speed variation capability. The requested speed or accelerator pedal position is calculated from Nominal RPM setpoint and SpeedRegOut value.

Nominal RPM = 1500		
Speed Gov Out	Requested Speed	Accelerator Pedal Position
0.000V	1350RPM	0%
5.000V	1500RPM	50%
10.000V	1650RPM	100%
Nominal RPM = 1800		
Speed Gov Out	Requested Speed	Accelerator Pedal Position
0.000V	1620RPM	0%
5.000V	1800RPM	50%
10.000V	1980RPM	100%


NOTE:

This function (speed adjust via CAN bus) has to be supported by the engine ECU. Without its support ComAp controllers can not adjust the engine speed.

Specific ECU/protocols,

Some ECUs do not offer J1939 communication protocol and so it is necessary to have a solution dedicated to each of these units. We recognize two groups:

- ECU communicating via Modbus using RS232/485 (e.g. some Cummins engines) – with controller, it is possible to connect such ECU directly (without I-CB unit),
- ECU with completely incompatible communication protocol and way of connection (e.g. MTU/MDEC CAN bus) – these units are supported with the use of an I-CB unit.



NOTE:

For more details about configuration and available values of I-CB refer to [I-CB Reference Guide](#).

Tier 4 support (DPF only),

Emission standards are requirements that set specific limits to the amount of pollutants that can be released into the environment. Many emissions standards focus on regulating pollutants released by power plants, small equipment such as lawn mowers and diesel generators.

Tier4 emission standards are to be phased-in over the period of 2008 to 2015. The Tier 4 standards require that emissions of PM and NOx be further reduced by about 90%. Such emission reductions can be achieved through the use of control technologies—including advanced exhaust gas aftertreatment.

















ComAp is continuously following this new emission trends in the industry. The investigation brings to ComAp controllers the ability to read the values related to the Tier4 emission standards (like Soot Load, Ash Load of DPF, etc.) as well as to control the engine aftertreatment directly by the controller or by service. The IntelliVision 5 and IntelliVision 8 offer in context with Tier4 user configurable icons to display the health of the engine. It is even more intuitive for the service or maintenance of the engine. IntelliLite^{NT} does not support user configurable icons display.

ComAp controller	Tier 4 support		
	Monitoring	Control	Icons
InteliNano ^{NT}	NO	NO	NO
InteliLite ^{NT}	YES	YES	YES
InteliCompact ^{NT}	NO	NO	NO
InteliGen ^{NT}	YES	YES	YES *
InteliSys ^{NT}	YES	YES	YES *
InteliDrive Lite	NO	NO	NO
InteliDrive DCU	YES	YES	NO
InteliDrive Mobile	YES	YES	NO
InteliDrive Nano	YES	NO	YES

NOTE:

Tier4 emission standard has to be supported by the engine ECU. Without its support ComAp controllers can not read related data, show the icon on the IntelliVision 5 or IntelliVision 8 or control the aftertreatment.

* Only if IntelliVision 5 or IntelliVision 8 is used.


Name	SPN	Icon	
		IntelliVision 5	IntelliVision 8
Diesel Particulate Filter Lamp Command	3697		
Exhaust System High Temperature Lamp Command	3698		
Diesel Particulate Filter Status	3701		
Diesel Particulate Filter Active Regeneration Inhibit Status	3702		
Diesel Particulate Filter Active Regeneration Inhibited Due to Inhibit Switch	3703		
Aftertreatment 1 Diesel Exhaust Fluid Tank 1 Low Level Indicator	5245		
Red Stop Lamp	0623		
Amber Warning Lamp	0624		

NOTE:

For further information about icon configuration please refer to [GenConfig](#) manual.

SAE – J1939 diagnostic connector,

Descriptions of Off-Board diagnostic connectors suppose to be used on engine to get the access to the engine communication links.



Pin label	Meaning
A	Battery negative
B	Battery positive - unswitched
C	CAN H
D	CAN L
E	CAN SHLD
F	SAE J1708 +
G	SAE J1708 -
H	Proprietary OEM use
J	Proprietary OEM use

Fault codes – FMI table,

To inform a service about engine failure sends the ECU a fault code to the controller via CAN bus (SAE J1939-73). The Fault codes are shown either in text form or as a code. The code (the text for as well) consists of

- SPN number (suspect parameter number) – is a particular code for each fault,
- FMI number (failure mode) – is a particular code for each cause of fault,
- OC number (occurrence count) – is an ECU internal counter for each combination of SPN and FMI.

The table describes the cause of fault base on the FMI code:


FMI	Meaning	FMI	Meaning
0	Data valid but above normal operational range – most severe level	16	Data valid but above normal operating range – moderately severe level
1	Data valid but below normal operational range – most severe level	17	Data valid but below normal operating range – least severe level
2	Data erratic, intermittent or incorrect	18	Data valid but below normal operating range – moderately severe level
3	Voltage above normal or shorted to high source	19	Received network data in error
4	Voltage below normal or shorted to low source	20	Data drifted high
5	Current below normal or open circuit	21	Data drifted low
6	Current above normal or grounded circuit	22	Reserved for SAE assignment
7	Mechanical system not responding or out of adjustment	23	Reserved for SAE assignment
8	Above frequency or pulse width or period	24	Reserved for SAE assignment

9	Abnormal update rate	25	Reserved for SAE assignment
10	Abnormal rate of change	26	Reserved for SAE assignment
11	Root cause not known	27	Reserved for SAE assignment
12	Bad intelligent device or component	28	Reserved for SAE assignment
13	Out of calibration	29	Reserved for SAE assignment
14	Special instructions	30	Reserved for SAE assignment
15	Data valid but above normal operating range – least severe level	31	Condition exists

How to create a constant for ECU control (PLC example),

There are at least two ways in GenConfig software:


1. By math function ADD in PLC where first input is a required analog value (constant) and the second input is zero value. The output of the function is a constant which can be used as a source for ECU control. In this example is created constant = 2.



2. By any of not used ExtValue1deflt - ExtValue4deflt setpoint. The value of an ExtValueXdeflt setpoint can be used as a source for ECU control. It is recommended to use a source Logical 1 for a particular ExtValueXreset (in LBI card).

There is a recommended way in DriveConfig software:

3. By math function ADD in PLC where first input is a required analog value (constant) and the second input is zero value. The output of the function is a constant which can be used as a source for ECU control. In this example is created constant = 2.



How to read this document,

The screenshot shows a technical document page with several sections highlighted in red and annotated with arrows from external labels:

- Engine manufacturer:** Points to "Steyr - M1" at the top left.
- ECU type:** Points to "Steyr" at the top left.
- Supported ECUs:** Points to the "ECU Types" table.
- Engine model fitted with particular ECU type:** Points to the "Engine Type" column in the "ECU Types" table.
- Detailed ECU description:** Points to the "M1" section header.
- ECU selection in PC configuration software:** Points to the "Steyr M1" selection in the "ECU selection in PC software for M1" section.
- Available signals (parameters):** Points to the "Available signals" table.
- List of all configurable values, marked values automatically configured:** Points to the "ECU analog outputs (controller's inputs)" table.
- Revision of the document:** Points to the footer information.

Revision of the document

ECU binary outputs
 commands come from the ECU to the controller (*Red Stop Lamp*)
ECU binary inputs
 commands come from the controller to the ECU (*Stop Request*)

ECU analog outputs
 values measured or calculated by the ECU (*Engine Speed*)
ECU analog inputs
 Requests from the controller for the ECU (*Requested Speed, Frequency Selection, ...*)

Kind of speed request
(Requested speed [RPM]
Accelerator Pedal Position [%])

Proper adjusting speed control in GenConfig
Proper adjusting speed control in Drive Config

Iveco Engines Support - EDC

ComAp

Requested Speed settings for IntelliGenTM or IntelliSysTM

Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A

Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile

Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. Speed (2100RPM)

Recommended wiring for NEF

Function	ECU AZ 85y/a connector	diagnostic connector	Controller
CAN H	57	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	58	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	7, 12, 13	N/A	N/A
Battery - (negative)	3, 14, 15	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 12 or [here](#).

PC configuration software (GenConfig)

Property	Value
Source	SpeedReq RPM
Convert	No
Limits	[0 .. 3000] -> [0 .. 0]
ECU value	Requested speed
Normalize	No
Resolution	1

Analog output limits calculator

Source value: Output value:

Low: 0 0

High: 3000 5000

[RPM] [RPM]

OK Cancel

t 05-2012.pdf page: 90

If Convert = YES
Analog output limit calculator (GenConfig)

Comparison table

Engine manufacturer	ECU Type	InteliSys ^{NT}	InteliGen ^{NT}	InteliDrive DCU	InteliDrive Mobile	InteliDrive Lite	InteliLite ^{NT}	InteliCompact ^{NT}	InteliNano ^{NT}	InteliDrive Nano	ID	Selection in PC software
		YES	YES	YES	YES	NO	NO		NO	NO		
AGCO	EEM4	YES	YES	YES	NO	NO	NO	NO	NO	NO	116	I-CB unit
	EMCP2 + CCM	YES	YES	YES	NO	NO	NO	NO	NO	NO	N/A	I-CB unit
Caterpillar	EMCP2 + PL1000	YES	YES	YES	NO	NO	NO	NO	NO	NO	N/A	I-CB unit
	ADEM + EMCP	YES	NO	NO	NO	NO	NO	NO	NO	NO	17	Caterpillar ADEM&EMCP
Cummins	ADEM	YES	YES	YES	YES	YES	YES	YES	YES	YES	10	Caterpillar J1939
	CM500	YES	YES	YES	YES	YES	NO	NO	NO	YES	57	Cummins CM500
	CM558	YES	YES	YES	YES	YES	NO	NO	NO	YES	33	Cummins CM558
	CM570	YES	YES	YES	YES	YES	YES	YES	YES	YES	4	Cummins CM570
	CM800	YES	YES	YES	YES	YES	NO	NO	NO	YES	67	Cummins CM800
	CM850	YES	YES	YES	YES	YES	YES	YES	YES	YES	26	Cummins CM850
	CM850 / CM2150 / CM2250	YES	NO	NO	NO	NO	YES	YES	YES	YES	43	Cummins CM850/CM2150/CM2250
	CM2250 industrial	NO	YES	YES	YES	YES	NO	NO	NO	YES	59	Cummins CM2250
	GCS	YES	YES	YES	YES	YES	NO	NO	NO	NO	5	Cummins MODBUS
	ADM2	NO	YES	YES	YES	YES	YES	YES	YES	YES	24	Daimler Chrysler ADM2
	ADM3	NO	YES	YES	YES	YES	NO	NO	NO	YES	42	Daimler Chrysler ADM3
	Detroit Diesel	DDEC IV	YES	YES	YES	YES	YES	YES	YES	YES	YES	9
DDEC V		YES	YES	YES	YES	YES	YES	YES	YES	YES	9	DDC DDEC IV/V
Deutz	EMR2	YES	YES	YES	YES	YES	YES	YES	YES	YES	8	Deutz EMR2
	EMR3	YES	YES	YES	YES	YES	YES	YES	YES	YES	25	Deutz EMR3
	EMR4	YES	YES	YES	YES	YES	YES	YES	YES	YES	70	Deutz EMR4
	TEM Evolution	YES	YES	YES	NO	NO	NO	NO	NO	NO	N/A	I-CB unit
Ford	E - control	YES	NO	NO	NO	NO	NO	NO	NO	NO	95	Ford e-control
	MEF14B / MEF15B	YES	YES	YES	YES	YES	NO	NO	NO	YES	34	GMI MEF14B / MEF15B
GM	MEF16	YES	YES	YES	YES	YES	YES	YES	YES	YES	71	GMI MEF16
	SECM	YES	YES	YES	YES	YES	YES	YES	YES	YES	35	GMI SECM
	E - control	YES	YES	YES	YES	YES	YES	YES	NO	YES	44	GMI e-control
Iveco	E - control LCI	YES	YES	YES	YES	YES	YES	YES	NO	YES	58	GMI e-control LCI
	EDC	YES	YES	YES	YES	YES	YES	YES	YES	YES	14	Iveco NEF & Cursor
	ADEM III	YES	YES	YES	YES	YES	YES	YES	YES	YES	28	Iveco Vector
Isuzu	EDC Tier3	YES	YES	YES	YES	YES	YES	YES	YES	YES	91	Iveco NEF & Cursor Tier3
	ECM	YES	YES	YES	YES	YES	YES	YES	YES	YES	36	Isuzu ECM


Engine manufacturer	ECU Type	InteliSys ^{NT}	InteliGen ^{NT}	InteliDrive DCU	InteliDrive Mobile	InteliDrive Lite	InteliLite ^{NT}		InteliCompact ^{NT}	InteliNano ^{NT}	InteliDrive Nano	ID	Selection in PC software
		NO	YES	YES	NO	YES	YES		YES	YES	NO		
JCB	Delphi DCM	NO	YES	YES	NO	YES	YES	YES	YES	NO	YES	23	JCB Delphi DCM
Jenbacher	DIA.NE	YES	YES	NO	NO	NO	NO	NO	NO	NO	NO	22	Jenbacher Diane
John Deere	JDEC	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	7	John Deere
Kubota	ECM	YES	YES	YES	YES	YES	TES	YES	YES	TES	YES	122	Kubota
MAN	EDC / MFR	YES	YES	YES	YES	YES	YES	YES	NO	NO	YES	29	MAN MFR
	Data logger	YES	YES	YES	YES	YES	NO	NO	NO	NO	NO	56	MAN data logger
	MDEC	YES	YES	YES	NO	NO	NO	NO	NO	NO	NO	N/A	1-CB unit
	ADEC & SAM	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	20	MTU ADEC J1939
MTU	ADEC & SAM	NO	YES	YES	YES	NO	NO	NO	NO	NO	YES	37	MTU ADEC J1939 P-engines
	ADEC & SMART connect	YES	YES	NO	NO	YES	YES	YES	YES	YES	NO	60	MTU SMART Connect
	DDEC10	YES	YES	YES	YES	YES	YES	YES	YES	NO	YES	117	MTU DDEC10
	A4E2	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	12	Perkins ECM
Perkins	ECM	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	12	Perkins ECM
	A4E2 or ECM	NO	NO	NO	NO	NO	YES	YES	YES	YES	NO	54	Perkins 1300
Scania	S6	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	3/16	Scania S6 Singlespeed
	S6	NO	YES	YES	YES	YES	NO	NO	YES	YES	YES	6/11	Scania S6 Allspeed
	S8	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	68	Scania S8 Singlespeed
	S8	NO	YES	YES	YES	YES	NO	NO	NO	NO	YES	69	Scania S8 Allspeed
Sisu	EEM2	NO	YES	YES	YES	YES	NO	NO	NO	NO	YES	19	Sisu EEM3 Propulsion
	EEM3	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	18	Sisu EEM3 Gen-set
Steyr	M1	NO	NO	YES	YES	YES	NO	NO	NO	YES	YES	66	Steyr M1
VM	EDC	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	32/31	VM Industrial / VM Maine
	EDG3 / EMS1 / EMS2	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	1	Volvo EMS 1 Singlespeed
Volvo	EDG3 / EMS1 / EMS2	YES	YES	YES	YES	YES	NO	NO	NO	NO	YES	2	Volvo EMS 1 Allspeed
	EDC4	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	8	Deutz EMR2
Waukesha	EDC7 Allspeed KWP2000	NO	YES	YES	YES	NO	NO	NO	NO	NO	NO	114	Volvo EDC7 Allspeed KWP2000
	ESM	YES	YES	NO	NO	NO	NO	NO	NO	NO	NO	15	Waukesha ESM
Yanmar	TNV	NO	NO	YES	YES	YES	NO	NO	NO	YES	YES	89	Yanmar TNV

AGCO POWER

ECU Types

ECU Type	Engine Type
EEM4	All Offroad, marine, land generating engines

EEM4



ECU selection in PC software:

AGCO Power EEM4

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Start Request <small>*1*2*3*4*5*6</small>	The command used for engine running. The recommended source value for this command is Fuel solenoid.
Stop Request <small>*1*2*3*4*5*6</small>	The command stops the running engine. The recommended source value for this command is stop pulse.
ECU analog outputs (controller's inputs)	
Ambient Air Temperature	Temperature of air surrounding vehicle
Cytalyst Tank Temperature	Temperature of the diesel exhaust fluid in the storage tank
DEF Tank 1 Level	Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container
DEF tank level lamp	For more information about, please contact local AGCO Power engine representative
SCR Act. dosing reagent quality	Quantity of diesel exhausts fluid in the aftertreatment system
SCR Dosing Reagent Abs. Press	The diesel exhaust fluid doser absolute pressure for aftertreatment system

SCR system state	<ul style="list-style-type: none"> 0 - Dormant (sleep mode) 1 - Preparing dosing readiness (wake up; prepare to operate; wait for start) 2 - Normal dosing operation 3 - System error pending 4 - Reserved for future assignment by SAE 5 - Protect mode against heat (pressure buildup) 6 - Protect mode against cold (defreeze) 7 - Shutoff (wait for afterrun) 8 - Diagnosis (afterrun) 9 - Service test mode, dosing allowed 10 - Service test mode, dosing not allowed 11 – 13 - Reserved for future assignment by SAE 14 - Error 15 - Not available
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Droop percentage request	Droop percentage request
Engine high idle switch	<ul style="list-style-type: none"> 0 - Normal high idle 1 - Alternative high idle selection 1 2 - Alternative high idle selection 2 3 – Not available
Engine low idle switch	<ul style="list-style-type: none"> 0 - Normal low idle 1 - Alternative low idle selection1 2 - Alternative low idle selection2 3 - Not available
Alternative high idle selection	<ul style="list-style-type: none"> 0 - Normal high idle 1 - Alternative high idle selection1 2 - Alternative high idle selection2 3 - Not available
Alternative low idle selection	<ul style="list-style-type: none"> 0 - Normal low idle 1 - Alternative low idle selection1 2 - Alternative low idle selection2 3 - Not available
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Recommended wiring



Function	ECU "K" connector	62 pin connector (837074045)	Controller
CAN H	54	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	C	CAN1 (extension modules/J1939) – CAN COM
CAN L	76	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	01, 03, 05	N/A	
Battery - (negative)	02, 04, 06	N/A	
Key Switch	88	N/A	
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Caterpillar

ECU Types

ECU Type	Engine Type
EMCP2 + CCM	35xx
EMCP2+PL1000	35xx, C9
ADEM A3 & EMCP / ADEM A4 & EMCP	34xx, C series
ADEM A3 / ADEM A4	C series
ADEM II is not supported !	

EMCP2 + CCM



Configuration

NOTE:

For connection to CAT CCM module it is necessary to use an I-CB module. Configuration of the controller and I-CB has to be done separately using GenConfig or DriveConfig and ICBEEdit software. For further information see I-CB [manual](#).


ECU selection in PC software:

Diesel	Gas
Legacy I-CB/CAT-Diesel / ICB module + I/O modules	Legacy I-CB/CAT-Gas / ICB module + I/O modules

Available commands


For more information about available values and signals, please refer to I-CB [manual](#) or ICBEEdit PC software.

Recommended wiring



WARNING!
Please check that CAN bus terminating resistors or appropriate jumpers are connected.

EMCP2 + PL1000



Configuration

NOTE:

For connection to CAT PL1000 module it is necessary to use an I-CB module. Configuration of the controller and I-CB has to be done separately using GenConfig or DriveConfig and ICBEEdit software. For further information see I-CB [manual](#).


ECU selection in PC software:

Diesel	Gas
Legacy I-CB/CAT-Diesel / ICB module + I/O modules	Legacy I-CB/CAT-Gas / ICB module + I/O modules

Available commands

For more information about available values and signals, please refer to I-CB [manual](#).


Recommended wiring of PL1000E or PL1000T



WARNING!

Please check that CAN bus terminating resistors or appropriate jumpers are connected.

ADEM A4 with EMCP3.x or ADEM A4 with EMCP4.x



NOTE:

The configuration and connection is the same on the gen-set equipped with ADEM A4 (ECU) and EMCP 3.x or EMCP 4.x (generator set controller). The ADEM 4.x is the successor of the ADEM 3.x.

ECU selection in PC software:

Caterpillar ADEM&EMCP

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Amber Warning Lamp EMCP	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped. This signal comes from EMCP panel.
Malfunction Lamp EMCP	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active. This signal comes from EMCP panel.
Protect Lamp EMCP	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related. This signal comes from EMCP panel.
Red Stop Lamp EMCP	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine. This signal comes from EMCP panel.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Gas Supply Pressure	Gage pressure of gas supply to fuel metering device.
Air Inlet Temperature	Temperature of air entering vehicle.
Barometric Pressure	Absolute air pressure of the atmosphere.
Alternator Bearing 1 Temperature	Temperature of the left/rear bearing inside the alternator.
Alternator Bearing 2 Temperature	Temperature of the right/front bearing inside the alternator.
Alternator Winding 1	Temperature of the windings inside the alternator.

Temperature	
Alternator Winding 2 Temperature	Temperature of the windings inside the alternator.
Alternator Winding 3 Temperature	Temperature of the windings inside the alternator.
Fuel Filter Diff.Press	Change in fuel delivery pressure, measured across the filter, due to accumulation of solid or semisolid matter on the filter element.
Oil Filter Diff.Press	Change in engine oil pressure, measured across the filter, due to the filter and any accumulation of solid or semisolid material on or in the filter.
Auxiliary Coolant Pressure	Gage pressure of coolant found in the intercooler located after the turbocharger.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Startup Mode	<ul style="list-style-type: none"> 0 - start not requested 1 - starter active, gear not engaged 2 - starter active, gear engaged 3 - start finished 4 - starter inhibited due to engine already running 5 - starter inhibited due to engine not ready for start 6 - starter inhibited due to driveline engaged or other transmission inhibit 7 - starter inhibited due to active immobilizer 8 - starter inhibited due to starter over-temp 9 -11 - reserved 12 - starter inhibited 13,14 - error (legacy implementation only, use 1110) 15 - not available
Engine speed EMCP	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders. Signal received from EMCP controller.
Accelerator Pedal Position 1	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
DesiredOpSpd	An indication by the engine of the optimal operating speed of the engine for the current
Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Change in fuel delivery pressure, measured across the filter, due to accumulation of solid or semisolid matter on the filter element
Engine Oil Pressure EMCP	Gage pressure of oil in engine lubrication system as provided by oil pump. Signal received from EMCP controller.
Fuel Delivery Pressure EMCP	Change in fuel delivery pressure, measured across the filter, due to accumulation of solid or semisolid matter on the filter element. Signal received from EMCP controller.
Fuel Filter Intake Abs Pressure	Absolute pressure of fuel at the intake of the fuel filter.
Pre-filter Oil Pressure	Gage pressure of the engine oil before the oil reaches the oil filter.
Exhaust Gas Port 1 Temp - Exhaust Gas Port 16 Temp	Temperature at the cylinder exhausts port of the engine.
Exhaust Gas Temp - Left Manifold	Temperature of combustion exhausts within the left engine exhaust manifold.
Exhaust Gas Temp - Right Manifold	Temperature of combustion exhausts within the right engine exhaust manifold.
Coolant Temp	Temperature of liquid found in engine cooling system.
Fuel Temp	Temperature of fuel entering injectors.
IntercoolTemp	Temperature of liquid found in the intercooler located after the turbocharger.
Oil Temperature	Temperature of the engine lubricant.
Coolant Temp EMCP	Temperature of liquid found in engine cooling system. Signal received from EMCP controller.
Fuel Temp EMCP	Temperature of fuel entering injectors. Signal received from EMCP controller.
Fuel Temperature 2	Temperature of the fuel.
Air Filter Differential Pressure	Change in engine air system pressure, measured across the filter, due to the filter and any

	accumulation of solid foreign matter on or in the filter. This is the measurement of the first filter in a multiple air filter system.
Air Inlet Pressure	Absolute air pressure at input port to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Air Filter 2 Differential Press	Change in engine air system pressure, measured across air filter 2.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Turbo 1 Inlet Pressure	Gage pressure of the air entering the compressor side of the turbocharger 1.
Turbo 2 Inlet Pressure	Gage pressure of the air entering the compressor side of the turbocharger 2.
Turbocharger 1 Intake Temp	Temperature of the combustion entering the turbine side of the turbocharger 1.
Turbocharger 2 Intake Temp	Temperature of the combustion entering the turbine side of the turbocharger 2.
Battery Potential (Voltage)	Measured electrical potential of the battery.
Electrical Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Battery Potential (Voltage) EMCP	Measured electrical potential of the battery. Signal received from EMCP controller.
Electrical Potential (Voltage) EMCP	Electrical potential measured at the input of the electronic control unit supplied through a switching device. Signal received from EMCP controller.
ECU analog inputs (controller's outputs)	

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

WARNING!

Speed control can be done by using PWM from the controller (SG interface) to the ADEM. PWM rate for InteliGen-NT or InteliSys-NT controller has to be set to 500Hz. See the SpdGovPWM rate setpoint in the Sync/Load ctrl group of setpoints. This feature has to be enabled in the ECU. Please contact your local distributor to check it.

Start/Stop command can be configured as Remote Start/Stop EMCP input. Use ECU PwrRelay controller output for this purpose.


Recommended wiring

Function	ECU 70pin AMP connector	9pin diagnostic connector	Controller
CAN H	50	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	42	C	CAN1 (extension modules/J1939) – CAN COM
CAN L	34	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	48,52,53,55	N/A	N/A
Battery - (negative)	61,63,65,69	N/A	N/A
Key Switch	70	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	66 (38-S-SPD*)	N/A	SG OUT
Analog Speed Control	68 (39-D-SPD*)	N/A	SG COM

* Caterpillar PWM speed control terminal

Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

ADEM



ECU selection in PC software for ADEM

Caterpillar J1939

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Alternator Potential (Voltage)	Electrical potential measured at the alternator output.
AuxPress	Temperature measured by auxiliary temperature sensor #1
AuxTemp	Pressure measured by auxiliary pressure sensor #1
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Coolant Temp	Temperature of liquid found in engine cooling system.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Fuel Filter Diff.Press	Change in fuel delivery pressure, measured across the filter, due to accumulation of solid or semisolid matter on the filter element.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Fuel Temp	Temperature of fuel entering injectors.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Left Exhaust Temp	Temperature of the combustion by-products entering the turbine side of the turbocharger.

Oil Filter Diff.Press	Change in engine oil pressure, measured across the filter, due to the filter and any accumulation of solid or semisolid material on or in the filter.
Oil Temperature	Temperature of the engine lubricant
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Right Exhaust Temp	Temperature of the combustion by-products entering the turbine side of the turbocharger.
ECU analog inputs (controller's outputs)	
Requested Speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU 70pin AMP connector	9pin diagnostic connector	Controller
CAN H	50	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	42	C	CAN1 (extension modules/J1939) – CAN COM
CAN L	34	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	48,52,53,55	N/A	N/A
Battery - (negative)	61,63,65,69	N/A	N/A
Key Switch	70	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	66 (38-S-SPD*)	N/A	SG OUT
Analog Speed Control	68 (39-D-SPD*)	N/A	SG COM

* Caterpillar PWM speed control terminal

Diagnostic connector layout is on page 16 or [here](#).

NOTE:


In case of **Marine** application the settings of the ECU has to be set to "Startboard". It changes the ECU address to 0 which is expected by the ComAp controller. Settings "Port" uses an address 1 and is not allowed.

Cummins

ECU Types

ECU Type	Engine type
CM500	Industrial engines QSK19, QSK23, QSK45, QSK60, QSK78,
CM558	Gas engines, QST30 (slave ECU)
CM570 (CM876)	Tier2/Tier3 > QSM11, QSX15, ISM 400, ISM 435
CM800	ISB, ISBe
CM850	Tier3 > QSL9, QSB5/7, QSK38, QSK19, QST30, QSK50/60
PGI 1.1 (CM850,CM2150,CM2250)	Tier4i > QSB7 and QSL9 Tier 2 > QSK50/60, QSK19, QSK38 MCRS Tier 3 > QSB5, QSB7, QSL9, QSM11
CM2350	Tier4 QSB6.7, QSL9, QSX15, QSF3.8, QSB4.5, QSG12
CM2250	Industrial engines (ISX, ISB series)
GCS	Tier2 > QSK23, QSK45/60/78, QST30

CM500



ECU selection in PC software:

Cummins CM500

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
AP low idle switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Water In Fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	

ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Air Inlet Temperature	Temperature of air entering air induction system.
AP Position	The ratio of actual position of the analog engine speed/torque request input device (such as an accelerator pedal or throttle lever) to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Barometric Pressure	Absolute air pressure of the atmosphere.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Coolant Temp	Temperature of liquid found in engine cooling system.
Demand Torque	The requested torque output of the engine by the torque controller.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Fuel Temp	Temperature of fuel entering injectors.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Oil Temp	Temperature of the engine lubricant.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
ECU analog inputs (controller's outputs)	
Requested Speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring


Function	ECU A2 connector	9pin diagnostic connector	Controller
CAN H	32	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	E	CAN1 (extension modules/J1939) – CAN COM
CAN L	33	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	3,4,5	B	N/A
Battery - (negative)	7,8	A	N/A
Key Switch	10	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

CM558

NOTE:

Support of this ECU is so far done for engines where CM558 is a standalone module not as a part of the gas genset system with master unit CM700 and other components.



ECU selection in PC software:

Cummins CM558

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Engine Fuel Shutoff 1 Control	For more information about, please contact local Cummins engine representative.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp123456	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Aftertreat1 ExhGas Temp 1	The reading from the exhaust gas temperature sensor located farthest upstream in the aftertreatment system in exhaust bank 1.
Aftertreat1 ExhGas Temp 2	The reading from the exhaust gas temperature sensor located midstream of the other two temperature sensors in the in the aftertreatment system in exhaust bank 1.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Barometric Pressure	Absolute air pressure of the atmosphere.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Engine Throttle Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
EngineOil Temp	Temperature of the engine lubricant.
EngTemp	Temperature of liquid found in engine cooling system.

Fuel Actuator 1 Command	The control command to fuel actuator 1, normalized to percent, where 0% represents fully close and 100% represents fully open. Typically, this fuel actuator is used to regulate low pressure natural gas flow rate, mixing into the air flow, which together then come into the engine.
Fuel Valve 1 Position	The position of a gaseous fuel valve that is metering the fuel flow to the engine. 0% indicates no fuel flow through valve and 100% mean maximum fuel flow through value.
Intake Manif. Absolute Press	The absolute pressure measured of the air intake manifold. If there are multiple air pressure sensors in the intake stream, this is the last one in flow direction before entering the combustion chamber.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
T-ECU	Temperature of the engine electronic control unit.
Throttle Actuator 1 Command	The control command to throttle actuator 1, normalized to percent, where 0% represents fully close and 100% represents fully open. Typically, this throttle actuator is used to regulate air or air / fuel mix to the engine.
ECU analog inputs (controller's outputs)	

Controller's analog output for speed control configuration


There is no speed control over CAN bus available for this particular ECU.

Recommended wiring

No documentation available so far!

Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

CM570



ECU selection in PC software:

Cummins CM570

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
PTO VarSpdSw	Switch signal which indicates that the remote PTO toggle switch is in the enabled (ON) position. If the toggle switch is enabled and other conditions are satisfied then the remote PTO control feature is activated and the PTO will control at a variable speed.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
Water in fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
Emergency Stop Indication <small>*1*2*3*4</small>	The command which should be used for normal shutdown and Emergency Stop is implemented by providing a normally-closed signal. The ECU will react in a manner as to disable fuel flow to the engine any time the command is active. The ECU will power down and stop the communication and broadcast of J1939 messages when the engine reaches 0 RPM. The recommended source value for this command is Logical 0.
Idle/Rated <small>*1*2*3*4</small>	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.
Run/Stop123456 <small>*1*2*3*4*5*6</small>	The command used for engine running. On the occasion of loss of datalink, the engine will not shut down as it is looking for the initial 'run' command and will only shutdown if it was sent 'stop' or if it experienced a shutdown fault. The recommended source value for this command is Fuel solenoid.
Utility/Isochronous Gain Select <small>*1*2*3*4</small>	Please contact Cummins representative for further information about this command. The recommended source value for this command is Logical 0.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Temp	Temperature of liquid found in engine cooling system.
DesiredOpSpd	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.

Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
ECU analog inputs (controller's outputs)	
Frequency Selection *1*2*3*4*5	This feature gives the operator ability to switch the rated speed between 50Hz and 60Hz. This feature will only be enabled and functional on engines that have been rated for dual speed operations. The engine has two speed set points that define the base operating speed of the engine. The system will only react to a state transition while the Engine speed is 0. If datalink is lost during operation the alternate frequency will not be effected until engine reaches 0 RPM. The recommended source value is a constant following the requested function.
Requested Speed (TSC1) *3*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active. This value is available only on ECU with non G-Drive calibration.
Speed Bias Reference *1*2*3*4*5*6	Speed bias provides the means to adjust the engine speed set point while the engine is running. It is used for synchronization with the power grid. Once synchronized and paralleled with other power sources the speed bias is used to make the gen-set and engine pick up or shed load. In the case of using speed bias to pick up and shed load the commanded engine speed does change, but the actual engine speed does not change.
Shutdown Override *1*2*3*4*5*6	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown. The recommended source value is a constant following the requested function.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Speed Bias Reference settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpdRegOut	
Convert	Yes	
Limits	-10.000 V	-10 %
	10.000 V	10 %
Speed Bias Reference settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	-10 %
	100.0 %	10 %

Frequency Selection	Source Value
50 Hz	0
60 Hz	1
Reserved	2 - 5
Error	6
Do not care	7

Shutdown override values meaning

Shutdown Override	Source Value
No shutdown override	0
Start block override	1
General shutdown override	2
All shutdown override	3
Error	4 -6
Don't care	7

NOTE:

If you have bought the engine as a part of gen-set package (with PCC panel) the ECU might be delivered with different communication interface (not PGI) which means that speed control doesn't work with ComAp controller. It is necessary to use/order ECU software with calibration for G-drive engines (with PGI).

Recommended wiring


Function	ECU C-01 50pin connector	9pin diagnostic connector	Controller
CAN H	46	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	37	E	CAN1 (extension modules/J1939) – CAN COM
CAN L	36	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	7,8,17,18,28	B	N/A
Battery - (negative)	29,30,39,40,50	A	N/A
Key Switch	38	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

Table of supported ECU calibration

Engine type	ECU calibration
QSX15-G4	N 11959.01
QSX15-G6	N 11960.01
QSX15-G7	N 11961.01
QSX15-G8	N 11962.01 N 11962.05 N12013.00
QSX15-G9	N 11963.01
ISM	L 21103.10

CM800



ECU selection in PC software:

Cummins CM800

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
PTO VarSPdSw	Switch signal which indicates that the remote PTO toggle switch is in the enabled (ON) position. If the toggle switch is enabled and other conditions are satisfied then the remote PTO control feature is activated and the PTO will control at a variable speed.
Water In Fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
Run/Stop <small>*1*2*3*4*5*6</small>	The command used for engine running. On the occasion of loss of datalink, the engine will not shut down as it is looking for the initial 'run' command and will only shutdown if it was sent 'stop' or if it experienced a shutdown fault. The recommended source value for this command is Fuel solenoid.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Temp	Temperature of liquid found in engine cooling system.
DesiredOpSpd	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
ECU analog inputs (controller's outputs)	
Requested Speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Shutdown Override <small>*1*2*3*4*5*6</small>	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown. The recommended source value is a constant following the requested function.
--	--

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Controller’s analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Shutdown override values meaning

Shutdown Override	Source Value
No shutdown override	0
Start block override	1
General shutdown override	2
All shutdown override	3
Error	4 -6
Don't care	7

Recommended wiring


Function	ECU 40pin top connector	3pin diagnostic connector	Controller
CAN H	53	2	CAN1 (extension modules/J1939) – CAN H
CAN COM	51	3	CAN1 (extension modules/J1939) – CAN COM
CAN L	52	1	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1,7,12,13	N/A	N/A
Battery - (negative)	3,9,14,15	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

Table of supported ECU calibration

Engine type	G-Drive ECU calibration
6ISBe	90132.05

CM850



ECU selection in PC software:



Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
PTO VarSpdSw	Switch signal which indicates that the remote PTO toggle switch is in the enabled (ON) position. If the toggle switch is enabled and other conditions are satisfied then the remote PTO control feature is activated and the PTO will control at a variable speed.
Red Stop Lamp123456	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Water in fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
Engine Auxiliary Shutdown Switch *5*6	Switch signal requests that engine fueling stop.
Idle/Rated *1*2*3*4	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.
Run/Stop *1*2*3*4*5*6	The command used for engine running. On the occasion of loss of datalink, the engine will not shut down as it is looking for the initial 'run' command and will only shutdown if it was sent 'stop' or if it experienced a shutdown fault. The recommended source value for this command is Fuel solenoid.
Shutdown Override *1*2*3*4*5*6	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown. The recommended source value for this command is Logical 0.
Shutdown Override CC *4	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown.
ECU analog outputs (controller's inputs)	
Auxiliary Pressure #1	Pressure measured by auxiliary pressure sensor 1.
Barometric Pressure	Absolute air pressure of the atmosphere.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Temp	Temperature of liquid found in engine cooling system.
DesiredOpSpd	An indication by the engine of the optimal operating speed of the engine for the current existing

	conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Electrical Potential	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Engine Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Engine Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
EngineOil Temp	Temperature of the engine lubricant.
Exhaust Gas Port 1 Temp - Exhaust Gas Port 16 Temp	Temperature at the cylinder exhausts port of the engine.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Exhaust Gas Temperature - Left Manifold	Temperature of combustion exhausts within the left engine exhaust manifold.
Exhaust Gas Temperature - Right Manifold	Temperature of combustion exhausts within the right engine exhaust manifold.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Fuel Temp	Temperature of fuel (gas) passing through the first fuel control system.
Inj. Timing Rail 1 Pressure	Gage pressure of fuel in the timing rail delivered from the supply pump to the injector timing intake.
Intake Manifold 2 Temperature - Intake Manifold 6 Temperature	Temperature of pre-combustion air in intake manifold of engine air supply system.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Intercooler Temp	Temperature of liquid found in the intercooler located after the turbocharger.
Intercooler Thermostat Opening	The current position of the thermostat used to regulate the temperature of the engine intercooler. A value of 0% represents the thermostat being completely closed.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Pre-filter Oil Pressure	Gage pressure of the engine oil before the oil reaches the oil filter.
Turbo Oil Temp	Temperature of the turbocharger lubricant.
Turbocharger 1 Boost Pressure - Turbocharger 4 Boost Pressure	Gage pressure of air measured of the compressor discharge side of the turbocharger.
ECU analog inputs (controller's outputs)	
Frequency Selection <small>*1*2*3*4*5</small>	This feature gives the operator ability to switch the rated speed between 50Hz and 60Hz. This feature will only be enabled and functional on engines that have been rated for dual speed operations. The engine has two speed set points that define the base operating speed of the engine. The system will only react to a state transition while the Engine speed is 0. If datalink is lost during operation the alternate frequency will not be effected until engine reaches 0 RPM. The recommended source value is a constant following the requested function. 0 – 50Hz 1 – 60Hz 2-5 – reserved 6 – error 7 – do not care
Governor Gain Adjustment	For service purpose only! Default value is 5 (20480 _{Dec} or 5000 _{Hex})
Requested speed (TSC1) <small>*3*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
Speed Bias Reference	Speed bias provides the means to adjust the engine speed set point while the engine is running. It is

*1*2*3*4*5	used for synchronization with the power grid. Once synchronized and paralleled with other power sources the speed bias is used to make the gen-set and engine pick up or shed load. In the case of using speed bias to pick up and shed load the commanded engine speed does change, but the actual engine speed does not change.
------------	---

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Speed Bias Reference settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpdRegOut	
Convert	Yes	
Limits	-10.000 V	-10 %
	10.000 V	10 %
Speed Bias Reference settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	-10 %
	100.0 %	10 %

Recommended wiring

Function	ECU J2 50pin connector	9pin diagnostic connector	Controller
CAN H	46	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	37	E	CAN1 (extension modules/J1939) – CAN COM
CAN L	47	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	B	N/A
Battery - (negative)	?	A	N/A
Key Switch	39	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM



Diagnostic connector layout is on page 16 or [here](#).

Table of supported ECU calibration

Engine type	G-Drive ECU calibration
Engine QSB7-G	AZ 90084.02
Engine QSL9	AZ90059.15
	AZ 90105.04
	AZ 90056.02
	AZ 90041.05 (analog speed control)

Engine type	Industrial ECU calibration
Engine QSK38	AQ 60186.98
	AQ 60176.01

PGI 1.1 interface (CM850 or CM2150 or CM2250)



ECU selection in PC software:

Cummins CM850/CM2150/CM2250

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
DPF Act. Reg. Inhibit Status	Indicates the state of diesel particulate filter active regeneration inhibition.
DPF ActRegInhibitDueTo InhSw	Indicates the state of diesel particulate filter active regeneration inhibition due to the diesel particulate filter regeneration inhibit switch.
DPF ActRegInhibNot WarmUp	Indicates the state of diesel particulate filter active regeneration inhibition due to engine not warmed up.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
Water in fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
DPF Reg.Force Switch <small>*1*2*3*4</small>	Indicates the state of a switch available to the operator that forces diesel particulate filter regeneration. The recommended source should follow the requested function.
DPF Reg.Inhibit Switch <small>*1*2*3*4</small>	Indicates the state of a switch available to the operator that inhibits diesel particulate filter regeneration. The recommended source should follow the requested function.
Idle/Rated <small>*1*2*3*4</small>	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.
Shutdown Override <small>*1*2*3*4</small>	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown. The recommended source value for this command is Logical 0.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Temp	Temperature of liquid found in engine cooling system.
DEF Tank 1 Low Level Indicator	The desired illumination of the driver's warning indicator for diesel exhaust fluid (DEF) tank low level.
DPF Lamp Command	Value used for Tier4 icon control.
DPF Status	Value used for Tier4 icon control.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine Oil Temp	Temperature of the engine lubricant.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by

	the number of cylinders.
Exhaust Gas Temp	Temperature of combustion exhausts byproducts leaving the engine.
Fuel Rate ¹²³⁴	Amount of fuel consumed by engine per unit of time.
HEST Lamp Command	Command to control the exhaust system high temperature lamp. This lamp indicates that the exhaust system temperature is high.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Interface Version1	For more information about, please contact local Cummins representative.
Interface Version2	For more information about, please contact local Cummins representative.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
ECU analog inputs (controller's outputs)	
Frequency Selection ^{*1*2*3*4*5}	This feature gives the operator ability to switch the rated speed between 50Hz and 60Hz. This feature will only be enabled and functional on engines that have been rated for dual speed operations. The engine has two speed set points that define the base operating speed of the engine. The system will only react to a state transition while the Engine speed is 0. If datalink is lost during operation the alternate frequency will not be effected until engine reaches 0 RPM. The recommended source value is a constant following the requested function. 0 – 50Hz 1 – 60Hz 2-5 – reserved 6 – error 7 – do not care
Generator Governing Bias ^{*1*2*3*4*5}	Speed bias provides the means to adjust the engine speed set point while the engine is running. It is used for synchronization with the power grid. Once synchronized and paralleled with other power sources the speed bias is used to make the gen-set and engine pick up or shed load. In the case of using speed bias to pick up and shed load the commanded engine speed does change, but the actual engine speed does not change.
Speed Bias Reference ^{*5}	Speed bias provides the means to adjust the engine speed set point while the engine is running. It is used for synchronization with the power grid. Once synchronized and paralleled with other power sources the speed bias is used to make the gen-set and engine pick up or shed load. In the case of using speed bias to pick up and shed load the commanded engine speed does change, but the actual engine speed does not change.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Generator Governing Bias settings for IntelliGen^{NT} or IntelliSys^{NT}		
Source	SpdRegOut	
Convert	Yes	
Limits	-10.000 V	-10 %
	10.000 V	10 %
Generator Governing Bias settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	-10 %
	100.0 %	10 %

NOTE:


If you have bought the engine as a part of gen-set package (with PCC panel) the ECU might be delivered with different communication interface (not PGI) which means that speed control doesn't work with ComAp controller. It is necessary to use/order ECU software with calibration for G-drive engines (with PGI).

Recommended wiring

Function	ECU J2 50pin connector	9pin diagnostic connector	Controller
CAN H	46	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	37	E	CAN1 (extension modules/J1939) – CAN COM
CAN L	47	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	B	N/A
Battery - (negative)	?	A	N/A
Key Switch	39	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

CM2250 industrial



ECU selection in PC software:

Cummins CM2250

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
DPF ActRegInhib NotWarmUp	Indicates the state of diesel particulate filter active regeneration inhibition due to engine not warmed up.
DPF ActRegInhibit DueToInhSw	Indicates the state of diesel particulate filter active regeneration inhibition due to the diesel particulate filter regeneration inhibit switch.
DPF Act. Reg. Inhibit Status	Indicates the state of diesel particulate filter active regeneration inhibition.
Water in fuel	Signal which indicates the presence of water in the fuel.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
DPFR Inhibit Switch *1*2*3*4*	Indicates the state of a switch available to the operator that inhibits diesel particulate filter regeneration. The recommended source should follow the requested function.
DPFR Force Switch *1*2*3*4	Indicates the state of a switch available to the operator that forces diesel particulate filter regeneration. The recommended source should follow the requested function.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Coolant Temp	Temperature of liquid found in engine cooling system.
DEF Tank 1 Low Level Indicator	The desired illumination of the driver's warning indicator for diesel exhaust fluid (DEF) tank low level.
DPF Lamp Command	Value used for Tier4 icon control.
DPF Status	Value used for Tier4 icon control.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.

Engine torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
HEST Lamp Command	Command to control the exhaust system high temperature lamp. This lamp indicates that the exhaust system temperature is high.
Intake Manifold Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.

ECU analog inputs (controller's outputs)

Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Requested Speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration



Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU connector	9pin diagnostic connector	Controller
CAN H	?	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	E	CAN1 (extension modules/J1939) – CAN COM
CAN L	?	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	B	N/A
Battery - (negative)	?	A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

GCS



ECU selection in PC software:

Cummins Modbus

Available signals

ECU binary outputs (controller's inputs)	
Fuel Shut-Off Valve Driver State	Is reporting a fuel Shut-Off Valve output.
Red Shutdown Lamp	It warrants stopping the engine.
Run/Stop Switch State	The command used for engine running. On the occasion of loss of datalink, the engine will not shut down as it is looking for the initial 'run' command and will only shutdown if it was sent 'stop' or if it experienced a shutdown fault. The recommended source value for this command is Fuel solenoid.
Yellow Warning Lamp	Is reporting a problem with the engine system but the engine need not be immediately stopped.
ECU binary inputs (controller's outputs - commands)	
Fault Acknowledge	Switch signal which indicates the position of the fault acknowledge switch. This switch function allows the operator to acknowledge faults of the engine. The recommended source value for this command is Logical 0.
Shutdown Override	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown. The recommended source value for this command is Logical 0.
ECU analog outputs (controller's inputs)	
Engine Speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Coolant Temp	Temperature of liquid found in engine cooling system.
Oil Pressure QSK23/45/60/78	Gage pressure of oil in engine lubrication system as provided by oil pump.
Oil Pressure QST30, QSX15	Gage pressure of oil in engine lubrication system as provided by oil pump.
Frequency Adjust Pot	A signal output is provided to read the generator set frequency. The frequency is adjustable within ± 3 Hz of the rated operating frequency.
Running Time	Accumulated time of operation of engine.
Final Speed Reference	Please contact Cummins representative for further information about this value.
+/- 2,5V Speed Bias	This speed bias signal is provided as feedback from compatible speed governing and load share controller.
Fuel Rate (UK)	Amount of fuel consumed by engine per unit of time.
Fuel Rate (US)	Amount of fuel consumed by engine per unit of time.
Intake Manif. Press (QSX15)	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Intake Manif. Temp (QSX15)	Temperature of pre-combustion air found in intake manifold of engine air supply system.

Oil Temperature (QSX15)	Temperature of the engine lubricant.
Intake Manif. Press (QSKxx)	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Intake Manif. Temp (QSKxx)	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Pump Pressure (QSKxx)	Please contact Cummins representative for further information about this value.
Fuel Rail Pressure (QSKxx)	Please contact Cummins representative for further information about this value.
Fuel Inlet Temperature (QSKxx)	Temperature of fuel entering injectors.
Timing Rail Pressure (QSKxx)	Please contact Cummins representative for further information about this value.
Intake Manif. Press L (QST30)	Gage pressure of air measured downstream on the left compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Intake Manif. Press R (QST30)	Gage pressure of air measured downstream on the right compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Intake Manif. Temp L (QST30)	Temperature of pre-combustion air found in intake manifold of engine left air supply system.
Intake Manif. Temp R (QST30)	Temperature of pre-combustion air found in intake manifold of engine right air supply system.
Oil Temperature (QST30)	Temperature of the engine lubricant.
ECU analog inputs (controller's outputs)	

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration


There is no speed control over CAN bus available for this particular ECU.

Recommended wiring

Function	ECU 25pin D6 connector	9pin diagnostic connector	Controller
RS485 A	21	N/A	RS485 – RS485 A
RS485 COM	?	N/A	RS485 – RS485 COM
RS485 B	18	N/A	RS485 – RS485 B
Battery + (positive)	?	N/A	N/A
Battery - (negative)	?	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Service Mode Enable	19 and 22	N/A	Loop
Function	ECU 25pin D3 connector	9pin diagnostic connector	Controller
Analog Speed Control*	11	N/A	SG OUT
Analog Speed Control	12	N/A	SG COM
Analog Speed Control Shield	20		N/A

*Analog Speed Control range 2.5VDC – 7.5VDC

Recommended wiring



NOTE:

In case that the GCS doesn't communicate try to activate input Diagnostic mode (pin 07 on connector D6).

Controller recommended setting (Setpoints/Comms settings group)

Controller	Setpoint	Value	Interface (Connector)
InteliGen ^{NT}	RS232(1) mode	ECU LINK	
	RS232(2) mode	ECU LINK	
InteliSys ^{NT}	RS485(X)conv.	ENABLED DISABLED	RS 485(1), RS 485(2) RS 232(1) * ³ , RS 232(2) * ³
	RS232(2) mode	ECU LINK	
InteliLite ^{NT}	RS485(X)conv.	ENABLED DISABLED	RS 485(2) RS 232(1) * ³ , RS 232(2) * ³
	COM2 Mode	ECU LINK	RS 485 * ²
InteliCompact ^{NT}	COM2 Mode	ECU LINK	RS 485 * ²
InteliDrive DCU * ⁴	RS485 Mode	ECU LINK	RS 485 * ³
InteliDrive Mobile * ⁴	RS485 Mode	ECU LINK	RS 485 pin 85(A), pin 87(B), pin 86(COM)
InteliDrive Lite	COM2 Mode	ECU LINK	RS 485 * ²

*² IL-NT RS232-485 communication module is required

*³ external RS232-485 converter is required

*⁴ Setpoints/Basic setpoints group


Available list of texts of fault codes is [here](#).

DaimlerChrysler

ECU Types

ECU Type	Engine type
ADM2	500, 900, 450
ADM3	500, 900, 450

ADM2



ECU selection in PC software:

DaimlerChrysler ADM2

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
ECU binary inputs (controller's outputs - commands)	
Engine start <small>*1*2*3*4*5*6</small>	The command used for engine start. The recommended source value for this command is Fuel solenoid.
Inhibit engine start	The command used for engine start inhibits. The recommended source value for this command is Logical 0.
Inhibit fuel injection <small>*1*2*3*4*5*6</small>	The command used for engine fuel injection inhibits. The recommended source value for this command is Logical 0.
Engine overspeed enable	For more information about these commands, please contact the local Cummins representative.
TorqueConvLockup Engaged	
ECU analog outputs (controller's inputs)	

Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Temp	Temperature of liquid found in engine cooling system.
Demand Torque	The requested torque output of the engine by the driver.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
ECU analog inputs (controller's outputs)	
Output shaft speed	If the speed signal Engine speed is not available, the Transmission output shaft speed can also be used to generate speed information.
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen^{NT} or InteliSys^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU 21pin connector	9pin diagnostic connector	Controller
CAN H	19	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	20	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	21	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1	N/A	N/A
Battery - (negative)	3	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

ADM3

ECU selection in PC software:

DaimlerChrysler ADM3

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
ECU binary inputs (controller's outputs - commands)	
Engine start	The command used for engine start. The recommended source value for this command is Fuel solenoid.
Inhibit engine start	The command used for engine start inhibits. The recommended source value for this command is Logical 0.
Inhibit fuel injection	The command used for engine fuel injection inhibits. The recommended source value for this command is Logical 0.
Engine overspeed enable	For more information about these commands, please contact the local Daimler/MTU representative.
TorqueConvLockup Engaged	
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Software Version	For service purpose only!
ECU analog inputs (controller's outputs)	
Output shaft speed	If the speed signal Engine speed is not available, the Transmission output shaft speed can also be used to generate speed information.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU 21pin connector	9pin diagnostic connector	Controller
CAN H	19	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	20	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	21	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1	N/A	N/A
Battery - (negative)	3	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM


Diagnostic connector layout is on page 16 or [here](#).

Detroit Diesel

ECU Types

ECU Type	Engine type
DDEC IV	Series 50, 60
DDEC V	Series 60
DDEC 10	Series DD13, DD15, DD16

DDEC IV or DDEC V



ECU selection in PC software:

DDC DDEC IV/V

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an

	application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	6pin communication connector	9pin diagnostic connector	Controller
CAN H	F	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	D	E	CAN1 (extension modules/J1939) – CAN COM
CAN L	E	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	A	N/A
Battery - (negative)	?	B	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

Deutz

ECU Types


ECU Type	Engine Type
EMR2	10xx series
EMR3-E (EDC16, EDC7)	TCD 2012 4V TCD 2013 4V TCD 2015
EMR3-S (EDC16, EDC7)	TCD 2012 2V TCD 2013 2V TCD 2013 4V
EMR4 (EDC17CV52)	TCD 3.6 L4 TCD 4.1 L4 TCD 6.1 L6 TCD 7.8 L6 TCD 12 V6 TCD 16 V8
TEM Evolution	TBG 616/620/632 TCG 2016/2020/2032

Previous engine designation	New engine designation
TCD 20xx L04	TCD 2.9 L4
TCD 2010 L04	TCD 3.6 L4
TCD 2012 L04	TCD 4.1 L4
TCD 2012 L06	TCD 6.1 L6
TCD 2013 L06	TCD 7.8 L6
TCD 2015 V06	TCD 12 V6
TCD 2015 V08	TCD 16 V8

Engine type explanation

Engine Type	Meaning
Txxxxxx	Turbocharged
xCxxxxx	Charge air cooled
xxDxxxx	Diesel engine
xxx12xx	Displacement in liters
xxxxLx	L – in line engine, V – V-engine
Xxxxxx6	Number of cylinders

EMR2



ECU selection in PC software:

Deutz EMR2

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Lock status	The command activates the engine start. If set engine stops and engine start prohibition will be active. The recommended source value for this command is Logical 0.
Stop Request <small>*1*2*3*4*5*6</small>	The command stops the running engine. The recommended source value for this command is stop pulse.
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.

Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Software ID	For service purpose only!
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

WARNING!

Deutz does not recommend switching off the engine by removing the power supply (battery). It causes fault code SPN=536.

Recommended setting of EMR2 using Serdia PC tool:

NOTE:


- Page 30: 4400 = 1 ... CAN activation
- Page 31: 4412 = 1 ... Activate TSC1a receive telegram
- Page 31: 4470 = 1 ... Activate CAN set point by TSC1a
- Page 12: 4829 = 8... Enable stop request telegram
- Page 10: 4900 = 8 ... Selection of input channel type for nominal speed value sensor
- 829 = FunctEngineStop – Switch assignment for “Engine stop” function
- 4424 = TelStopRequestOn – SAEJ1939: Active Engine Stop Request receives telegram

Recommended wiring

Function	ECU 25pin F connector	9pin diagnostic connector	Controller
CAN H	12	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	13	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	14	N/A	N/A
Battery - (negative)	1	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

EMR3-E



ECU selection in PC software:

Deutz EMR3

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Lock status	The command activates the engine start. If set engine stops and engine start prohibition will be active. The recommended source value for this command is Logical 0.
Stop Request *1*2*3*4*5*6	The command stops the running engine. The recommended source value for this command is stop pulse.
Start Lock *4	As long as the start is forbidden, the value 1 has to be send. Sending the 0 will release the start lock. This value is used for normal operation with no start prohibition. It can not release a start prohibition which is caused by other sources, i.e. internal engine protection functions or other CAN bus messages. The recommended source value for this command is Logical 0.
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.

Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Software ID	For service purpose only!

ECU analog inputs (controller's outputs)	
Engine speed droop	Switch between internal droop1 and droop2. The recommended source value is a constant following the requested function.
High Idle Droop	Switch between internal high idle droop1 and high idle droop2. The recommended source value is a constant following the requested function.
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active. It is not allowed by Deutz to control speed over CAN bus on genset engines! Use pedal position input on ECU instead (see more details in Recommended wiring).
Torque Map	Switch between internal torque map1 and torque map0. The recommended source value is a constant following the requested function.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#).

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Torque Map values meaning

Value	Torque Map	Engine Speed Droop	High Idle Droop
0	no modification of torque map	no modification of droop	no modification of high idle droop
1	switch to torque map 1	selects droop 1	Selects high idle droop 1
2	switch to torque map 2	selects droop 2	selects high idle droop 2

Recommended wiring

Function	ECU D2 connector	diagnostic connector	Controller
CAN H	35	M	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	34	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	2,3,8,9 (klemme 30)	A	N/A
Battery - (negative)	5,6,10,11 (klemme	B	N/A

	31)		
Key Switch	40	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	79	N/A	SG OUT *
Analog Speed Control	78	N/A	SG COM

*Analog Speed Control range 0VDC to 5VDC, 100kOhm pull-down resistance

Diagnostic connector layout is on page 16 or [here](#).


WARNING!

It is not allowed by Deutz to control speed over CAN bus on gen-set engines! Use pedal position input on ECU instead. The SG OUT signal **MUST NOT** exceed the limits otherwise EMR3 blocks speed control via this input. Therefore it is recommended to keep the controller powered on always while the EMR3 is powered on (by Klemme 30). Or it is necessary to switch off this protection in EMR3.

NOTE:

EMR3-E has internal relay providing power supply to EMR3. As soon as the ignition key is turned off (Klemme 15) the main relay switches off the EMR3 within cca. 10 seconds. The main relay separates the EMR3 from the battery + (Klemme 30).

EMR3-S



ECU selection in PC software:

Deutz EMR3

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Lock status	The command activates the engine start. If set engine stops and engine start prohibition will be active. The recommended source value for this command is Logical 0.
Stop Request *1*2*3*4*5*6	The command stops the running engine. The recommended source value for this command is stop pulse.
Start Lock *4	As long as the start is forbidden, the value 1 has to be send. Sending the 0 will release the start lock. This value is used for normal operation with no start prohibition. It can not release a start prohibition which is caused by other sources, i.e. internal engine protection functions or other CAN bus messages. The recommended source value for this command is Logical 0.
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.

Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Software ID	For service purpose only!
ECU analog inputs (controller's outputs)	
Engine speed droop	Switch between internal droop1 and droop2. The recommended source value is a constant following the requested function.
High Idle Droop	Switch between internal high idle droop1 and high idle droop2. The recommended source value is a constant following the requested function.
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active. It is not allowed by Deutz to control speed over CAN bus on genset engines! Use pedal position input on ECU instead (see more details in Recommended wiring).
Torque Map	Switch between internal torque map1 and torque map0. The recommended source value is a constant following the requested function.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#).

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Torque Map values meaning

Value	Torque Map	Engine Speed Droop	High Idle Droop
0	no modification of torque map	no modification of droop	no modification of high idle droop
1	switch to torque map 1	selects droop 1	Selects high idle droop 1
2	switch to torque map 2	selects droop 2	selects high idle droop 2

Recommended wiring

Function	ECU D2 connector	diagnostic connector	Controller
CAN H	62	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	61	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1,3,5	N/A	N/A

Battery - (negative)	2,4,6	N/A	N/A
Key Switch	28	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	9	N/A	SG OUT
Analog Speed Control	30	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

WARNING!


It is not allowed by Deutz to control speed over CAN bus on gen-set engines! Use pedal position input on ECU instead.

The SG OUT signal MUST NOT exceed the limits otherwise EMR3 blocks speed control via this input. Therefore it is recommended to keep the controller powered on always while the EMR3 is powered on. Or it is necessary to switch off this protection in EMR3.

NOTE:

EMR3-E has internal relay providing power supply to EMR3. As soon as the ignition key is turned off the main relay switches off the EMR3 within cca. 10 seconds. The main relay separates the EMR3 from the battery +.

EMR4



ECU selection in PC software:

Deutz EMR4

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
DPF Active Regeneration	Indicates the state of diesel particulate filter active regeneration inhibition.
DPF ActRegInhibitDue ToInhSw	Indicates the state of diesel particulate filter active regeneration inhibition due to the diesel particulate filter regeneration inhibit switch.
DPF Inhibited Status	Indicates the state of diesel particulate filter active regeneration inhibition.
DPF Passive Regeneration	Indicates the state of diesel particulate filter passive regeneration.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
Bank 1 Exhaust Dew Point	Indicates that the temperature on the exhaust side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 1.
Bank 1 Intake Dew Point	Indicates that the temperature on the intake side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 1.
Bank 2 Exhaust Dew Point	Indicates that the temperature on the exhaust side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 2.
Bank 2 Intake Dew Point	Indicates that the temperature on the intake side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 2.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
DPF Regeneration Force1234	Indicates the state of a switch available to the operator that forces diesel particulate filter regeneration. The recommended source should follow the requested function.
DPF Regeneration Inhibit1234	Indicates the state of a switch available to the operator that inhibits diesel particulate filter regeneration. The recommended source should follow the requested function.
DPF Inhibit Command	Indicates the state of a switch available to the operator that inhibits diesel particulate filter regeneration.
DPF Regeneration Request	Indicates the state of a switch available to the operator that forces diesel particulate filter regeneration.
Start Lock EP	For more information about this signal contact local Deutz representative

Start Lock	As long as the start is forbidden, the value 1 has to be send. Sending the 0 will release the start lock. This value is used for normal operation with no start prohibition. It can not release a start prohibition which is caused by other sources, i.e. internal engine protection functions or other CAN bus messages. The recommended source value for this command is Logical 0.
Stop Request <small>*1*2*3*4*5*6</small>	The command stops the running engine. The recommended source value for this command is stop pulse.
ECU analog outputs (controller's inputs)	
Air Intake Temperature	Temperature of air entering air induction system.
Barometric pressure (absolute)	Absolute air pressure of the atmosphere.
Catalyst Intake Temperature	Temperature of the engine combustion exhausts entering the diesel oxidation catalyst in exhaust bank 1. This diesel parameter should be used with engines fueled by diesel fuel (not natural gas or propane).
Catalyst Outlet Temperature	Temperature of the engine combustion exhausts leaving the diesel oxidation catalyst in exhaust bank 1. This diesel parameter should be used with engines fueled by diesel fuel (not natural gas or propane).
DPF Differential Pressure	Exhaust differential pressure measured between the intake and exhaust of a diesel particulate filter in exhaust bank 1.
DPF Ash Load Percent	Indicates the ash load percent of diesel particulate filter 1. 100% is the level at which active diesel particulate filter ash service should be performed.
DPF Soot Load Percent	Indicates the soot load percent of diesel particulate filter 1. 100% is the level at which active diesel particulate filter regeneration should be triggered.
DEF Tank 1 Level	Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container
Urea Temperature	Temperature of the diesel exhausts fluid in the storage tank.
DPF Lamp	Command to control the diesel particulate filter lamp.
DPF Status	Indicates the state of the diesel particulate filter regeneration need and urgency.
HEST Lamp Command	Command to control the exhaust system high temperature lamp. This lamp indicates that the exhaust system temperature is high.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Starter mode	<ul style="list-style-type: none"> 0 - start not requested 1 - starter active, gear not engaged 2 - starter active, gear engaged 3 - start finished 4 - starter inhibited due to engine already running 5 - starter inhibited due to engine not ready for start 6 - starter inhibited due to driveline engaged or other transmission inhibit 7 - starter inhibited due to active immobilizer 8 - starter inhibited due to starter over-temp 9 - 11 - reserved 12 - starter inhibited 13,14 - error (legacy implementation only, use 1110) 15 - not available
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Hand Gas Position	The ratio of actual position of the remote analog engine speed/torque request input device to the maximum position of the input device. For example, in on-highway vehicles this could be an accelerator control device that is external to the drivers cab or an accelerator that is controlled by a hand lever from the operator's seat.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Exhaust Gas Mass Flow	Measured/calculated exhaust gas mass upstream of the aftertreatment system in exhaust bank 1 and 2.
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.

Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Fuel Temperature	Temperature of fuel entering injectors.
Air Filter Differential Pressure	Change in engine air system pressure, measured across the filter, due to the filter and any accumulation of solid foreign matter on or in the filter. This is the measurement of the first filter in a multiple air filter system.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
DPF Inlet Pressure	Exhaust back pressure as a result of particle accumulation on filter media placed in the exhaust stream.
Exhaust Gas Temperature	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Software ID	For service purpose only!
Battery Potential	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Power Reduction	Reduces the max. engine torque. The base for the percentage value is the max. torque curve 1. If there is more than one source for power reduction active, i.e. internal power protection by temperature and this message, the lowest value (= the highest reduction) will be used. If there is a timeout of a message the last valid data will be used furthermore for the calculation. 0% causes the EMR4 to switch off the engine. 100% means no power reduction.
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration


Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

No documentation available so far!

Diagnostic connector layout is on page 16 or [here](#).

TEM Evolution



Configuration

NOTE:

For connection to Deutz TEM module it is necessary to use an I-CB module. Configuration of the controller and I-CB has to be done separately using GenConfig or DriveConfig and ICBedit software. For further information see I-CB [manual](#).


ECU selection in PC software:

Deutz TEM
Legacy I-CB/DeutzTEME / ICB module + I/O modules

Available commands

For more information about available values and signals, please refer to I-CB [manual](#) or ICBedit PC software.

Recommended wiring




Ford

ECU Types

ECU Type	Engine type
E-control	DSG-423, WSG-1068

E-control



ECU selection in PC software:

Deutz EMR4

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Air Inlet Temperature	Temperature of air entering air induction system.
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Engine torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum

	position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Accelerator Pedal Position2	The ratio of actual position of the second analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the secondary accelerator control in an application.
AccPedal 1 Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
Load At Current Speed	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Intercooler Temp	Temperature of liquid found in the intercooler located after the turbocharger.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Requested speed123456	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported by the non-configurable controllers:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen^{NT} or InteliSys^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A

Recommended wiring

Function	ECU B connector	Customer 42-pin connector	Controller
CAN H	14	28	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	15	29	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	60,79	N/A	N/A
Battery - (negative)	4,69,81	N/A	N/A
Key Switch	N/A	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM


Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

GM

ECU Types

ECU Type	Engine Type
MEFI4B MEFI5B MEFI6	Diesel engines
SECM	Gas engines
E-control E-control LCI	Natural gas or propane engines: GM 3.0 liter GM 4.3 liter GM 5.0 liter GM 5.7 liter GM 8.1 naturally aspirated GM 8.1 turbo GM 11.1 liter GM 21.9 liter

E-control



ECU selection in PC software for E-control

GM e-control

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal

	becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Air Inlet Temperature	Temperature of air entering air induction system.
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Engine torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Accelerator Pedal Position2	The ratio of actual position of the second analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the secondary accelerator control in an application.
AccPedal 1 Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
Load At Current Speed	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Intercooler Temp	Temperature of liquid found in the intercooler located after the turbocharger.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU B connector	diagnostic connector	Controller
CAN H	A (N)	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	? (S)	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	B (P)	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	N/A	N/A
Battery - (negative)	?	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

E-control LCI

ECU selection in PC software for E-control LCI

GM e-control LCI

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Air Inlet Temperature	Temperature of air entering air induction system.
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Engine torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Intercooler Temp	Temperature of liquid found in the intercooler located after the turbocharger.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration


Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU B connector	diagnostic connector	Controller
CAN H	A	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	B	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	N/A	N/A
Battery - (negative)	?	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

MEFI4B, MEFI5B



ECU selection in PC software:

GM MEFI4/MEFI5B

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Amber Warning Lamp prop	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp prop	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp prop	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp prop	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Fuel Level (MEFI5B only)	Ratio of volume of fuel to the total volume of fuel storage container.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Air Intake Pressure (MEFI5B)	Absolute air pressure at inlet to intake manifold or air box.

only)	
Boost Pressure (MEFI5B only)	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temp (MEFI5B only)	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp (MEFI5B only)	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate (MEFI5B only)	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU J1 or J2 connectors	diagnostic connector	Controller
CAN H	24 (J2)	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	9 (J2)	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1 (J2)	N/A	N/A
Battery - (negative)	13,28,29 (J1)	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

MEFI6

ECU selection in PC software:

GM MEFI6

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
MEFI6 Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped. This is a proprietary GM lamp.
MEFI6 Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active. This is a proprietary GM lamp.
MEFI6 Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related. This is a proprietary GM lamp.
MEFI6 Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine. This is a proprietary GM lamp.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
AT1 Intake O2	Indicates that the temperature on the intake side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 1.
AT1 Outlet O2	Indicates that the temperature on the exhaust side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 1.
AT2 IntakeO2	Indicates that the temperature on the intake side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 2.
AT2 Outlet O2	Indicates that the temperature on the exhaust side of the aftertreatment system has exceeded the dew point, as estimated by the ECM in exhaust bank 2.
Fuel Level	Ratio of volume of fuel to the total volume of fuel storage container.
ECM Hardware	For service purpose only!
ECM Information1	For service purpose only!
Engine Displacement	For service purpose only!
OEM Engine ID	For service purpose only!
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Starter Mode	<ul style="list-style-type: none"> 0 - start not requested 1 - starter active, gear not engaged 2 - starter active, gear engaged 3 - start finished 4 - starter inhibited due to engine already running 5 - starter inhibited due to engine not ready for start 6 - starter inhibited due to driveline engaged or other transmission inhibit

	7 - starter inhibited due to active immobilizer 8 - starter inhibited due to starter over-temp 9 -11 - reserved 12 - starter inhibited 13,14 - error (legacy implementation only, use 1110) 15 - not available
AP Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Oil Temperature	Temperature of the engine lubricant.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential	Electrical potential measured at the input of the electronic control unit supplied through a switching device.

ECU analog inputs (controller's outputs)

Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active. This is a proprietary GM speed request.
TSC1 Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active. This is a standard J1939 speed request.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 –InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration


Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

No documentation available so far!

Diagnostic connector layout is on page 16 or [here](#).

SECM



ECU selection in PC software:

GM SECM

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Approaching Shutdown	Status signal which indicates that engine shutdown is imminent. This engine protection signal can be a result of different systems failing, i.e., engine overheating.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
System Configuration	Parameter which indicates the configuration of the engine shutdown system.
System Timer State	Status signal which indicates the current mode of the engine protection system timer system.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Inlet Air Mass Flow Rate	Mass flow rate of fresh air entering the engine air intake, before any EGR mixer, if used. Flow rate of fresh air conducted to the engine cylinders to support combustion.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.

Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Engine Throttle Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU B connector	diagnostic connector	Controller
CAN H	20	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	21	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	22	N/A	N/A
Battery - (negative)	17	N/A	N/A
Key Switch	N/A	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT


Diagnostic connector layout is on page 16 or [here](#).

Isuzu

ECU Types

ECU Type	Engine Type
ECM	4HK series 5.2L (140kW-190kW)
	4J series 3.0L (46kW-140kW)
	6HK series 7.8L (up to 300kW)
	6U series 9.8L (up to 400kW)
	6W series 15.7L (up to 400kW)

ECM



ECU selection in PC software:

Isuzu ECM

Available signals

ECU binary outputs (controller's inputs)	
DPF BuzzerMode	For more information about this signal contact local Isuzu representative
DPF GrLampMode	DPF green lamp mode. For more information about this signal contact local Isuzu representative
DPF RegenFlag	For more information about this signal contact local Isuzu representative
DPF RegLampReq	DPF option regen lamp request. For more information about this signal contact local Isuzu representative
StarterSwitch	For more information about this signal contact local Isuzu representative
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
DPF SwitchKnd	For more information about this signal contact local Isuzu representative
DPF SwitchUns	For more information about this signal contact local Isuzu representative
EGRGasTmpWrn	EGR gas temp warning. For more information about this signal contact local Isuzu representative
Ignition key switch	For more information about this signal contact local Isuzu representative

RegAuxLoadReq1	For more information about this signal contact local Isuzu representative
RegAuxLoadReq2	For more information about this signal contact local Isuzu representative
StartCutRelay	Starter cut relay signal. For more information about this signal contact local Isuzu representative
BoostTmpRise	Boost temp rise warning. For more information about this signal contact local Isuzu representative
ClntTmpRise	Coolant temp rise warning. For more information about this signal contact local Isuzu representative
EmerSDoperSig	Emergency shutdown operation signal. For more information about this signal contact local Isuzu representative
EngOilPresDrop	Engine oil press drop warning. For more information about this signal contact local Isuzu representative
ExhstGasTmpWrn	Exhaust gas temp warning. For more information about this signal contact local Isuzu representative
FuelFltrClogg	Fuel filters clogging warning. For more information about this signal contact local Isuzu representative
FuelTmpRise	Fuel temp rise warning. For more information about this signal contact local Isuzu representative
Glow signal	For more information about this signal contact local Isuzu representative
InAirBstTmpWrn	I ntake air and boost temp diff warning. For more information about this signal contact local Isuzu representative
IntAirTmpWrn	Intake air temperature warning. For more information about this signal contact local Isuzu representative
OverrunWrn	For more information about this signal contact local Isuzu representative
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
EngProtHoldSig	Engine Protection System Holding Signal. For more information about this signal contact local Isuzu representative
PreheatStartSg	Preheating Start Signal. For more information about this signal contact local Isuzu representative
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop solenoid.
ECU analog outputs (controller's inputs)	
Atmospheric pressure	Absolute air pressure of the atmosphere.
T-Ambient	Temperature of air entering vehicle air induction system.
DPF AmLampMode	DPF amber lamp mode. For more information about this signal contact local Isuzu representative
DPF IndiStat	DPF indicator status. For more information about this signal contact local Isuzu representative
EngOil Filter Diff.Press	Change in engine oil pressure, measured across the filter, due to the filter and any accumulation of solid or semisolid material on or in the filter.
PCode	For more information about this signal contact local Isuzu representative
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Remote Accelerator Pedal Position	The ratio of actual position of the remote analog engine speed/torque request input.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Commonrail Pressure	The gage pressure of fuel in the first metering rail as delivered from the supply pump.
DiffPressJudg1	For more information about this signal contact local Isuzu representative
Turmo actual opening	For more information about this signal contact local Isuzu representative

Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temperature	Temperature of fuel passing the first fuel control system.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Boost temp	Status of the (virtual) boost temperature alarm switch.
Catalyst inlet gas temp	For more information about this signal contact local Isuzu representative
DPF filter Inlet Gas Temp	For more information about this signal contact local Isuzu representative
EGR gas temp	For more information about this signal contact local Isuzu representative
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Boost Pressure	For more information about this signal contact local Isuzu representative
Engine percent torque	For more information about this signal contact local Isuzu representative
Fuel injection quantity level	For more information about this signal contact local Isuzu representative
Target engine speed	For more information about this signal contact local Isuzu representative
Commonrail Diff Pressure	For more information about this signal contact local Isuzu representative
Instruction engine speed	For more information about this signal contact local Isuzu representative
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Main relay voltage	Volatge of the first source of battery potential as measured at the input of the ECM.
ECU analog inputs (controller's outputs)	
EngineModel/SN	For more information about this signal contact local Isuzu representative
Requested speee *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 –InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen^{NT} or InteliSys^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU 121pin connector	diagnostic connector	Controller
CAN H	18	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	37	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	2,5	N/A	N/A
Battery - (negative)	1,3,4	N/A	N/A
Key Switch	24	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM


Diagnostic connector layout is on page 16 or [here](#).

Iveco

ECU Types

ECU Type	Engine Type
EDC (EDC62 or EDC7C1 or EDC7UC31) EDC7 EDC7 EDC7UC31 EDC7UC31 MS 6.2 EDC7UC31 MS 6.3 EDC7UC31	NEF and Cursor (9, 10, 13) NEF marine NEF tier2 NEF tier3 NEF 560 marine Cursor 8,10,13 tier2 Cursor 9 marine Cursor 9 industrial tier2 Cursor 9 industrial tier3
EDC7	Tier3 Genset industrial application (Cursor and NEF engines)
ADEMIII	Vector

EDC or NEF



ECU selection in PC software:

Iveco NEF&Cursor

Available signals

ECU binary outputs (controller's inputs)	
Brake Switch	Switch signal which indicates that the driver operated brake foot pedal is being pressed. This brake foot pedal is controlling the vehicles' service brake (total braking application, not park brakes). It is necessary for safe drivetrain behavior that the switch activates before the physical braking components are activated.
Clutch Switch	Switch signal which indicates that the clutch pedal is being pressed. It is necessary for a safe drivetrain behavior that the clutch switch is set before the clutch is opened.
Cruise Control Active	Cruise control is switched on. It is not ensured that the engine is controlled by Druide control, as in the case of a large driver's demand the engine is controlled by the driver while cruise control is active. The cruise control is set to 0 if a switch off condition occurs.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.

Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Diagnostic Lamp Status	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Engine Oil Pressure Low	Low pressure of oil in engine lubrication system as provided by oil pump.
Engine Oil Temperature High	High temperature of oil in engine lubrication system as provided by oil pump.
Engine Overspeed	This signal is active when the actual engine speed is above the operating range.
Fuel Filter Heater Status	This signal is active when the fuel filter heater is active.
Immobilizer Fuel Block	Please contact local Iveco representative for further information about this signal.
Water In Fuel	Signal which indicates the presence of water in the fuel.
APP Kick Down Switch	Switch signal which indicates whether the accelerator pedal kickdown switch is opened or closed.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
Retarder Brake Assist Switch	Switch signal which indicates whether the operator wishes the retarder to be enabled for braking assist. The retarder does not check this switch, nor does the enabling of this switch engage the retarder.
Retarder Shift Assist Switch	Switch signal which indicates whether the operator wishes the retarder to be enabled for braking assist. The retarder does not check this switch, nor does the enabling of this switch engage the retarder.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
Wait To Start Lamp	Lamp signal which indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Catalyst Tank Level	Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container.
Barometric Pressure	Absolute air pressure of the atmosphere.
DEF Tank 1 Level	For more information about this signal contact local Iveco representative
Cold Start Heater Status	Please contact local Iveco representative for further information about this signal.
ECM Operational Status	For service purpose only!
Engine Degradation Level	Please contact local Iveco representative for further information about this signal.
Engine Over Temp Status	Indicates the state of pre-warming of the engine. 0 – No warning 1 – Prewarning 2 – Warning 3 to 7 – Not defined
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Engine Torque Mode	State signal which indicates which engine torque mode is currently generating, limiting, or controlling the torque. Note that the modes are not in prioritized order. Not all modes may be relevant for a given device. Some device may not implement all functions. The data type of this parameter is measured. Mode 0 means 'No request': engine torque may range from 0 to full load only due to low idle governor output; retarder torque = 0 (no braking). Modes 1b to 14 indicate that there is either a torque request or the identified function is currently controlling the engine/retarder: engine/retarder torque may range from 0 (no fueling/no braking) to the upper limit.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are

	excluded from this calculation.
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.
Operating Speed Asymmetry	For service purpose only!
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
DEF Warning	For more information about this signal contact local Iveco representative
Actual Retarder Torque	Actual braking torque of the retarder as a percent of retarder configuration reference torque.
Retarder Torque Mode	State signal which indicates which retarder torque mode is currently generating, limiting, or controlling the torque. Note that the modes are not in prioritized order. Not all modes may be relevant for a given device. Mode 0 means 'No request': engine torque may range from 0 to full load only due to low idle governor output; retarder torque = 0 (no braking). Modes 1 to 14 indicate that there is either a torque request or the identified function is currently controlling the engine/retarder: engine/retarder torque may range from 0 (no fueling/no braking) to the upper limit.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Trap Inlet Pressure	Exhaust back pressure as a result of particle accumulation on filter media placed in the exhaust stream.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Catalyst Downstream Temp	For more information about this signal contact local Iveco representative
Catalyst Upstream Temp	For more information about this signal contact local Iveco representative
Urea Pressure	For more information about this signal contact local Iveco representative
Urea Quantity	For more information about this signal contact local Iveco representative
Urea tank level	For more information about this signal contact local Iveco representative
Urea Tank Temp	For more information about this signal contact local Iveco representative
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Mode with SCI	This mode must be used when a SCI module is connected to the CAN bus. Source has to be set " Not used ", i.e. there can't be set any value!
Mode without SCI *1*2*3*4*5*6	This mode is recommended to use when there is no SCI connected to the CAN bus. Source has to be set " Not used ", i.e. there can't be set any value!
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
Requested speed (VE) *1*2*3*4	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring for NEF

Function	ECU A2 89pin connector	diagnostic connector	Controller
CAN H	52	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	53	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1, 7, 12, 13	N/A	N/A
Battery - (negative)	3, 9, 14, 15	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Recommended wiring for Cursor

Function	ECU A2 89pin connector	diagnostic connector	Controller
CAN H	11	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	12	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	N/A	N/A
Battery - (negative)	?	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

EDC Tier3

ECU selection in PC software:

Iveco NEF&Cursor Tier 3

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Diagnostic Lamp Status	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
ECM Fuelling	For more information about this signal contact local Iveco representative
Engine Oil Pressure Low	Low pressure of oil in engine lubrication system as provided by oil pump.
Engine Oil Temperature High	High temperature of oil in engine lubrication system as provided by oil pump.
Engine Overspeed	This signal is active when the actual engine speed is above the operating range.
Fuel Block Status By Immobilizer	Please contact local Iveco representative for further information about this signal.
Fuel Filter Heater Status	This signal is active when the fuel filter heater is active.
OBD MIL Status	For more information about this signal contact local Iveco representative
Status Of Start Button	For more information about this signal contact local Iveco representative
Status Of Stop Button	For more information about this signal contact local Iveco representative
Water In Fuel	Signal which indicates the presence of water in the fuel.
Wait To Start Lamp	Lamp signal which indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Air Inlet Temperature	Temperature of air entering air induction system.
Ambient Air Temperature	Temperature of air surrounding vehicle
Barometric Pressure	Absolute air pressure of the atmosphere.
Cab Interior Temperature	Temperature of air inside the vehicle.
Cold Start Status	Please contact local Iveco representative for further information about this signal.
ECM Operational Status	Please contact local Iveco representative for further information about this signal.
Engine Degradation Level	Please contact local Iveco representative for further information about this signal.
Engine Overtemperature	Please contact local Iveco representative for further information about this signal.
Humidity	Please contact local Iveco representative for further information about this signal.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Controlling Device Address	The source address of the device currently controlling the engine.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Engine Starter Mode	<ul style="list-style-type: none"> 0 - start not requested 1 - starter active, gear not engaged 2 - starter active, gear engaged 3 - start finished 4 - starter inhibited due to engine already running 5 - starter inhibited due to engine not ready for start 6 - starter inhibited due to driveline engaged or other transmission inhibit

	7 - starter inhibited due to active immobilizer 8 - starter inhibited due to starter over-temp 9 -11 - reserved 12 - starter inhibited 13,14 - error (legacy implementation only, use 1110) 15 - not available
Engine Torque Mode	
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Remote Accelerator	The ratio of actual position of the remote analog engine speed/torque request input device.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions.
Nominal Friction - % Torque	The calculated torque that indicates the amount of torque required by the engine itself and the loss torque of accessories.
Operating Speed Asymetry	Indicates the engine's preference of lower versus higher engine speeds should its desired speed not be achievable.
Coolant Pressure	Gage pressure of liquid found in engine cooling system. Dones from Master unit.
Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Extended Crankcase Blow-by Pressure	Differential crankcase blow-by pressure as measured through a tube.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Intercooler Temperature	Temperature of liquid found in the intercooler located after the turbocharger.
Turbo Oil Temperature	Temperature of the turbocharger lubricant.
Air Filter Diff. Pressure	Change in engine air system pressure, measured across the filter, due to the filter and any accumulation of solid foreign matter on or in the filter. This is the measurement of the first filter in a multiple air filter system.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Coolant Filter Diff. Pressure	Change in coolant pressure, measured across the filter.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Trap Inlet Pressure	Exhaust back pressure as a result of particle accumulation on filter media placed in the exhaust stream.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration


Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring for EDC

Function	ECU A2 89pin connector	diagnostic connector	Controller
CAN H	52	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	53	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1, 7, 12, 13	N/A	N/A
Battery - (negative)	3, 9, 14, 15	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

ADEMIII



ECU selection in PC software:

Iveco Vector

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Cold Start Request	The command for start the engine in cold environment conditions. If Cold Start Request signal is not used, configure it to Logical 0. Otherwise the engine will not start.
Start Request *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Fuel solenoid.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Cooling water temp	Temperature of liquid found in engine cooling system.
Oil pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.

Oil temperature	Temperature of the engine lubricant.
ECU analog inputs (controller's outputs)	
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

WARNING!

In case if alternative format (°F, psi, gph) is selected in LiteEdit PC software, the value Total Fuel Used is showed in dimension US gaollon instead of Imperial gallon !

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen^{NT} or InteliSys^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	Interface card	diagnostic connector	Controller
CAN H	J2 1	C	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	J2 2	D	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	116	N/A	N/A
Battery - (negative)	117	N/A	N/A
Key Switch	J7 18,19 *	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

WARNING!

Emergency stop must open this contact. After power on it has to wait for 10 seconds before start the engine - if ECU PwrRelay output is used to close this contact Prestart time has to be set to at least 10 seconds.

JCB

ECU Types

ECU Type	Engine Type
JCB Delphi DCM	Dieselmax or ecoMAX

Delphi DCM

ECU selection in PC software:

JCB Delphi DCM

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
APP Kick Down Switch	Switch signal which indicates whether the accelerator pedal kickdown switch is opened or closed.
Idle Shutdown has Shutdown Engine	Status signal which identifies whether or not the engine has been shutdown by the idle shutdown timer system.
Idle Shutdown Timer Function	Parameter which indicates the configuration of the idle shutdown timer system.
Idle Shutdown Timer Override	Status signal which indicates the status of the override feature of the idle shutdown timer system.
Idle Shutdown Timer State	Status signal which indicates the current mode of operation of the idle shutdown timer system.
Wait to Start Lamp	Lamp signal which indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
Water In Fuel Indicator	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine Demand Torque	The requested torque output of the engine by all dynamic internal inputs, including smoke control, noise control and low and high speed governing.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Engine Torque Mode	State signal which indicates which engine torque mode is currently generating, limiting, or controlling the torque. Note that the modes are not in prioritized order. Not all modes may be relevant for a given device. Some device may not implement all functions. The data type of this parameter is measured. Mode 0 means 'No request': engine torque may range from 0 to full load only due to low idle governor output; retarder torque = 0 (no braking). Modes 1b to 14 indicate that there is either a torque request or the identified function is currently controlling the engine/retarder: engine/retarder torque may range from 0 (no fueling/no braking) to the upper limit.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an

	application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Remote Accelerator	The ratio of actual position of the remote analog engine speed/torque request input device to the maximum position of the input device. For example, in on-highway vehicles this could be an accelerator control device that is external to the drivers cab or an accelerator that is controlled by a hand.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
T-ECU	Temperature of the engine electronic control unit.
Estimated Percent Fan Speed	Estimated fan speed as a ratio of the fan drive (current speed) to the fully engaged fan drive. A two state fan (off/on) will use 0% and 100% respectively. A variable speed fan will use 0% to 100%. Multiple fan systems will use 0 to 100% to indicate the percent cooling capacity being provided.
Fan Drive State	This parameter is used to indicate the current state or mode of operation by the fan drive. See the table below. 0 - Fan off 1 - Engine system-General 2 - Excessive engine air temperature 3 - Excessive engine oil temperature 4 - Excessive engine coolant temperature 5 - Excessive transmission oil temperature 6 - Excessive hydraulic oil temperature 7 - Default Operation 8 - Reverse Operation 9 - Manual control 10 - Transmission retarder 11 - A/C system 12 - Timer 13 - Engine brake 14 - Other 15 - Not available
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.

ECU analog inputs (controller's outputs)

Fuel Level	Ratio of volume of fuel to the total volume of fuel storage container.
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLiteNT *3 – IntelliDrive Lite *4 – IntelliCompactNT *5 – IntelliNano *6 –IntelliDrive Nano

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	

Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU X2 62pin connector	diagnostic connector	Controller
CAN H	27	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	19	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	23	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	57, 60, 53, 49	N/A	N/A
Battery - (negative)	58, 59, 61, 62	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

Jenbacher

ECU Types

ECU Type	Engine Type
DIA.NE	Gas engines

DIA.NE



WARNING!

To enable communication with Jenbacher Diane over Modbus, order the engine with Modbus interface!

ECU selection in PC software for DIA.NE



Available signals

ECU binary outputs (controller's inputs)	
GCB Closed	This signal indicates closed position of generator circuit breaker.
GCB Open	This signal indicates open position of generator circuit breaker.
MCB Closed	This signal indicates closed position of utility circuit breaker.
MCB Open	This signal indicates open position of utility circuit breaker.
Operation OFF	For more information about this signal contact local Jenbacher representative
Operation ON	For more information about this signal contact local Jenbacher representative
Ready for Aut. Demand OFF	For more information about this signal contact local Jenbacher representative
Ready for Aut. Demand ON	For more information about this signal contact local Jenbacher representative
Service Selector Switch AUT	The feedback from Service Selector Switch. The switch is in Auto position.
Service Selector Switch MAN	The feedback from Service Selector Switch. The switch is in Manual position.
Service Selector Switch OFF	The feedback from Service Selector Switch. The switch is in OFF position.
Demand for Auxiliaries	For more information about this signal contact local Jenbacher representative
GCB Closed 2	For more information about this signal contact local Jenbacher representative
General Trip	For more information about this signal contact local Jenbacher representative
General Warning	For more information about this signal contact local Jenbacher representative
MCB Closed 2	For more information about this signal contact local Jenbacher representative
Module is Demanded	For more information about this signal contact local Jenbacher representative
Operation - Engine is	For more information about this signal contact local Jenbacher representative

Running	
Pulse for Start Counter	For more information about this signal contact local Jenbacher representative
Ready for Aut. Demand	For more information about this signal contact local Jenbacher representative
Re-synchronizing Activated	For more information about this signal contact local Jenbacher representative
Service Select. Switch AUT 2	For more information about this signal contact local Jenbacher representative
Service Select. Switch MAN 2	For more information about this signal contact local Jenbacher representative
Synchronizing Gen. Activated	For more information about this signal contact local Jenbacher representative
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Jacket Water Temperature	For more information about this signal contact local Jenbacher representative
Jacket Water Pressure	Gage pressure of liquid found in engine cooling system.
Engine Oil Temperature	Temperature of the engine lubricant.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
ExhstGasTemp-Turbocharger	For more information about this signal contact local Jenbacher representative
ExhstGasTemp-HeatExchanger	For more information about this signal contact local Jenbacher representative
PlateTempExhstGasHeatExch.	For more information about this signal contact local Jenbacher representative
Cylinder Exhaust Gas Temp	For more information about this signal contact local Jenbacher representative
Heating Water Return Temp	For more information about this signal contact local Jenbacher representative
Generator Power Factor	For more information about this signal contact local Jenbacher representative
Generator Frequency	For more information about this signal contact local Jenbacher representative
Gener. Current Average	For more information about this signal contact local Jenbacher representative
Gener. Voltage Aver. Ph-Ph	For more information about this signal contact local Jenbacher representative
Total Active Output	For more information about this signal contact local Jenbacher representative
Total Reactive Output	For more information about this signal contact local Jenbacher representative
Setpoint Power Control	For more information about this signal contact local Jenbacher representative
Operation Hours Counter	Accumulated time of operation of engine.
Start Counter	For more information about this signal contact local Jenbacher representative
Fuel Mixture Temperature	For more information about this signal contact local Jenbacher representative
Excitation Voltage	For more information about this signal contact local Jenbacher representative
Generator Voltage L1-L2	For more information about this signal contact local Jenbacher representative
Generator Power	For more information about this signal contact local Jenbacher representative
Generator Reactive Power	For more information about this signal contact local Jenbacher representative
Generator Apparent Power	For more information about this signal contact local Jenbacher representative
Generator Neutral Current	For more information about this signal contact local Jenbacher representative
Boost Pressure Actual Value	For more information about this signal contact local Jenbacher representative
Gasmixer Position	For more information about this signal contact local Jenbacher representative
Throttle Valve Position	For more information about this signal contact local Jenbacher representative
Turbocharg Bypass Position	For more information about this signal contact local Jenbacher representative
ECU analog inputs (controller's outputs)	

Controller's analog output for speed control configuration

There is no speed control over CAN bus available for this particular ECU.

Recommended wiring

Function	Siemens converter	9pin diagnostic connector	Controller
RS485 A	A	N/A	RS485 – RS485 A
RS485 COM	COM	N/A	RS485 – RS485 COM
RS485 B	B	N/A	RS485 – RS485 B
Battery + (positive)	?	N/A	N/A
Battery - (negative)	?	N/A	N/A
Key Switch	N/A	N/A	Any binary output configured as ECU PwrRelay

Diagnostic connector layout is on page 16 or [here](#).

Controller recommended setting (Setpoints/Comms settings group)

Controller	Setpoint	Value	Interface (Connector)
InteliGen ^{NT}	RS232(1) mode	ECU LINK	
	RS232(2) mode		
InteliSys ^{NT}	RS485(X)conv.	ENABLED	RS 485(1), RS 485(2) RS 232(1) * ³ , RS 232(2) * ³
		DISABLED	
	RS232(2) mode	ECU LINK	
	RS485(X)conv.	ENABLED	RS 485(2) RS 232(1) * ³ , RS 232(2) * ³
	DISABLED		

*³ external RS232-485 converter is required

NOTE:

The address of the DIA.NE has to be set to 11 (0B_{HEX}).

John Deere

ECU Types

ECU Type	Engine Type
JDEC	Diesel engines


Engine type explanation

Engine type	Meaning	
4045HF275	4xxxxxxx	Number of cylinders
	x045xxxx	Displacement in litres YY.Z
	xxxxHxxxx	T - turbocharger w/o aftercooler H - turbocharger w aftercooler
	xxxxFxxx	F - OEM engine
	xxxxxx4xx	Valves/cylinder
	xxxxxxx8x	Emissions: 7 - Tier II 8 - Tier III
	xxxxxxx5	0 - no ECU 5 - J1939 ECU 9 - J1939 ECU, Tier II electronic

PowerTech engine type explanation

Engine type	Meaning	
PSS 6.8L	Pxxxx	Technology : P - Powertech plus E - Powertech E
	xSxxxx	Turbocharger : V – Variable geometry turbocharger (VGT) S – Series turbochargers W – wastegate turbocharger
	xxSxxx	Aftertreatment : S – Exhaust filter and SCR X – Exhaust filter
	xxx6.8L	Displacement

JDEC



ECU selection in PC software:

John Deere

Available signals

ECU binary outputs (controller's inputs)	
Brake Switch	Indicates that the brake foot pedal is being pressed.
Clutch Switch	Indicates that the clutch pedal is being pressed.
Cruise Control Accelerate Switch	Indicates that the activator is in the position "accelerate."
Cruise Control Active	Cruise control is switched on.
Cruise Control Coast Switch	Indicates that the activator is in the position "coast (decelerate)."
Cruise Control Enable Switch	Indicates that it is possible to manage the cruise control function.
Cruise Control Resume Switch	Indicates that the activator is in the position "resume."
Cruise Control Set Switch	Indicates that the activator is in the position "set."
Engine Test mode switch	Indicates the position of the engine test mode switch.
Idle Decrement Switch	Indicates the position of the idle decrement switch.
Idle Increment Switch	Indicates the position of the idle increment switch.
Parking Brake Switch	Indicates when the parking brake is set.
Two Speed Axle Switch	Indicates the current axle range.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
DPF Act. Reg. Inhibit Status	Indicates the state of diesel particulate filter active regeneration inhibition.
DPF ActRegInhibitDueToInhSw	Indicates the state of diesel particulate filter active regeneration inhibition due to the Diesel Particulate Filter Regeneration Inhibit Switch.
DPF ActRegInhibNotWarmUp	Indicates the state of diesel particulate filter active regeneration inhibition due to the engine not being warmed up.
DPF Auto Reg.Configuration	Indicates the configuration of diesel particulate filter active regeneration automatic initiation.
DPF ConditionNotRegen	Indicates that diesel particulate filter is not able to begin or continue an active regenerate event at the current engine operating conditions.
DPF Inhibit DueTo Breake	Indicates the state of diesel particulate filter active regeneration inhibition due to the service brake being active.

DPF Inhibit DueTo Clutch	Indicates the state of diesel particulate filter active regeneration inhibition due to the clutch being disengaged.
DPF Inhibit DueTo Exh.Press	Indicates the state of diesel particulate filter active regeneration inhibition due to low exhaust gas pressure.
DPF Inhibit DueTo Exh.Temp	Indicates the state of diesel particulate filter active regeneration inhibition due to the exhaust gas temperature being too low.
DPF Inhibit DueTo Idle	Indicates the state of diesel particulate filter active regeneration inhibition due to the accelerator pedal being off idle.
DPF Inhibit DueTo LowSpeed	Indicates the state of diesel particulate filter active regeneration inhibition due to vehicle speed being less than the allowed vehicle speed.
DPF Inhibit DueTo Neutral	Indicates the state of diesel particulate filter active regeneration inhibition due to the transmission being out of neutral.
DPF Inhibit DueTo Park.Brake	Indicates the state of diesel particulate filter active regeneration inhibition due to the parking brake being not set.
DPF Inhibit DueTo Peranent Lockout	Indicates the state of diesel particulate filter active regeneration inhibition due to a permanent system lockout.
DPF Inhibit DueTo PTO	Indicates the state of diesel particulate filter active regeneration inhibition due to the PTO being active.
DPF Inhibit DueTo Speed	Indicates the state of diesel particulate filter active regeneration inhibition due to the vehicle speed being above an allowed limit.
DPF Inhibit DueTo SysFault	Indicates the state of diesel particulate filter active regeneration inhibition due to a system fault being active.
DPF Inhibit DueTo SysLockout	Indicates the state of diesel particulate filter active regeneration inhibition due to a temporary system lockout.
DPF Inhibit DueTo SysTimeout	Indicates the state of diesel particulate filter active regeneration inhibition due to a system timeout.
DPF Pas.Reggen.Status	Indicates the state of diesel particulate filter passive regeneration.
DPF Regen. Status	Indicates the state of diesel particulate filter active regeneration.
HydrocarbonDoserEna	Purging enable of the Hydrocarbon Doser (HCD).
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
DPF Regen.Force Switch *1*2*3*4	Indicates the state of a switch available to the operator that forces diesel particulate filter regeneration. The recommended source should follow the requested function.
DPF Regen.Inhibit Switch *1*2*3*4*	Indicates the state of a switch available to the operator that inhibits diesel particulate filter regeneration. The recommended source should follow the requested function.
Cleaning Allow *1*2*3*4	Please contact local John Deere representation for more information about this command. The recommended source should follow the requested function.
ECU analog outputs (controller's inputs)	
Ash Load Percent	Indicates the ash load percent of diesel particulate filter 1. 100% is the level at which active diesel particulate filter ash service should be performed.
Soot Load Percent	Indicates the soot load percent of diesel particulate filter 1. 100% is the level at which active diesel particulate filter regeneration should be triggered.
DEF Tank 1 Level	Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container
DEF Tank 1 Low Level Indicator	The desired illumination of the driver's warning indicator for diesel exhaust fluid (DEF) tank low level.
DPF Act.Reg.ForcedStatus	Value used for Tier4 icon control.
DPF Lamp Command	Value used for Tier4 icon control.
DPF Staus	Indicates the state of the diesel particulate filter regeneration need and urgency.
HEST Lamp Command	Command to control the exhaust system high temperature lamp. This lamp indicates that the exhaust system temperature is high.
Fuel Rail Pressure	Please contact John Deere representative for further information about this value.
Manifold Air Pressure	Please contact John Deere representative for further information about this value.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.

Demand Torque	The requested torque output of the engine by the driver.
Engine Demand Torque	The requested torque output of the engine by all dynamic internal inputs, including smoke control, noise control and low and high speed governing.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Remote Accelerator	The ratio of actual position of the remote analog engine speed/torque request input device to the maximum position of the input device. For example, in on-highway vehicles this could be an accelerator control device that is external to the drivers cab or an accelerator that is controlled by a hand.
Desired Operation Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Coolant Pressure	Gage pressure of liquid found in engine cooling system. Dones from Master unit..
Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Coolant Temp	Temperature of liquid found in engine cooling system.
Fuel Temp	Temperature of fuel entering injectors.
Intercooler Temp	Temperature of liquid found in the intercooler located after the turbocharger.
Oil Temp	Temperature of the engine lubricant.
Turbo Oil Temp	Temperature of the turbocharger lubricant.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.

ECU analog inputs (controller's outputs)

Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
--	---

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	

Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU 21pin connector	diagnostic connector	Controller
CAN H	V	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	F	F	CAN1 (extension modules/J1939) – CAN COM
CAN L	U	B	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	B	E	N/A
Battery - (negative)	E	D	N/A
Key Switch	G	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

NOTE:

Important JDEC settings for speed control via CAN are:

Torque speed control - Enable TSC1 Source 1; Source Address 1 set to 3

Governor droop – Set RPM of droop to e.g. 36 (it will enable controller to vary engine speed its nominal speed)

Throttle – Disable all throttles

MAN

ECU Types

ECU Type	Engine Type
EDC Master and MFR interface unit	6 R
EDC Master, EDC Slave and MFR interface unit	8 V, 12 V
DataLogger	Diesel engines equipped with a data logger

Engine type explanation

Engine type	Meaning
D 0836 LE 201/203	D - Water-cooled four stroke Diesel engine with direct fuel injection E - Water-cooled 4 stroke Otto-gas-engines with spark ignition
	E - naturally aspirated engine TE - turbocharged engine LE - turbocharged and intercooled engine
Number of cylinders, arrangement	Meaning
6 R	R - vertically arranged in-line V - cylinders in 90° V arrangement

Data logger

ECU selection in PC software:

MAN data logger

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	Please contact MAN representative for further information about this value.
Malfunction Lamp	Please contact MAN representative for further information about this value.
Protect Lamp	Please contact MAN representative for further information about this value.
Red Stop Lamp	Please contact MAN representative for further information about this value.
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Oil Temp A	Please contact MAN representative for further information about this value.
Oil Temp B	Please contact MAN representative for further information about this value.
Boost Pressure	Please contact MAN representative for further information about this value.
Oil Pressure A	Please contact MAN representative for further information about this value.
Oil Pressure B	Please contact MAN representative for further information about this value.
Cooling Water	Please contact MAN representative for further information about this value.
Cooling Water 2	Please contact MAN representative for further information about this value.
Exhaust Temp A	Please contact MAN representative for further information about this value.
Exhaust Temp B	Please contact MAN representative for further information about this value.
ECU analog inputs (controller's outputs)	



Diagnostic

The ECU does not support any diagnostic protocol.

Recommended wiring

Function	Left (L) or Right (R) 48pin connector	diagnostic connector	Controller
CAN H	R88	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	R89	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	R91	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	R95	N/A	N/A
Battery - (negative)	L12, L36, L48 R60, R72, R84, R96	N/A	N/A
Key Switch	N/A	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

EDC Master, EDC Slave and MFR interface system



ECU selection in PC software:

MAN MFR

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Amber Warning Lamp (MFR)	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp (MFR)	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active. This signal comes from Master ECU.
Protect Lamp (MFR)	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related. This signal comes from Master ECU.
Red Stop Lamp (MFR)	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine. . This signal comes from Master ECU.
Amber Warning Lamp (sl)	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped. . This signal comes from Slave ECU.
Malfunction Lamp (sl)	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active. This signal comes from Slave ECU.
Protect Lamp (sl)	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related. This signal comes from Slave ECU.
Red Stop Lamp (sl)	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine. This signal comes from Slave ECU.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Start Request *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Fuel solenoid.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop solenoid.
ECU analog outputs (controller's inputs)	


Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Fakt UW	For more information about this signal contact the local MAN representative.
Load	For more information about this signal contact the local MAN representative.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Coolant Pressure Master	Gage pressure of liquid found in engine cooling system. Comes from Master unit..
Engine Oil Pressure Master	Gage pressure of oil in engine lubrication system as provided by oil pump. Comes from Master unit.
Fuel Del. Pressure Master	Gage pressure of fuel in system as delivered from supply pump to the injection pump. Comes from Mater unit.
Coolant Pressure Slave	Gage pressure of liquid found in engine cooling system.
Engine Oil Pressure Slave	Gage pressure of oil in engine lubrication system as provided by oil pump. Comes from Slave unit.
Fuel Del. Pressure Slave	Gage pressure of fuel in system as delivered from supply pump to the injection pump. Comes from Slave unit.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Coolant level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Water in fuel	Signal which indicates the presence of water in the fuel.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
P-Grad *1*2*3*4*5*6	P-GRAD Drehzahlregler is parameter for setting engine droop. From this value is calculated real engine droop. See the graph, there is a conversion P-GRAD parameter to real engine droop. The engine droop can not be set exactly – it depends on engine. The value lies between MAX and MIN engine droop. The recommended source value is a constant following the requested function. See the chart below.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
ZDR Parametersatz *1*2*3*4*5*6	ZDR parameters are an internal setting of MAN company. This parameter set the regulation loop in the engine ECU. For more information, please contact your MAN local distributor. Adjust to 0 for singlespeed applications. The recommended source value is a constant following the requested function.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#).

Available list of texts of fault codes is [here](#).



NOTE:

Controller ECU PwrRelay output can be used to activate Ignition (Kl.15).

Controller’s analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Diagnostic

The controller shows in the alarm list for each fault:

- Text message or fault code number
- SPN number on the bottom row
- OC number on the bottom row which says from where comes this fault:
 - 0 ... EDC Master
 - 1 ... EDC Slave
 - 39 ... MFR
- FMI number in the right bottom corner

Fault details are displayed in the bottom row when fault is selected with > mark in the list of faults by Up/Down arrows.

Example 1: Oil pressure alarm from ECD Master is active (inverse background color).

```

E C U   A l a R m L i s t
> * O i l P R e s s u r e   W r n
S P N           1 0 0   O C   0   F M   0
    
```

Example 2: Oil pressure alarm from ECD Slave is not active.

```

E C U   A l a r m L i s t
> * O i l   P R e s s u r e           W r n

S P N           1 0 0   O C   1   F M   0
    
```

Example 3: Intake manifold 2 temperature alarm from MFR is active.

```

E C U   A l a r m L i s t
> * I n t a k e M a n i f 2 T m p     W r n

S P N           1 1 3 1   O C   3 9   F M   1
    
```

Recommended wiring

Function	ECU 89pin connector	diagnostic connector	Controller
CAN H	53	X2-28	CAN1 (extension modules/J1939) – CAN H
CAN COM	51	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	52	X2-29	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1,7,12,13	X2-33	N/A
Battery - (negative)	3,9,14,15	X2-32	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM


Diagnostic connector layout is on page 16 or [here](#).

MTU

ECU Types

ECU Type	Engine Type
MDEC ADEC & SAM	Series 2000, 4000
ADEC & SAM ECU8 (ADEC) & SMART Connect	Series 1600
DDEC10	Series 4R1000, 6R1000, 6R1100, 6R1300, 6R1500

MDEC



Configuration

NOTE:

For connection to MTU MDEC module it is necessary to use an I-CB module. Configuration of the controller and I-CB has to be done separately using GenConfig or DriveConfig and ICBEEdit software. For further information see I-CB [manual](#).


ECU selection in PC software:

MTU MDEC
Legacy I-CB/MTU-Diesel / ICB module + I/O modules

Available commands

For more information about available values and signals, please refer to I-CB [manual](#) or ICBEEdit PC software.



Recommended wiring



WARNING!

Please check that CAN bus terminating resistors or appropriate jumpers are connected.

ADEC (ECU7) & SAM



NOTE:

For communication with the ComAp controller the CCB2 card has to be present and J1939 has to be configured using the minidialog.

WARNING!

No fault codes in DM1 frame are provided by MTU ADEC system. Fault codes are only available as analog input "Failure Codes". ECU binary inputs may be used as fault code representative. Therefore you can use only 16 fault codes – binary inputs (standard ECU size) or 32 (large ECU size)!

ECU selection in PC software:

**MTU ADEC J1939
or
MTU ADEC J1939 P-engines**

Available signals for MTU ADEC J1939

ECU binary outputs (controller's inputs)	
AL ECU Defect	For more information about this signal contact local MTU representative. PV index = 116
AL Speed Demand Defect	For more information about this signal contact local MTU representative. PV index = 118
HI Power Supply	Power supply voltage over the limit. Protection Level1. PV index = 123
HI T-Coolant	Coolant temperature over the limit. Protection Level1. PV index = 129
HI T-ECU	Temperature of the ECU over the limit. Protection Level1. PV index = 170
HI T-Exhaust A	Temperature of the exhaust A-side over the limit. Protection Level1. PV index = 500
HI T-Exhaust B	Temperature of the exhaust B-side over the limit. Protection Level1. PV index = 510
HI T-Charge Air	Temperature of the turbocharger over the limit. Protection Level1. PV index = 133
HI T-Lube Oil	Temperature of the engine lube oil over the limit. Protection Level1. PV index = 143
HIHI ECU Power Supp Volt	Power supply voltage over the limit. Protection Level2. PV index = 271
HIHI T-Coolant	Coolant temperature over the limit. Protection Level2. PV index = 129
HIHI T-Charge Air	Temperature of the turbocharger over the limit. Protection Level2. PV index = 168
HIHI T-Lube Oil	Temperature of the engine lube oil over the limit. Protection Level2. PV index = 144
LO Coolant Level	Level of the coolant under the limit. Protection Level1. PV index = 55
LO P-Lube Oil	Pressure of the engine lube oil under the limit. Protection Level1. PV index = 29
LO Power Supply	Power supply voltage under the limit. Protection Level1. PV index = 122
LOLO ECU Power Supp Volt	Power supply voltage under the limit. Protection Level2. PV index = 270
LOLO P-Lube Oil	Pressure of the engine lube oil under the limit. Protection Level1. PV index = 30
SS Engine Speed Low	For more information about this signal contact local MTU representative. PV index = 177

HI T-Fuel	Fuel temperature over the limit. Protection Level1. PV index = 299
Override Feedback for ECU	For more information about this signal contact local MTU representative. PV index = 66
SS Overspeed	For more information about this signal contact local MTU representative. PV index = 3
Cylinder Cutout	For more information about this signal contact local MTU representative. PV index = 74
Engine Running	For more information about this signal contact local MTU representative. PV index = 68
Ext Stop Activated	For more information about this signal contact local MTU representative. PV index = 1
Feedback CAN Mode Switch	For more information about this signal contact local MTU representative.
Feedback Decrease Speed	For more information about this signal contact local MTU representative. PV index = 19
Feedback Increase Speed	For more information about this signal contact local MTU representative. PV index = 18
Load Generator ON	For more information about this signal contact local MTU representative. PV index = 78
Preaheat Temp. Not Reached	For more information about this signal contact local MTU representative. PV index = 89
Priming Pump On	For more information about this signal contact local MTU representative. PV index = 301
Speed Demand Fail Mode	For more information about this signal contact local MTU representative. PV index = 13
AL Idle Speed Not Reached	For more information about this signal contact local MTU representative. PV index = 241
AL Prelubrication Fault	For more information about this signal contact local MTU representative.
AL Runup Speed Not Reached	For more information about this signal contact local MTU representative.
AL Start Speed Not Reached	For more information about this signal contact local MTU representative. PV index = 239
HI Level Day-Tank	For more information about this signal contact local MTU representative. PV index = 353
HI Level Holding-Tank	For more information about this signal contact local MTU representative. PV index = 363
HI Pressure 1	For more information about this signal contact local MTU representative. PV index = 520
HI Pressure 2	For more information about this signal contact local MTU representative. PV index = 530
HI T-Ambient	Ambient temperature over the limit. Protection Level1. PV index = 580
HI T-Coolant Intercooler	Intercooler temperature over the limit. Protection Level1. PV index = 139
HI T-Winding 1	Winding1 temperature over the limit. Protection Level1. PV index = 540
HI T-Winding 2	Winding2 temperature over the limit. Protection Level1. PV index = 550
HI T-Winding 3	Winding3 temperature over the limit. Protection Level1. PV index = 560
LO Intercooler Coolant Level	Level of the intercoolant under the limit. Protection Level1. PV index = 99
LO Level Day-Tank	For more information about this signal contact local MTU representative. PV index = 354
LO Level Holding-Tank	For more information about this signal contact local MTU representative. PV index = 364
T-Generator Warning	For more information about this signal contact local MTU representative. PV index = 241
AL Water In Fuel Prefilter 1	For more information about this signal contact local MTU representative. PV index = 590
AL Water In Fuel Prefilter 2	For more information about this signal contact local MTU representative. PV index = 600
Automatic Shutdown	For more information about this signal contact local MTU representative. PV index = 213
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
50/60Hz *1*2*3*4*5	This feature gives the operator ability to switch the rated speed between 50Hz and 60Hz. The system will only react to a state transition while the Engine speed is 0. The recommended source value for this command is Logical 0 for 50Hz and Logical 1 for 60Hz.
Alarm Reset *1*2*3*4	The command for Reset ECU Alarms. The recommended source value for this command is FltResButnEcho.
Disable CylinderCutOut 2	For more information about this signal contact local MTU representative.
Engine Start *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.
Governor ParameterSet Select.	For more information about this signal contact local MTU representative.
Intermittent Oil Priming	For more information about this signal contact local MTU representative.
Mode Switch	For more information about this signal contact local MTU representative.
Request Test Overspeed	For more information about this signal contact local MTU representative.
Speed Setting Limit Active	For more information about this signal contact local MTU representative.
Override *1*2*3*4	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown. The recommended source value for

	this command is Logical 0.
Engine Stop *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Pressure 1	Pressure measured by auxiliary pressure sensor #1.
Pressure 2	Pressure measured by auxiliary pressure sensor #2.
T-Ambient	Temperature of air surrounding vehicle.
Failure Codes	Number of fault codes. If there is more than 1 fault code, the "Failure Codes" shows are fault codes step by step.
Actual Droop	For more information about this signal contact local MTU representative.
Level Day-Tank	For more information about this signal contact local MTU representative.
Level Holding-Tank	For more information about this signal contact local MTU representative.
T-Winding 1	Temperature of the windings inside the alternator.
T-Winding 2	Temperature of the windings inside the alternator.
T-Winding 3	Temperature of the windings inside the alternator.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Nominal Speed	The maximum governed rotational velocity of the engine crankshaft under full load.
Rated Power	For more information about this signal contact local MTU representative.
P-Fuel	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
P-Lube Oil	Gage pressure of oil in engine lubrication system as provided by oil pump.
T-Exhaust A (20V4000 only)	Temperature of combustion exhausts leaving the engine. Measured on side – A.
T-Exhaust B (20V4000 only)	Temperature of combustion exhausts leaving the engine. Measured on side – B.
T-Coolant	Temperature of liquid found in engine cooling system.
T-Coolant Intercooler	Temperature of liquid found in the intercooler located after the turbocharger.
T-Fuel	Temperature of fuel entering injectors.
T-Lube Oil	Temperature of the engine lubricant.
T-ECU	Temperature of the engine electronic control unit.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
P-Charge Air	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Speed Demand Source	For more information about this signal contact local MTU representative.
Requested Torque	For more information about this signal contact local MTU representative.
Engine Optimized	For more information about this signal contact local MTU representative.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Trip Avg Fuel Rate	Average fuel rate, equal to trip fuel divided by trip time while the engine speed is above zero, since the last trip reset. This includes idle, PTO (both moving and non-moving) and drive operation but excludes ignition-on time while the engine speed is at zero rpm.
Start Process 1	For service purpose only!
Start Process 2	For service purpose only!
Effective Speed Demand	For more information about this signal contact local MTU representative.
Selected Speed Demand	For more information about this signal contact local MTU representative.
Fdb Spd Demand ana.CAN	For more information about this signal contact local MTU representative.
Fdb Spd Demand analog	For more information about this signal contact local MTU representative.
T-Charge Air	Temperature of the air exiting the turbocharger 1 compressor outlet.
ETC Speed Turbo Charger 1	Rotational velocity of rotor in the turbocharger.
ECU Power Supply Voltage	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Engine alternate droop accelerator 1 select *1*2*3*4*5*6	For more information about this signal contact local MTU representative.
Speed Demand Switches *1*2*3*4*5*6	For more information about this signal contact local MTU representative.
Speed Demand Analog	This is the engine speed which the engine is expected to operate at if the speed control mode is active

*1*2*3*4*5*6	or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
--------------	---

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Available signals for MTU ADEC J1939 P-engines

ECU binary outputs (controller's inputs)	
AL ECU Defect	For more information about this signal contact local MTU representative.
HI ETC Speed (Turbo Charger 1)	For more information about this signal contact local MTU representative.
HI P-Fuel (Common Rail)	For more information about this signal contact local MTU representative.
HI P-Oil Filter Difference	For more information about this signal contact local MTU representative.
HI Power Supply	For more information about this signal contact local MTU representative.
HI T-Coolant	For more information about this signal contact local MTU representative.
HI T-ECU	For more information about this signal contact local MTU representative.
HI T-Exhaust A	For more information about this signal contact local MTU representative.
HI T-Exhaust B	For more information about this signal contact local MTU representative.
HI T-Charge Air	For more information about this signal contact local MTU representative.
HI T-Lube Oil	For more information about this signal contact local MTU representative.
HIHI ECU Power Supp Volt	For more information about this signal contact local MTU representative.
LO P-Fuel (Common Rail)	For more information about this signal contact local MTU representative.
LO P-Charge Air A-Site	For more information about this signal contact local MTU representative.
LO P-Lube Oil (ECU)	For more information about this signal contact local MTU representative.
LO Power Supply	For more information about this signal contact local MTU representative.
LOLO ECU Power Supp Volt	For more information about this signal contact local MTU representative.
SS Engine Speed Low	For more information about this signal contact local MTU representative.
SS ETC (Turbo Charger 1)	For more information about this signal contact local MTU representative.
SS P-Lube Oil (ECU)	For more information about this signal contact local MTU representative.
SS T-Coolant	For more information about this signal contact local MTU representative.
SS T-Fuel	For more information about this signal contact local MTU representative.
SS T-Charge Air	For more information about this signal contact local MTU representative.
SS T-Lube Oil	For more information about this signal contact local MTU representative.
Combined Alarm	For more information about this signal contact local MTU representative.
HI T-Fuel	For more information about this signal contact local MTU representative.
Override Feedback for ECU	For more information about this signal contact local MTU representative.
SS Overspeed	For more information about this signal contact local MTU representative.
Engine Running	For more information about this signal contact local MTU representative.
HI P-Crankcase	For more information about this signal contact local MTU representative.
HI T-Coolant Intercooler	For more information about this signal contact local MTU representative.
LO P-Coolant After Pump	For more information about this signal contact local MTU representative.
SS P-Coolant After Pump	For more information about this signal contact local MTU representative.
SS P-Crankcase	For more information about this signal contact local MTU representative.
AL Barring Gear Engaged	For more information about this signal contact local MTU representative.
AL SDAF Closed	For more information about this signal contact local MTU representative.
BO Hi P-Diff. Fuel Prefilter	For more information about this signal contact local MTU representative.
Coolant Level Charge Air NT	For more information about this signal contact local MTU representative.
Coolant Level Switch HT	For more information about this signal contact local MTU representative.
Crankshaft (EMU)	For more information about this signal contact local MTU representative.
P-DiffFuel ECU	For more information about this signal contact local MTU representative.
SS P-Lube Oil Red (EMU)	For more information about this signal contact local MTU representative.
SS T-Coolant Intercooler	For more information about this signal contact local MTU representative.
SS T-Coolant water (EMU)	For more information about this signal contact local MTU representative.
SS T-Exhaust Combined A	For more information about this signal contact local MTU representative.
SS T-Exhaust Combined B	For more information about this signal contact local MTU representative.

TD P-Lube Oil	For more information about this signal contact local MTU representative.
TD T-Coolant	For more information about this signal contact local MTU representative.
HI Single cylinder A1	For more information about this signal contact local MTU representative.
HI Single cylinder A10	For more information about this signal contact local MTU representative.
HI Single cylinder A2	For more information about this signal contact local MTU representative.
HI Single cylinder A3	For more information about this signal contact local MTU representative.
HI Single cylinder A4	For more information about this signal contact local MTU representative.
HI Single cylinder A5	For more information about this signal contact local MTU representative.
HI Single cylinder A6	For more information about this signal contact local MTU representative.
HI Single cylinder A7	For more information about this signal contact local MTU representative.
HI Single cylinder A8	For more information about this signal contact local MTU representative.
HI Single cylinder A9	For more information about this signal contact local MTU representative.
HI Single cylinder B1	For more information about this signal contact local MTU representative.
HI Single cylinder B10	For more information about this signal contact local MTU representative.
HI Single cylinder B2	For more information about this signal contact local MTU representative.
HI Single cylinder B3	For more information about this signal contact local MTU representative.
HI Single cylinder B4	For more information about this signal contact local MTU representative.
HI Single cylinder B5	For more information about this signal contact local MTU representative.
HI Single cylinder B6	For more information about this signal contact local MTU representative.
HI Single cylinder B7	For more information about this signal contact local MTU representative.
HI Single cylinder B8	For more information about this signal contact local MTU representative.
HI Single cylinder B9	For more information about this signal contact local MTU representative.
AL Fuel Leakage	For more information about this signal contact local MTU representative.
EMU Emergency Stop-Open Circuit	For more information about this signal contact local MTU representative.
WB SaSy Emergency Stop Output	For more information about this signal contact local MTU representative.
Air Flap A wire break	For more information about this signal contact local MTU representative.
Air Flap B wire break	For more information about this signal contact local MTU representative.
ASO Voltage to Lo on Relay	For more information about this signal contact local MTU representative.
ASO Watchdog Relay	For more information about this signal contact local MTU representative.
ASO Flap A Feedback Contact	For more information about this signal contact local MTU representative.
ASO Flap B Feedback Contact	For more information about this signal contact local MTU representative.
Emergency Stop Input 2	For more information about this signal contact local MTU representative.
Emergency Stop Input 3	For more information about this signal contact local MTU representative.
Emergency Stop Input 4	For more information about this signal contact local MTU representative.
Water In Fuel Indicator	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
50/60Hz *1*2*3*4*5	This feature gives the operator ability to switch the rated speed between 50Hz and 60Hz. The system will only react to a state transition while the Engine speed is 0. The recommended source value for this command is Logical 0 for 50Hz and Logical 1 for 60Hz.
Alarm Reset *1*2*3*4	The command for Reset ECU Alarms. The recommended source value for this command is FltResButnEcho.
Disable CylinderCutOut 2	For more information about this signal contact local MTU representative.
Engine Start *1*2*3*4	The command used for engine running. The recommended source value for this command is Starter.
Governor ParameterSet Select.	For more information about this signal contact local MTU representative.
Intermittent Oil Priming	For more information about this signal contact local MTU representative.
Lamp Test	For more information about this signal contact local MTU representative.
Mode Switch	For more information about this signal contact local MTU representative.
Priming Engine Start	For more information about this signal contact local MTU representative.
Request Test Overspeed	For more information about this signal contact local MTU representative.
Speed Decrease	For more information about this signal contact local MTU representative.
Speed Increase	For more information about this signal contact local MTU representative.

Speed Setting Limit Active	For more information about this signal contact local MTU representative.
Override *1*2*3*4*5	Switch signal which indicates the position of the engine shutdown override switch. This switch function allows the operator to override an impending engine shutdown. The recommended source value for this command is Logical 0.
Engine Stop *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
Starter Reset	For more information about this signal contact local MTU representative.
ECU analog outputs (controller's inputs)	
Auxiliary Temperature 2	Temperature measured by auxiliary temperature sensor 2.
P-Fuel Before Filter	Pressure measured by auxiliary pressure sensor #1.
T-Coolant water (EMU) AUX	For more information about this signal contact local MTU representative.
Engine Speed Camshaft	For more information about this signal contact local MTU representative.
Engine Speed Crankshaft	For more information about this signal contact local MTU representative.
Failure Codes	For more information about this signal contact local MTU representative.
T-Bearing DE	Temperature of the bearing inside the alternator.
T-Bearing NDE	Temperature of the bearing inside the alternator.
T-Winding 1	Temperature of the windings inside the alternator.
T-Winding 2	Temperature of the windings inside the alternator.
T-Winding 3	Temperature of the windings inside the alternator.
P-Coolant Water Intercooler	Gage pressure of coolant found in the intercooler which is located after the turbocharger.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
P-Coolant Water After Pump	Gage pressure of liquid found in engine cooling system.
P-Crankcase	Gage pressure inside engine crankcase.
P-Fuel	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
P-Lube Oil	Gage pressure of oil in engine lubrication system as provided by oil pump.
P-Lube Oil Before Filter	Gage pressure of the engine oil before the oil reaches the oil filter.
Single Cylinder A1 - Single Cylinder A10	Temperature at the cylinder exhausts port of the engine.
Single Cylinder B1 - Single Cylinder B10	Temperature at the cylinder exhausts port of the engine.
T-Exhaust A	Temperature of combustion exhaust within the left engine exhaust manifold.
T-Exhaust B	Temperature of combustion exhaust within the right engine exhaust manifold.
T-Coolant	Temperature of liquid found in engine cooling system.
T-Coolant Intercooler	Temperature of liquid found in the intercooler located after the turbocharger.
T-Fuel	Temperature of fuel of the first fuel control system.
T-Lube Oil	Temperature of the engine lubricant.
T-ECU	For more information about this signal contact local MTU representative.
P-Fuel After Filter	For more information about this signal contact local MTU representative.
Crankshaft (EMU) (Engine Speed)	For more information about this signal contact local MTU representative.
P-Charge Air	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
T-Intake Air	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Trip Avg Fuel Rate	Fuel consumed during all or part of a journey.
Start Process 1	For more information about this signal contact local MTU representative.
Start Process 2	For more information about this signal contact local MTU representative.
T-Charge Air	Temperature of the air exiting the turbocharger compressor outlet.
Transmission Oil Pressure	Gage pressure of lubrication fluid in transmission, measured after pump.
ETC Speed Turbo Charger 1	For more information about this signal contact local MTU representative.
ECU analog inputs (controller's outputs)	
Load Signal	For more information about this signal contact local MTU representative.

Engine alternate droop accelerator 1 select	For more information about this signal contact local MTU representative.
Rating Switch 1	0 – indicates maximum power fueling 1 – indicates alternate power fueling 1 2 – indicates alternate power fueling 2 3 – indicates alternate power fueling 3 4 - 253 - indicates alternate power fueling 4 thru 253 254 – Error condition 255 – Not available
Speed Demand Switches	For more information about this signal contact local MTU representative.
Speed Demand Analog <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

More about a constant for ECU controller is on page 17 or [here](#).

Controller’s analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Abbreviation explanation

Abbreviation	Meaning
AL	Alarm - Warning or alarm due to a binary signal
LO	Low - Warning or alarm threshold due to a shortfall
HI	High - Warning or alarm limits are exceeded
TD	Transmitter Deviation - Warning or alarm due to a large deviation between the analog values of two redundant sensors
SD	Sensor Defective - Warning or alarm because of a defective sensor
SF	Switch Fault - Warning or alarm condition due to an improper combination two complementary switch
SS	Security Shutdown - Alarm, which led to engine emergency stop
MG	Message - Message from external system
SE	System Error - Warning, a system error
DL	Default Lost - Warning due to a node failure in the default field bus
RL	Redundancy Lost - Warning due to a node failure in the redundant fieldbus
PB	Push Buton - Indicator due to the activation of certain control keys

Protection Level	Protection type
Protection Level1	Warning
Protection Level2	Shutdown

NOTE:

If you have some problems with frame EBC1 (PGN=61441d, F001h) e.g. binary output *engine stop*, please contact your MTU serviceman to upgrade firmware in your ECU / SAM module.

NOTE:

Automatically it is configured to isochronous (Droop2 = 0% corresponds to Engine alternate droop accelerator 1 select = 1). If you want to use droop (Droop1 = 4%) then set Source to 0.

Recommended wiring between ADEC and SAM module

Function	ADEC X1 connector	SAM X6 connector
CAN H	19	3
CAN COM	20	1
CAN L	35	2

Recommended wiring for power supply

Function	ADEC X3 connector	SAM X13 connector
+24VDC	3,6,9,12,13	1,2
GND	1,4,7,10	3,4

Recommended wiring (SAM with CCP2 card)

Function	SAM module	diagnostic connector	Controller
CAN H	X23 – 2	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	X23 – 3	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	X23 – 1	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	X13 – 1,2	N/A	N/A
Battery - (negative)	X13 – 3,4	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Recommended wiring (SAM without CCP2 card – marine version)

Function	SAM module	diagnostic connector	Controller
CAN H	X8 – 3	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	X8 – 1	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	X8 – 2	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	X13 – 1,2	N/A	N/A
Battery - (negative)	X13 – 3,4	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

DDEC10

ECU selection in PC software:

MTU DDEC10

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
DPF Active Regeneration Inhibited Due to Accelerator Pedal Off Idle	Indicates the state of diesel particulate filter active regeneration inhibition due to the accelerator pedal being off idle.
DPF Active Regeneration Inhibited Due to Clutch Disengaged	Indicates the state of diesel particulate filter active regeneration inhibition due to the clutch being disengaged.
DPF Active Regeneration Inhibited Due to Inhibit Switch	Indicates the state of diesel particulate filter active regeneration inhibition due to the Diesel Particulate Filter Regeneration Inhibit Switch.
DPF Active Regeneration Inhibited Due to Low Exhaust Gas Temperature	Indicates the state of diesel particulate filter active regeneration inhibition due to the exhaust gas temperature being too low.
DPF Active Regeneration Inhibited Due to Parking Brake Not Set	Indicates the state of diesel particulate filter active regeneration inhibition due to the parking brake being not set.
DPF Active Regeneration Inhibited Due to PTO Active	Indicates the state of diesel particulate filter active regeneration inhibition due to the PTO being active.
DPF Active Regeneration Inhibited Due to System Fault Active	Indicates the state of diesel particulate filter active regeneration inhibition due to a system fault being active.
DPF Active Regeneration Inhibited Due to Vehicle Speed Above Allowed Speed	Indicates the state of diesel particulate filter active regeneration inhibition due to the vehicle speed being above an allowed limit.
DPF Active Regeneration Inhibited Status	Indicates the state of diesel particulate filter active regeneration inhibition.
DPF Active Regeneration Status	Indicates the state of diesel particulate filter active regeneration.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
Water In Fuel Indicator	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
DPF Regeneration Force Switch *1*2*3*4*5*6	For more information about this signal contact local MTU representative.
DPF Regeneration Inhibit Switch *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.

ECU analog outputs (controller's inputs)	
Diesel Exhaust Fluid Concentration	A measure of the concentration of urea in water.
Diesel Exhaust Fluid Temperature 2	Temperature of the diesel exhausts fluid at the device measuring diesel exhaust fluid quality.
SCR Catalyst Intake Gas Temperature	Temperature of engine combustion exhausts entering the SCR catalyst in exhaust bank 1.
SCR Catalyst Outlet Gas Temperature	Temperature of engine combustion exhausts leaving the SCR catalyst exhaust in exhaust bank 1.
Turbocharger Wastegate Valve Position	The position of the turbocharger wastegate valve (not the electronic wastegate control valve).
DPF Intake Pressure 1	The diesel particulate filter intake gage pressure.
DPF Outlet Pressure 1	The diesel particulate filter outlet gage pressure.
Intake NOx	The amount of combined NO and NO2 in the exhaust entering the aftertreatment system.
DPF Intake Gas Temperature	Temperature of engine combustion exhausts entering the diesel particulate filter in exhaust bank 1.
Exhaust Gas Temperature 1	The reading from the exhaust gas temperature sensor located farthest upstream in the aftertreatment system.
DPF Differential Pressure	Exhaust differential pressure measured between the intake and exhaust of a diesel particulate filter.
Outlet NOx	The amount of combined NO and NO2 in the exhaust exiting the aftertreatment system.
DPF Outlet Gas Temperature	Temperature of engine combustion exhausts leaving the diesel particulate filter exhaust in exhaust bank 1.
DEF Tank 1 Level	Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container
DEF Tank 1 Low Level Indicator	The desired illumination of the driver's warning indicator for diesel exhaust fluid (DEF) tank low level.
Diesel Exhaust Fluid Tank 1 Heater	Percentage of heating applied to the aftertreatment diesel exhaust fluid tank heater.
Diesel Exhaust Fluid Tank 1 Temperature	Temperature of the diesel exhausts fluid in the storage tank.
SCR Operator Inducement Severity	The severity of operator inducement for anomalies with the SCR system, such as tampering, low DEF quality, and DEF tank level.
DPF Lamp Command	Value used for Tier4 icon control.
Exhaust System High Temperature Lamp Command	Command to control the exhaust system high temperature lamp.
Engine Speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Torque	The calculated output torque of the engine.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Remote Accelerator Pedal Position	The ratio of actual position of the remote analog engine speed/torque request input device.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Rated Power	For more information about this signal contact local MTU representative.
Rated Speed	For more information about this signal contact local MTU representative.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Crankcase Pressure	Gage pressure inside engine crankcase.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.

Injector Metering Rail Pressure	The gage pressure of fuel in the primary, or first, metering rail as delivered from the supply pump to the injector metering intake.
Coolant Temperature	Temperature of liquid found in engine cooling system.
Fuel Temperature	Temperature of the fuel.
Intercooler Temperature	Temperature of liquid found in the intercooler located after the turbocharger.
Oil Temperature	Temperature of the engine lubricant.
ECU Temperature	Temperature of the engine electronic control unit.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Exhaust Gas Temperature	Temperature of combustion exhausts leaving the engine.
Intake Manifold Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Intake Manifold Temperature	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle Valve Position	For more information about this signal contact local MTU representative
Turbocharger 1 Speed	Rotational velocity of rotor in the turbocharger.
Battery Potential	Measured electrical potential of the battery.
Keyswitch Battery Potential	Battery potential measured at the input of the electronic control unit.
ECU analog inputs (controller's outputs)	
Requested speed <small>*1*2*3*4*5*6</small>	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 –InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen ^{NT} or InteliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring


Function	Unit connectors ST2(B) or ST3(C)	diagnostic connector	Controller
CAN H	ST2-18	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	ST2-17	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	ST2-16	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	ST2-01	N/A	N/A
Battery - (negative)	ST2-02	N/A	N/A
Key Switch	ST2-03	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	ST3-04	N/A	SG OUT
Analog Speed Control	ST3-02	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

NOTE:

To enable the function of Remote throttle sensor on pin ST3-02, the parameter 13/63 has to be set to 1.

ADEC (ECU7)



Configuration

NOTE:

For connection to MTU ADEC module it is necessary to use an I-CB module. Configuration of the controller and I-CB has to be done separately using GenConfig or DriveConfig and ICBEdit software. For further information see I-CB [manual](#).


ECU selection in PC software:

Legacy I-CB/MTU-Diesel
/
ICB module + I/O modules

Available commands

For more information about available values and signals, please refer to I-CB [manual](#) or ICBEdit PC software.



Recommended wiring



WARNING!

Please check that CAN bus terminating resistors or appropriate jumpers are connected.

ECU8 and SMARTConnect



ECU selection in PC software:

MTU SMART Connect

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Coolant Pre-heated State	For more information about this signal contact local MTU representative.
Engine Cylinder Cutoff	Status of "global" cylinder cutoff. This means there is at least one cylinder cut off.
External Stop State	For more information about this signal contact local MTU representative.
Load Generator Status	For more information about this signal contact local MTU representative.
MTU Engine Running State	For more information about this signal contact local MTU representative.
Safety&ProtectionOverStat	For more information about this signal contact local MTU representative.
Oper Speed Down Switch Fdb	For more information about this signal contact local MTU representative.
Oper. Speed Up Switch Fdb	For more information about this signal contact local MTU representative.
Speed Demand Fail Mode	For more information about this signal contact local MTU representative.
EPS Engine Shutdown	For more information about this signal contact local MTU representative.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
MTU Req Speed Limit Switch	For more information about this signal contact local MTU representative.
Oper. Speed Down Switch	For more information about this signal contact local MTU representative.
Operating Speed Up Switch	For more information about this signal contact local MTU representative.
DisableEngCyl CutoffCmd2	For more information about this signal contact local MTU representative.
Engine Overspeed Test Cmd	For more information about this signal contact local MTU representative.
Engine Start Command *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.
Engine Stop Command *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
EngSafety&ProtOverrideCmd *1*2*3*4	Overrides Engine Safety System and Engine Protection System ("Limp home switch"). The recommended source value for this command is Logical 0.

EngSpdGovernor ParamSwitch	For more information about this signal contact local MTU representative.
IntermittentOil PrimingCmd	For more information about this signal contact local MTU representative.
Trip Group 1	For more information about this signal contact local MTU representative.
ECU analog outputs (controller's inputs)	
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Rated Power	For more information about this signal contact local MTU representative.
Rated Speed	For more information about this signal contact local MTU representative.
Engine Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
T-Lube Oil	Temperature of the engine lubricant.
ECU Temperature	Temperature of the engine electronic control unit.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
P-Charge Air	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Abs Press	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Trip Fuel	Fuel consumed during all or part of a journey.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Trip Avg Fuel Rate	Fuel consumed during all or part of a journey.
MTU Requested Abs. Torque	For more information about this signal contact local MTU representative.
Current Speed Demand src	For more information about this signal contact local MTU representative.
Demanded Operating Speed	For more information about this signal contact local MTU representative.
Speed Demand Analog In fdb	For more information about this signal contact local MTU representative.
Speed Demand CAN fdb	For more information about this signal contact local MTU representative.
Actual Droop	For more information about this signal contact local MTU representative.
MTU Error Codes	For more information about this signal contact local MTU representative.
Keyswitch Battery Voltage	For more information about this signal contact local MTU representative.
ECU analog inputs (controller's outputs)	
Frequency Selection <small>*1*2*3*4*5</small>	This feature gives the operator ability to switch the rated speed. The system will only react to a state transition while the Engine speed is 0. The recommended source values is an constant following the requested function.
Speed Demand Switches	CAN Demand Switches contains at: Bit 0 - 3 the source for Local normal switch position Bit 4 - 7 the source for Local Emergency switch position Bit 8 - 11 the source for Remote normal switch position Bit 12 - 15 the source for Remote Emergency switch position With the following assignment per bit group: 0: Analog CAN 1: Up/Down ECU 2: Up/Down CAN 3: Analog ECU 4: Analog ECU relative 5: Frequency 6: Notch Position (not used)
Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active

*1*2*3*4*5*6	or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
--------------	---

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#).

Controller’s analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Frequency Selection	Source Value
50 Hz	0
60 Hz	1
Reserved	2 - 5
Error	6
Do not care	7

Smart module DIP switches adjustment

1	2	3	4	5	6	7	8
Speed demand			Droop (0/4%)	50/60Hz	J1939/CANOpen	N/A	N/A
ON	OFF	ON	OFF	OFF	OFF	OFF	OFF

NOTE:

Please, notice that the DIP switch configuration is checking up after SMART connects powering up. Any change of DIP switches requires power off and on again of SMART connect.

Speed demand DIP swichs codes			
Code DEC	Code BIN	Designation	
0	000	ECU default	ECU default settings of the 4 internal speed demand switches – default speed up/down
1	001	ECU direct up / down	The speed demand (up / down) controlled over binary inputs directly at the ECU. Settings can by done via DiaSys at the ECU.
2	010	ECU analogue relative	The analogoue speed demand controlled over analogue input directly at the ECU. Settings can by done via DiaSys at the ECU. 0VDC = -100RPM 5VDC = +100RPM
3	011	ECU analogue relative	The analogoue speed demand controlled over analogue input directly at the ECU. Settings can by done via DiaSys at the ECU. 0VDC = -100RPM 10VDC = +100RPM
4	100	ECU analogue relative	The analogoue speed demand controlled over analogue input directly at the ECU. Settings can by done via DiaSys at the ECU. 4mADC = -100RPM 20mADC = +100RPM
5	101	CAN analogue	The speed demand value (unit,RPM) will be transferred via CAN bus from SAM/SMART to the ECU. The speed demand information must be received from an external CAN bus (CANopen,SEA J1939)
6	110	CAN up / down	The speed demand (up / down) will be transferred via CAN bus from SAM/SMART to the ECU. The speed demand information must be received from an external CAN bus (CANopen,SEA J1939)
7	111	External speed demand source	The speed demand is flexible. The speed demand source can be transmitted from an external controller.

Recommended wiring

NOTE:

Please, notice that this wiring is valid for the engines where SMART CAN1 is configured for MCS5 protocol (MTU proprietary) and CAN2 is configured for J1939 protocol. This configuration is going to be available on 1600 series engines since May 2011.

Recommended wiring between ADEC and SMART module

Function	ADEC X1 connector	SMART X3 connector	SMART X4 connector
CAN1 H	1	1	
CAN1 COM	5	3	
CAN1 L	2	2	
CAN2 H	3		1
CAN2 COM	8		3
CAN2 L	4		2

Recommended wiring

Function	SMART connector	diagnostic connector	Controller
CAN H	X4 – 1	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	X4 – 3	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	X4 – 2	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	X1 – 2	N/A	N/A

Battery - (negative)	X1 – 3	N/A	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Ignition (switched by K1)

Function	Connector
Ignition +24VDC	X1 – 32
Ignition IN	X1 – 31


Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

Perkins

ECU Types

ECU Type	Engine Type
A4E1 of A4E2	1100 series
1300	1300 series
ECM or CAT ADEM3, ADEM4	2300 series 2500 series 2800 series

1100 series



ECU selection in PC software:

Perkins ECM

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Alarm Reset *4	For more information about this signal contact local Perkins representative.
Engine Start *4	For more information about this signal contact local Perkins representative.
Override *4	For more information about this signal contact local Perkins representative.
Stop Request	The command for normal stopping of the engine. The recommended source value for this command is

*1*2*3*4*5*6	Stop pulse.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Rated engine speed	For more information about this signal contact local Perkins representative.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Engine alternate droop accelerator 1 select	For more information about this signal contact local Perkins representative.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring for A4E1

Function	ECU connector	diagnostic connector	Controller
CAN H	52	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	61	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	56,57	A	N/A

Battery - (negative)	68,69	B	N/A
Key Switch	70	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	25	N/A	SG OUT
Analog Speed Control	44	N/A	SG COM



Recommended wiring for A4E2

Function	ECU connector	diagnostic connector	Controller
CAN H	20	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	22	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	21	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	7,8,15,16	A	N/A
Battery - (negative)	1,2,3,9,10	B	N/A
Key Switch	40	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	3	N/A	SG OUT
Analog Speed Control	17	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).


NOTE:

To enable speed control over CAN bus set Desired Speed Input Arrangement to "CAN Input" and Digital Speed Control Installed to "Not Installed" in Perkins EST program.



Diagnostic connector layout is on page 16 or [here](#).

1300 series



NOTE:

To enable speed control over the CAN bus, order the engine with load sharing option. Speed control over the datalink is supported by the engine manufactured since 2003.

ECU selection in PC software:

Perkins ECM
Or
Perkins 1300 (option) – no speed control

Available signals – Perkins ECM

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Alarm Reset *4	For more information about this signal contact local Perkins representative.
Engine Start *4	For more information about this signal contact local Perkins representative.
Override *4	For more information about this signal contact local Perkins representative.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands

	from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Rated engine speed	For more information about this signal contact local Perkins representative.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Engine alternate droop accelerator 1 select	For more information about this signal contact local Perkins representative.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLiteNT *3 – IntelliDrive Lite *4 – IntelliCompactNT *5 – IntelliNano *6 – IntelliDrive Nano

Available signals – Perkins 1300

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Rated engine speed	For more information about this signal contact local Perkins representative.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.

Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen^{NT} or InteliSys^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring for 1300 unit

Function	ECU connector	diagnostic connector	Controller
CAN H	19	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	18	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	20	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	25,21,22,41	A	N/A
Battery - (negative)	23,42,1,2	B	N/A
Key Switch	24	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	30	N/A	SG OUT
Analog Speed Control	11	N/A	SG COM

Recommended wiring for CAT unit

Function	ECU J1 21-pin connector	diagnostic connector	Controller
CAN H	20	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	22	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	21	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	7,8,15,16	A	N/A
Battery - (negative)	1,2,3,9,10	B	N/A
Key Switch	40	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	3	N/A	SG OUT
Analog Speed Control	17	N/A	SG COM

NOTE:



To enable speed control over CAN bus if possible - set Desired Speed Input Arrangement to "CAN Input" and Digital Speed Control Installed to "Not Installed" in Perkins EST program.

WARNING!

No value for speed control being sent to the ECU when Perkins 1300 is configured!



NOTE:

To enable speed control over CAN bus set Desired Speed Input Arrangement to "CAN Input" and Digital Speed Control Installed to "Not Installed" in Perkins EST program.



Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

2300, 2500, 2800 series



ECU selection in PC software:

Perkins ECM

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Alarm Reset *4	For more information about this signal contact local Perkins representative.
Engine Start *4	For more information about this signal contact local Perkins representative.
Override *4	For more information about this signal contact local Perkins representative.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Rated engine speed	For more information about this signal contact local Perkins representative.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.

Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Throttle position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential (Voltage)	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Engine alternate droop accelerator 1 select	For more information about this signal contact local Perkins representative.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen^{NT} or IntelliSys^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring for ADEM4 (2200, 2500 series)

Function	ECU J1 connector	diagnostic connector	Controller
CAN H	50	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	42	C	CAN1 (extension modules/J1939) – CAN COM
CAN L	34	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	48,52,53,70	A	N/A
Battery - (negative)	61,63,65	B	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

Recommended wiring for ADEM 3 (2300, 2800 series)



Function	ECU J1 connector	diagnostic connector	Controller
CAN H	50	G	CAN1 (extension modules/J1939) – CAN H
CAN COM	42	C	CAN1 (extension modules/J1939) – CAN COM
CAN L	34	F	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	48,52,53,70	A	N/A

Battery - (negative)	61,63,65	B	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	17	N/A	SG OUT
Analog Speed Control	3	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

NOTE:

To enable speed control over CAN bus set Desired Speed Input Arrangement to "CAN Input" and Digital Speed Control Installed to "Not Installed" in Perkins EST program. Or make a loop on J1 connector pins 49 and 18.



Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

Scania


ECU Types

ECU Type	Engine Type
S6 (EMS)	DC9, DI12, DC12, DC16, D9M, DI12M, DI16M
S8	DC9, DC13,DC16

Engine type explanation

Engine Type	Meaning
Dxxx	Diesel fuel
xCxx	Intercooler: C - Air/Air, I - Water/Air
xx12	Displacement
xxxxM	Marine

S6



ECU selection in PC software:

Scania S6 Singlespeed; Scania S6 Singlespeed from ver.1794335
Or
Scania S6 Allspeed; Scania S6 Allspeed from ver.1794335

Available signals – S6 Singlespeed

ECU binary outputs (controller's inputs)	
Engine stop limit exceed	For more information about this signal contact local Scania representative.
Generator Charge	For more information about this signal contact local Scania representative.
High Engine Coolant Temp	Temperature of liquid in engine cooling system over the limit.
Low Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
PowerLost Due to HighTemp	For more information about this signal contact local Scania representative.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system

	that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
APP Kickdown Switch	For more information about this signal contact local Scania representative.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Brake Switch	Indicates that the brake foot pedal is being pressed.
Clutch Switch	Indicates that the clutch pedal is being pressed.
Cruise Control Accelerate Switch	Indicates that the activator is in the position "accelerate."
Cruise Control Coast Switch	Indicates that the activator is in the position "coast (decelerate)."
Cruise Control Enable Switch	Indicates that it is possible to manage the cruise control function.
Cruise Control Resume Switch	Indicates that the activator is in the position "resume."
Engine Shutdown Override Switch	If engine shut down due to low oil pressure, low coolant level or high water temperature is available this switch can override the function. The recommended source value for this command is Logical 0.
Engine Test mode switch	Indicates the position of the engine test mode switch.
Parking Brake Switch	Indicates when the parking brake is set.
Droop enable	Enable or disable droop function. The droop value is changeable with calibration parameter or with TSC-proprietary. The recommended source value for this command is Logical 0.
Emergency Engine Stop	Normally used for engine emergency stop. When used it will set an error- / information code. The recommended source value for this command is Logical 0.
Engine Start	The command used for engine running. The recommended source value for this command is Starter.
Engine Stop	Normally used for engine emergency stop. Engine Stop (without error code).
Exhaust brake – Brake Assist Switch	For more information about this signal contact local Scania representative.
Exhaust brake floor switch	For more information about this signal contact local Scania representative.
Idle Command	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.
Nominal Speed 1 *1*2*3*4*5*6	Choose nominal engine speed with these switches. NSSW1 NSSW2 Nominal speed 0 0 Use changeable calibration parameter
Nominal Speed 2 *1*2*3*4*5*6	1 0 1500 RPM 0 1 1800 RPM 1 1 Low idle command
Torque enable	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction. The recommended source value for this command is Logical 0.
Torque Limit 1	Choosing between 4 different torque limit curves (if available) TLSW1 TLSW2 Torque limit 0 0 Highest torque limit curve. (Curve 0)
Torque Limit 2	1 0 Low torque limit curve. (Curve 1) 0 1 User defined curve. (Curve 2) 1 1 User defined curve. (Curve 3)
White smoke limit request	For more information about this signal contact local Scania representative.
ECU analog outputs (controller's inputs)	
CAN Version of DLN2	For service purpose only!
Economy Speed High	For more information about this signal contact local Scania representative.
Economy Speed Low	For more information about this signal contact local Scania representative.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.

Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
ECU analog inputs (controller's outputs)	
Nominal speed offset *1*2*3*4*5*6	Nominal speed offset (if Torque enable is "Engine speed control"). Increase or decrease the referens speed (with or without droop) in relation to nominal speed. The offset range is changeble with calibration parameters. (normaly ± 120 rpm, 0% = -120 rpm and 100% = +120 rpm)

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Available signals – S6 Singlespeed ver.1794335

ECU binary outputs (controller's inputs)	
Diagnostic Status	For more information about this signal contact local Scania representative.
Engine stop limit exceed	For more information about this signal contact local Scania representative.
Generator Charge	For more information about this signal contact local Scania representative.
High Engine Coolant Temp	Temperature of liquid in engine cooling system over the limit.
Low Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
New DTC	For more information about this signal contact local Scania representative.
PowerLost Due to HighTemp	For more information about this signal contact local Scania representative.
Test Engine Lamp	For more information about this signal contact local Scania representative.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
APP Kickdown Switch	For more information about this signal contact local Scania representative.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Brake Switch	For more information about this signal contact local Scania representative.
Clutch Switch	For more information about this signal contact local Scania representative.
Cruise Control Accelerate Switch	For more information about this signal contact local Scania representative.

Cruise Control Coast Switch	For more information about this signal contact local Scania representative.															
Cruise Control Enable Switch	For more information about this signal contact local Scania representative.															
Cruise Control Resume Switch	For more information about this signal contact local Scania representative.															
Engine Shutdown Override Switch1234	If engine shut down due to low oil pressure, low coolant level or high water temperature is available this switch can override the function. The recommended source value for this command is Logical 0.															
Engine Test mode switch	For more information about this signal contact local Scania representative.															
Parking Brake Switch	For more information about this signal contact local Scania representative.															
Droop enable1234	Enable or disable droop function. The droop value is changeable with calibration parameter or with TSC-proprietary. The recommended source value for this command is Logical 0.															
Emergency Engine Stop	Normally used for engine emergency stop. When used it will set an error- / information code. The recommended source value for this command is Logical 0.															
Engine Start123456	The command used for engine running. The recommended source value for this command is Starter.															
Engine Stop123456	Normally used for engine emergency stop. Engine Stop (without error code).															
Exhaust brake – Brake Assist Switch	For more information about this signal contact local Scania representative.															
Exhaust brake floor switch	For more information about this signal contact local Scania representative.															
Idle Command	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.															
Nominal Speed 1 *1*2*3*4*5*6	Choose nominal engine speed with these switches.															
Nominal Speed 2 *1*2*3*4*5*6																
	<table border="1"> <thead> <tr> <th>NSSW1</th> <th>NSSW2</th> <th>Nominal speed</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Use changeable calibration parameter</td> </tr> <tr> <td>1</td> <td>0</td> <td>1500 RPM</td> </tr> <tr> <td>0</td> <td>1</td> <td>1800 RPM</td> </tr> <tr> <td>1</td> <td>1</td> <td>Low idle command</td> </tr> </tbody> </table>	NSSW1	NSSW2	Nominal speed	0	0	Use changeable calibration parameter	1	0	1500 RPM	0	1	1800 RPM	1	1	Low idle command
NSSW1	NSSW2	Nominal speed														
0	0	Use changeable calibration parameter														
1	0	1500 RPM														
0	1	1800 RPM														
1	1	Low idle command														
Torque enable	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction. The recommended source value for this command is Logical 0.															
Torque Limit 1	Choosing between 4 different torque limit curves (if available)															
Torque Limit 2																
	<table border="1"> <thead> <tr> <th>TLSW1</th> <th>TLSW2</th> <th>Torque limit</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Highest torque limit curve. (Curve 0)</td> </tr> <tr> <td>1</td> <td>0</td> <td>Low torque limit curve. (Curve 1)</td> </tr> <tr> <td>0</td> <td>1</td> <td>User defined curve. (Curve 2)</td> </tr> <tr> <td>1</td> <td>1</td> <td>User defined curve. (Curve 3)</td> </tr> </tbody> </table>	TLSW1	TLSW2	Torque limit	0	0	Highest torque limit curve. (Curve 0)	1	0	Low torque limit curve. (Curve 1)	0	1	User defined curve. (Curve 2)	1	1	User defined curve. (Curve 3)
TLSW1	TLSW2	Torque limit														
0	0	Highest torque limit curve. (Curve 0)														
1	0	Low torque limit curve. (Curve 1)														
0	1	User defined curve. (Curve 2)														
1	1	User defined curve. (Curve 3)														
White smoke limit request	For more information about this signal contact local Scania representative.															
Droop Dec	For more information about this signal contact local Scania representative.															
Droop Inc	For more information about this signal contact local Scania representative.															
TSC1 Droop Enable	Enable or disable droop function. The droop value is changeable with calibration parameter or with TSC-proprietary. The recommended source value for this command is Logical 0.															
ECU analog outputs (controller's inputs)																
CAN Version of DLN2	For service purpose only!															
Single Speed Droop Value	The actual droop value for single speed engines is transmitted.															
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.															
Demand Torque	The requested torque output of the engine by the driver.															
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.															
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.															
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.															
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself,															

	and the losses of fuel, oil and cooling pumps.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.

ECU analog inputs (controller's outputs)

Nominal speed offset <small>*1*2*3*4*5*6</small>	Nominal speed offset (if Torque enable is "Engine speed control"). Increase or decrease the referens speed (with or without droop) in relation to nominal speed. The offset range is changeble with calibration parameters. (normaly ± 120 rpm, 0% = -120 rpm and 100% = +120 rpm)
Requested Droop	For more information about this signal contact local Scania representative.
Requested Speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Available signals – S6 Allspeed

ECU binary outputs (controller's inputs)

Engine stop limit exceed	For more information about this signal contact local Scania representative.
Generator Charge	For more information about this signal contact local Scania representative.
High Engine Coolant Temp	Temperature of liquid in engine cooling system over the limit.
Low Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
PowerLost Due to HighTemp	For more information about this signal contact local Scania representative.
Test Engine Lamp	For more information about this signal contact local Scania representative.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
APP Kickdown Switch	For more information about this signal contact local Scania representative.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.

ECU binary inputs (controller's outputs - commands)

Brake Switch	For more information about this signal contact local Scania representative.
Clutch Switch	For more information about this signal contact local Scania representative.
Cruise Control Accelerate Switch	For more information about this signal contact local Scania representative.
Cruise Control Coast Switch	For more information about this signal contact local Scania representative.
Cruise Control Enable Switch	For more information about this signal contact local Scania representative.
Cruise Control Resume Switch	For more information about this signal contact local Scania representative.
Engine Shutdown Override Switch <small>*1*2*3*4</small>	If engine shut down due to low oil pressure, low coolant level or high water temperature is available this switch can override the function. The recommended source value for this command is Logical 0.
Engine Test mode switch	For more information about this signal contact local Scania representative.

Parking Brake Switch	For more information about this signal contact local Scania representative.															
AP kickdown switch	A plausibility check is performed in engine control unit between kickdown switch and Accelerator Pedal Position.															
AP Low Idle Switch	A plausibility check is performed in engine control unit between Low Idle Switch and Accelerator Pedal Position.															
CC-Off	CC-off turns off the cruise-control or PTO if they are active.															
Emergency Engine Stop	Normally used for engine emergency stop. When used it will set an error- / information code. The recommended source value for this command is Logical 0.															
Engine Control Allowed	With this switch you override the Nominal speed switch 1 and 2 and choose nominal speed in message TSC-proprietary instead.															
Engine Start *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.															
Engine Stop *1*2*3*4*5*6	Normally used for engine emergency stop. Engine Stop (without error code).															
Exhaust brake – Brake Assist Switch	For more information about this signal contact local Scania representative.															
Exhaust brake floor switch	For more information about this signal contact local Scania representative.															
Idle Command	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.															
Increased Speed Sw1 *1*2*3*4	Choose between 4 different PTO (power take off) modes.															
Increased Speed Sw1 *1*2*3*4	<table border="1"> <thead> <tr> <th>NSSW1</th> <th>NSSW2</th> <th>PTO-mode</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Normal hand throttle</td> </tr> <tr> <td>1</td> <td>0</td> <td>Limited hand throttle</td> </tr> <tr> <td>0</td> <td>1</td> <td>Temporary changed low idle</td> </tr> <tr> <td>1</td> <td>1</td> <td>Locked engine speed</td> </tr> </tbody> </table>	NSSW1	NSSW2	PTO-mode	0	0	Normal hand throttle	1	0	Limited hand throttle	0	1	Temporary changed low idle	1	1	Locked engine speed
NSSW1	NSSW2	PTO-mode														
0	0	Normal hand throttle														
1	0	Limited hand throttle														
0	1	Temporary changed low idle														
1	1	Locked engine speed														
Retarder Speed Control Off	For more information about this signal contact local Scania representative.															
Retarder Speed Control Set	Retarder Speed Control Setswitch															
Torque Limit 1	Choosing between 4 different torque limit curves (if available)															
Torque Limit 2	<table border="1"> <thead> <tr> <th>TLSW1</th> <th>TLSW2</th> <th>Torque limit</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Highest torque limit curve. (Curve 0)</td> </tr> <tr> <td>1</td> <td>0</td> <td>Low torque limit curve. (Curve 1)</td> </tr> <tr> <td>0</td> <td>1</td> <td>User defined curve. (Curve 2)</td> </tr> <tr> <td>1</td> <td>1</td> <td>User defined curve. (Curve 3)</td> </tr> </tbody> </table>	TLSW1	TLSW2	Torque limit	0	0	Highest torque limit curve. (Curve 0)	1	0	Low torque limit curve. (Curve 1)	0	1	User defined curve. (Curve 2)	1	1	User defined curve. (Curve 3)
TLSW1	TLSW2	Torque limit														
0	0	Highest torque limit curve. (Curve 0)														
1	0	Low torque limit curve. (Curve 1)														
0	1	User defined curve. (Curve 2)														
1	1	User defined curve. (Curve 3)														
White smoke limit request	For more information about this signal contact local Scania representative.															
ECU analog outputs (controller's inputs)																
CAN Version of DLN2	For service purpose only!															
Economy Speed High	For more information about this signal contact local Scania representative.															
Economy Speed Low	For more information about this signal contact local Scania representative.															
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.															
Demand Torque	The requested torque output of the engine by the driver.															
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.															
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.															
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.															
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.															
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.															
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.															
Coolant Temp	Temperature of liquid found in engine cooling system.															
Engine Oil Temp	Temperature of the engine lubricant.															

Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
ECU analog inputs (controller's outputs)	
Accelerator Pedal Position <small>*1*2*3*4*5*6</small>	Nominal speed offset (if Torque enable is "Engine speed control"). Increase or decrease the referens speed (with or without droop) in relation to nominal speed. The offset range is changeble with calibration parameters. (normaly ± 120 rpm, 0% = -120 rpm and 100% = +120 rpm)
Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 –InteliDrive Nano

Available list of texts of fault codes is [here](#).

Available signals – S6 Allspeed from ver.1794335

ECU binary outputs (controller's inputs)	
Diagnostic Status	
Engine stop limit exceed	For more information about this signal contact local Scania representative.
Generator Charge	For more information about this signal contact local Scania representative.
High Engine Coolant Temp	Temperature of liquid in engine cooling system over the limit.
Low Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
New DTC	
PowerLost Due to HighTemp	For more information about this signal contact local Scania representative.
Test Engine Lamp	For more information about this signal contact local Scania representative.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
APP Kickdown Switch	For more information about this signal contact local Scania representative.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
ECU binary inputs (controller's outputs - commands)	
Brake Switch	For more information about this signal contact local Scania representative.
Clutch Switch	For more information about this signal contact local Scania representative.
Cruise Control Accelerate Switch	For more information about this signal contact local Scania representative.
Cruise Control Coast Switch	For more information about this signal contact local Scania representative.
Cruise Control Enable Switch	For more information about this signal contact local Scania representative.
Cruise Control Resume Switch	For more information about this signal contact local Scania representative.
Engine Shutdown Override Switch <small>*1*2*3*4</small>	If engine shut down due to low oil pressure, low coolant level or high water temperature is available this switch can override the function. The recommended source value for this command is Logical 0.
Engine Test mode switch	For more information about this signal contact local Scania representative.
Parking Brake Switch	For more information about this signal contact local Scania representative.
AP kickdown switch	A plausibility check is performed in engine control unit between kickdown switch and Accelerator Pedal Position.
AP Low Idle Switch	A plausibility check is performed in engine control unit between Low Idle Switch and Accelerator Pedal Position.
CC-Off	CC-off turns off the cruise-control or PTO if they are active.
Emergency Engine Stop	Normaly used for engine emergency stop. When used it will set an error- / information code. The recommended source value for this command is Logical 0.

Engine Control Allowed	Enables speed control in TSC-proprietary (PTO mode 4).		
Engine Start *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.		
Engine Stop *1*2*3*4*5*6	Normally used for engine emergency stop. Engine Stop (without error code).		
Exhaust brake – Brake Assist Switch	For more information about this signal contact local Scania representative.		
Exhaust brake floor switch	For more information about this signal contact local Scania representative.		
Idle Command	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.		
Increased Speed Sw1 *1*2*3*4	NSSW1	NSSW2	PTO-mode
	0	0	Normal hand throttle
Increased Speed Sw1 *1*2*3*4	1	0	Limited hand throttle
	0	1	Temporary changed low idle
	1	1	Locked engine speed
Retarder Speed Control Off	For more information about this signal contact local Scania representative.		
Retarder Speed Control Set	For more information about this signal contact local Scania representative.		
Torque Limit 1	TLSW1	TLSW2	Torque limit
	0	0	Highest torque limit curve. (Curve 0)
Torque Limit 2	1	0	Low torque limit curve. (Curve 1)
	0	1	User defined curve. (Curve 2)
	1	1	User defined curve. (Curve 3)
White smoke limit request	For more information about this signal contact local Scania representative.		
ECU analog outputs (controller's inputs)			
CAN Version of DLN2	For service purpose only!		
Single Speed Droop Value			
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.		
Demand Torque	The requested torque output of the engine by the driver.		
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.		
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.		
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.		
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.		
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.		
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.		
Coolant Temp	Temperature of liquid found in engine cooling system.		
Engine Oil Temp	Temperature of the engine lubricant.		
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.		
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.		
Fuel Rate	Amount of fuel consumed by engine per unit of time.		
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.		
ECU analog inputs (controller's outputs)			
Accelerator Position *5*6	Pedal	Nominal speed offset (if Torque enable is "Engine speed control"). Increase or decrease the referens speed (with or without droop) in relation to nominal speed. The offset range is changeble with calibration parameters. (normaly ± 120 rpm, 0% = -120 rpm and 100% = +120 rpm)	
Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active		

	or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
--	---

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration


Nominal speed offset settings for IntelliGen ^{NT} or IntelliSys ^{NT}	
Source	Speed request
Convert	No
Speed Bias Reference settings for IntelliDrive DCU, IntelliDrive Mobile	
Source	Speed Request
Convert	No

Recommended wiring for

Function	ECU B1 connector	diagnostic connector	Controller
CAN H	9	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	10	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1,6	N/A	N/A
Battery - (negative)	2,7	N/A	N/A
Key Switch	3	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

S8



ECU selection in PC software:

**Scania S8 Singlespeed
or
Scania S8 Allspeed**

Available signals – Scania S8 Allspeed

ECU binary outputs (controller's inputs)	
Diagnostic Status	For more information about this signal contact local Scania representative.
Engine stop limit exceed	The message is sent when the coolant temperature exceeds the switch-off limit (normally 103°C).
Generator Charge	For more information about this signal contact local Scania representative.
High Engine Coolant Temp	Normally controls the high coolant temperature warning lamp. The parameter is set when the coolant temperature exceeds the limit (normally 95°C).
High Engine Oil Level	Oil level over the limit.
Low Engine Oil Level	Oil level under the limit.
Low Engine Oil Pressure	Oil pressure under the limit.
Low Urea Level	Urea level under the limit.
New DTC	When a new DTC has been saved in the engine control unit, parameter is set for 1 second.
PowerLost Due to HighTemp	For more information about this signal contact local Scania representative.
Test Engine Lamp	For more information about this signal contact local Scania representative.
Afterrun Status	For more information about this signal contact local Scania representative.
Engine Air Filter Clogged	For more information about this signal contact local Scania representative.
GasLeakage	For more information about this signal contact local Scania representative.
Incorrect Driver Init Engine Sd	For more information about this signal contact local Scania representative.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Acceleration Rate Limit	For more information about this signal contact local Scania representative.
APP Kickdown Switch	For more information about this signal contact local Scania representative.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.

Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Shutdown Override Switch	If engine shut down due to low oil pressure, low coolant level or high water temperature is available this switch can override the function. The recommended source value for this command is Logical 0.
AP Low Idle Switch Released	A plausibility check is performed in engine control unit between Low Idle Switch and Accelerator Pedal Position.
Emergency Engine Stop	Normally used for engine emergency stop. When used it will set an error- / information code. The recommended source value for this command is Logical 0.
Engine Start *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.
Engine Stop *1*2*3*4*5*6	Normally used for engine emergency stop. Engine Stop (without error code).
Idle Command	Idle Command, forces the engine to run on low idle.
Lamp Test	Activates AC_ACT on the engine control unit, which is used for the Throttle out of order lamp if it is connected.
White smoke limit request	Exhaust brake floor switch, Exhaust brake – Brake Assist Switch or White smoke limit request.
DPF Manual Inhibit	For more information about this signal contact local Scania representative.
ECU analog outputs (controller's inputs)	
Single Speed Droop Value	The actual droop value for single speed engines is transmitted.
Malfunction Indicator	For more information about this signal contact local Scania representative.
Oil Level Measuring Status	Oil Level Measuring
Urea Level	For more information about this signal contact local Scania representative.
Starter Motor Normal Temp	For more information about this signal contact local Scania representative.
Urea level inducement state	0 – urea level OK 1 – low urea level 2 – fill up urea 3 – urea tank empty 6 – error 7 – not available
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential	Electrical potential measured at the input of the electronic control unit supplied through a switching device.

ECU analog inputs (controller's outputs)	
APP - Nominal Speed Offset <small>*1*2*3*4*5*6</small>	If Torque enable is engine speed control. Increase or decrease the reference speed (with or without droop) in relation to nominal engine speed. The setting range can be changed with calibration parameters, normally ± 120 rpm.
DPF Manual Activation	0 – No request 1 – Unvalidated manual regeneration request 2 - Manual regeneration request 3 – 13 – Reserved 14 – Error 15 – Don't care
Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Available signals – Scania S8 Singlespeed

ECU binary outputs (controller's inputs)	
Diagnostic Status	For more information about this signal contact local Scania representative.
Engine stop limit exceed	For more information about this signal contact local Scania representative.
Generator Charge	For more information about this signal contact local Scania representative.
High Engine Coolant Temp	Temperature of liquid in engine cooling system over the limit.
High Engine Oil Level	Oil level over the limit.
Low Engine Oil Level	Oil level under the limit.
Low Engine Oil Pressure	Oil pressure under the limit.
Low Urea Level	Urea level under the limit.
New DTC	For more information about this signal contact local Scania representative.
PowerLost Due to HighTemp	For more information about this signal contact local Scania representative.
Test Engine Lamp	For more information about this signal contact local Scania representative.
Afterrun Status	For more information about this signal contact local Scania representative.
Engine Air Filter Clogged	For more information about this signal contact local Scania representative.
GasLeakage	For more information about this signal contact local Scania representative.
Incorrect Driver Init Engine Sd	For more information about this signal contact local Scania representative.
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Acceleration Rate Limit	For more information about this signal contact local Scania representative.
APP Kickdown Switch	For more information about this signal contact local Scania representative.
APP Low Idle Switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch. The low idle switch is defined in SAE J1843.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Shutdown Override Switch	If engine shut down due to low oil pressure, low coolant level or high water temperature is available this switch can override the function. The recommended source value for this command is Logical 0.
Droop enable <small>*1*2*3*4</small>	Engage or disengage the droop function. The droop value can be changed with a calibration parameter or with TSC-proprietary.
Emergency Engine Stop	Normally used for engine emergency stop. When used it will set an error- / information code. The recommended source value for this command is Logical 0.
Engine Start	The command used for engine running. The recommended source value for this command is Starter.

*1*2*3*4*5*6	
Engine Stop *1*2*3*4*5*6	Normally used for engine emergency stop. Engine Stop (without error code).
Exhaust brake Brake Assist Switch	For more information about this signal contact local Scania representative.
Exhaust brake floor switch	For more information about this signal contact local Scania representative.
Nominal speed switch 1 *1*2*3*4	Choose nominal engine speed with these switches. NSSW1 NSSW2 Nominal speed 0 0 Use changeable calibration parameter
Nominal speed switch 2 *1*2*3*4	1 0 1500 RPM 0 1 1800 RPM 1 1 Low idle command
Retarder Selection	For more information about this signal contact local Scania representative.
Torque Limit 1	Choosing between 4 different torque limit curves (if available) TLSW1 TLSW2 Torque limit 0 0 Highest torque limit curve. (Curve 0)
Torque Limit 2	1 0 Low torque limit curve. (Curve 1) 0 1 User defined curve. (Curve 2) 1 1 User defined curve. (Curve 3)
White smoke limit request	For more information about this signal contact local Scania representative.
DPF Manual Inhibit	For more information about this signal contact local Scania representative.
ECU analog outputs (controller's inputs)	
Single Speed Droop Value	The actual droop value for single speed engines is transmitted.
Malfunction Indicator	For more information about this signal contact local Scania representative.
Oil Level Measuring Status	Oil Level Measuring
Urea Level	For more information about this signal contact local Scania representative.
Starter Motor Normal Temp	For more information about this signal contact local Scania representative.
Urea level inducement state	0 – urea level OK 1 – low urea level 2 – fill up urea 3 – urea tank empty 6 – error 7 – not available
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Nominal Friction Torque	The calculated torque that indicates the amount of torque required by the basic engine itself added by the loss torque of accessories. It contains the frictional and thermodynamic loss of the engine itself, and the losses of fuel, oil and cooling pumps.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential	Electrical potential measured at the input of the electronic control unit supplied through a switching

	device.
ECU analog inputs (controller's outputs)	
APP - Nominal Speed Offset <small>*1*2*3*4*5*6</small>	Nominal speed offset (if Torque enable is "Engine speed control"). Increase or decrease the referens speed (with or without droop) in relation to nominal speed. The offset range is changeble with calibration parameters. (normaly ± 120 rpm, 0% = -120 rpm and 100% = +120 rpm)
DPF Manual Activation	0 – No request 1 – Unvalidated manual regeneration request 2 - Manual regeneration request 3 – 13 – Reserved 14 – Error 15 – Don't care
Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Nominal speed offset settings for InteliGen^{NT} or InteliSys^{NT}	
Source	Speed request
Convert	No
Speed Bias Reference settings for InteliDrive DCU, InteliDrive Mobile	
Source	Speed Request
Convert	No

Recommended wiring

Function	ECU connector	8pin diagnostic connector	Controller
CAN H	?	6	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	?	7	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	1,3,4	N/A
Battery - (negative)	?	2,5	N/A
Key Switch	?	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

SISU


ECU Types

ECU Type	Engine Type
EEM2	xxDxx
EEM3	xxCxx

Engine type explanation

Engine Type	Meaning
74xxx	Cylinder volume in 0.1 litres
xxCxx	C - Common rail D - Bosch VP 44/30 solenoid controlled injection pumps
xxxTx	Turbocharged
xxxxA	Air-to-air intercooler

EEM2 or EEM3



ECU selection in PC software:

SISU EEM3 Gen-set
or
SISU EEM3 Propulsion

Available signals – Gen-set

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Wait to Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	

Start Request *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Fuel solenoid.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Engine Oil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Droop percentage request	Nominal speed offset (if Torque enable is "Engine speed control"). Increase or decrease the referens speed (with or without droop) in relation to nominal speed.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Available signals – Propulsion

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
ECU binary inputs (controller's outputs - commands)	
Start Request *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Fuel solenoid.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.

Coolant Temp	Temperature of liquid found in engine cooling system.
Fuel Temp	Temperature of fuel entering injectors.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
Droop percentage request	Nominal speed offset (if Torque enable is "Engine speed control"). Increase or decrease the referens speed (with or without droop) in relation to nominal speed.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for InteliGen^{NT} or InteliSys^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for InteliDrive DCU, InteliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring – EEM2

Function	ECU 31pin connector	8pin diagnostic connector	Controller
CAN H	30	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	31	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1,3,8,13	N/A	N/A
Battery - (negative)	2,4,7,9	N/A	N/A
Key Switch	5	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

Recommended wiring – EEM3

Function	ECU A2 89pin connector	8pin diagnostic connector	Controller
CAN H	53	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	51	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	52	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1,7,12,13	N/A	N/A
Battery - (negative)	3,9,14,15	N/A	N/A
Key Switch	N/A	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

Steyr

ECU Types

ECU Type	Engine Type
M1	Marine engines

M1

ECU selection in PC software for M1

Steyr M1

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Engine Oil Pressure Light	For more information about this signal contact local Steyr representative.
Engine Warning Light	For more information about this signal contact local Steyr representative.
Preheating Control Light	For more information about this signal contact local Steyr representative.
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	
Engine Speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Position	For more information about this signal contact local Steyr representative.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Keyswitch Battery Potential	Battery potential measured at the input of the electronic control unit.
ECU analog inputs (controller's outputs)	

Controller's analog output for speed control configuration

There is no speed control over CAN bus available for this particular ECU.

Recommended wiring

No documentation available so far!


Diagnostic connector layout is on page 16 or [here](#).

VM

ECU Types

ECU Type	Engine Type
EDC	Industrial and marine

EDC



ECU selection in PC software:

**VM Industrial
or
VM Marine**

Available signals - Industrial

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
PTO Accelerate Switch	Switch signal which indicates that the remote PTO toggle switch is in the enabled (ON) position. If the toggle switch is enabled and other conditions are satisfied then the remote PTO control feature is activated and the PTO will control at a variable speed.
PTO Cost/Decelerate Switch	For more information about this signal contact local VM representative.
PTO Enable Switch	For more information about this signal contact local VM representative.
PTO Resume Switch	For more information about this signal contact local VM representative.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
Water in Fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
Brake Switch	Switch signal which indicates when the brake is set. The recommended source value for this command is Logical 0.
Clutch Switch	For more information about this signal contact local VM representative.
Cruise Control Accelerate Switch	Switch signal of the cruise control activator which indicates that the activator is in the position 'accelerate.' The recommended source value for this command is Logical 0.

Cruise Control Coast Switch	Switch signal of the cruise control activator which indicates that the activator is in the position 'coast (decelerate).' The recommended source value for this command is Logical 0.
Cruise Control Enable Switch	Switch signal which indicates that it is possible to manage the cruise control function. The recommended source value for this command is Logical 0.
Cruise Control Resume Switch	Switch signal of the cruise control activator which indicates that the activator is in the position 'resume.' The recommended source value for this command is Logical 0.
Parking Brake Switch	Switch signal which indicates when the parking brake is set. The recommended source value for this command is Logical 0.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.

ECU analog outputs (controller's inputs)

Barometric Pressure	Absolute air pressure of the atmosphere.
PartTrapAshLoad	For more information about this signal contact local VM representative.
PartTrapSootLoad	For more information about this signal contact local VM representative.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Estimated Percent Fan Speed	Estimated fan speed as a ratio of the fan drive (current speed) to the fully engaged fan drive. A two state fan (off/on) will use 0% and 100% respectively. A variable speed fan will use 0% to 100%. Multiple fan systems will use 0 to 100% to indicate the percent cooling capacity being provided.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temperature	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.

ECU analog inputs (controller's outputs)

PTO State	For more information about this signal contact local VM representative.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Available signals - Marine

ECU binary outputs (controller's inputs)

Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
PTO Accelerate Switch	Switch signal which indicates that the remote PTO toggle switch is in the enabled (ON) position. If the

	toggle switch is enabled and other conditions are satisfied then the remote PTO control feature is activated and the PTO will control at a variable speed.
PTO Cost/Decelerate Switch	For more information about this signal contact local VM representative.
PTO Enable Switch	For more information about this signal contact local VM representative.
PTO Resume Switch	For more information about this signal contact local VM representative.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
Water in Fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
Brake Switch	Switch signal which indicates when the brake is set. The recommended source value for this command is Logical 0.
Clutch Switch	For more information about this signal contact local VM representative.
Cruise Control Accelerate Switch	Switch signal of the cruise control activator which indicates that the activator is in the position 'accelerate.' The recommended source value for this command is Logical 0.
Cruise Control Coast Switch	Switch signal of the cruise control activator which indicates that the activator is in the position 'coast (decelerate).' The recommended source value for this command is Logical 0.
Cruise Control Enable Switch	Switch signal which indicates that it is possible to manage the cruise control function. The recommended source value for this command is Logical 0.
Cruise Control Resume Switch	Switch signal of the cruise control activator which indicates that the activator is in the position 'resume.' The recommended source value for this command is Logical 0.
Parking Brake Switch	Switch signal which indicates when the parking brake is set. The recommended source value for this command is Logical 0.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
Barometric Pressure	Absolute air pressure of the atmosphere.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
EngineOil Temp	Temperature of the engine lubricant.
Fuel Temp	Temperature of fuel entering injectors.
Estimated Percent Fan Speed	Estimated fan speed as a ratio of the fan drive (current speed) to the fully engaged fan drive. A two state fan (off/on) will use 0% and 100% respectively. A variable speed fan will use 0% to 100%. Multiple fan systems will use 0 to 100% to indicate the percent cooling capacity being provided.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
ECU analog inputs (controller's outputs)	
PTO State	For more information about this signal contact local VM representative.
Requested speed *1*2*3*4*5*6	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

More about a constant for ECU controller is on page 17 or [here](#). Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Requested Speed settings for IntelliGen ^{NT} or IntelliSys ^{NT}		
Source	SpeedReq RPM	
Convert	NO	
Limits	N/A	N/A
	N/A	N/A
Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Recommended wiring

Function	ECU connector	diagnostic connector	Controller
CAN H	62	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	N/A	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	83	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	1,5	N/A	N/A
Battery - (negative)	2,4,6	N/A	N/A
Key Switch	28	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	N/A	N/A	SG OUT
Analog Speed Control	N/A	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

Volvo

ECU Types

ECU Type	Engine Type
EDC3 (EMS1)	xxD12xxxx
EMS2	xxD9xxxx, xxD16xxxx, xxD734xx
EDC4 (EMR2)	xxD5xxxx, xxD7xxxx


Engine type explanation

Engine Type	Meaning
Txxxxxxx	Turbocharged
xAxxxxxx	Air to air intercooled
xxDxxxxx	Diesel fuel
xxx16xxxx	Displacement indication
xxxxx3xxx	Generation
xxxxxx0xx	Version
xxxxxxxGx	Generator drive
xxxxxxxEx	Emission controlled

Standalone connection (hardwired speed potentiometer)

On D12 industrial genset engines it's possible to connect stand alone connection. If there is a ComAp panel connected via CAN bus during power up the engine will detect this and will be controlled via CAN bus. But if the ComAp panel is dead during power up the engine and if there is connected a potentiometer on standalone connector the engine will detect this and will run in stand alone mode.

EDC3 (EMS1) or EMS2 (singlespeed engines only)



ECU selection in PC software:

Volvo EMSI Singlespeed / EMSII

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Approaching Shutdown	Status signal which indicates that engine shutdown is imminent. This engine protection signal can be a result of different systems failing, i.e., engine overheating.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
15 Fuse Status	The of the 15 supply fuse.
30 Fuse Status	The of the 30 supply fuse.
Buzzer	Controls the buzzer.
Buzzer/Lampstest	Controls the buzzertest / lampstest.
Coolant Level Alarm	The status of the coolant level alarm switch.
Coolant Temperature	The status of the (virtual) coolant temperature alarm switch.
EMS DiagnoseRedLamp	The status of the red diagnose lamp of the EMS (Mirror of PID 44, J1587)
EMS DiagnoseYellow Lamp	The status of the yellow diagnose lamp of the EMS (Mirror of PID 44, J1587).
EMS Fuse Status	The of the EMS supply fuse.
EngineOil Filter Diff.Press	The status of the engine oil filters differential pressure alarm.
Extra Fuse Status	The of the extra supply supply fuse.
Fuel Pressure Alarm	The status of the Fuel pressure alarm.
General Lampstest	Controls the general lampstest.
Charge Alarm	The status of the (virtual) charge alarm switch.
Oil Pressure Alarm	The status of the (virtual) oil pressure alarm switch.
Oil Temperature Alarm	The status of the (virtual) oil temprature alarm switch.
Override Indication	The status of the engine protection override.
Overspeed Alarm	Status of the (virtual) overspeed alarm switch.

Preheat Indication	The status of the preheat relay.
Primary Bat.Status	Status of the primary battery circuit.
Running Indication	The running status of the engine.
Secondary Bat.Status	Status of the secondary battery circuit.
Water in Fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	
Diagnostic Request *1*2*3*4*5*6	For more information about this commands, please contact local Volvo representative.
Frequency Select *1*2*3*4*5	Indicates if the engine shall operate at Primary engine speed or Secondary engine speed.
Fuel disable request	For more information about this commands, please contact local Volvo representative. The recommended source value for this command is Logical 0.
Governor Mode *1*2*3*4*5*6	Indicates if the engine shall operate in Engine speed mode or Torque mode. 0 – Isochronous mode 1 – Droop mode
Idle Speed Select *1*2*3*4	The idle/rated switch allows commanding the engine between idle speed and rated speed. The recommended source value for this command is Idle/Nominal.
Preheat Request *1*2*3*4	Status of the Preheat request. The recommended source value for this command is Logical 0.
Protection Override *1*2*3*4*5*6	Status of the Engine protection override request. The recommended source value for this command is Logical 0.
Start Request *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
DEF Tank 1 Level	Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container
DEF Tank 1 Low Level Indicator	The desired illumination of the driver's warning indicator for diesel exhaust fluid (DEF) tank low level.
Operator Inducement Severity	The severity of operator inducement for anomalies with the SCR system, such as tampering, low DEF quality, and DEF tank level. Higher numerical levels indicate more severe levels of inducement. Level 1 is the least severe.
EngOil Filter Diff.Press	Change in engine oil pressure, measured across the filter, due to the filter and any accumulation of solid or semisolid material on or in the filter.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Fuel Temp	Temperature of fuel entering injectors.
Oil Temp	Temperature of the engine lubricant.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.

Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Idle engine speed	The calibrated idle speed of the engine.
Maximum engine speed	The maximum engine speed.
ECU analog inputs (controller's outputs)	
Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
Accelerator Pedal Position <small>*1*2*3*4*5*6</small>	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – InteliLite^{NT} *3 – InteliDrive Lite *4 – InteliCompact^{NT} *5 – InteliNano *6 – InteliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Accelerator Pedal Position settings for InteliGen^{NT} or InteliSys^{NT}	
Source	Speed request
Convert	No
Accelerator Pedal Position settings for InteliDrive DCU, InteliDrive Mobile	
Source	Speed Request
Convert	Yes

Frequency change procedure

Customers, who are using ComAp control unit, must transmit certain messages to the D9 / D16 in the same way as Volvo Penta's CIU in order to change from 1500 to 1800 RPM (or opposite).

Procedure if not energized:

1. Power up the ECU.
2. Change the Frequency select setpoint of transmitted value.
3. Send a stop request – press the Stop button.

The whole procedure (step 1 to 3) must not exceed 10 seconds.

Procedure with power on:

1. Send a stop request – press the Stop button.
2. Change the Frequency select setpoint of transmitted value.
3. Send a stop request – press the Stop button.

The whole procedure (step 1 to 3) must not exceed 10 seconds.

Recommended wiring

Function	ECU connector	8pin diagnostic connector	Controller
CAN H	?	1	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	?	2	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	4	N/A
Battery - (negative)	?	3	N/A
Key Switch	?	5	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM
Stop Request	?	6	Any binary output configured as inverted ECU Comm error

Diagnostic connector layout is on page 16 or [here](#).

NOTE:

If the engine doesn't crank, check the state of engine mounted auxiliary stop device.


WARNING!

It is important that there is no continuous active stop signal on pin 6. The active stop signal depends on the configuration and represents either +24VDC or GND is present on the pin 6.

If there is a constant active stop signal a number of problems will occur:

- It is impossible to change parameters.
- It is impossible to reprogram the control unit.
- The ECU could be damaged when power is removed.

EDC3 (EMS1) or EMS2 (allspeed engines only)



ECU selection in PC software:

Volvo EMS1 Allspeed

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Approaching Shutdown	Status signal which indicates that engine shutdown is imminent. This engine protection signal can be a result of different systems failing, i.e., engine overheating.
Shutdown Engine	Status signal which indicates whether or not the engine protection system has shutdown the engine.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Boost Temperature	Status of the (virtual) boost temperature alarm switch.
Coolant Level Alarm	The status of the coolant level alarm switch.
Coolant Temperature	Temperature of liquid found in engine cooling system.
Crankcase Pressure	Gage pressure inside engine crankcase.
EngOil Filter Diff.Press	Change in engine oil pressure, measured across the filter, due to the filter and any accumulation of solid or semisolid material on or in the filter.
Exhaust Temperature	Temperature of combustion exhausts leaving the engine.
Fresh Water Pressure	Status of the (virtual) fresh water pressure alarm switch.
Fuel Pressure Alarm	The status of the Fuel pressure alarm.
Charge Alarm	The status of the (virtual) charge alarm switch.
Oil Level Alarm	The status of the oil level alarm switch.
Oil Pressure Alarm	Gage pressure of oil in engine lubrication system as provided by oil pump.
Oil Temperature Alarm	The status of the (virtual) oil temprature alarm switch.
Overspeed Alarm	Status of the (virtual) overspeed alarm switch.
Piston Cooling Pressure	Status of the piston cooling pressure alarm switch.
Running Indication	The running status of the engine.
Sea Water Pressure	Status of the (virtual) sea water pressure alarm switch.
Water in Fuel Alarm	The status of the water in fuel alarm switch.
Water in Fuel	Signal which indicates the presence of water in the fuel.
ECU binary inputs (controller's outputs - commands)	

Current Gear	For more information about this commands, please contact local Volvo representative.
Crank Request *1*2*3*4*5*6	The command used for engine running. The recommended source value for this command is Starter.
Stop Request *1*2*3*4*5*6	The command for normal stopping of the engine. The recommended source value for this command is Stop pulse.
ECU analog outputs (controller's inputs)	
DEF Tank 1 Level	Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container
DEF Tank 1 Low Level Indicator	The desired illumination of the driver's warning indicator for diesel exhaust fluid (DEF) tank low level.
Operator Inducement Severity	The severity of operator inducement for anomalies with the SCR system, such as tampering, low DEF quality, and DEF tank level. Higher numerical levels indicate more severe levels of inducement. Level 1 is tge least severe.
EngOil Filter Diff.Press	Change in engine oil pressure, measured across the filter, due to the filter and any accumulation of solid or semisolid material on or in the filter.
Actual Torque	The calculated output torque of the engine. The data is transmitted in indicated torque as a percent of reference engine torque. The engine percent torque value will not be less than zero and it includes the torque developed in the cylinders required to overcome friction.
Demand Torque	The requested torque output of the engine by the driver.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application. For on-highway vehicles, this will typically be the operator's accelerator pedal. In marine applications, this will typically be the operator's throttle lever.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Coolant Level	Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank.
Coolant Pressure	Gage pressure of liquid found in engine cooling system.
Crankcase Pressure	Gage pressure inside engine crankcase.
Engine Oil Level	Ratio of current volume of engine sump oil to maximum required volume.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Fuel Delivery Pressure	Gage pressure of fuel in system as delivered from supply pump to the injection pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Fuel Temp	Temperature of fuel entering injectors.
Oil Temp	Temperature of the engine lubricant.
Air Intake Pressure	Absolute air pressure at inlet to intake manifold or air box.
Boost Pressure	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger.
Exhaust Gas Temp	Temperature of combustion exhausts leaving the engine.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Fuel Rate	Amount of fuel consumed by engine per unit of time.
Battery Potential	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Sea Water Pressure	The sea water pressure.
Idle engine speed	The calibrated idle speed of the engine.
Maximum engine speed	The maximum engine speed.
ECU analog inputs (controller's outputs)	
Requested speed	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
Throttle Position *1*2*3*4*5*6	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 – IntelliDrive Nano

Available list of texts of fault codes is [here](#).

Controller's analog output for speed control configuration

Accelerator Pedal Position settings for IntelliGen ^{NT} or IntelliSys ^{NT}	
Source	Speed request
Convert	No
Accelerator Pedal Position settings for IntelliDrive DCU, IntelliDrive Mobile	
Source	Speed Request
Convert	No

Frequency change procedure

Customers, who are using ComAp control unit, must transmit certain messages to the D9 / D16 in the same way as Volvo Penta's CIU in order to change from 1500 to 1800 RPM (or opposite).

Procedure if not energized:

1. Power up the ECU.
2. Change the Frequency select setpoint of transmitted value.
3. Send a stop request – press the Stop button.

The whole procedure (step 1 to 3) must not exceed 10 seconds.

Procedure with power on:

1. Send a stop request – press the Stop button.
2. Change the Frequency select setpoint of transmitted value.
3. Send a stop request – press the Stop button.

The whole procedure (step 1 to 3) must not exceed 10 seconds.

Recommended wiring

Function	ECU connector	8pin diagnostic connector	Controller
CAN H	?	1	CAN1 (extension modules/J1939) – CAN H
CAN COM	?	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	?	2	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	?	4	N/A
Battery - (negative)	?	3	N/A
Key Switch	?	5	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM
Stop Request	?	6	Any binary output configured as inverted ECU Comm error

Diagnostic connector layout is on page 16 or [here](#).

NOTE:

If the engine doesn't crank, check the state of engine mounted auxiliary stop device.


WARNING!

It is important that there is no continuous active stop signal on pin 6. The active stop signal depends on the configuration and represents either +24VDC or GND is present on the pin 6.

If there is a constant active stop signal a number of problems will occur:

- It is impossible to change parameters.
- It is impossible to reprogram the control unit.
- The ECU could be damaged when power is removed.

EDC4 (EMR2)



For more information follow [Deutz EMR2](#) chapter (page 61).

Waukesha

ECU Types

ECU Type	Engine Type
ESM	VHP & APG engine family

ESM



ECU selection in PC software:

Waukesha ESM

Available signals


ECU binary outputs (controller's inputs)	
Main Fuel Valve	Status of the main fuel valve.
Pre-chamber Fuel Valve	Status of the pre-chamber fuel valve (if applicable).
Engine Running	Whether the engine is running or not running.
Starter Motor	Whether the starter motor is engaged or not.
Pre/Post Lube	Whether the pre/post lube pump is running.
Yellow Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Red Shutdown Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Engine Knocking	Whether the engine is in uncontrollable knock.
Start Engine Signal	Whether the start engine signal is active.
Normal Shutdown	Whether the normal shutdown signal is active.
Emergency Shutdown	Whether the emergency shutdown signal is active.
Remote rpm Select	Whether the remote rpm analog input is active or inactive.
Run High Idle	Whether the run high idle digital input is active.
Load Coming	Whether the load coming digital input is active.
Alter Dynamics/Synchr Mode	Whether the alternate governor dynamics is active.
Lockout Button/Ignit Module	Whether either the lockout button has been depressed or the IPM-D has failed, or is not powered.
ECU binary inputs (controller's outputs - commands)	
ECU analog outputs (controller's inputs)	

Engine Speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Intake Manifold Press	Gage pressure of air measured downstream on the compressor discharge side of the turbocharger. If there is one boost pressure to report and this range and resolution is adequate, this parameter should be used.
Throttle Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Coolant Temp	Temperature of liquid found in engine cooling system.
Battery Voltage	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Intake Manifold Temp	Temperature of pre-combustion air found in intake manifold of engine air supply system.
Engine Oil Temp	Temperature of the engine lubricant.
First exhaust temperature	For more information about this commands, please contact local Waukesha representative.
Second exhaust temperature	For more information about this commands, please contact local Waukesha representative.
ECU analog inputs (controller's outputs)	

Controller's analog output for speed control configuration

There is no speed control over datalink available for this particular ECU.

Recommended wiring



WARNING!

Check that RS485 bus terminating resistors or appropriate jumpers are connected.

Recommended wiring

Function	ECU 47pin connector	9pin diagnostic connector	Controller
RS485 A	2	N/A	RS485 – RS485 A
RS485 COM	N/A	N/A	RS485 – RS485 COM
RS485 B	23	N/A	RS485 – RS485 B
Battery + (positive)	N/A	N/A	N/A
Battery - (negative)	N/A	N/A	N/A
Key Switch	N/A	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	28	N/A	SG OUT
Analog Speed Control	29	N/A	SG COM

*Analog Speed Control range - 2.5VDC to + 2.5VDC

Controller recommended setting (Setpoints/Comms settings group)

Controller	Setpoint	Value	Interface (Connector)
InteliGen ^{NT}	RS232(1) mode RS232(2) mode	ECU LINK	
	RS485(X)conv.	ENABLED DISABLED	RS 485(1), RS 485(2) RS 232(1) * ³ , RS 232(2) * ³
InteliSys ^{NT}	RS232(2) mode	ECU LINK	
	RS485(X)conv.	ENABLED DISABLED	RS 485(2) RS 232(1) * ³ , RS 232(2) * ³

*³ external RS232-485 converter is required

Available list of texts of fault codes is [here](#).

Waukesha wiring recommendations

Two modbus wires are available at the end of the Customer Interface Harness (loose wires). The two wires are grey and labeled **RS 485A-** and **RS 485B+**.

RS-485 networking needs termination resistors if long wire runs are used. Termination resistors of 120Ω are placed across the RS-485 A- and B+ wires at each device and at the MODBUS master (INTELIGEN-NT, INTELISYS-NT controllers has jumper connecting this resistor closed as default). For short distances of 10 m or less and with slower baud rates (ComAp uses 9600 bps), termination resistors are not needed.

Typically, short distances of 32 ft. (10 m) would not require termination resistors; however, if you experience communication errors, first check the programmed baud rate. ComAp uses 9600 bps which is Waukesha default setting. If communication errors persist, termination resistors may be necessary even for short distances.

Diagnostic lamps


It is possible to configure Yellow Warning Lamp and Red Shutdown Lamp as binary inputs. Displaying of fault codes in the alarm list is conditioned by configuration of these inputs. Once they are not configured the alarms are blocked and not displayed.

Yanmar

ECU Types

ECU Type	Engine Type
TNV	All TNV Common Rail Series

TNV



ECU selection in PC software:

Yanmar TNV

Available signals

ECU binary outputs (controller's inputs)	
Amber Warning Lamp	This lamp is used to relay trouble code information that is reporting a problem with the engine system but the engine need not be immediately stopped.
Malfunction Lamp	This lamp is used to relay only emissions-related trouble code information. This lamp is only illuminated when there is an emission-related trouble code active.
Protect Lamp	This lamp is used to relay trouble code information that is reporting a problem with a engine system that is most probably not electronic subsystem related.
Red Stop Lamp	This lamp is used to relay trouble code information that is of a severe enough condition that it warrants stopping the engine.
Preheat	The status of the preheat relay.
AP low idle switch	Switch signal which indicates the state of the accelerator pedal 1 low idle switch.
Wait To Start Lamp	This lamp indicates that the engine is too cold to start and the operator should wait until the signal becomes inactive (turns off).
ECU binary inputs (controller's outputs - commands)	
Shutdown Requests	For more information about this signal contact local Yanmar representative.
ECU analog outputs (controller's inputs)	
Air Inlet Temperature	Temperature of air entering air induction system.
Barometric Pressure	Absolute air pressure of the atmosphere.
Engine speed	Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders.
Starter mode	0 - start not requested 1 - starter active, gear not engaged 2 - starter active, gear engaged 3 - start finished 4 - starter inhibited due to engine already running

	5 - starter inhibited due to engine not ready for start 6 - starter inhibited due to driveline engaged or other transmission inhibit 7 - starter inhibited due to active immobilizer 8 - starter inhibited due to starter over-temp 9 -11 - reserved 12 - starter inhibited 13,14 - error (legacy implementation only, use 1110) 15 - not available
AP Position	The ratio of actual position of the analog engine speed/torque request input device (such as an accelerator pedal or throttle lever) to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.
Percent Load	The ratio of actual engine percent torque (indicated) to maximum indicated torque available at the current engine speed, clipped to zero torque during engine braking.
Desired Operating Speed	An indication by the engine of the optimal operating speed of the engine for the current existing conditions. These conditions may include the torque generated to accommodate powertrain demands from the operator. Dynamic commands from functions such as smoke control or shift control are excluded from this calculation.
Engine Oil Pressure	Gage pressure of oil in engine lubrication system as provided by oil pump.
Coolant Temp	Temperature of liquid found in engine cooling system.
Oil Temp	Temperature of the engine lubricant.
ECU Temperature	Temperature of the engine electronic control unit.
Battery Potential (Voltage)	Electrical potential measured at the input of the electronic control unit supplied through a switching device.
Electrical Potential	Measured electrical potential of the battery.
ECU analog inputs (controller's outputs)	
Requested speed123456	This is the engine speed which the engine is expected to operate at if the speed control mode is active or the engine speed which the engine is not expected to exceed if the speed limit mode is active.
Accelerator Pedal Position	The ratio of actual position of the analog engine speed/torque request input device to the maximum position of the input device. This parameter is intended for the primary accelerator control in an application.

Supported parameter by the controllers configured by NanoEdit, DriveEdit or LiteEdit PC software:

*1 – IntelliLite^{NT} *3 – IntelliDrive Lite *4 – IntelliCompact^{NT} *5 – IntelliNano *6 –IntelliDrive Nano

Controller's analog output for speed control configuration

Requested Speed settings for IntelliDrive DCU, IntelliDrive Mobile		
Source	Speed Request	
Convert	Yes	
Limits	0.0 %	Min eng. speed (800RPM)
	100.0 %	Max eng. speed (2100RPM)

Diagnostic connector layout is on page 16 or [here](#). Available list of texts of fault codes is [here](#).

Recommended wiring

Function	ECU connector	diagnostic connector	Controller
CAN H	40	N/A	CAN1 (extension modules/J1939) – CAN H
CAN COM	30	N/A	CAN1 (extension modules/J1939) – CAN COM
CAN L	39	N/A	CAN1 (extension modules/J1939) – CAN L
Battery + (positive)	34	N/A	N/A
Battery - (negative)	33,45	N/A	N/A
Key Switch	7	N/A	Any binary output configured as ECU PwrRelay
Analog Speed Control	?	N/A	SG OUT
Analog Speed Control	?	N/A	SG COM

Diagnostic connector layout is on page 16 or [here](#).

List of Texts of ECU Fault Codes

Agco Power EEM4

Fault Code (SPN)	Text				
3	Fuel Injectors	639	Vehicle CAN	9031	MainRelay2Shrt
51	ThrottlePos	651	SolenoidValve1	9032	MainRelay3Shrt
91	AccelPedalPos	652	SolenoidValve2	9033	MainRelay
94	Fuel Presssure	653	SolenoidValve3	9034	MainRelayDfct
97	Water In Fuel	654	SolenoidValve4	9035	NormalRecovery
98	EngineOilLevel	655	SolenoidValve5	9036	Full restart
100	Oil Pressure	656	SolenoidValve6	9070	CrankSpeedSens
101	CrankcasePress	677	EngStartRelay	9071	CrankSpeedSens
102	Boost Pressure	723	Cam Speed Sig	9072	CrankSpeedSens
105	IntakeAir Temp	898	RequestedSpeed	9080	CamSpeedSensor
106	AirInletPress	970	AuxEngSdSwitch	9081	CamSpeedSensor
107	Air Filter	971	EngDerateSwtch	9082	CamSpeedSensor
108	Ambient Press	1043	Int.12VSupply	9083	CamSpeedSensor
109	Coolant Press	1076	MPROP Control	9090	EngineSpeedErr
110	Coolant Temp	1077	MPROP Temp	9107	InvalidECUAddr
111	Coolant Level	1109	EngSdApproach	9131	SolenoidValve1
153	CrankcasePress	1110	Engine Sd	9132	SolenoidValve2
157	Rail Pressure	1136	ECU Temp	9133	SolenoidValve3
168	BAT Voltage	1485	MainRelay	9134	SolenoidValve4
172	AirInlet Temp	3509	5V Supply 1	9135	SolenoidValve5
174	Fuel Temp	3510	5V Supply 2	9136	SolenoidValve6
175	EngOil Temp	3511	5V Supply 3	9140	Throttle2Sens
189	RatedEngSpeed	3512	12V Supply 1	9141	Throttle3Sens
190	Engine Speed	4201	CrankSpeed Sig	9150	Rail Pressure
231	J1939 Datalink	9006	VehicleCANoff	9151	PressReliefVlv
237	VIN	9008	IDmoduleCANoff	9152	FuelFiltrPress
515	EngDesOpSpeed	9010	AmbientPress	9153	FuelFiltrPress
620	5V SupplyFail	9021	5Vdc Supply 1	9174	MPROP
626	Grid Heater	9022	5Vdc Supply 2	9230	EngSpecMismtch
628	EMSProgFailure	9023	5Vdc Supply 3	9231	EngSNMismatch
629	EEPROMChecksum	9024	WaterInFuelSup	9233	IDM-NotPresent
630	CalibrMemFail	9025	SelfTestWtchdg	9234	IDM-NotComptbl
636	Crank Sensor	9026	SelfTestVoltHi	9235	ID Module
637	TimingSensor	9027	SelfTestVoltLo	9236	IDM-MemDefect
		9030	MainRelay1Shrt	9237	IDM-Watchdog

9238	IDM-Brownout
9239	EngSpecMissing
9240	EngSNMissing
9241	IDM-NotPresent
9242	GeneratedByPTE
9243	MaxECUByPTE
9305	BadDIConfig
9306	PTO InputError
9310	ExternalFlt1
9311	ExternalFlt2
9312	TorqCtrlInput
520200	Powerstages
520201	Engine CAN
520202	Main Relay 1
520203	Main Relay 2
520208	Rail PRV
520209	Fuel Injectors

520210	Fuel Injectors
520212	Internal 0105
520213	Internal 0106
520214	Internal 0107
520215	Internal 0108
520216	Internal 0109
520217	Internal 0110
520218	Internal 0111
520219	Internal 0112
520220	Internal 0113
520221	Internal 0114
520222	Internal 0115
520223	Internal 0116
520224	Internal 0117
520225	Internal 0118
520226	Internal 0119
520227	Internal 0120

520228	Internal 0121
520229	Internal 0122
520230	Engine Spec
520232	Digital Inputs
520233	Internal 0128
520234	Internal 0129
520235	Internal 0130
520236	Internal 0131
520240	InjectorBank 0
520241	InjectorBank 1
520243	Rail PRV
520244	Rail PRV
520245	Rail PRV
520246	Rail PRV
520247	Internal 0123
520297	Internal 0132
520298	Internal 0133

Caterpillar ADEM A4 with EMCP3.x or ADEM A4 with EMCP4.x

Fault Code (SPN)	Text				
38	ExtTankFuelLvl	515	EngDesOpSpeed	1142	ExhaustTemp 6
51	ThrottlePos	620	5V SupplyFail	1143	ExhaustTemp 7
82	StartAirPress	625	SCADA DataLink	1144	ExhaustTemp 8
91	AccelPedalPos	626	PrehActuator	1145	ExhaustTemp 9
94	FuelDelPress	628	EMSProgFailure	1146	ExhaustTemp10
95	FuelFiltDifPre	629	EEPROMChecksum	1147	ExhaustTemp11
96	Fuel Level	630	CalibrMemFail	1148	ExhaustTemp12
97	WaterInFuelInd	636	Crank Sensor	1149	ExhaustTemp13
98	EngineOilLevel	637	TimingSensor	1150	ExhaustTemp14
99	OilFilterDifPr	639	J1939 CAN Bus	1151	ExhaustTemp15
100	EngOil Press	651	InjectorCyl#1	1152	ExhaustTemp16
101	CrankcasePress	652	InjectorCyl#2	1203	AuxCoolantPres
102	Boost Press	653	InjectorCyl#3	1231	Accessory DL
105	Intake Temp	654	InjectorCyl#4	1239	Fuel Leakage
106	AirInletPress	655	InjectorCyl#5	1485	ECU MainRelay
107	AirFiltDifPres	656	InjectorCyl#6	1656	hidden
108	BarometricPres	677	EngStartRelay	1664	Start Fail
109	Coolant Press	701	Custom Event 1	2433	RExhaustTemp
110	EngCool Temp	702	Custom Event 2	2434	LExhaustTemp
111	Coolant Level	703	Custom Event 3	2436	Gen Frequency
137	FireExtinPress	704	Custom Event 4	2440	Gen Voltage
153	CrankcasePress	705	Custom Event 5	2448	Gen Current
158	BattPotential	706	Custom Event 6	2452	Gen Rev. Power
167	BattChrgSystV	898	RequestedSpeed	2648	ServiceTime
168	BatteryVoltage	924	Digital Out 1	4000	AirDampClosed
171	AmbientAirTemp	925	Digital Out 2	4001	ATS in NormPos
172	AirInlet Temp	970	AuxEngSdSwitch	4002	ATS in EmerPos
173	Exhaust Temp	971	EngDerateSwtch	4003	BattChrgFail
174	Fuel Temp	1109	EngSdApproach	4004	GCB Closed
175	EngOil Temp	1110	Engine Sd	4005	MCB Closed
189	RatedEngSpeed	1122	GenRBearingTmp	4006	hidden
190	EngineSpeed	1137	ExhaustTemp 1	4007	hidden
231	J1939 Datalink	1138	ExhaustTemp 2	4008	Engine Sd
234	hidden	1139	ExhaustTemp 3	4193	CoolantPumpTmp
237	VIN	1140	ExhaustTemp 4		
		1141	ExhaustTemp 5		

hidden – the fault code is not displayed in the controller’s alarm and history list

Caterpillar ADEM

Fault Code (SPN)	Text				
51	ThrottlePos	153	CrankcasePress	636	Crank Sensor
91	AccelPedalPos	158	BattPotential	637	TimingSensor
94	FuelDelPress	168	BatteryVoltage	639	J1939 CAN Bus
97	WaterInFuelInd	172	AirInlet Temp	651	InjectorCyl#1
98	EngineOilLevel	174	Fuel Temp	652	InjectorCyl#2
100	EngOil Press	175	EngOil Temp	653	InjectorCyl#3
101	CrankcasePress	189	RatedEngSpeed	654	InjectorCyl#4
102	Boost Press	190	EngineSpeed	655	InjectorCyl#5
105	Intake Temp	231	J1939 Datalink	656	InjectorCyl#6
106	AirInletPress	237	VIN	677	EngStartRelay
107	AirFiltDifPres	515	EngDesOpSpeed	898	RequestedSpeed
108	BarometricPres	620	5V SupplyFail	970	AuxEngSdSwitch
109	Coolant Press	626	PrehActuator	971	EngDerateSwth
110	EngCool Temp	628	EMSProgFailure	1109	EngSdApproach
111	Coolant Level	629	EEPROMChecksum	1110	Engine Sd
		630	CalibrMemFail	1485	ECU MainRelay

Cummins CM500

Fault Code (SPN)	Text				
29	Hand Throttle	168	BatteryVoltage	1043	IntManifold
91	hidden	174	Fuel Temp	1076	FuelPump
94	FuelDelPress	175	EngOil Temp	1077	FuelPump
97	WaterInFuelInd	190	EngineSpeed	1078	FuelPump
98	EngineOilLevel	191	OutShaftSpeed	1083	AuxTempSensor
100	EngOil Press	558	AP Idle	1084	AuxPressSensor
102	Boost Press	620	5V SupplyFail	1129	IntakePressure
105	Intake Temp	626	PrehActuator	1131	IntakeMan2Temp
108	BarometricPres	627	PowerLost	1132	IntakeMan3Temp
109	Coolant Press	629	EEPROMChecksum	1172	Turbo Temp
110	EngCool Temp	630	CalibrMemFail	1173	Turbo 2 Temp
111	Coolant Level	632	FuelShutoff	1244	FuelingAct
135	FuelPump	633	FuelActuator	1349	InjectorRail#2
156	FuelTiming	635	EngineTiming	1347	FuelPressure
157	FuelRail Press	639	J1939 CAN Bus	1380	LowOilLevel
		974	RemAPSensor	1384	Shutdown J1939

hidden – the fault code is not displayed in the controller's alarm and history list

Cummins CM558

Fault Code (SPN)	Text				
51	ThrottlePos	624	DiagnosticLamp	2634	Main Relay
100	EngOil Press	629	EEPROMChecks um	3464	ThrottleCmd
105	Intake Temp	630	CalibrMemFail	3509	SensorSupply1
109	Coolant Press	632	FuelShutoff	3510	SensorSupply2
110	EngCool Temp	633	FuelActuator	3563	IntakePress 1
168	BatteryVoltage	639	J1939 CAN Bus	3938	GenSpdGovBias
190	EngineSpeed	724	Heated Oxygen	520352	IgnitSdRelay
444	Battery 2 Volt	1136	ECU Temp	520353	CarburInletGas
623	RedStopLamp	1204	ElectricalLoad		
		1442	Fuel Valve 1		

Cummins CM570

Fault Code (SPN)	Text				
51	ThrottlePos	158	BattPotential	636	Crank Sensor
91	AccelPedalPos	168	BatteryVoltage	637	TimingSensor
94	FuelDelPress	172	AirInlet Temp	639	J1939 CAN Bus
97	WaterInFuelInd	174	Fuel Temp	651	InjectorCyl#1
98	EngineOilLevel	175	EngOil Temp	652	InjectorCyl#2
100	EngOil Press	189	RatedEngSpeed	653	InjectorCyl#3
101	CrankcasePress	190	EngineSpeed	654	InjectorCyl#4
102	Boost Press	231	J1939 Datalink	655	InjectorCyl#5
105	Intake Temp	237	VIN	656	InjectorCyl#6
106	AirInletPress	515	EngDesOpSpeed	677	EngStartRelay
107	AirFiltDifPres	620	5V SupplyFail	898	RequestedSpeed
108	BarometricPres	626	PrehActuator	970	AuxEngSdSwitch
109	Coolant Press	627	PowerLost	971	EngDerateSwtch
110	EngCool Temp	628	EMSProgFailure	1109	EngSdApproach
111	Coolant Level	629	EEPROMChecksum	1110	Engine Sd
153	CrankcasePress	630	CalibrMemFail	1485	ECU MainRelay

Cummins CM800

Fault Code (SPN)	Text				
51	ThrottlePos	158	BattPotential	636	Crank Sensor
91	AccelPedalPos	168	BatteryVoltage	637	TimingSensor
94	FuelDelPress	172	AirInlet Temp	639	J1939 CAN Bus
97	WaterInFuelInd	174	Fuel Temp	651	InjectorCyl#1
98	EngineOilLevel	175	EngOil Temp	652	InjectorCyl#2
100	EngOil Press	189	RatedEngSpeed	653	InjectorCyl#3
101	CrankcasePress	190	EngineSpeed	654	InjectorCyl#4
102	Boost Press	231	J1939 Datalink	655	InjectorCyl#5
105	Intake Temp	237	VIN	656	InjectorCyl#6
106	AirInletPress	515	EngDesOpSpeed	677	EngStartRelay
107	AirFiltDifPres	620	5V SupplyFail	898	RequestedSpeed
108	BarometricPres	626	PrehActuator	970	AuxEngSdSwitch
109	Coolant Press	627	PowerLost	971	EngDerateSwtch
110	EngCool Temp	628	EMSProgFailure	1109	EngSdApproach
111	Coolant Level	629	EEPROMChecksum	1110	Engine Sd
153	CrankcasePress	630	CalibrMemFail	1485	ECU MainRelay

Cummins CM850

Fault Code (SPN)	Text
51	ThrottlePos
91	AccelPedalPos
94	FuelDelPress
97	WaterInFuelInd
98	EngineOilLevel
100	EngOil Press
101	CrankcasePress
102	Boost Press
105	Intake Temp
106	AirInletPress
107	AirFiltDifPres
108	BarometricPres
109	Coolant Press
110	EngCool Temp
111	Coolant Level
153	CrankcasePress
157	FuelRail Press
158	BattPotential
166	CylPowerImbal
168	BatteryVoltage
172	AirInlet Temp
173	Exhaust Temp
174	Fuel Temp

175	EngOil Temp
189	RatedEngSpeed
190	EngineSpeed
231	J1939 Datalink
237	VIN
515	EngDesOpSpeed
611	APCDieselFlow
612	CrankshaftSpd
620	5V SupplyFail
626	PrehActuator
627	PowerLost
628	EMSProgFailure
629	EEPROMChecksum
630	CalibrMemFail
633	FuelActuator
636	Crank Sensor
637	TimingSensor
639	hidden
651	InjectorCyl#1
652	InjectorCyl#2
653	InjectorCyl#3
654	InjectorCyl#4
655	InjectorCyl#5
656	InjectorCyl#6

677	EngStartRelay
697	PWM1-Gauge1
723	SecSpeedSens
898	RequestedSpeed
970	AuxEngSdSwitch
971	EngDerateSwthch
1075	ElectrLiftPump
1109	EngSdApproach
1110	Engine Sd
1347	FuelPressure
1485	ECU MainRelay
2802	ECMDataLost
3509	SensorSupply1
3510	SensorSupply2
3511	SensorSupply3
3512	SensorSupply4
3597	ECUSupplyVolt
3938	GenSpdGovBias
4182	GenFrequencPot
4183	DroopPotentiom

hidden – the fault code is not displayed in the controller’s alarm and history list

Cummins PGI 1.1 interface (CM850 or CM2150 or CM2250)

Fault Code (SPN)	Text				
27	EGRValvePos	611	APCDieselFlow	1073	EngComprBrake
81	DPF Pressure	612	CrankshaftSpd	1075	ElectrLiftPump
84	SpeedSensor	623	RedStopLamp	1112	EngineBrake#3
91	AccelPedalPos	627	PowerLost	1128	IntakeMan2Pres
93	SwitchData	629	EEPROMChecksum	1131	IntakeMan2Temp
94	FuelDelPress	630	CalibrMemFail	1132	IntakeMan3Temp
95	FuelFilDifPres	633	FuelActuator	1133	IntakeMan4Temp
97	WaterInFuel	639	hidden	1136	ECU Temp
99	OilFilterDifPr	640	AuxCmdDualSd	1137	ExhaustTemp 1
100	EngOil Press	641	VGT Actuator	1138	ExhaustTemp 2
101	CrankcasePress	644	ExtSpeedInput	1139	ExhaustTemp 3
102	Boost Press	647	CoolingFan	1140	ExhaustTemp 4
103	TBC1Speed	651	InjectorCyl#1	1141	ExhaustTemp 5
105	Intake Temp	652	InjectorCyl#2	1142	ExhaustTemp 6
108	BarometricPres	653	InjectorCyl#3	1143	ExhaustTemp 7
109	Coolant Press	654	InjectorCyl#4	1144	ExhaustTemp 8
110	EngCool Temp	655	InjectorCyl#5	1145	ExhaustTemp 9
111	Coolant Level	656	InjectorCyl#6	1146	ExhaustTemp 10
157	FuelRail Press	657	InjectorCyl#7	1147	ExhaustTemp 11
166	CylPowerImbal	658	InjectorCyl#8	1148	ExhaustTemp 12
168	BatteryVoltage	659	InjectorCyl#9	1149	ExhaustTemp 13
171	AmbientAirTemp	660	InjectorCyl#10	1150	ExhaustTemp 14
173	Exhaust Temp	661	InjectorCyl#11	1151	ExhaustTemp 15
174	Fuel Temp	662	InjectorCyl#12	1152	ExhaustTemp 16
175	EngOil Temp	663	InjectorCyl#13	1172	Turbo Temp
183	Fuel Rate	664	InjectorCyl#14	1208	Pre-OilFilterP
190	EngineSpeed	665	InjectorCyl#15	1209	ExhaustGasPres
191	OutShaftSpeed	666	InjectorCyl#16	1231	CAN Bus OFF
251	RTCPowerInterr	697	PWM1-Gauge1	1235	CAN Bus OFF
411	ExhaustGasPres	701	AuxInput1Act	1242	BrakePower
412	EGR Temp	702	AuxInOut#2	1265	OilBurnValve
441	AuxTempSensIn1	703	AuxInOut#3	1322	MisfireCyls
558	AP Idle	723	SecSpeedSens	1323	MisfireCyl1
597	BrakeSwitch	729	AirHeaterRelay	1324	MisfireCyl2
		974	RemAPSensor	1325	MisfireCyl3

1326	MisfireCyl4	2434	LExhaustTemp	3610	DPFOutletPress
1327	MisfireCyl5	2623	AccelPedalPos	3703	DPF RegenInhib
1328	MisfireCyl6	2630	ChargeAirTemp	3936	DPF System
1329	MisfireCyl7	2789	SysDiagCode#1	3938	GenSpdGovBias
1330	MisfireCyl8	2791	EGR Actuator	4182	GenFrequencPot
1331	MisfireCyl9	2797	InjectorBank	4183	DroopCircuit
1332	MisfireCyl10	3050	AftertreatDOC	4184	GainCircuit
1333	MisfireCyl11	3058	EngineEGR	4185	OverspeedSDRel
1334	MisfireCyl12	3241	AftExhGasTmp#1	4186	LOP SD Relay
1335	MisfireCyl13	3242	DPFIntakGasTmp	4187	HET SD Relay
1336	MisfireCyl14	3245	AftExhGasTmp#3	4188	Pre-LowOilPres
1337	MisfireCyl15	3246	DPFOultGasTmp	4223	Pre-HighEngTmp
1338	MisfireCyl16	3249	AftExhGasTmp#2	4795	Aftertreatment
1347	Fuel-pump	3251	APFDiffPresSns	4796	Aftertreatment
1377	MultUnitSynch	3481	AftFuelRate	5298	Aftertreatment
1378	OilChangeTime	3509	SensorSupply1	520199	CruiseControl
1380	LowOilLevel	3510	SensorSupply2	520320	CrankcasDepres
1387	AuxPressure	3511	SensorSupply3	520441	EGROutPresSens
1388	AuxPressSens#1	3512	SensorSupply4	520442	EGRMixTempSens
1484	Severe Fault	3513	SensorSupply5	520448	CrankcaseVent
1563	ECMIdentificat	3514	SensorSupply6	524286	TemporaryUse
1632	LowOilLevel	3549	Post-OilFilter		
1634	CVN Error	3555	AmbientAirDens		
1800	BatteryTemp	3556	AftFuelInj#1		
2433	RExhaustTemp	3597	ECUSupplyVolt		

hidden – the fault code is not displayed in the controller's alarm and history list

Cummins CM2250 industrial

Fault Code (SPN)	Text				
27	EGRValvePos	641	VGT Actuator	1209	ExhaustGasPres
81	DPF Pressure	647	CoolingFan	1231	CAN Bus OFF
97	WaterInFuelInd	651	InjectorCyl#1	1347	FuelPressure
100	EngOil Press	652	InjectorCyl#2	1378	OilChangeTime
101	CrankcasePress	653	InjectorCyl#3	2789	SysDiagCode#1
102	Boost Press	654	InjectorCyl#4	2791	EGR Actuator
103	TBC1Speed	655	InjectorCyl#5	2797	InjectorBank
105	Intake Temp	656	InjectorCyl#6	3509	SensorSupply1
110	EngCool Temp	657	InjectorCyl#7	3510	SensorSupply2
111	Coolant Level	658	InjectorCyl#8	3511	SensorSupply3
157	FuelRail Press	659	InjectorCyl#9	3512	SensorSupply4
168	BatteryVoltage	660	InjectorCyl#10	3513	SensorSupply5
171	AmbientAirTemp	661	InjectorCyl#11	3514	SensorSupply6
190	EngineSpeed	662	InjectorCyl#12	3555	AmbientAirDens
411	ExhaustGasPres	663	InjectorCyl#13	3597	ECUSupplyVolt
412	EGR Temp	664	InjectorCyl#14	4795	Aftertreatment
611	FuelInletMeter	665	InjectorCyl#15	4796	Aftertreatment
627	PowerLost	666	InjectorCyl#16	520320	CrankcasDepres
629	EEPROMChecksum	723	SecSpeedSens		
633	FuelActuator	729	AirHeaterRelay		
639	hidden	1075	ElectrLiftPump		
		1136	ECU Temp		

hidden – the fault code is not displayed in the controller's alarm and history list

Cummins GCS

Fault Code (SPN)	Text				
111	ECM-IntFailure	219	EngOilLevelLow	1428	LOPLampError
115	MagPickupSenSd	221	BarPressSensH	1429	HETLampError
121	MgPickupSenWrn	222	BarPressSensL	1431	PreLOPLampErr
122	IntkManPressLH	223	OilBurnValvSol	1432	PreHETLampErr
123	IntkManPressLL	228	CoolPresCritLo	1433	LocEmergStop
128	IntkManPressRH	231	CoolPressSensH	1434	RemEmergStop
129	IntkManPressRL	232	CoolPressSensL	1435	EngineCold
135	OilPrsSenShrtH	234	EngSpeedHigh	1438	FailToCrank
141	OilPrsSenShrtL	235	CoolLvlCritLow	1443	BattVoltLow
143	EngOilPressLow	253	OilLvlCritLow	1473	ECMWatchdogFls
144	CoolTSenShortH	254	FuelShutoffVal	1479	FailToStrtLamp
145	CoolTSenShortL	261	FuelTempHigh	2297	FuelSuppPumpLa
146	EngCoolTmpHigh	263	FuelTmpSenShrH	2974	RackPosSensor1
151	EngCoolTCritH	265	FuelTmpSenShrL	2975	RackPosSensor2
152	EngCoolTempLow	266	FuelTmpCritHig	112	EngTimingActtr
153	IntakeManTmpLB	343	ECM-IntHWFail	113	EngTimActCirc
154	IntakManTmpSen	415	OilPresCritLow	116	FuelPresSensSH
155	CritIntakeManT	421	OilTempHigh	117	FuelPresSensSL
159	IntkManTmpSenH	422	CoolLvlSensor	118	FuelPumpSensSH
161	IntkManTmpSenL	471	OilLevelLow	119	FuelPumpSensSL
166	RackPositSensH	488	IntakeManTmpH	224	CentinelActShr
167	RackPositSensL	581	FuelSuppPumpPH	236	EngPositionSen
168	RackActPositLB	582	FuelSuppPumpPL	252	EngOilLevelSen
169	RackActPositLB	1211	FuelShutoffVlv	259	FuelShutoffVlv
171	FuelRackActPos	1212	FuelShutoffVlv	316	FuelSuppPumpSH
174	RackActuatrPos	1411	GenOutFreqPot	318	FuelSuppPumpSt
179	RackPositSensH	1412	DroopAdjPotent	326	EngOilLevelLow
181	RackPositSensL	1413	ContrConfigErr	359	FailedToStart
182	RackActPositRB	1416	FailToShutdown	423	FuelActtrStuck
183	RackActPositRB	1417	ECMPowrdwnFail	441	Batt1VoltLow
197	CoolantLvlLow	1418	GainAdjPotent	442	Batt1VoltHigh
212	OilTempSensorH	1424	DiagLampError	451	InjectrPSensSH
213	OilTempSensorL	1425	CommSdLampErr	452	InjectrPSensSL
214	OilTmpCritHigh	1426	CommWrnLampErr	455	FuelCtrlValvSH
		1427	OSLampError	467	TimRailActCirc

468	FuelRailActCrc
498	EngOilLvlSenSH
499	EngOilLvlSenSL
514	FuelCtrlValve
554	FuelPresSenErr
555	EnginBlowbyWrn
556	EngineBlowbySD
611	EngHotShutdown

649	ChangeLubrOil
688	EngOilLvl1High
689	EngSpeedSenErr
719	BlowbyPrSensSH
729	BlowbyPrSensSL
1419	FuelRailError
1421	TimingRailDrv1
1422	TimingRailDrv2

1423	FuelPumpDiagEr
1436	HPI-PTFuelSyst
2111	EngCoolTmp2SSH
2112	EngCoolTmp2SSL
2113	EngCoolTmp2Wrn
2114	EngCoolTemp2SD

Daimler Chrysler ADM2

Fault Code (SPN)	Text				
51	ThrottlePos	153	CrankcasePress	636	Crank Sensor
91	AccelPedalPos	158	BattPotential	637	TimingSensor
94	FuelDelPress	168	BatteryVoltage	639	J1939 CAN Bus
97	WaterInFuelInd	172	AirInlet Temp	651	InjectorCyl#1
98	EngineOilLevel	174	Fuel Temp	652	InjectorCyl#2
100	EngOil Press	175	EngOil Temp	653	InjectorCyl#3
101	CrankcasePress	189	RatedEngSpeed	654	InjectorCyl#4
102	Boost Press	190	EngineSpeed	655	InjectorCyl#5
105	Intake Temp	231	J1939 Datalink	656	InjectorCyl#6
106	AirInletPress	237	VIN	677	EngStartRelay
107	AirFiltDifPres	515	EngDesOpSpeed	898	RequestedSpeed
108	BarometricPres	620	5V SupplyFail	970	AuxEngSdSwitch
109	Coolant Press	626	PrehActuator	971	EngDerateSwtch
110	EngCool Temp	628	EMSProgFailure	1109	EngSdApproach
111	Coolant Level	629	EEPROMChecksum	1110	Engine Sd
		630	CalibrMemFail	1485	ECU MainRelay

Daimler Chrysler ADM3

Fault Code (SPN)	Text				
51	ThrottlePos	153	CrankcasePress	636	Crank Sensor
91	AccelPedalPos	158	BattPotential	637	TimingSensor
94	FuelDelPress	168	BatteryVoltage	639	J1939 CAN Bus
97	WaterInFuelInd	172	AirInlet Temp	651	InjectorCyl#1
98	EngineOilLevel	174	Fuel Temp	652	InjectorCyl#2
100	EngOil Press	175	EngOil Temp	653	InjectorCyl#3
101	CrankcasePress	189	RatedEngSpeed	654	InjectorCyl#4
102	Boost Press	190	EngineSpeed	655	InjectorCyl#5
105	Intake Temp	231	J1939 Datalink	656	InjectorCyl#6
106	AirInletPress	237	VIN	677	EngStartRelay
107	AirFiltDifPres	515	EngDesOpSpeed	898	RequestedSpeed
108	BarometricPres	620	5V SupplyFail	970	AuxEngSdSwitch
109	Coolant Press	626	PrehActuator	971	EngDerateSwtch
110	EngCool Temp	628	EMSProgFailure	1109	EngSdApproach
111	Coolant Level	629	EEPROMChecksum	1110	Engine Sd
		630	CalibrMemFail	1485	ECU MainRelay

Detroit Diesel Engines DDEC IV/DDEC V

Fault Code (SPN)	Text				
51	ThrottlePos	158	BattPotential	637	TimingSensor
91	AccelPedalPos	168	BatteryVoltage	639	J1939 CAN Bus
94	FuelDelPress	172	AirInlet Temp	651	InjectorCyl#1
97	WaterInFuelInd	173	Exhaust Temp	652	InjectorCyl#2
98	EngineOilLevel	174	Fuel Temp	653	InjectorCyl#3
100	EngOil Press	175	EngOil Temp	654	InjectorCyl#4
101	CrankcasePress	189	RatedEngSpeed	655	InjectorCyl#5
102	Boost Press	190	EngineSpeed	656	InjectorCyl#6
105	Intake Temp	231	J1939 Datalink	677	EngStartRelay
106	AirInletPress	237	VIN	898	RequestedSpeed
107	AirFiltDifPres	515	EngDesOpSpeed	970	AuxEngSdSwitch
108	BarometricPres	620	5V SupplyFail	971	EngDerateSwth
109	Coolant Press	626	PrehActuator	1109	EngSdApproach
110	EngCool Temp	628	EMSProgFailure	1110	Engine Sd
111	Coolant Level	629	EEPROMChecksum	1485	ECU MainRelay
153	CrankcasePress	630	CalibrMemFail		
		636	Crank Sensor		

Deutz EMR2

Fault Code (SPN)	Text
84	SpeedSensor
91	AccelPedalPos
98	EngineOilLevel
100	EngOil Press
102	Boost Press
105	Intake Temp
108	BarometricPres
109	Coolant Press
110	EngCool Temp
111	Coolant Level
171	AmbientAirTemp
174	Fuel Temp

190	EngineSpeed
200	RackPosition
201	Hand Throttle
202	AutoCalibrFail
203	CAN-MsgTimeout
204	PWM1
205	PWM2
206	IntMemoryFault
207	BattVoltToLow
208	OutputEngStop
209	ActorRackPos
210	CalibrMemFault
231	J1939 Datalink

535	Actuator Diff
536	hidden
563	Main Relay 3
572	DigitalOutput6
743	CAN Bus Comm
752	Program Test
765	Param Store
766	RAMTest/PwrCur
898	RequestedSpeed

hidden – the fault code is not displayed in the controller’s alarm and history list

Deutz EMR3-E and EMR3-S

Fault Code (SPN)	Text				
29	Hand Throttle	701	AuxInput1Act	523222	FrmMngTOTCO1
84	SpeedSensor	702	AuxInOut#2	523238	FrmMngTOSwtOut
91	AccelPedalPos	703	ECU IntError	523239	FrmMngDecV1
94	FuelDelPress	704	CoolTempLamp	523240	FrmMngFunModCt
97	WaterInFuellnd	705	OilPressLamp	523350	InjVlvBnk1A
100	EngOil Press	729	AirHeaterRelay	523351	InjVlvBnk1B
102	Boost Press	730	AirHeaterValve	523352	InjVlvBnk2A
105	Intake Temp	898	RequestedSpeed	523353	InjVlvBnk2B
107	AirFiltDifPres	923	EngPowerOutput	523354	InjVlvChipA
108	BarometricPres	975	Fan Actuator	523355	InjVlvChipB
109	Coolant Press	1072	InterEngBrake	523370	CompresionTest
110	EngCool Temp	1074	EngBrkFlapAct	523420	Watchdog
111	Coolant Level	1079	Sensorvoltage	523450	MultiStateSw
157	FuelRail Press	1080	ECUIntError	523451	MultiStateSw
158	IgnitNotDetect	1081	PreheatLamp	523452	MultiStateSw
168	BatteryVoltage	1109	EngSdApproach	523470	RailPressValve
174	Fuel Temp	1231	CAN Bus OFF	523490	ShutoffCond
175	EngOil Temp	1235	CAN Bus OFF	523500	FrmMngTxTO
190	EngineSpeed	1237	OverrideSwitch	523550	TPU Defect
520	FrmMngTOTSC1TR	1322	MisfireCyls	523561	BIP Cyl1
563	Main Relay 3	1323	MisfireCyl1	523562	BIP Cyl2
624	DiagnosticLamp	1324	MisfireCyl2	523563	BIP Cyl3
630	EEPROM Access	1325	MisfireCyl3	523564	BIP Cyl4
639	J1939 CAN Bus	1326	MisfireCyl4	523565	BIP Cyl5
651	InjectorCyl#1	1327	MisfireCyl5	523566	BIP Cyl6
652	InjectorCyl#2	1328	MisfireCyl6	523567	BIP Cyl7
653	InjectorCyl#3	1346	Misfire	523568	BIP Cyl8
654	InjectorCyl#4	1450	MisfireCyl7	523600	SerialComm
655	InjectorCyl#5	1451	MisfireCyl8	523601	ReferenceVolt
656	InjectorCyl#6	1638	CustomerSensor	523602	Fan Speed
657	InjectorCyl#7	2634	Main Relay	523604	FrmMngTOEngTmp
658	InjectorCyl#8	2791	EGR Actuator	523605	FrmMngTOTSC1AE
676	AirHeaterRelay	523212	FrmMngTOEngPrt	523606	FrmMngTOTSC1AR
677	EngStartRelay	523216	FrmMngTOPrHt	523607	FrmMngTOTSC1DE
		523218	FrmMngTORxCCVS	523608	FrmMngTOTSC1DR

523609	FrmMngTOTSC1PE
523610	FrmMngTOTSC1VE
523611	FrmMngTOTSC1VR

523612	ECUIntMonitor
523613	RailPressure
523615	MeterUnitValve

523617	HWEMonCom
--------	-----------

Deutz EMR4

Fault Code (SPN)	Text				
29	Hand Throttle	701	AuxInput1Act	523222	FrmMngTOTCO1
84	SpeedSensor	702	AuxInOut#2	523238	FrmMngTOSwtOut
91	AccelPedalPos	703	ECU IntError	523239	FrmMngDecV1
94	FuelDelPress	704	CoolTempLamp	523240	FrmMngFunModCt
97	WaterInFuellnd	705	OilPressLamp	523350	InjVlvBnk1A
100	EngOil Press	729	AirHeaterRelay	523351	InjVlvBnk1B
102	Boost Press	730	AirHeaterValve	523352	InjVlvBnk2A
105	Intake Temp	898	RequestedSpeed	523353	InjVlvBnk2B
107	AirFiltDifPres	923	EngPowerOutput	523354	InjVlvChipA
108	BarometricPres	975	Fan Actuator	523355	InjVlvChipB
109	Coolant Press	1072	InterEngBrake	523370	CompresionTest
110	EngCool Temp	1074	EngBrkFlapAct	523420	Watchdog
111	Coolant Level	1079	Sensorvoltage	523450	MultiStateSw
157	FuelRail Press	1080	ECUIntError	523451	MultiStateSw
158	IgnitNotDetect	1081	PreheatLamp	523452	MultiStateSw
168	BatteryVoltage	1109	EngSdApproach	523470	RailPressValve
174	Fuel Temp	1231	CAN Bus OFF	523490	ShutoffCond
175	EngOil Temp	1235	CAN Bus OFF	523500	FrmMngTxTO
190	EngineSpeed	1237	OverrideSwitch	523550	TPU Defect
520	FrmMngTOTSC1TR	1322	MisfireCyls	523561	BIP Cyl1
563	Main Relay 3	1323	MisfireCyl1	523562	BIP Cyl2
624	DiagnosticLamp	1324	MisfireCyl2	523563	BIP Cyl3
630	EEPROM Access	1325	MisfireCyl3	523564	BIP Cyl4
639	J1939 CAN Bus	1326	MisfireCyl4	523565	BIP Cyl5
651	InjectorCyl#1	1327	MisfireCyl5	523566	BIP Cyl6
652	InjectorCyl#2	1328	MisfireCyl6	523567	BIP Cyl7
653	InjectorCyl#3	1346	Misfire	523568	BIP Cyl8
654	InjectorCyl#4	1450	MisfireCyl7	523600	SerialComm
655	InjectorCyl#5	1451	MisfireCyl8	523601	ReferenceVolt
656	InjectorCyl#6	1638	CustomerSensor	523602	Fan Speed
657	InjectorCyl#7	2634	Main Relay	523604	FrmMngTOEngTmp
658	InjectorCyl#8	2791	EGR Actuator	523605	FrmMngTOTSC1AE
676	AirHeaterRelay	523212	FrmMngTOEngPrt	523606	FrmMngTOTSC1AR
677	EngStartRelay	523216	FrmMngTOPrHt	523607	FrmMngTOTSC1DE
		523218	FrmMngTORxCCVS	523608	FrmMngTOTSC1DR

523609	FrmMngTOTSC1PE	523612	ECUIntMonitor	523617	HWEMonCom
523610	FrmMngTOTSC1VE	523613	RailPressure		
523611	FrmMngTOTSC1VR	523615	MeterUnitValve		

Ford e-control

Fault Code (SPN)	Text				
0	RS485	656	Injector6	1271	Sparkcoil4
29	FPP2	657	Injector7	1272	Sparkcoil5
51	TPS1	658	Injector8	1273	Sparkcoil6
84	Roadspeed	659	Injector9	1274	Sparkcoil7
91	FPP1	660	Injector10	1275	Sparkcoil8
94	FuelPress	695	OverrrdCtrlMode	1276	Sparkcoil9
100	EngOil Press	697	PWM1-Gauge1	1277	Sparkcoil10
102	Boost Press	698	PWM2-Gauge2	1321	Start Relay
105	IAT	699	PWM3-Gauge3	1323	Cylinder1
106	AMP	700	PWM4-Gauge4	1324	Cylinder2
108	BPpressure	701	AuxInput1Act	1325	Cylinder3
109	Coolant Press	702	AuxInOut#2	1326	Cylinder4
110	ECT	703	AuxInOut#3	1327	Cylinder5
168	BatteryVoltage	704	AUX1	1328	Cylinder6
173	EGTtemperature	705	AUX2	1329	Cylinder7
174	FTvoltage	706	AUX3	1330	Cylinder8
190	CrankSignalFI	710	AUXpull-down	1347	Fuel-pump
441	EMWT1	711	AUXpull-down2	1348	Fuelpump
442	EMWT2	712	AUXpull-down3	1384	Shutdown J1939
443	ERWT1voltage	713	AUXpull-down4	1386	ERWT2 Voltage
444	ERWT2voltage	723	SecSpeedSens	1485	Powerrelay
515	EngineSpeed	724	EGO1 Open/Lazy	1692	Boostcontrol
558	IVSstuck	731	Knock1sensor	2000	CAN-J1939Fault
628	FLASH	920	BuzzerControl	2646	PWM8 Short
629	EEPROMChecksum	925	PWM6	2647	PWM9 Short
630	RAM	926	PWM7	3050	Catalystinact
636	CRANKsignal	1079	SupplyVoltage	3051	CatalInactGas2
639	CAN-J1939fault	1080	Sensorsupply2	3056	UEGO return V
645	Tachoutput	1127	TIP Voltage	3217	UEGOSenseCell
651	Injector1	1192	WGPvoltage	3218	UEGOPumpVShort
652	Injector2	1213	MILcontrol	3221	UEGOprocessor
653	Injector3	1239	FuelRunOutLong	3222	UEGO
654	Injector4	1268	Sparkcoil1	3225	UEGOPump
655	Injector5	1269	Sparkcoil2	3227	EGO1open/lazy
		1270	Sparkcoil3	3256	EGO1open/lazy

3266	EGO4 Open/Lazy	520215	AUXAnaPullDn1V	522593	MegaJectorComm
3468	Gaseousfuel	520216	AUXAnaPullUp1V	522594	MegaJectorVolt
3673	TPS2voltage	520217	AUXAnaPullUp2V	522595	MegaJectorAct
4236	Closes-loopGB1	520218	AUXAnaPullUp3V	522596	MegaJectorCirc
4237	Adap-learnGB1	520219	AUXAnaPullUp1	522597	MegaJectorComm
4238	Closes-loopGB2	520220	AUXAnaPullUp2	522598	PWM4 Short
4239	Adap-learnGB1	520221	AUXAnaPullUp3	522599	Injector1Short
520197	Knock2sensor	520222	AUX digital 1	522600	Injector4Short
520199	FPP1/2Invalid	520223	AUX digital 2	522601	Injector2Short
520200	AdpLrnGasBank1	520224	AUX digital 3	522602	Injector3Short
520201	AdpLrnGasBank2	520230	PWM5	522603	GasFuelTempVFI
520202	AdaptLearn LPG	520240	GasFuelTempVFI	522604	Power relay
520203	AdaptLearn NG	520241	Knock2	522606	EGO2 Open/Lazy
520204	C-L GasolBank1	520250	FPP1	522655	CLGasBank1/LPG
520205	C-L GasolBank2	520251	TPS2 voltage	522660	AdpLrnGas1/LPG
520206	ClosedLoop LPG	520252	IACwiring	522697	MicroprocFail
520207	Closed-loop NG	520260	MegaJector	522710	TPS1 voltage
520208	EGO2 Open/Lazy	520270	Gov1/2/3Fail	522711	TPS2 voltage
520209	EGO3 Open/Lazy	520401	FuellmpurityH	522712	FPP1 voltage
520210	EGO4 Open/Lazy	520800	InCam/DistFl	522737	EGO1 Open/Lazy
520211	CatallnactGas1	520801	ExhtCamPosErr	522752	CAMInputSignal
520212	CatallnactGas2	520803	MegaJectorFl	524260	SensorSupplyV2
520213	CatallnactLPG	522525	CatalystInact	524261	SensorSupplyV1
520214	CatallnactOnNG	522540	PWM3-Gauge3		

GM MEFI4B, MEFI5B

Fault Code (SPN)	Text				
38	FuelLevel2	65542	Coil B Fault	65591	MisfireCyl1
51	ThrottlePos	65543	Coil C Fault	65592	MisfireCyl2
84	Speed Sensor	65544	Coil D Fault	65593	MisfireCyl3
94	FuelDelPress	65545	Coil E Fault	65594	MisfireCyl4
96	FuelLevel1	65546	Coil F Fault	65595	MisfireCyl5
98	EngineOilLevel	65547	Coil G Fault	65596	MisfireCyl6
100	EngOil Press	65548	Coil H Fault	65597	MisfireCyl7
105	Intake Temp	65549	Knock1Inactive	65598	MisfireCyl8
106	AirInletPress	65550	Knock2Inactive	65599	MisfireRandom
108	BaroSensor	65551	RomAndCheckSum	65600	TacModuleFault
109	Coolant Press	65552	OxygenSensor1	65601	EtcTps2
110	EngCool Temp	65553	OxygenSensor2	65602	EtcTps1
113	GovIntHigh	65554	FuelPumpRelay	65604	EtcPps2
174	Fuel Temp	65555	Inj A Short	65605	EtcPps1
175	OilTemp	65556	Inj B Short	65610	EtcTps12Corr
620	5V SupplyFail	65557	Recirc Fault	65613	EtcPps12Corr
627	SystemVoltage	65558	Depspwr Ref	65615	EtcActuation
630	CalMemory	65559	CANBus HWFault	65616	EtcProcess
636	Crank Fault	65560	CanBusGovCmd	65618	EtcReturn
651	Injector1	65561	OxyVoltageA1	65620	V5Buff A
652	Injector2	65562	OxyVoltageA2	65621	V5Buff B
653	Injector3	65563	OxyVoltageB1	65671	Cat A Temp
654	Injector4	65564	OxyVoltageB2	65672	Cat B Temp
655	Injector5	65565	OxyFuelTrimA	65673	Cat A Temp
656	Injector6	65566	OxyFuelTrimB	65674	Cat B Temp
657	Injector7	65567	OxyResponseA1	65675	Cat A Efficien
658	Injector8	65568	OxyResponseB1	65676	Cat B Efficien
723	SecSpeedSens	65570	CamPhaserW	65677	Cat A Exotherm
3563	ScipSensor	65571	CamPhaserX	65678	Cat B Exotherm
65537	OxygenSensor	65572	CamPhaserY	65690	VarGov
65538	EgrNotTracking	65573	CamPhaserZ	65701	Gener Warning1
65539	Est	65580	CPU	65702	Gener Warning2
65540	EstOrBypass	65581	MHC	65703	Stop Engine
65541	Coil A Fault	65582	NvRAM	65710	EmergencyStop
		65590	Misfire	65723	CamSensorW

65724	CamSensorX
65725	CamSensorY
65726	CamSensorZ
66001	StarterRelayLS
66002	StarterRelayHS
66003	MilDriver
66004	SvsLamp
66005	GovStatusLamp
66006	DTCLamp3
66007	BuzzerDriver
66008	DTCLamp1

66009	DTCLamp2
66010	SlowModeLamp
66011	SpeedBasedOut
66012	TransUpShift
66013	Powertrain
66014	Powertrain
66015	CanisterPurge
66016	EGR
66017	FuelPump1Relay
66018	Tachometer
66019	OxyHeaterA1

66020	OxyHeaterB1
66021	OxyHeaterA2
66022	OxyHeaterB2
66025	FuelPump2Relay
66026	ShiftInterrupt
66030	InterCooler
66035	BoostControl
66040	OEMOutput1
66041	OEMOutput2
66042	OEMOutput3
66043	OEMOutput4

GM MEF16

Fault Code (SPN)	Text				
27	EGRValvePos	601	CruiseCtResume	1239	Fuel Leakage
38	ExtTankFuelLvl	602	CruiseCtrAccel	1268	IgnitionCoil#1
51	ThrottlePos	620	5V SupplyFail	1269	IgnitionCoil#2
84	Speed Sensor	623	RedStopLamp	1270	IgnitionCoil#3
87	CruiseSpdHigh	627	PowerLost	1271	IgnitionCoil#4
91	AccelPedalPos	628	EMSProgFailure	1272	IgnitionCoil#5
94	FuelDelPress	630	CalibrMemFail	1273	IgnitionCoil#6
96	Fuel Level	632	FuelShutoff	1274	IgnitionCoil#7
98	EngineOilLevel	636	CrankSensor	1275	IgnitionCoil#8
100	EngOil Press	637	Pickup Crank	1321	Start Relay
103	TBC1Speed	639	J1939 CAN Bus	1322	MisfireCyls
105	Intake Temp	650	ActuatorSupply	1323	MisfireCyl1
106	AirInletPress	651	InjectorCyl#1	1324	MisfireCyl2
108	BarometricPres	652	InjectorCyl#2	1325	MisfireCyl3
109	Coolant Press	653	InjectorCyl#3	1326	MisfireCyl4
110	EngCool Temp	654	InjectorCyl#4	1327	MisfireCyl5
113	GovIntHigh	655	InjectorCyl#5	1328	MisfireCyl6
132	MassAirFlow	656	InjectorCyl#6	1329	MisfireCyl7
135	FuelPump	657	InjectorCyl#7	1330	MisfireCyl8
158	BattPotential	658	InjectorCyl#8	1352	Cyl1Knock
159	FuelRailPres	680	InjPressRegul	1353	Cyl2Knock
167	SysVolt	723	SecSpeedSens	1354	Cyl3Knock
168	BatteryVoltage	731	Knock1sensor	1355	Cyl4Knock
174	Fuel Temp	836	EngRPMOutput	1356	Cyl5Knock
175	EngOil Temp	837	ContModuleVSS	1357	Cyl6Knock
188	SpeedAtIdleLow	876	ClutchRelay	1358	Cyl7Knock
190	EngineSpeed	911	Maintenance	1359	Cyl8Knock
237	VIN	931	FuelPumpSec	1360	Cyl9Knock
245	OdometerNotPrg	987	CheckEngLamp	1361	Cyl10Knock
527	SpdControlLamp	1071	Fan1	1362	Cyl11Knock
596	CruiseContInpA	1127	BoostPress	1363	Cyl12Knock
597	BrakeSwitch	1188	WastegateOut	1393	IgnCoilASecCir
599	CruiseCtrSet	1195	ImmKeyNoProg	1394	IgnCoilBSecCir
600	CruiseCtrCoast	1196	ImmKeyIncorr	1395	IgnCoilCSecCir
		1213	MILcontrol	1396	IgnCoilDSecCir

1397	IgnCoilESecCir	4256	CrankRPMTooLow	65605	EtcPps1
1398	IgnCoilFSecCir	65537	OxygenSensor	65613	EtcPps12
1399	IgnCoilGSecCir	65538	EgrNotTracking	65615	EtcActuation
1400	IgnCoilHSecCir	65539	Est	65616	EtcProcess
1442	FuelPresReg2	65540	EstOrBypass	65618	EtcReturn
1634	CVN Error	65541	Coil A Fault	65675	CatEfficiencyA
1635	CMM_CODECAL	65542	Coil B Fault	65676	CatEfficiencyB
1765	FuelValve	65543	Coil C Fault	65701	CoolantLevel
2000	ECU failure	65544	Coil D Fault	65702	Gener Warning2
2430	ECSensor	65545	Coil E Fault	65703	Stop Engine
2434	ExGasTempB2	65546	Coil F Fault	65723	CamSensorW
2628	FuelShutoffVlv	65547	Coil G Fault	65724	CamSensorX
2645	Main Relay	65548	Coil H Fault	65725	CamSensorY
2659	EGRFlow	65549	Knock1Inactive	65728	CamSensorZ
2807	FuelShutoffVlv	65550	Knock2Inactive	66002	StarterRelay
2923	PwrSteerPress	65551	RomAndCheckSum	66003	MilDriver
3050	CatEffBellowB1	65552	OxygenSensor1	66011	GasLockOFF
3051	CatEffBellowB2	65553	OxygenSensor2	66013	PowertrainDrr
3053	FuelCapLamp	65555	ChangeOil	66014	PowertrainSw
3061	ColdStart	65600	TacModuleFault	66015	FuelControlVlv
3217	O2B1S1	65554	FuelPumpRelay	66019	OxyHeater
3223	O2B1S1HtrLow	65556	Inj B Short	66021	PostOxy Heater
3227	PostCatFuel	65557	Recirc Fault	75701	Gener Warning1
3232	O2B1S2	65558	Depspwr Ref	522545	MIL_Lamp
3256	O2B1S2	65559	CANBus HWFault	522608	O2 Heater
3261	O2B2S1	65560	CanBusGovCmd	522609	Rear O2
3266	PostCatFuel	65561	OxyVoltage	522610	Throttle
3271	O2B2S2	65562	PostO2Voltage	522611	Throttle Area1
3464	ThrottleCmd	65565	OxyFuelTrim	522612	Throttle Area3
3472	SecAirFlow	65567	OxyResponse	522613	Throttle Area3
3476	SecAirValv Bt	65580	CPU	522614	ThrottleFailed
3509	SensorSupply1	65581	MHC	522615	ThrottleClosed
3510	SensorSupply2	65582	NvRam	522616	ThrottlePos
3511	SensorSupply3	65585	FuelSellInput	522617	ThrottleNotDwn
3563	IntakePress 1	65601	EtcTps2	522630	O2LeanBank1
3673	Throttle	65602	EtcTps1	522631	O2RichBank1
4002	StarterReqCirc	65604	EtcPps2	522632	O2LeanBank2

522633	O2RichBank2	522700	RMC_TIMEOUTPP	522746	OXY_S2_MSR
522635	LFBK1LeanFuel	522712	APS_1_CC1	522747	OXY_SENS_PER
522636	LFBK1RichFuel	522713	APS_2_CC1	522748	OXY_S2_PERIODE
522637	LFBK2LeanFuel	522729	ADPT_OBD_GAIN	522749	OXY_SENS_RL_R
522638	LFBK2RichFuel	522730	ADPT_OBD_OFF	522750	OXY_S2_RL_RESP
522690	SPI Bus Error	522731	ADPT_OBD_PRES	522752	FailToStart
522691	ChecksumError	522735	O2 Bank1	522755	FuelPump
522692	RedundantFlt	522736	O2 Bank1	523821	OilLamp
522694	ChecksumError	522739	O2 HeaterBank1	524260	5VPowerSupply
522695	RMC_PAPMPP	522740	O2 HeaterBank1	524261	5VPowerSupply
522696	RMC_PEDMPP	522743	OBDII Lean1	524266	ThrottleMotor
522698	RMC_CLOCKPP	522744	OBDII Lean1	524286	ThrottleMotor
522699	RMC_INHWP	522745	OXY_SENS_MSR	524287	TorqReduction

GM SECM

Fault Code (SPN)	Text				
51	ThrottlePos	724	Heated Oxygen	1270	IgnitionCoil#3
100	EngOil Press	911	ServiceFault1	1271	IgnitionCoil#4
102	Boost Press	912	ServiceFault2	1272	IgnitionCoil#5
105	Intake Temp	913	ServiceFault3	1273	IgnitionCoil#6
109	Coolant Press	1079	Sensorvoltage	1274	IgnitionCoil#7
110	EngCool Temp	1116	GasFuelAdapt	1275	IgnitionCoil#8
158	BattPotential	1118	GasO2	1379	ServiceFault4
190	EngineSpeed	1119	ActExhaustOxyg	1442	LSD FltDither1
632	FuelShutoff	1213	MILcontrol	1443	LSD FltDither2
651	InjectorCyl#1	1268	IgnitionCoil#1	3057	GasPostO2
		1269	IgnitionCoil#2	3464	ThrottleCmd

GM E-control

Fault Code (SPN)	Text				
0	RS485	656	Injector6	1271	Sparkcoil4
29	FPP2	657	Injector7	1272	Sparkcoil5
51	TPS1	658	Injector8	1273	Sparkcoil6
84	Roadspeed	659	Injector9	1274	Sparkcoil7
91	FPP1	660	Injector10	1275	Sparkcoil8
94	FuelPress	695	OverrrdCtrlMode	1276	Sparkcoil9
100	EngOil Press	697	PWM1-Gauge1	1277	Sparkcoil10
102	Boost Press	698	PWM2-Gauge2	1321	Start Relay
105	IAT	699	PWM3-Gauge3	1323	Cylinder1
106	AMP	700	PWM4-Gauge4	1324	Cylinder2
108	BPpressure	701	AuxInput1Act	1325	Cylinder3
109	Coolant Press	702	AuxInOut#2	1326	Cylinder4
110	ECT	703	AuxInOut#3	1327	Cylinder5
168	BatteryVoltage	704	AUX1	1328	Cylinder6
173	EGTtemperature	705	AUX2	1329	Cylinder7
174	FTvoltage	706	AUX3	1330	Cylinder8
190	CrankSignalFI	710	AUXpull-down	1347	Fuel-pump
441	EMWT1	711	AUXpull-down2	1348	Fuelpump
442	EMWT2	712	AUXpull-down3	1384	Shutdown J1939
443	ERWT1voltage	713	AUXpull-down4	1386	ERWT2 Voltage
444	ERWT2voltage	723	SecSpeedSens	1485	Powerrelay
515	EngineSpeed	724	EGO1 Open/Lazy	1692	Boostcontrol
558	IVSstuck	731	Knock1sensor	2000	CAN-J1939Fault
628	FLASH	920	BuzzerControl	2646	PWM8 Short
629	EEPROMChecksum	925	PWM6	2647	PWM9 Short
630	RAM	926	PWM7	3050	Catalystinact
636	CRANKsignal	1079	SupplyVoltage	3051	CatalInactGas2
639	CAN-J1939fault	1080	Sensorsupply2	3056	UEGO return V
645	Tachoutput	1127	TIP Voltage	3217	UEGOsenseCell
651	Injector1	1192	WGPvoltage	3218	UEGOpumpVShort
652	Injector2	1213	MILcontrol	3221	UEGOprocessor
653	Injector3	1239	FuelRunOutLong	3222	UEGO
654	Injector4	1268	Sparkcoil1	3225	UEGOpump
655	Injector5	1269	Sparkcoil2	3227	EGO1open/lazy
		1270	Sparkcoil3	3256	EGO1open/lazy

3266	EGO4 Open/Lazy
3468	Gaseousfuel
3673	TPS2voltage
4236	Closes-loopGB1
4237	Adap-learnGB1
4238	Closes-loopGB2
4239	Adap-learnGB1
520197	Knock2sensor
520199	FPP1/2Invalid
520200	AdpLrnGasBank1
520201	AdpLrnGasBank2
520202	AdaptLearn LPG
520203	AdaptLearn NG
520204	C-L GasolBank1
520205	C-L GasolBank2
520206	ClosedLoop LPG
520207	Closed-loop NG
520208	EGO2 Open/Lazy
520209	EGO3 Open/Lazy
520210	EGO4 Open/Lazy
520211	CatallnactGas1
520212	CatallnactGas2
520213	CatallnactLPG
520214	CatallnactOnNG

520215	AUXAnaPullDn1V
520216	AUXAnaPullUp1V
520217	AUXAnaPullUp2V
520218	AUXAnaPullUp3V
520219	AUXAnaPullUp1
520220	AUXAnaPullUp2
520221	AUXAnaPullUp3
520222	AUX digital 1
520223	AUX digital 2
520224	AUX digital 3
520230	PWM5
520240	GasFuelTempVFI
520241	Knock2
520250	FPP1
520251	TPS2 voltage
520252	IACwiring
520260	MegaJector
520270	Gov1/2/3Fail
520401	FuellmpurityH
520800	InCam/DistFI
520801	ExhtCamPosErr
520803	MegaJectorFI
522525	CatalystInact
522540	PWM3-Gauge3

522593	MegaJectorComm
522594	MegaJectorVolt
522595	MegaJectorAct
522596	MegaJectorCirc
522597	MegaJectorComm
522598	PWM4 Short
522599	Injector1Short
522600	Injector4Short
522601	Injector2Short
522602	Injector3Short
522603	GasFuelTempVFI
522604	Power relay
522606	EGO2 Open/Lazy
522655	CLGasBank1/LPG
522660	AdpLrnGas1/LPG
522697	MicroprocFail
522710	TPS1 voltage
522711	TPS2 voltage
522712	FPP1 voltage
522737	EGO1 Open/Lazy
522752	CAMInputSignal
524260	SensorSupplyV2
524261	SensorSupplyV1

GM E-control LCI

Fault Code (SPN)	Text				
0	Gov1/2/3fail	657	Injector7	1271	Sparkcoil4
29	FPP2voltage	658	Injector8	1272	Sparkcoil5
51	TPS1voltage	659	Injector9	1273	Sparkcoil6
84	Roadspeed	660	Injector10	1274	Sparkcoil7
91	FPP1voltage	697	PWM1-Gauge1	1275	Sparkcoil8
94	FPvoltage	698	PWM2-Gauge2	1276	Sparkcoil9
100	EngOil Press	699	PWM3-Gauge3	1277	Sparkcoil10
102	Boost Press	700	PWM4-Gauge4	1323	Cylinder1
105	IATvoltage	701	AuxInput1Act	1324	Cylinder2
106	MAPpressure	702	AuxInOut#2	1325	Cylinder3
108	BPpressure	703	AuxInOut#3	1326	Cylinder4
109	Coolant Press	704	AUX1	1327	Cylinder5
110	ECTvoltage	705	AUX2	1328	Cylinder6
168	BatteryVoltage	706	AUX3	1329	Cylinder7
173	EGTtemperature	707	AUXdigital1	1330	Cylinder8
174	FTvoltage	708	AUXdigital2	1347	Fuel-pump
441	EMWT1voltage	709	AUXdigital3	1348	Fuelpump
442	EMWT2voltage	710	AUXpull-down	1385	ERWT1voltage
515	EngineSpeed	711	AUXpull-down2	1485	Powerrelay
558	IVSstuck	712	AUXpull-down3	3050	Catalystinact
616	Startrelay	713	AUXpull-down4	3217	EGO1open/lazy
628	FLASH	723	SecSpeedSens	3227	EGO1open/lazy
629	EEPROMChecksum	731	Knock1sensor	3256	EGO1open/lazy
630	RAM	920	BuzzerControl	3468	Gaseousfuel
632	FuelShutoff	924	PWM5	3673	TPS2voltage
636	CRANKsignal	925	PWM6	4236	Closes-loopGB1
639	CAN-J1939fault	926	PWM7	4237	Adap-learnGB1
645	Tachoutput	1079	Sensorvoltage	4238	Closes-loopGB2
651	Injector1	1080	Sensorsupply2	4239	Adap-learnGB1
652	Injector2	1110	J1939request	520197	Knock2sensor
653	Injector3	1192	WGPvoltage	520252	IACwiring
654	Injector4	1213	MILcontrol	520260	MegaJector
655	Injector5	1268	Sparkcoil1		
656	Injector6	1269	Sparkcoil2		
		1270	Sparkcoil3		

Isuzu ECM

Fault Code (SPN)	Text				
91	hidden	655	InjectorCyl#5	10007	CPU fault
100	EngOil Press	656	InjectorCyl#6	10008	A/D Conversion
102	Boost Press	675	Glow plug lamp	10009	5V SupplyFail3
105	Intake Temp	676	hidden	10010	5V SupplyFail4
108	BarometricPres	677	hidden	10011	5V SupplyFail5
109	Coolant Press	723	SecSpeedSens	10013	EEPROM fault
110	EngCool Temp	987	CheckEngLamp	1131	ManifTempSens
157	FuelRail Press	1077	CPU Monitor IC	1381	/Chinese/
172	AirInlet Temp	1079	Sensorvoltage	158	BattHighVolt
174	Fuel Temp	1080	Sensorsupply2	10050	InjectorICMalf
190	EngineSpeed	1239	Fuel Leakage	10052	InjlCcheckSum
628	EMSProgFailure	1240	NoPumpPresFeed	10051	InjectComm
633	FuelActuator	1347	SCV OC +B S GS	10046	Sw-IC1Int
636	Crank Sensor	1485	ECU MainRelay	10048	Sw-IC1Comm
639	hidden	10001	EGR Position	10045	ADIC
651	InjectorCyl#1	10002	EGR Valve Ctrl	697	5V SupplyFail3
652	InjectorCyl#2	10003	InjectNozzCom1	10033	RAM malfuncion
653	InjectorCyl#3	10004	InjectNozzCom2	10032	QR code
654	InjectorCyl#4	10005	ChargeCircuit1		
		10006	ChargeCircuit2		

hidden – the fault code is not displayed in the controller's alarm and history list

Iveco EDC

Fault Code (SPN)	Text				
51	ThrottlePos	639	J1939 CAN Bus	0x10067	Cyl 1 OpenLoad
91	AccelPedalPos	651	InjectorCyl#1	0x10068	Cyl 2 OpenLoad
94	FuelDelPress	652	InjectorCyl#2	0x10069	Cyl 3 OpenLoad
97	WaterInFuelInd	653	InjectorCyl#3	0x1006A	Cyl 4 OpenLoad
98	EngineOilLevel	654	InjectorCyl#4	0x1006B	Cyl 5 OpenLoad
100	EngOil Press	655	InjectorCyl#5	0x1006C	Cyl 6 OpenLoad
101	CrankcasePress	656	InjectorCyl#6	0x1006D	Rail monitor
102	Boost Press	677	EngStartRelay	0x10071	Bank 1 error
105	Intake Temp	898	RequestedSpeed	0x10072	Bank 1 error
106	AirInletPress	970	AuxEngSdSwitch	0x10073	Bank 2 error
107	AirFiltDifPres	971	EngDerateSwtch	0x10074	Bank 2 error
108	BarometricPres	1109	EngSdApproach	0x1007B	Misfire
109	Coolant Press	1110	Engine Sd	0x1007C	Chip error
110	EngCool Temp	1485	ECU MainRelay	0x1007E	InjectionLimit
111	Coolant Level	65579	hidden	0x10084	SRA2EDC
153	CrankcasePress	65585	CoolantTmpSens	0x10085	Load-IdleRange
158	BattPotential	65588	BoostPressSens	0x30085	Drift Limit
168	BatteryVoltage	65589	FuelTempSens	0x10086	Supply Voltage
172	AirInlet Temp	65592	OilPressSens	0x20086	AirMassSignal
173	Exhaust Temp	65594	OilTempSens	0x30086	AirMassSignal
174	Fuel Temp	0x10051	Cyl 1 error	0x40086	Reference
175	EngOil Temp	0x10052	Cyl 2 error	0x10087	PosGovernor
189	RatedEngSpeed	0x10053	Cyl 3 error	0x10088	NegGovernor
190	EngineSpeed	0x10054	Cyl 4 error	0x20088	GovernorCheck
231	J1939 Datalink	0x10055	Cyl 5 error	0x10089	EGR PowerStage
237	VIN	0x10056	Cyl 6 error	0x20089	EGR PowerStage
515	EngDesOpSpeed	0x10059	PWM Powerstage	0x30089	EGR PowerStage
620	5V SupplyFail	0x1005A	AD-Channel	0x1008A	EGR Bypass
626	PrehActuator	0x1005B	High pressure	0x1008B	ThrottActuator
628	EMSProgFailure	0x10061	Cyl 1 ShortCir	0x2008B	ValveActuator
629	EEPROMChecksum	0x10062	Cyl 2 ShortCir	0x3008B	TVA
630	CalibrMemFail	0x10063	Cyl 3 ShortCir	0x1008D	PosGovernor
636	Crank Sensor	0x10064	Cyl 4 ShortCir	0x1008E	NegGovernor
637	TimingSensor	0x10065	Cyl 5 ShortCir	0x1008F	RgnNrm time
		0x10066	Cyl 6 ShortCir	0x10091	BoostPressure

0x10092	BPA
0x20092	BPA
0x30092	BPA
0x10093	TurbineSpeed
0x10094	EPctl
0x10095	PCR deviation
0x20095	PCR Check
0x10096	Cyl 1 Timing
0x20096	Cyl 2 Timing
0x30096	Cyl 3 Timing
0x40096	Cyl 4 Timing
0x10097	Cyl 1 Calibr
0x20097	Cyl 2 Calibr
0x30097	Cyl 3 Calibr
0x40097	Cyl 4 Calibr
0x10098	Cylinder 5
0x20098	Cylinder 6

0x30098	Cylinder 5
0x40098	Cylinder 6
0x10099	P2 pressure
0x1009A	TurbineSpeed
0x1009B	Hi TurbineSpd
0x1009C	P3 pressure
0x1009D	InnerCtrlTemp
0x1009E	OuterCtrlTemp
0x1009F	EGSys-NOxEstlv
0x100A1	Lambda Nox
0x200A1	Lambda Nox
0x100A2	Nox Sensor
0x100A3	Nox Sensor
0x100A4	Nox Sensor
0x100A5	DM1DCU timeout
0x100A6	SCR1 timeout
0x200A6	SCR2 timeout

0x100A8	LowUreaLevel
0x200A8	LowUreaLevel
0x300A8	Urea Sensor
0x400A8	Wrong urea
0x100A9	GasTemp
0x200AB	GasPipePress
0x100AB	VDC1
0x100AC	EGR
0x200AC	EngGsFlowRt
0x100AD	ExhaustGasTemp
0x100AE	AirHumidity
0x100AF	SPN1 message
0x200AF	SPN2 message
0x300AF	SPN3 message
0x400AF	SPN4 message

hidden – the fault code is not displayed in the controller's alarm and history list

Iveco EDC Tier3

Fault Code (SPN)	Text				
51	ThrottlePos	639	J1939 CAN Bus	0x10067	Cyl 1 OpenLoad
91	AccelPedalPos	651	InjectorCyl#1	0x10068	Cyl 2 OpenLoad
94	FuelDelPress	652	InjectorCyl#2	0x10069	Cyl 3 OpenLoad
97	WaterInFuelInd	653	InjectorCyl#3	0x1006A	Cyl 4 OpenLoad
98	EngineOilLevel	654	InjectorCyl#4	0x1006B	Cyl 5 OpenLoad
100	EngOil Press	655	InjectorCyl#5	0x1006C	Cyl 6 OpenLoad
101	CrankcasePress	656	InjectorCyl#6	0x1006D	Rail monitor
102	Boost Press	677	EngStartRelay	0x10071	Bank 1 error
105	Intake Temp	898	RequestedSpeed	0x10072	Bank 1 error
106	AirInletPress	970	AuxEngSdSwitch	0x10073	Bank 2 error
107	AirFiltDifPres	971	EngDerateSwth	0x10074	Bank 2 error
108	BarometricPres	1109	EngSdApproach	0x1007B	Misfire
109	Coolant Press	1110	Engine Sd	0x1007C	Chip error
110	EngCool Temp	1485	ECU MainRelay	0x1007E	InjectionLimit
111	Coolant Level	65579	hidden	0x10084	SRA2EDC
153	CrankcasePress	65585	CoolantTmpSens	0x10085	Load-IdleRange
158	BattPotential	65588	BoostPressSens	0x30085	Drift Limit
168	BatteryVoltage	65589	FuelTempSens	0x10086	Supply Voltage
172	AirInlet Temp	65592	OilPressSens	0x20086	AirMassSignal
173	Exhaust Temp	65594	OilTempSens	0x30086	AirMassSignal
174	Fuel Temp	0x10051	Cyl 1 error	0x40086	Reference
175	EngOil Temp	0x10052	Cyl 2 error	0x10087	PosGovernor
189	RatedEngSpeed	0x10053	Cyl 3 error	0x10088	NegGovernor
190	EngineSpeed	0x10054	Cyl 4 error	0x20088	GovernorCheck
231	J1939 Datalink	0x10055	Cyl 5 error	0x10089	EGR PowerStage
237	VIN	0x10056	Cyl 6 error	0x20089	EGR PowerStage
515	EngDesOpSpeed	0x10059	PWM Powerstage	0x30089	EGR PowerStage
620	5V SupplyFail	0x1005A	AD-Channel	0x1008A	EGR Bypass
626	PrehActuator	0x1005B	High pressure	0x1008B	ThrottActuator
628	EMSProgFailure	0x10061	Cyl 1 ShortCir	0x2008B	ValveActuator
629	EEPROMChecksum	0x10062	Cyl 2 ShortCir	0x3008B	TVA
630	CalibrMemFail	0x10063	Cyl 3 ShortCir	0x1008D	PosGovernor
636	Crank Sensor	0x10064	Cyl 4 ShortCir	0x1008E	NegGovernor
637	TimingSensor	0x10065	Cyl 5 ShortCir	0x1008F	RgnNrm time
		0x10066	Cyl 6 ShortCir	0x10091	BoostPressure

0x10092	BPA	0x30098	Cylinder 5	0x100A8	LowUreaLevel
0x20092	BPA	0x40098	Cylinder 6	0x200A8	LowUreaLevel
0x30092	BPA	0x10099	P2 pressure	0x300A8	Urea Sensor
0x10093	TurbineSpeed	0x1009A	TurbineSpeed	0x400A8	Wrong urea
0x10094	EPctl	0x1009B	Hi TurbineSpd	0x100A9	GasTemp
0x10095	PCR deviation	0x1009C	P3 pressure	0x200AB	GasPipePress
0x20095	PCR Check	0x1009D	InnerCtrlTemp	0x100AB	VDC1
0x10096	Cyl 1 Timing	0x1009E	OuterCtrlTemp	0x100AC	EGR
0x20096	Cyl 2 Timing	0x1009F	EGSys-NOxEstlv	0x200AC	EngGsFlowRt
0x30096	Cyl 3 Timing	0x100A1	Lambda Nox	0x100AD	ExhaustGasTemp
0x40096	Cyl 4 Timing	0x200A1	Lambda Nox	0x100AE	AirHumidity
0x10097	Cyl 1 Calibr	0x100A2	Nox Sensor	0x100AF	SPN1 message
0x20097	Cyl 2 Calibr	0x100A3	Nox Sensor	0x200AF	SPN2 message
0x30097	Cyl 3 Calibr	0x100A4	Nox Sensor	0x300AF	SPN3 message
0x40097	Cyl 4 Calibr	0x100A5	DM1DCU timeout	0x400AF	SPN4 message
0x10098	Cylinder 5	0x100A6	SCR1 timeout		
0x20098	Cylinder 6	0x200A6	SCR2 timeout		

hidden – the fault code is not displayed in the controller's alarm and history list

Iveco Vector

Fault Code (SPN)	Text				
29	Hand Throttle	652	InjectorCyl#2	1127	BoostPress
100	EngOil Press	653	InjectorCyl#3	1239	Fuel Leakage
105	Intake Temp	654	InjectorCyl#4	1661	CrankTermRelay
108	BarometricPres	655	InjectorCyl#5	1980	OverspeedLamp
109	Coolant Press	656	InjectorCyl#6	1981	OilPressLamp
110	EngCool Temp	657	InjectorCyl#7	1984	ShutdownLamp
132	TurboHeatLimit	658	InjectorCyl#8	1985	J1 5V SupplyEr
157	FuelRailPress	659	InjectorCyl#9	1986	RemoteOperLamp
168	BatteryVoltage	660	InjectorCyl#10	1987	CoolTempLamp
174	Fuel Temp	661	InjectorCyl#11	1993	WarningLamp
175	EngOil Temp	662	InjectorCyl#12	1994	DiagnosticLamp
190	EngineSpeed	677	EngStartRelay	1995	PersModuleErr
639	J1939 CAN Bus	723	SecSpeedSens	1997	FuelValveErr
651	InjectorCyl#1	729	AirHeaterRelay	1998	J2 5V SupplyEr
		1108	SdOverridden		

JCB Delphi DCM

Fault Code (SPN)	Text				
51	ThrottlePos	158	BattPotential	653	InjectorCyl#3
84	Speed Sensor	168	BatteryVoltage	654	InjectorCyl#4
86	CruiseControl	172	AirInlet Temp	655	InjectorCyl#5
91	AccelPedalPos	174	Fuel Temp	656	InjectorCyl#6
94	FuelDelPress	175	EngOil Temp	677	EngStartRelay
97	WaterInFuelInd	189	RatedEngSpeed	731	Knock1sensor
98	EngineOilLevel	190	EngineSpeed	898	RequestedSpeed
100	EngOil Press	231	J1939 Datalink	970	AuxEngSdSwitch
101	CrankcasePress	237	VIN	971	EngDerateSwtch
102	Boost Press	515	EngDesOpSpeed	974	RemAPSensor
105	Intake Temp	620	5V SupplyFail	1075	ElectrLiftPump
106	AirInletPress	626	PrehActuator	1076	FuelPump
107	AirFiltDifPres	627	PowerLost	1079	Sensorvoltage
108	BarometricPres	628	EMSProgFailure	1080	Sensorsupply2
109	Coolant Press	629	EEPROMChecksum	1083	ECU Temperat
110	EngCool Temp	630	CalibrMemFail	1109	EngSdApproach
111	Coolant Level	636	Crank Sensor	1110	Engine Sd
153	CrankcasePress	637	TimingSensor	1213	MILcontrol
156	FuelTiming	639	J1939 CAN Bus	1485	ECU MainRelay
157	FuelRail Press	651	InjectorCyl#1	1804	IntakeAirHeatr
		652	InjectorCyl#2	2648	ServiceTime

John Deere JDEC

Fault Code (SPN)	Text				
51	ThrottlePos	189	RatedEngSpeed	898	RequestedSpeed
91	AccelPedalPos	190	EngineSpeed	970	AuxEngSdSwitch
94	FuelDelPress	237	VIN	971	EngDerateSwthch
97	WaterInFuelInd	412	EGR Temp	1076	FuInPuFctrIVlv
100	EngOil Press	515	EngDesOpSpeed	1077	FuellnPumpCtrl
102	Boost Press	611	InjectorWiring	1078	FuellnPumpSens
105	Intake Temp	620	5V SupplyFail	1079	Sensorvoltage
106	AirInletPress	627	PowerLost	1080	Sensorsupply2
107	AirFiltDifPres	629	EEPROMChecksum	1109	EngSdApproach
108	BarometricPres	632	FuelShutoff	1110	Engine Sd
109	Coolant Press	636	Crank Sensor	1172	Turbo Temp
110	EngCool Temp	637	TimingSensor	1347	FuelPressure
111	Coolant Level	651	InjectorCyl#1	1348	FuelPumpAsse#2
157	FuelRail Press	652	InjectorCyl#2	1485	ECU MainRelay
158	BattPotential	653	InjectorCyl#3	1569	EngProtDerate
168	BatteryVoltage	654	InjectorCyl#4	2000	ECU failure
174	Fuel Temp	655	InjectorCyl#5	2630	ChargeAirTemp
175	EngOil Temp	656	InjectorCyl#6		
		677	EngStartRelay		

MAN EDC Master, EDC Slave and MFR interface system

Fault Code (SPN)	Text				
81	DPF Pressure	652	InjectorCyl#2	3772	M/S Ignition
94	FuelDelPress	653	InjectorCyl#3	3775	Rail Pressure
98	EngineOilLevel	654	InjectorCyl#4	3804	MFR/EDC CAN TO
100	EngOil Press	655	InjectorCyl#5	3806	EDC M/S CAN TO
102	Boost Press	656	InjectorCyl#6	3813	Starter Fail
105	Intake Temp	1131	IntakeMan2Temp	3815	ExhaustBackP
109	Coolant Press	3009	Overspped	3823	Missfiring
110	EngCool Temp	3014	No Ignition	3923	Coolant Temp 2
168	BatteryVoltage	3069	RedundSpdProt	5000	SupplyVoltFail
173	Exhaust Temp	3076	Wrong MFR	5016	Overspeed
174	Fuel Temp	3687	UnderpresValve	5017	OverrideActive
175	EngOil Temp	3732	Initial Fail	5019	EngineCANFail
190	Engine Speed	3751	Starter Relay	5034	CustCAN TO KSM
609	Controller#2	3752	Camshaft Sens	5035	FuelFilterWtrL
651	InjectorCyl#1	3753	Mainshaft Sens		
		3771	M/S CAN Fail		

MTU ADEC (ECU7) & SAM

Fault Code (SPN)	Text				
003	HI T-Fuel	081	AL RailLeakage	207	SD T-ExhaustB
004	SS T-Fuel	082	HI P-Fuel	208	SD P-ChargeAir
005	HI T-ChargeAir	083	LO P-Fuel	211	SD P-Lube Oil
006	SS T-ChargeAir	089	SS Speed Low	212	SD P-Coolant
009	HI T-CoolInter	090	SS IdleNtReach	215	SD P-HD
010	SS T-CoolInter	091	SS ReleaseSpd	216	SD T-Lube Oil
015	LO P-Lube Oil	092	SS StarterSpd	219	SD T-IntakeAir
016	SS P-Lube Oil	093	SS T-Preheat	220	SD LvlCoolWatr
019	HI T-ExhaustA	094	LO T-Preheat	221	SD P-Diff Oil
020	SS T-ExhaustA	095	AL Prelubric	222	SD LeakFuelLvl
021	HI T-ExhaustB	102	AL FuelConsCnt	223	SD LvlCoolIntr
022	SS T-ExhaustB	104	AL EngHoursCnt	227	SD OilPressure
023	LO CoolLevel	118	LO ECUPwrSupp	228	SD P-Fuel
024	SS CoolLevel	119	LOLO ECUPower	229	AL StopCamshaf
025	HI P-Diff Oil	120	HI ECUPwrSupp	230	SD CranksftSpd
026	SS P-Diff Oil	121	HIHI ECUPower	231	SD CamshaftSpd
030	SS Overspeed	122	HI T-ECU	232	SD ChrgrSpeed1
031	HI ETC1Overspd	141	AL PwrTooHigh	239	SD P-Diff Fuel
032	SS ETC1Overspd	142	AL MCR1HourExc	240	SD P-Fuel
033	HI P-DiffFuel	176	AL LifeDataNA	245	SD ECUPwrSupp
034	SS P-DiffFuel	177	AL LifeDataInc	266	SD SpeedDemand
036	HI ETC2Overspd	180	AL CAN1NodeLst	269	SD LoadAnalog
037	SS ETC2Overspd	181	AL CAN2NodeLst	270	SD FreqInput
044	LO CoolLvlInt	182	AL CANWrongPar	301	AL TimingCIA1
051	HI T-Lube Oil	183	AL CANNNoPUData	302	AL TimingCIA2
052	SS T-Lube Oil	184	AL CANPUDataEr	303	AL TimingCIA3
057	LO P-coolant	186	AL CAN1BusOff	304	AL TimingCIA4
058	SS P-Coolant	187	AL CAN1ErrPass	305	AL TimingCIA5
059	SS T-CoolantL3	188	AL CAN2BusOff	306	AL TimingCIA6
060	SS T-CoolantL4	189	AL CAN2ErrPass	307	AL TimingCIA7
065	LO P-Fuel	201	SD T-Coolant	308	AL TimingCIA8
066	SS P-Fuel	202	SD T-Fuel	309	AL TimingCIA9
067	HI T-Coolant	203	SD T-ChargeAir	310	AL TimingCIA10
068	SS T-Coolant	205	SD T-CoolInter	311	AL TimingClB1
		206	SD T-ExhaustA	312	AL TimingClB2

313	AL TimingCIB3	350	AL OpenLdCIA10	439	HI P-Fuel 2
314	AL TimingCIB4	351	AL OpenLdCIB1	441	AL Syst2Leaks
315	AL TimingCIB5	352	AL OpenLdCIB2	444	SD U-PDU
316	AL TimingCIB6	353	AL OpenLdCIB3	445	SD P-Amb Air
317	AL TimingCIB7	354	AL OpenLdCIB4	446	SD P-HD2
318	AL TimingCIB8	355	AL OpenLdCIB5	448	HI P-ChargeAir
319	AL TimingCIB9	356	AL OpenLdCIB6	449	SS P-ChargeAir
320	AL TimingCIB10	357	AL OpenLdCIB7	450	SD TorqueInp
321	AL WiringCIA1	358	AL OpenLdCIB8	454	SS PowerReduct
322	AL WiringCIA2	359	AL OpenLdCIB9	463	SD AUX 2
323	AL WiringCIA3	360	AL OpenLdCIB10	464	SD P-AUX 1
324	AL WiringCIA4	361	AL PwrStageLow	468	SD T-AUX 1
325	AL WiringCIA5	362	AL PwrStagHigh	469	SD AUX 1
326	AL WiringCIA6	363	AL StopPwrStag	470	SD T-ECU
327	AL WiringCIA7	365	AL StopMVWirin	471	SD CoilCurr
328	AL WiringCIA8	371	AL Wiring TO1	472	AL Stop SD
329	AL WiringCIA9	381	AL WiringTOP1	474	AL Wiring FO
330	AL WiringCIA10	382	AL WiringTOP2	475	AL CR Trigger
331	AL WiringCIB1	383	AL WiringTOP3	476	AL CrashRecErr
332	AL WiringCIB2	384	AL WiringTOP4	478	hidden
333	AL WiringCIB3	390	AL MCRExceeded	479	hidden
334	AL WiringCIB4	400	AL DigitInp 1	480	AL ExtEngProt
335	AL WiringCIB5	401	AL DigitInp 2	510	AL Override
336	AL WiringCIB6	402	AL DigitInp 3	515	AL Starter
337	AL WiringCIB7	403	AL DigitInp 4	543	AL >1 FDHSlave
338	AL WiringCIB8	404	AL DigitInp 5	544	AL ConfigChang
339	AL WiringCIB9	405	AL DigitInp 6	549	AL PwrInterrupt
340	AL WiringCIB10	406	AL DigitInp 7	555	AL Call MTU
341	AL OpenLdCIA1	407	AL DigitInp 8	576	AL ESCMOverride
342	AL OpenLdCIA2	408	AL Emerg Stop	594	AL L1 UDVFault
343	AL OpenLdCIA3	410	LO U-PDU	595	AL L2 UDVFault
344	AL OpenLdCIA4	411	LOLO U-PDU	598	AL L1 UDVFault
345	AL OpenLdCIA5	412	HI U-PDU	599	AL L2 UDVFault
346	AL OpenLdCIA6	413	HIHI U-PDU	610	AL HPFuel1Wir
347	AL OpenLdCIA7	414	HI WtrFuelPref	611	AL HPFuel2Wir
348	AL OpenLdCIA8	417	SD WtrFuelpref	612	AL PresValve1
349	AL OpenLdCIA9	438	LO P-Fuel 2	613	AL PresValve2

hidden – the fault code is not displayed in the controller's alarm and history list

MTU ADEC (ECU7) & SAM – P-engines

The ECU does not support a diagnostic fault code.

MTU DDEC10

There is no text for fault codes for this ECU in this version of ECU list.

MTU ECU8 and SMARTConnect

Fault Code (SPN)	Text				
52	IntercoolerTmp	111	Coolant Level	898	RequestedSpeed
94	FuelDelPress	158	BattPotential	1136	ECU Temp
100	EngOil Press	174	Fuel Temp	2629	Turbo1 OutTemp
109	Coolant Press	175	EngOil Temp	520837	Starter Speed
110	EngCool Temp	188	SpeedAtIdleLow	520838	EngRunUpSpeed
		190	EngineSpeedLow		

Perkins ECM

Fault Code (SPN)	Text				
1	InjectorCyl#1	174	Fuel Temp	628	EMSProgFailure
2	InjectorCyl#2	175	EngOil Temp	629	EEPROMChecksum
3	InjectorCyl#3	183	Fuel Rate	630	CalibrMemFail
4	InjectorCyl#4	189	RatedEngSpeed	636	Crank Sensor
5	InjectorCyl#5	190	EngineSpeed	637	TimingSensor
6	InjectorCyl#6	228	TimingCalibr	639	J1939 CAN Bus
41	8VSensPwrSupp	231	J1939 Datalink	651	InjectorCyl#1
51	ThrottlePos	234	Incorrect FW	652	InjectorCyl#2
91	AccelPedalPos	237	VIN	653	InjectorCyl#3
92	PercentLoad	247	TotalEngHours	654	InjectorCyl#4
94	FuelDelPress	248	DataLinkComm	655	InjectorCyl#5
97	WaterInFuelInd	253	CheckSysParams	656	InjectorCyl#6
98	EngineOilLevel	254	ECM Fault	677	EngStartRelay
100	EngOil Press	261	TimingCalibr	678	ECM 8DC supply
101	CrankcasePress	262	5VSensPwrSupp	695	OverrrdCtrlMode
102	Boost Press	268	CheckPrgParams	723	SecSpeedSens
105	Intake Temp	273	TurboOutltPres	799	Service Tool
106	AirInletPress	274	AtmospherPress	898	RequestedSpeed
107	AirFiltDifPres	281	ActionAlrtLamp	970	AuxEngSdSwitch
108	BarometricPres	282	EngOverspdLamp	971	EngDerateSwtch
109	Coolant Press	285	EnCoolTempLamp	1108	CritOverrideEn
110	EngCool Temp	286	LubOilPresLamp	1109	EngSdApproach
111	Coolant Level	323	EnShutdownLamp	1110	Engine Sd
153	CrankcasePress	324	EngWarningLamp	1111	CheckCfgParams
157	FuelRailPress	342	EngSpeedSens2	1266	DiagnosticLamp
158	BattPotential	443	CrankTermRelay	1485	ECU MainRelay
168	BatteryVoltage	515	EngDesOpSpeed	1690	AnlgThrottISig
172	AirInlet Temp	620	5V SupplyFail		
		626	PrehActuator		

Perkins 1300

Fault Code (SPN)	Text				
1	InjectorCyl#1	174	Fuel Temp	628	EMSProgFailure
2	InjectorCyl#2	175	EngOil Temp	629	EEPROMChecksum
3	InjectorCyl#3	183	Fuel Rate	630	CalibrMemFail
4	InjectorCyl#4	189	RatedEngSpeed	636	Crank Sensor
5	InjectorCyl#5	190	EngineSpeed	637	TimingSensor
6	InjectorCyl#6	228	TimingCalibr	639	J1939 CAN Bus
41	8VSensPwrSupp	231	J1939 Datalink	651	InjectorCyl#1
51	ThrottlePos	234	Incorrect FW	652	InjectorCyl#2
91	AccelPedalPos	237	VIN	653	InjectorCyl#3
92	PercentLoad	247	TotalEngHours	654	InjectorCyl#4
94	FuelDelPress	248	DataLinkComm	655	InjectorCyl#5
97	WaterInFuelInd	253	CheckSysParams	656	InjectorCyl#6
98	EngineOilLevel	254	ECM Fault	677	EngStartRelay
100	EngOil Press	261	TimingCalibr	678	ECM 8DC supply
101	CrankcasePress	262	5VSensPwrSupp	695	OverrrdCtrlMode
102	Boost Press	268	CheckPrgParams	723	SecSpeedSens
105	Intake Temp	273	TurboOutltPres	799	Service Tool
106	AirInletPress	274	AtmospherPress	898	RequestedSpeed
107	AirFiltDifPres	281	ActionAlrtLamp	970	AuxEngSdSwitch
108	BarometricPres	282	EngOverspdLamp	971	EngDerateSwtch
109	Coolant Press	285	EnCoolTempLamp	1108	CritOverrideEn
110	EngCool Temp	286	LubOilPresLamp	1109	EngSdApproach
111	Coolant Level	323	EnShutdownLamp	1110	Engine Sd
153	CrankcasePress	324	EngWarningLamp	1111	CheckCfgParams
157	FuelRailPress	342	EngSpeedSens2	1266	DiagnosticLamp
158	BattPotential	443	CrankTermRelay	1485	ECU MainRelay
168	BatteryVoltage	515	EngDesOpSpeed	1690	AnlgThrottlSig
172	AirInlet Temp	620	5V SupplyFail		
		626	PrehActuator		

Scania S6 Single speed

Fault (SPN)	Code	Text
0x1000		Overspeed
0x1100		EngSpdSensor1
0x1200		EngSpdSensor2
0x2000		WtrTempSensor
0x2100		ChrgAirTmpSens
0x2200		ChrgAirPrsSens
0x2300		OilTempSensor
0x2400		OilPressSensor
0x2600		SensorSupply1
0x2700		SensorSupply2
0x2800		ExtrAnalogInp
0x3200		BatteryVoltage
0x3300		CAN msg not ok
0x3403		CAN version
0x4300		HWWatchdog
0x6200		FanActuator
0x6400		WasteGateAct
0x6600		StarterActuatr
0x6605		Starter Motor
0x6702		AlternatorChrg
0x6A00		ExhaustBrkAct
0xB000		OilPressProt
0xB100		CoolantLevProt
0xB200		OverheatCoolWt
0xB300		EmergencyStop
0xB501		CoolantLevel
0xC000		PDEInjectorCyl1
0xC100		PDEInjectorCyl2
0xC200		PDEInjectorCyl3
0xC300		PDEInjectorCyl4
0xC400		PDEInjectorCyl5
0xC500		PDEInjectorCyl6
0xC600		PDEInjectorCyl7
0xC700		PDEInjectorCyl8
0xE200		OverheatProt
0xE600		CoordEmergStop

Scania S6 Single speed from ver.1794335

Fault Code (SPN)	Text
0x1000	Overspeed
0x1100	EngSpdSensor1
0x1200	EngSpdSensor2
0x2000	WtrTempSensor
0x2100	ChrgAirTmpSens
0x2200	ChrgAirPrsSens
0x2300	OilTempSensor
0x2400	OilPressSensor
0x2600	SensorSupply1
0x2700	SensorSupply2
0x2800	ExtrAnalogInp
0x3200	BatteryVoltage

0x3300	CAN msg not ok
0x3403	CAN version
0x4300	HWWatchdog
0x6200	FanActuator
0x6400	WasteGateAct
0x6600	StarterActuatr
0x6605	Starter Motor
0x6702	AlternatorChrg
0x6A00	ExhaustBrkAct
0xB000	OilPressProt
0xB100	CoolantLevProt
0xB200	OverheatCoolWt
0xB300	EmergencyStop

0xB501	CoolantLevel
0xC000	PDEInjctorCyl1
0xC100	PDEInjctorCyl2
0xC200	PDEInjctorCyl3
0xC300	PDEInjctorCyl4
0xC400	PDEInjctorCyl5
0xC500	PDEInjctorCyl6
0xC600	PDEInjctorCyl7
0xC700	PDEInjctorCyl8
0xE200	OverheatProt
0xE600	CoordEmergStop

Scania S6 Allspeed

Fault Code (SPN)	Text				
0x1000	Overspeed	0x3300	CAN msg not ok	0xB501	CoolantLevel
0x1100	EngSpdSensor1	0x3403	CAN version	0xC000	PDEInjctorCyl1
0x1200	EngSpdSensor2	0x4300	HWWatchdog	0xC100	PDEInjctorCyl2
0x2000	WtrTempSensor	0x6200	FanActuator	0xC200	PDEInjctorCyl3
0x2100	ChrgAirTmpSens	0x6400	WasteGateAct	0xC300	PDEInjctorCyl4
0x2200	ChrgAirPrsSens	0x6600	StarterActuatr	0xC400	PDEInjctorCyl5
0x2300	OilTempSensor	0x6605	Starter Motor	0xC500	PDEInjctorCyl6
0x2400	OilPressSensor	0x6702	AlternatorChrg	0xC600	PDEInjctorCyl7
0x2600	SensorSupply1	0x6A00	ExhaustBrkAct	0xC700	PDEInjctorCyl8
0x2700	SensorSupply2	0xB000	OilPressProt	0xE200	OverheatProt
0x2800	ExtrAnalogInp	0xB100	CoolantLevProt	0xE600	CoordEmergStop
0x3200	BatteryVoltage	0xB200	OverheatCoolWt		
		0xB300	EmergencyStop		

Scania S6 Allspeed from ver.1794335

Fault Code (SPN)	Text				
0x1000	Overspeed	0x3300	CAN msg not ok	0xB501	CoolantLevel
0x1100	EngSpdSensor1	0x3403	CAN version	0xC000	PDEInjctorCyl1
0x1200	EngSpdSensor2	0x4300	HWWatchdog	0xC100	PDEInjctorCyl2
0x2000	WtrTempSensor	0x6200	FanActuator	0xC200	PDEInjctorCyl3
0x2100	ChrgAirTmpSens	0x6400	WasteGateAct	0xC300	PDEInjctorCyl4
0x2200	ChrgAirPrsSens	0x6600	StarterActuatr	0xC400	PDEInjctorCyl5
0x2300	OilTempSensor	0x6605	Starter Motor	0xC500	PDEInjctorCyl6
0x2400	OilPressSensor	0x6702	AlternatorChrg	0xC600	PDEInjctorCyl7
0x2600	SensorSupply1	0x6A00	ExhaustBrkAct	0xC700	PDEInjctorCyl8
0x2700	SensorSupply2	0xB000	OilPressProt	0xE200	OverheatProt
0x2800	ExtrAnalogInp	0xB100	CoolantLevProt	0xE600	CoordEmergStop
0x3200	BatteryVoltage	0xB200	OverheatCoolWt		
		0xB300	EmergencyStop		

Scania S8 Singlespeed

Fault Code (SPN)	Text				
0x1000	Overspeed	0xC000	PDEInjectorCyl1	636	Crank Sensor
0x1100	EngSpdSensor1	0xC100	PDEInjectorCyl2	651	InjectorCyl#1
0x1200	EngSpdSensor2	0xC200	PDEInjectorCyl3	652	InjectorCyl#2
0x2000	WtrTempSensor	0xC300	PDEInjectorCyl4	653	InjectorCyl#3
0x2100	ChrgAirTmpSens	0xC400	PDEInjectorCyl5	654	InjectorCyl#4
0x2200	ChrgAirPrsSens	0xC500	PDEInjectorCyl6	655	InjectorCyl#5
0x2300	OilTempSensor	0xC600	PDEInjectorCyl7	656	InjectorCyl#6
0x2400	OilPressSensor	0xC700	PDEInjectorCyl8	657	InjectorCyl#7
0x2600	SensorSupply1	0xE200	OverheatProt	658	InjectorCyl#8
0x2700	SensorSupply2	0xE600	CoordEmergStop	677	EngStartRelay
0x2800	ExtrAnalogInp	27	EGRValvePos	696	Power Take Off
0x3200	BatteryVoltage	51	ThrottlePos	898	RequestedSpeed
0x3300	CAN msg not ok	70	Parking Brake	986	Fan Actuator
0x3403	CAN version	100	EngOil Press	1111	ESD Override
0x4300	HWWatchdog	102	Boost Press	1188	WastegateOut
0x6200	FanActuator	105	Intake Temp	1624	Speed Signal
0x6400	WasteGateAct	110	EngCool Temp	1632	EngTorqueLimit
0x6600	StarterActuatr	111	Coolant Level	2797	Fault in TPU
0x6605	Starter Motor	132	MassFlowSensor	3353	Generator 1
0x6702	AlternatorChrg	168	BatteryVoltage	3354	Generator 2
0x6A00	ExhaustBrkAct	175	EngOil Temp	3509	SensorSupply1
0xB000	OilPressProt	190	EngineSpeed	3510	SensorSupply2
0xB100	CoolantLevProt	521	Brake Pedal	3585	CoordinatorESD
0xB200	OverheatCoolWt	558	AP Idle	4000	Exhaust Brake
0xB300	EmergencyStop	559	AP Kickdown		
0xB501	CoolantLevel	598	ConvCD		
		599	Cruise Control		

Scania S8 Singlespeed

Fault Code (SPN)	Text				
0x1000	Overspeed	0xC000	PDEInjectorCyl1	636	Crank Sensor
0x1100	EngSpdSensor1	0xC100	PDEInjectorCyl2	651	InjectorCyl#1
0x1200	EngSpdSensor2	0xC200	PDEInjectorCyl3	652	InjectorCyl#2
0x2000	WtrTempSensor	0xC300	PDEInjectorCyl4	653	InjectorCyl#3
0x2100	ChrgAirTmpSens	0xC400	PDEInjectorCyl5	654	InjectorCyl#4
0x2200	ChrgAirPrsSens	0xC500	PDEInjectorCyl6	655	InjectorCyl#5
0x2300	OilTempSensor	0xC600	PDEInjectorCyl7	656	InjectorCyl#6
0x2400	OilPressSensor	0xC700	PDEInjectorCyl8	657	InjectorCyl#7
0x2600	SensorSupply1	0xE200	OverheatProt	658	InjectorCyl#8
0x2700	SensorSupply2	0xE600	CoordEmergStop	677	EngStartRelay
0x2800	ExtrAnalogInp	27	EGRValvePos	696	Power Take Off
0x3200	BatteryVoltage	51	ThrottlePos	898	RequestedSpeed
0x3300	CAN msg not ok	70	Parking Brake	986	Fan Actuator
0x3403	CAN version	100	EngOil Press	1111	ESD Override
0x4300	HWWatchdog	102	Boost Press	1188	WastegateOut
0x6200	FanActuator	105	Intake Temp	1624	Speed Signal
0x6400	WasteGateAct	110	EngCool Temp	1632	EngTorqueLimit
0x6600	StarterActuatr	111	Coolant Level	2797	Fault in TPU
0x6605	Starter Motor	132	MassFlowSensor	3353	Generator 1
0x6702	AlternatorChrg	168	BatteryVoltage	3354	Generator 2
0x6A00	ExhaustBrkAct	175	EngOil Temp	3509	SensorSupply1
0xB000	OilPressProt	190	EngineSpeed	3510	SensorSupply2
0xB100	CoolantLevProt	521	Brake Pedal	3585	CoordinatorESD
0xB200	OverheatCoolWt	558	AP Idle	4000	Exhaust Brake
0xB300	EmergencyStop	559	AP Kickdown		
0xB501	CoolantLevel	598	ConvCD		
		599	Cruise Control		

Sisu EEM2/EEM3 Gen-set

Fault Code (SPN)	Text				
51	ThrottlePos	651	InjectorCyl#1	9081	CamSpeedSensor
91	AccelPedalPos	652	InjectorCyl#2	9082	CamSpeedSensor
94	FuelDelPress	653	InjectorCyl#3	9083	CamSpeedSensor
97	WaterInFuelInd	654	InjectorCyl#4	9090	EngineSpeedErr
98	EngineOilLevel	655	InjectorCyl#5	9107	InvalidECUAddr
100	EngOil Press	656	InjectorCyl#6	9131	SolenoidValve1
101	CrankcasePress	677	EngStartRelay	9132	SolenoidValve2
102	Boost Press	898	RequestedSpeed	9133	SolenoidValve3
105	Intake Temp	970	AuxEngSdSwitch	9134	SolenoidValve4
106	AirInletPress	971	EngDerateSwch	9135	SolenoidValve5
107	AirFiltDifPres	1109	EngSdApproach	9136	SolenoidValve6
108	BarometricPres	1110	Engine Sd	9140	Throttle2Sens
109	Coolant Press	1136	ECU Temp	9141	Throttle3Sens
110	EngCool Temp	1485	ECU MainRelay	9150	Rail Pressure
111	Coolant Level	9006	VehicleCANoff	9151	PressReliefVlv
153	CrankcasePress	9008	IDmoduleCANoff	9152	FuelFiltrPress
157	FuelRail Press	9010	AmbientPress	9153	FuelFiltrPress
168	BatteryVoltage	9021	5Vdc Supply 1	9174	MPROP
172	AirInlet Temp	9022	5Vdc Supply 2	9230	EngSpecMismtch
174	Fuel Temp	9023	5Vdc Supply 3	9231	EngSNMismatch
175	EngOil Temp	9024	WaterInFuelSup	9233	IDM-NotPresent
189	RatedEngSpeed	9025	SelfTestWtchdg	9234	IDM-NotComptbl
190	EngineSpeed	9026	SelfTestVoltHi	9235	ID Module
231	J1939 Datalink	9027	SelfTestVoltLo	9236	IDM-MemDefect
237	VIN	9030	MainRelay1Shrt	9237	IDM-Watchdog
515	EngDesOpSpeed	9031	MainRelay2Shrt	9238	IDM-Brownout
620	5V SupplyFail	9032	MainRelay3Shrt	9239	EngSpecMissing
626	PrehActuator	9033	MainRelay	9240	EngSNMissing
628	EMSProgFailure	9034	MainRelayDfct	9241	IDM-NotPresent
629	EEPROMChecksum	9035	NormalRecovery	9242	GeneratedByPTE
630	CalibrMemFail	9036	Full restart	9243	MaxECUByPTE
636	Crank Sensor	9070	CrankSpeedSens	9305	BadDIConfig
637	TimingSensor	9071	CrankSpeedSens	9306	PTO InputError
639	J1939 CAN Bus	9072	CrankSpeedSens	9310	ExternalFlt1
		9080	CamSpeedSensor	9311	ExternalFlt2

9312	TorqCtrlInput
------	---------------

Sisu EEM2/EEM3 Propulsion

Fault Code (SPN)	Text				
51	ThrottlePos	651	InjectorCyl#1	9081	CamSpeedSensor
91	AccelPedalPos	652	InjectorCyl#2	9082	CamSpeedSensor
94	FuelDelPress	653	InjectorCyl#3	9083	CamSpeedSensor
97	WaterInFuelInd	654	InjectorCyl#4	9090	EngineSpeedErr
98	EngineOilLevel	655	InjectorCyl#5	9107	InvalidECUAddr
100	EngOil Press	656	InjectorCyl#6	9131	SolenoidValve1
101	CrankcasePress	677	EngStartRelay	9132	SolenoidValve2
102	Boost Press	898	RequestedSpeed	9133	SolenoidValve3
105	Intake Temp	970	AuxEngSdSwitch	9134	SolenoidValve4
106	AirInletPress	971	EngDerateSwthc	9135	SolenoidValve5
107	AirFiltDifPres	1109	EngSdApproach	9136	SolenoidValve6
108	BarometricPres	1110	Engine Sd	9140	Throttle2Sens
109	Coolant Press	1136	ECU Temp	9141	Throttle3Sens
110	EngCool Temp	1485	ECU MainRelay	9150	Rail Pressure
111	Coolant Level	9006	VehicleCANoff	9151	PressReliefVlv
153	CrankcasePress	9008	IDmoduleCANoff	9152	FuelFiltrPress
157	FuelRail Press	9010	AmbientPress	9153	FuelFiltrPress
168	BatteryVoltage	9021	5Vdc Supply 1	9174	MPROP
172	AirInlet Temp	9022	5Vdc Supply 2	9230	EngSpecMismtch
174	Fuel Temp	9023	5Vdc Supply 3	9231	EngSNMismatch
175	EngOil Temp	9024	WaterInFuelSup	9233	IDM-NotPresent
189	RatedEngSpeed	9025	SelfTestWtchdg	9234	IDM-NotComptbl
190	EngineSpeed	9026	SelfTestVoltHi	9235	ID Module
231	J1939 Datalink	9027	SelfTestVoltLo	9236	IDM-MemDefect
237	VIN	9030	MainRelay1Shrt	9237	IDM-Watchdog
515	EngDesOpSpeed	9031	MainRelay2Shrt	9238	IDM-Brownout
620	5V SupplyFail	9032	MainRelay3Shrt	9239	EngSpecMissing
626	PrehActuator	9033	MainRelay	9240	EngSNMissing
628	EMSProgFailure	9034	MainRelayDfct	9241	IDM-NotPresent
629	EEPROMChecksum	9035	NormalRecovery	9242	GeneratedByPTE
630	CalibrMemFail	9036	Full restart	9243	MaxECUByPTE
636	Crank Sensor	9070	CrankSpeedSens	9305	BadDIConfig
637	TimingSensor	9071	CrankSpeedSens	9306	PTO InputError
639	J1939 CAN Bus	9072	CrankSpeedSens	9310	ExternalFlt1
		9080	CamSpeedSensor	9311	ExternalFlt2

9312	TorqCtrlInput
------	---------------

VM Industrial

Fault Code (SPN)	Text				
27	EGRValvePos	190	EngineSpeed	658	InjectorCyl#8
51	ThrottlePos	228	MOfsCaScrS	675	GlwCDLmp
84	VSSCD1	231	J1939 Datalink	676	GlwCD
91	AccelPedalPos	237	VIN	677	EngStartRelay
94	FuelDelPress	515	EngDesOpSpeed	723	EngMCaS1
97	WaterInFuelInd	597	BrakeSwitch	767	GearbxRgear
98	EngineOilLevel	598	ConvCD	835	OPSCDLmp
100	EngOil Press	604	GearCDPNLmpOut	859	FIFCDHtg
101	CrankcasePress	620	5V SupplyFail	898	RequestedSpeed
102	Boost Press	624	DiagnosticLamp	970	AuxEngSdSwitch
105	Intake Temp	625	FMTCTNonMonoMap	971	EngDerateSwtch
106	AirInletPress	626	PrehActuator	976	FrmMngTOPTO
107	AirFiltDifPres	627	HWEMonUMinSupp	977	FanCD
108	BarometricPres	628	EMSProgFailure	979	MSSCD
109	Coolant Press	629	EEPROMChecksum	1079	SSpMon
110	EngCool Temp	630	CalibrMemFail	1109	EngSdApproach
111	Coolant Level	633	PCVCD	1110	Engine Sd
132	AFSCD	634	TVACD	1137	ExhaustTemp 1
153	CrankcasePress	636	Crank Sensor	1138	ExhaustTemp 2
157	RailMeUn	637	TimingSensor	1213	MILcontrol
158	BattPotential	639	J1939 CAN Bus	1347	MeUnCD
164	RailPressure	651	InjectorCyl#1	1351	ACCDCmpr
168	BatteryVoltage	652	InjectorCyl#2	1484	Severe Fault
172	AirInlet Temp	653	InjectorCyl#3	1485	ECU MainRelay
174	Fuel Temp	654	InjectorCyl#4	1680	AOHtCDHt1
175	EngOil Temp	655	InjectorCyl#5		
189	RatedEngSpeed	656	InjectorCyl#6		
		657	InjectorCyl#7		

VM Marine

Fault Code (SPN)	Text				
51	ThrottlePos	172	AirInlet Temp	652	InjectorCyl#2
91	AccelPedalPos	174	Fuel Temp	653	InjectorCyl#3
94	FuelDelPress	175	EngOil Temp	654	InjectorCyl#4
97	WaterInFuelInd	189	RatedEngSpeed	655	InjectorCyl#5
98	EngineOilLevel	190	EngineSpeed	656	InjectorCyl#6
100	EngOil Press	228	MOFsCaScrS	657	InjectorCyl#7
101	CrankcasePress	231	J1939 Datalink	658	InjectorCyl#8
102	Boost Press	237	VIN	677	EngStartRelay
105	Intake Temp	515	EngDesOpSpeed	679	RailPCV5
106	AirInletPress	620	5V SupplyFail	723	EngMCA1
107	AirFiltDifPres	624	DiagnosticLamp	835	OPSCDLmp
108	BarometricPres	626	PrehActuator	898	RequestedSpeed
109	Coolant Press	627	HWEMonUMin	970	AuxEngSdSwitch
110	EngCool Temp	628	EMSProgFailure	971	EngDerateSwth
111	Coolant Level	629	EEPROMChecksum	976	FrmMngTOPTO
132	AFSCD	630	CalibrMemFail	1079	SSpMon
153	CrankcasePress	633	PCVCD	1109	EngSdApproach
157	RailMeUn	636	Crank Sensor	1110	Engine Sd
158	BattPotential	637	TimingSensor	1347	MeUnCD
164	RailPressure	639	J1939 CAN Bus	1485	ECU MainRelay
168	BatteryVoltage	641	PCRGvnrDvt	1680	AOHtCDHt1
		651	InjectorCyl#1		

Volvo EDC3 (EMS1) or EMS2 (singlespeed engines only)

Fault Code (SPN)	Text				
20	EngCool Press	652	InjectorCyl#2	0x000AD	Exhaust Temp
91	AccelPedalPos	653	InjectorCyl#3	0x000AE	Fuel Temp
94	FuelDelPress	654	InjectorCyl#4	0x000AF	EngineOil Temp
97	WaterInFuelInd	655	InjectorCyl#5	0x200E7	SAE J1939 fail
98	EngineOilLevel	656	InjectorCyl#6	0x200E8	5V DC Fail
100	EngOil Press	677	EngStartRelay	0x200F0	Prg MemoryFail
101	CrankcasePress	679	InjPressRegul	0x200F5	EMS HW Failure
102	Boost Press	729	PreheatSensor	0x200FA	SAE J1587 fail
105	Intake Temp	975	Fan Speed	0x200FD	CalibrMem fail
106	AirInletPress	1080	5V Sensor 2	0x200FE	Controller#1
107	AirFiltDifPres	1184	Exhaust Temp	0x30001	Injector 1
108	BarometricPres	1188	WastegateOut	0x30002	Injector 2
109	Coolant Press	1239	RailPresSystem	0x30003	Injector 3
110	EngCool Temp	1485	ECU MainRelay	0x30004	Injector 4
111	Coolant Level	1675	EngStartRelay	0x30005	Injector 5
153	CrankcasePress	2791	EGR Status	0x30006	Injector 6
158	BattPotential	520192	PistonCoolSw	0x30015	Pickup Cam
164	RailPressure	520193	SeaWaterPress	0x30016	Pickup Crank
172	AirInlet Temp	520194	Starter input	0x30020	WastegateOut
173	Exhaust Temp	520195	Stop input	0x30021	CoolingFan
175	EngOil Temp	0x00014	EngCool Press	0x40003	Starter Output
190	EngineSpeed	0x0001A	Fan Speed	0x40006	ExtSTOP Active
231	J1939 Datalink	0x0005E	Fuel Press	0x40008	Piston CoolPr
608	J1587 Datalink	0x00061	Water in fuel	0x40062	J1587 Sync
620	5V SupplyFail	0x00062	Oil Level	0x40084	J1587 Throttl
626	PrehActuator	0x00063	Oil Diff Press	0x4010B	SeaWater Press
628	EMSProgFailure	0x00064	EngOil Press	0x600C9	J1939 Datalink
629	EEPROMChecksum	0x00066	Boost Press	0x600D8	J1939 Bus
630	CalibrMemFail	0x00069	Intake Temp	0x73C01	Primary Batt
636	Pickup Cam	0x0006A	AirInletPress	0x73C02	Secondary Batt
637	Pickup Crank	0x0006C	Barom Press	0x73C03	15 supply
639	J1939 CAN Bus	0x0006E	EngCool Temp	0x73C04	30 supply
647	CoolingFan	0x0006F	Coolant Level	0x73C05	EMS supply
651	InjectorCyl#1	0x00099	CrankcasePress	0x73C06	Extra supply
		0x0009E	BattPotential		

Volvo EDC3 (EMS1) or EMS2 (allspeed engines only)

Fault Code (SPN)	Text				
20	EngCool Press	653	InjectorCyl#3	0x00CE	INJECTOR 6
51	ThrottlePos	654	InjectorCyl#4	0x0694	SuperChargCtrl
94	FuelDelPress	655	InjectorCyl#5	0x00014	EngCool Press
97	WaterInFuelInd	656	InjectorCyl#6	0x0001A	Fan Speed
98	EngineOilLevel	677	EngStartRelay	0x0005E	Fuel Press
100	EngOil Press	679	InjPressRegul	0x00061	Water in fuel
101	CrankcasePress	729	PreheatSensor	0x00062	Oil Level
102	Boost Press	975	Fan Speed	0x00063	Oil Diff Press
105	Intake Temp	1080	5V Sensor 2	0x00064	EngOil Press
106	AirInletPress	1184	Exhaust Temp	0x00066	Boost Press
107	AirFiltDifPres	1188	WastegateOut	0x00069	Intake Temp
108	BarometricPres	1239	RailPresSystem	0x0006A	AirInletPress
109	Coolant Press	1485	ECU MainRelay	0x0006C	Barom Press
110	EngCool Temp	1675	EngStartRelay	0x0006E	EngCool Temp
111	Coolant Level	2791	EGR Status	0x0006F	Coolant Level
153	CrankcasePress	520192	PistonCoolSw	0x00099	CrankcasePress
158	BattPotential	520193	SeaWaterPress	0x0009E	BattPotential
164	RailPressure	520194	Starter input	0x000AD	Exhaust Temp
172	AirInlet Temp	520195	Stop input	0x000AE	Fuel Temp
173	Exhaust Temp	0x0073	Coolant Temp	0x000AF	EngineOil Temp
175	EngOil Temp	0x00B4	Fuel Temp	0x200E7	SAE J1939 fail
190	EngineSpeed	0x00EF	AirInletTemp	0x200E8	5V DC Fail
231	J1939 Datalink	0x00EB	AirInletPress	0x200F0	Prg MemoryFail
608	J1587 Datalink	0x0069	BarometrPress	0x200F5	EMS HW Failure
620	5V SupplyFail	0x00C3	EngOilTemp	0x200FA	SAE J1587 fail
626	PrehActuator	0x0208	EngOilPress	0x200FD	CalibrMem fail
628	EMSProgFailure	0x0230	BatteryVoltage	0x200FE	Controller#1
629	EEPROMChecksum	0x00BE	FuelRailPress	0x30001	Injector 1
630	CalibrMemFail	0x0709	WaterInFuel	0x30002	Injector 2
636	Pickup Cam	0x014F	PickupFlyWheel	0x30003	Injector 3
637	Pickup Crank	0x0154	PICKUP CAM	0x30004	Injector 4
639	J1939 CAN Bus	0x00C9	INJECTOR 1	0x30005	Injector 5
647	CoolingFan	0x00CA	INJECTOR 2	0x30006	Injector 6
651	InjectorCyl#1	0x00CB	INJECTOR 3	0x30015	Pickup Cam
652	InjectorCyl#2	0x00CC	INJECTOR 4	0x30016	Pickup Crank
		0x00CD	INJECTOR 5	0x30020	WastegateOut

0x30021	CoolingFan	0x40084	J1587 Throttl	0x73C02	Secondary Batt
0x40003	Starter Output	0x4010B	SeaWater Press	0x73C03	15 supply
0x40006	ExtSTOP Active	0x600C9	J1939 Datalink	0x73C04	30 supply
0x40008	Piston CoolPr	0x600D8	J1939 Bus	0x73C05	EMS supply
0x40062	J1587 Sync	0x73C01	Primary Batt	0x73C06	Extra supply

Waukesha ESM

Fault Code (SPN)	Text				
211	OilPressSenFlt	311	Cyl16-IgnitFlt	454	BattVoltOut
212	IMAP-LB SenFlt	312	EngOverload	455	ECUTempHigh
213	OilTempSenFlt	313	IgnitionFault	523	AlternatorFlt
214	IMAP-RB SenFlt	314	RemoteRPMFlt	541	UserDI Changed
221	IMAT SenFlt	315	HighIMAT	542	StartWithRPM>0
222	MainFuelValve	322	CalibrateAct	552	EngBeingDriven
223	OilPressLow	323	StuckThrotLink	555	InternalFault
224	Knock	332	IgnitCommFlt	65748	CrankMagPickup
225	KnockSenFlt	333	CoolTempHigh	65750	CamMagPickup
231	Cyl1-IgnitFlt	335	OilTempHigh	65757	EngOverspeed
232	Cyl2-IgnitFlt	353	IgnitPwrHigh	65758	CustomerSd
233	Cyl3-IgnitFlt	341	StepperLeftFlt	65759	OilPressLow
234	Cyl4-IgnitFlt	342	SteperRightFlt	65760	Knock
235	Cyl5-IgnitFlt	343	LBOxygSensFlt	65767	OverCrank
241	Cyl6-IgnitFlt	344	ExhTempHighLB	65768	EngineStall
242	Cyl7-IgnitFlt	345	RBOxygSensFlt	65787	CustOverspeed
243	Cyl8-IgnitFlt	351	ExhTempHighRB	65848	EngOverload
244	Cyl9-IgnitFlt	413	LeanLimitLeft	65849	Lockout/Ignit
245	Cyl10-IgnitFlt	415	RichLimitLeft	65851	HighIMAT
251	Cyl11-IgnitFlt	422	CoolTempSenFlt	65869	CoolTempHigh
252	Cyl12-IgnitFlt	423	LeanLimitRight	65871	KnockAbsThres
253	Cyl13-IgnitFlt	425	RichLimitRight	66087	Update Err/Flt
254	Cyl14-IgnitFlt	432	StepperCommFlt	66089	SecurityViolat
255	Cyl15-IgnitFlt	441	ThrottleActFlt	66091	InternalFault
		451	RemoteRPMOver		

Yanmar TNV

Fault Code (SPN)	Text				
51	ThrottlePos	153	CrankcasePress	636	Crank Sensor
91	AccelPedalPos	158	BattPotential	637	TimingSensor
94	FuelDelPress	168	BatteryVoltage	639	J1939 CAN Bus
97	WaterInFuelInd	172	AirInlet Temp	651	InjectorCyl#1
98	EngineOilLevel	174	Fuel Temp	652	InjectorCyl#2
100	EngOil Press	175	EngOil Temp	653	InjectorCyl#3
101	CrankcasePress	189	RatedEngSpeed	654	InjectorCyl#4
102	Boost Press	190	EngineSpeed	655	InjectorCyl#5
105	Intake Temp	231	J1939 Datalink	656	InjectorCyl#6
106	AirInletPress	237	VIN	677	EngStartRelay
107	AirFiltDifPres	515	EngDesOpSpeed	898	RequestedSpeed
108	BarometricPres	620	5V SupplyFail	970	AuxEngSdSwitch
109	Coolant Press	626	PrehActuator	971	EngDerateSwth
110	EngCool Temp	628	EMSProgFailure	1109	EngSdApproach
111	Coolant Level	629	EEPROMChecksum	1110	Engine Sd
		630	CalibrMemFail	1485	ECU MainRelay

Standard J1939 engine

Fault (SPN)	Code	Text
51		ThrottlePos
91		AccelPedalPos
94		FuelDelPress
97		WaterInFuelInd
98		EngineOilLevel
100		EngOil Press
101		CrankcasePress
102		Boost Press
105		Intake Temp
106		AirInletPress
107		AirFiltDifPres
108		BarometricPres
109		Coolant Press
110		EngCool Temp
111		Coolant Level

153	CrankcasePress
158	BattPotential
168	BatteryVoltage
172	AirInlet Temp
174	Fuel Temp
175	EngOil Temp
189	RatedEngSpeed
190	EngineSpeed
231	J1939 Datalink
237	VIN
515	EngDesOpSpeed
620	5V SupplyFail
626	PrehActuator
628	EMSProgFailure
629	EEPROMChecksum
630	CalibrMemFail

636	Crank Sensor
637	TimingSensor
639	J1939 CAN Bus
651	InjectorCyl#1
652	InjectorCyl#2
653	InjectorCyl#3
654	InjectorCyl#4
655	InjectorCyl#5
656	InjectorCyl#6
677	EngStartRelay
898	RequestedSpeed
970	AuxEngSdSwitch
971	EngDerateSwtch
1109	EngSdApproach
1110	Engine Sd
1485	ECU MainRelay

Notes